

Your Excellency :

We are honored by your purchase of GSK980TDi turning machine CNC system

The user manual introduces the programming, the operation, the installation and the connection of GSK980TTC turning machine CNC system in details.

To ensure safe and effective running, please read this manual carefully before installation and operation.

# WARNING

Accident may occur by improper connection and operation! This system can only be operated by authorized and qualified personnel.

## **Special caution:**

The power supply fixed on/in the cabinet is exclusively used for the CNC system

It can't be applied to other purposes, or else it may cause serious danger!

# CAUTIONS

#### Delivery and storage

- Packing box over 6 layers in pile is unallowed.
- Never climb the packing box, stand on it or place heavy objects on it.
- Do not move or drag the products by the cables connected to it.
- Forbid collision or scratch to the panel and display screen.
- Avoid dampness, insolation and drenching.

#### Open-package inspection

- Confirm that the products are the required ones.
- Check whether the products are damaged in transit.
- Confirm that the parts in packing box are in accordance with the packing list.
- Contact us in time if any inconsistence, shortage or damage is found.

#### Connection

- Only qualified personnel can connect the system or check the connection.
- The system must be earthed, and the earth resistance must be less than 0.1Ω.
  The earth wire cannot be replaced by zero wire.
- The connection must be correct and firm to avoid any fault or unexpected consequence.
- Connect with surge diode in the specified direction to avoid damage to the system.
- Switch off power supply before plugging out or opening electric cabinet.

#### Troubleshooting

- Switch off power supply before troubleshooting or changing components.
- Check the fault when short circuit or overload occurs. Restart can only be done after troubleshooting.
- Frequent switching on/off of the power is forbidden, and the interval time should be at least 1 min.

## Announcement

 This manual describes various possibilities as much as possible. However, operations allowable or unallowable cannot be explained one by one due to so many possibilities that may involve with, so the contents that are not specially stated in this manual shall be considered as unallowable.

## Warning !

• Before installing, connecting, programming and operating, please carefully read the product user manual and the manual from the machine tool manufacturer and strictly operate accordance with the regulations in the manual; otherwise, the product or the machine tool may be damaged, the workpiece may get rejected, even the personal injury may occur.

## Caution !

- Functions, technical indexes (such as precision and speed) described in this user manual are only for this system. Actual function deployment and technical performance of the machine tool are designed by the machine tool manufacturer, so function configuration and technical indexes are subject to the user manual from the machine tool manufacturer.
- The system is with the standard machine operation panel, but the function of each button on the machine panel is defined by the PLC program (ladder diagram).
   Please pay attention to that the function of the buttons in the manual is described based on the standard PLC programs!
- Refer to the user manual from the machine tool manufacturer for function and meaning of each button on the machine panel.

All specifications and designs herein are subject to change without notice.

# Section I Programming

Introduce the technical specification, the product introduction, the command code and the program format.

## Section II Operation

Introduce the operation of CNC system of GSK980TDi turning machine.

Section III Installation and Connection

Introduce the installation, connection and setting method of CNC system of GSK980TDi turning machine.

# Appendix

Introduce the overall installation dimensions of CNC system of GSK980TDi turning machine and those of its accessories and the alarm information list, etc.

## SAFETY RESPONSIBILITY

#### Manufacturer's Responsibility

- —Be responsible for the danger which should be eliminated and/or controlled on design and configuration of the provided CNC systems and accessories.
- ——Be responsible for the safety of the provided CNC systems and accessories.
- —Be responsible for the provided message and advice for the users.

#### **User's Responsibility**

- ——Be responsible for being familiar with and mastering the safety operation procedures through training with the safety operation of the CNC system.
- ——Be responsible for the dangers caused by adding, changing or altering the original CNC systems and the accessories.
- ——Be responsible for the dangers caused by failing to observe the provisions in the manual for operation, adjustment, maintenance, installation and storage.

#### This manual is kept by the end user.



VI

## CONTENTS

I Program		1
CHAPTER	1 PROGRAMMING	3
1.1 GS	K980TDi Introduction	3
1.1.1	Product Introduction	3
1.1.2	Technical Specification	4
1.1.3	Environment & Conditions	7
1.1.4	Power Supply	7
1.1.5	Guard	7
1.2 CN	C System of Machine Tools & CNC Machine Tools	7
13 Pro	aramming Fundamentals	a
1.0 110	Coordinates Definition	0 Q
122	Machina Coordinate System Machina Zara & Machina Potorance Doint	10
1.3.2	Wachine Coordinate System, Wachine Zero & Wachine Reference Folin	10
1.3.3	Internalation Experien	10
1.3.4		11
1.3.5	Absolute Programming & Incremental Programming	12
1.3.6	Diameter Programming & Radius Programming	13
1.4 Stru	acture of an NC Program	13
1.4.1	General Structure of Program	14
1.4.2	Main Program & Subprogram	17
1.5 Pro	gram Run	18
1.5.1	Sequence of Program Run	18
1.5.2	Execution Sequence of Word	19
1.6 Bas	sic Axis Incremental System	19
1.6.1	Incremental system speed of basic axis	20
1.6.2	Incremental System Unit of Basic Axis	20
163	Incremental System Data Range of Basic Axis	20
164	Incremental System Data Range & Unit of Basic Axis	21
1.6.5	Program Address Value   Init & Range of Incremental System of Basic Axis	21
17 Ad	ditional Avis Incremental System	20
1.7 //00	Additional Avis of Current Incremental System	24
1.7.1	Additional Axis of US A Incremental System	24 24
		24
	Z MSTECOMMAND	20
2.1 IVI (		25
2.1.1	End of Program MU2	25
2.1.2	End of Program run M30	25
2.1.3	Subprogram Call M98	26
2.1.4	Return From Subprogram M99	26
2.1.5	Macro Program Call M9000~M9999	27
2.1.6	M commands Defined by Standard PLC Ladder Diagram	27
2.1.7	Program Stop M00	28
2.1.8	Program Optional Stop M01	29
2.1.9	Spindle CW. CCW & Stop Control M03, M04, M05	29
2 1 10	Cooling Control M08 M09	29
2 1 11	Tailstock Control M10 M11	29
2.1.11	Chuck Control M12 M13	29
2.1.12	Spindle Position/Speed Control Switch M14, M15	30
2.1.13	Spindle Clampod/Poloased M20, M21	30 ∩2
2.1.14	The 2 <sup>nd</sup> Spindle Desition/Speed Switch M24, M25	00
2.1.15	Lubrighting Control M22, M22	30
2.1.16	Lubricaling Control M32, M33	30
2.1.1/	Spindle Automatic Gear Unange M41, M42, M43, M44	30
2.1.18	Spindle 8-point Orientation M50~M58	31
2.1.19	The 2 <sup>III</sup> Spindle Rotation CCW/CW, Stop M63, M64, M65	31
2.2 Spi		
2.2 00	ndle Function	31
2.2.1	ndle Function Spindle Speed Switching Value Control	31 31

2.2.3	Spindle Speed Series Control	32
2.2.4	Constant Surface Speed Control G96, Constant Rotational Speed Control G97	33
2.2.5	Spindle Override	35
2.2.6	Multiple Spindle Control Function	35
2.2.7	Cs Contour Control Funciton	37
2.2.8	Spindle Positioning Function	37
2.3 Too	ol Function	37
2.3.1	Tool Control	37
2.3.2	Tool Life Management	41
CHAPTER	3 G COMMANDS	51
3.1 Co	mmands	51
3.1.1	Modal, One-Shot & Initial Mode	53
3.1.2	Omitting Words	53
3.1.3	Related Definitions	55
3.2 Ra	pid Traverse Movement G00	55
3.3 Lin	ear Interpolation G01	56
3.4 Cir	cular Interpolation G02, G03	57
3.5 IN	ree-point Circular Interpolation G05, G05.1	60
3.6 EIII	pse Interpolation G6.2, G6.3	62
3.7 Pa	rabola Interpolation G7.2, G7.3	60
3.8 Pla	line Selection G17 $\sim$ G19	70
3.9 Po	lar Coordinate Interpolation G12.1, G13.1	/1
3.10 C	ylindrical interpolation G7.1	74
3.11 C	namiering Function	79
3.11.1	Linear Chamfering	79
3.11.Z	Special Cases	10 00
212 5	Special Cases	03 03
3.12 L	unction of Directly Inputting Graphic Dimension	-04 88
314		
3.14 D	achine Zero Function	03 03
3 15 1	Machine 1 <sup>st</sup> Reference Point G28	90
3 15 2	Machine $2^{nd}$ $3^{rd}$ $4^{th}$ Reference Point G30	
3.16 S	kip Interpolation G31	
3.16.1	Following Block Execution After Skip	93
3.16.2	Signals Relevant to G31	94
3.16.3	Parameters Relevant to G31: Refer to III INSTALLATION & CONNECTION, Section	n
3.2.15	, )	94
3.17 A	utomatic Tool Offset G36, G37	94
3.17.1	Signals Relevant to G36, G37 Automatic Tool Offset:	94
3.17.2	Parameters Relevant to G36, G37: Refer to INSTALLATION, Section 3.2.16	95
3.17.3	G36, G37 Automatic Tool Offset Command Use	95
3.18 W	/orkpiece Coordinate System G50	96
3.19 Lo	ocal Coordinate System	97
3.20 W	/orkpiece Coordinate System G54 $\sim$ G59	99
3.21 Fi	ixed Cycle Command	101
3.21.1	Axial Cutting Cycle G90	101
3.21.2	Radial Cutting Cycle G94	104
3.21.3	Caution of Fixed Cycle Commands	106
3.22 M	lultiple Cycle Commands	106
3.22.1	Axial Roughing Cycle G71	107
3.22.2	Radial Roughing Cycle G72	114
3.22.3	Closed Cutting Cycle G73	118
3.22.4	Finishing Cycle G70	123
3.22.5	Axial Grooving Multiple Cycle G74	124
3.22.6	Radial Grooving Multiple Cycle G/5	127
3.22.7	Drilling Cycle G83 or G87	130
3.23 T	hread Cutting Commands	133

3.23.1 Ihread Cutting with Constant Lead G32	133
3.23.2 Rigid Thread Cutting G32.1	136
3.23.3 Arc Threading Cutting Code G32.2 or G32.3	
3.23.4 Thread Cutting with Variable Lead G34	
3.23.5 Z Thread Cutting G33	
3.23.6 Rigid Tapping G84, G88	
3.23.7 Thread Cutting Cycle G92	145
3.23.8 Rigid Thread Cutting Cycle G92.1	148
3.23.9 Thread Reparation Function G92 P1 or G92.1 P1	152
3.23.10 Multiple Thread Cutting Cycle G76	154
3.23.11 Enhancement Thread Cutting Cycle G78	157
3.24 Constant Surface Speed Control G96, Constant Rotational Speed Control G97	′163
3.25 Feedrate per Minute G98, Feedrate per Rev G99	163
3.26. Additional Axis Function	165
3.26.1 Additional Axis Start	165
3.26.2 Motion of Additional Axis	165
3.26.3 Additional Axis Coordinates Display	166
3.27 Macro Commands	166
3.27.1 Macro Variables	166
3.27.2 Operation & Jump Command G65	170
3.27.3 Program Example with Macro Command	174
3.28 Statement Macro Command	176
3.28.1 Arithmetic & Logic Operation	176
3.28.2 Transfer & Cycle	177
3.29 Metric/Inch Switch	179
3.30 Stored Stroke Limit 2 Detection G22 or G23	180
3.31 G Code Macro Program Call	181
3.32 Editable Parameter Read/Write G10 L52	
CHAPTER 4 TOOL NOSE RADIUS COMPENSATION (G41, G42)	
4.1 Application	187
4.1.1 Overview	
4.1.2 Imaginary Tool Nose Direction	187
4.1.3 Compensation Value Setting	191
4.1.4 Command Format	
4.1.5 Compensation Direction	
4.1.6 Notes	
4.1.7 Application	
4.2 Tool Nose Radius Compensation Offset Path	
4.2.1 Inner & Outer Side	
4.2.2 Tool Traversing when Starting Tool	
4.2.3 Tool Traversing in Offset Mode	
4.2.4 Tool Traversing in Offset Canceling Mode	
4.2.5 Tool Interference Check	
4.2.6 Commands for Canceling Compensation Vector Temporarily	
II Operation	
CHAPTER 1 OPERATION MODE AND DISPLAY INTERFACE	211
1 1 Panel Division	211
1 1 1 State Indication	212
1 1 2 Edit Keypad	212
1 1 3 Menu Display	יבי ביייביי. 213
1 1 4 Machine Panel	213 21/
1.2 Summary of Operation Mode	2⊥4 017
1.2 Display Interface	2⊥7 21♀
131 POS Interface	210 21♀
1.3.1 FUS IIITEIIAUE	0ו∠ ^^^
	∠∠U ດດດ
1.3.3 TOOL OF I SET IIILEII dUE	۲۲۲
1.3.4 ALARIVI IIIIEIIdue	∠∠4 ⊃ວ⊊
1.3.3 Setting Interface.	ZZ5
1.3.0 Parameter Interfaces	

# **CNCmakers**

1.3.7	Diagnosis Interface	229
1.3.8	Graph Interface	230
1.3.9	Ladder Interface	231
CHAPTER	2 POWER ON/OFF AND PROTECTION	235
2.1 Sys	stem Power-on	235
2.2 Svs	stem Power-off	235
2.3 Ove	ertravel Protection	236
231	Hardware Overtravel Protection	236
2.0.1 2.4 Em	ergency Operation	200
2.7 LIII		207
2.4.1		201 220
2.4.2	EOF	230
2.4.3		
2.4.4	Power-Off.	238
CHAPTER	3 MANUAL OPERATION	239
3.1 Co	ordinate Axis Move	239
3.1.1	Manual Feed	239
3.1.2	Manual Rapid Traverse	239
3.1.3	Speed Regulation	240
3.2 Oth	ner Manual Operations	241
3.2.1	Spindle CCW, CW, Stop Control	241
3.2.2	Spindle JOG	
323	Cooling Control	241
324		242
325	Chuck Control	2/2
2.2.5	Tailstook Control	
3.2.0		
3.2.7		
3.2.8	Manual Tool Change	243
3.2.9	Spindle Override	243
CHAPTER	4 MPG/STEP OPERATION	245
4.1 Ste	p Feed	245
4.1.1	Increment Selection	245
4.1.2	Moving Direction Selection	246
4.2 MP	G Feed	246
4.2.1	Increment Selection	247
4.2.2	Moving Axis & Direction Selection	247
423	MPG Feedrate	248
424	Other Operations	248
4.2.4	Explanation Items	2/10
		251
	J MDI OF LIKATION	201
5.1 BIO	ck input	
5.2 BIO	CK Execution	
5.3 Par	rameter Setting	
5.4 Dat	a Alteration	252
5.5 Oth	ner Operations	253
CHAPTER	6 PROGRAM EDIT & MANAGEMENT	255
6.1 Pro	gram Creation	255
6.1.1	Creating a Block Number	255
6.1.2	Inputting a Program	255
6.1.3	Searching a Character	257
6.1.4	Inserting a Character	
615	Deleting a Character	
616	Altering a Character	261
617	Deleting a Single Block	262
610	Conving & Disting a Block	202
0.1.0	Concelling & Recovering a Drogram	
0.1.9	Circle Command Aided Drogramming	
0.1.10	Circle Command Alded Programming	
6.1.11	Program Save	
6.1.12	Macro Program Edit	268
6.1.13	Creating & Modifying a Program Annotation	269

6.2 De	leting Programs	270
6.2.1	Deleting a Program	
6.2.2	Deleting All Programs	
6.3 Sel	ecting a Program	
6.3.1	Searching	
6.3.2	Scanning	
633	Direct Confirmation	274
64 Exe	ecuting a Program	274
6.5 Re	naming a Program	274
6.6 Co	nunning a Frogram	275
6.7 Pro	param Management	276
	unter Function	270 277
6.0 Eo	anter i ancion	
6 1 0 D	ragram Provide Eurotian	270
0.10 F	Interface Display of Dath Draviow	
0.10.1	Operation of Dath Draview	
6.10.2	Operation of Path Preview	
6.10.3		
6.10.4	Precautions	
6.11 lea		
6.12 O	ther Operations Available in Edit Mode	284
CHAPTER	7 TOOL OFFSET AND SETTING	287
7.1 Too	ol Positioning Setting	287
7.2 Tria	al Tool-setting	288
7.3 Too	ol-Setting by Machine Zero Return	289
7.4 Co	ordinates Record	292
7.5 Set	tting & Altering an Offset Value	293
7.5.1	Offset Setting	293
7.5.2	Offset Alteration	293
7.5.3	Offset Alteration in Communication Mode	294
7.5.4	Offset Values Clearing	294
755	Setting & Altering a Tool Wear	295
756	Locking & Unlocking an Offset Value	295
757	No 0 Tool Offset Moving Workpiece Coordinate System	295
76 Hi	ah Efficiency Tool-Change	296
761		296
7.0.1	Tool-Change Safety Area Setting	290 207
7.0.2	Setting Clear in Tool Change Sefety Area	
7.0.3	Ligh Efficiency Teo Change Drogramming Format	
7.0.4	High-Efficiency Tool-Change Programming Format	
7.0.5		
7.6.6		
CHAPTER	8 COORDINATE SYSTEM	
8.1 CO	ordinate System Setting	
8.1.1		
8.1.2	Measure Input	
8.1.3	Machine Tool Coordinate Record	304
8.2 Co	ordinate System Modification	304
8.3 Co	ordinate System Clearing	305
CHAPTER	9 AUTO OPERATION	307
9.1 Aut	tomatic Run	307
9.1.1	Selection of a Program Running	307
9.1.2	Start of Automatic Run	307
9.1.3	Stop of Automatic Run	
9.1.4	Automatic Run From an Arbitrary Block	
9.1.5	Adjustment of Feedrate & Rapid Rate	
9.1.6	Spindle Speed Adjustment	
9.2 Ru	nning State	
921	Single Block Execution	309
922	Dry Run	310
9.2.3	Machine Lock	
5.2.5		

9.2.4 MST Lock	311
9.2.5 Block Skip	311
9.3 MPG Trial-Cut	311
9.3.1 Switching MPG Trial-cut Mode	311
9.3.2 Command Speed in MPG Trial-Cut Mode	312
9.3.3 Notes in MPG Trial-Cut Mode	312
9.3.4 Temporarily Invalid in MPG Trial-cut Mode	313
9.4 MPG Interrupted Function	313
9.4.1 MPG Interrupted Operation	313
9.4.2 Affection of Coordinate System from MPG Interruption	314
9.4.3 MPG Interruption Value Cancel	315
9.4.4 MPG Interruption Display Page	316
9.4.5 Precaution of MPG Interruption	317
9.5 Other Operations	
CHAPTER 10 ZERO RETURN OPERATION	
10.1 Program Zero Return	319
10.1.1 Program Zero	319
10.1.2 Program Zero Return Steps	319
10.2 Machine Zero Return	
10.2.1 Machine Zero	
10.2.2 Machine Zero Return Stens	320
10.3 Other Operations in Zero Return	321
CHAPTER 11 DATA SETTING	323
11.1 Data Setting	323
11.1.1 Switch Setting	323
11.1.2 Level Setting	324
11.1.3 Parameter Operation	
11.2 Clock Setting	327
11.3 Graphic Display	327
11.4 Parameter Setting	
11 4 1 State Parameter	331
11.4.2 Data Parameter. Pitch Compensation	333
11.4.3 Classification Parameter	334
11.4.4 Often Used Parameters	335
11.5 Macro Variable Note	336
11.5.1 Macro Variable Note Page	336
11.5.2 Note List	336
11.5.3 Macro Variable Note File	337
CHAPTER 12 U OPERATION FUNCTION	339
12.1 File Management Function Introduction	339
12.2 Often Used File Operation Function Introduction	339
12.2.1 File Extension & Return	339
12.2.2 File Selection & Cancellation of File Selection	340
12.2.3 File Copy	341
12.3 Data Copy & Resume	341
12.3.1 Entering Backup/Resume Page	341
12.3.2 Backup/Resume Operation	342
12.3.3 Operation Path Selection	342
12.3.4 Format of Data Backup/Resume File	343
12.3.5 Level Explanation of Data Backup/Resume Operation	344
12.4 System Update	344
12.5 Notes	345
CHAPTER 13 COMMUNICATION	347
13.1 GSK980TDi Communication Software GSKComm	347
13.1.1 GSKComm's System (PC) Requirements	347
13.1.2 Software Interface	347
13.1.3 Receiving Files (CNC→PC)	348
13.1.4 Sending Files (CNC $\rightarrow$ PC)	349
13.1.5 Part Program Management	351

13.2 Preparatory Before Communication	
13.2.1 Communication Cable Connection	.352
13.2.2 Communication Setting Baud Rate	352
CHAPTER 14 MACHINING EXAMPLES	355
14.1 Programming	356
14.2 Program Input	357
1/21 View a Saved Program	357
14.2.2 Creating a New Program	358
14.2. Checkout a Program	250
14.3 Checkoul a Flogialli	250
14.3.1 Graphic Setting	
14.5.2 PloyIdIII Check	
14.4 IOOI-setting & Running	359
	363
CHAPTER 1 INSTALLATION LAYOUT	365
1.1 GK9801Di System Connection	365
1.1.1 GK980TDi Rear Cover Interface Layout	365
1.1.2 Interface Explanation	365
1.2 GSK980TDi Installation	366
1.2.1 GSK980TDi External Dimensions	366
1.2.2 Preconditions of Cabinet Installation	366
1.2.3 Measures Against Interference	366
CHAPTER 2 DEFINITION & CONNECTION OF INTERFACE SIGNALS	369
2.1 GSKLink Bus Interface	369
2.2 Being Connected with Spindle Encoder	369
2.2.1 Spindle Encoder Interface Definition	369
222 Signal Explanation	369
2.2.2 Spindle Encoder Interface Connection	370
2.3 MPG Connection	371
2.3 MPC Interface Definition	371
2.2.2 Signal Evaluation	
2.3.2 Signal Explaination	
2.4 Analog Spinule Interface.	3/3
2.4.1 Analog Spindle Interface Definition	3/3
	3/3
2.5 GSK9801Di / GSK9801Di-V being Connected with PC	374
2.5.1 Communication Interface Definition	374
2.5.2 Communication Interface Connection	374
2.6 Network Interface	375
2.7 Power Interface Connection	375
2.8 I/O Interface Definition	376
2.8.1 Input Signal	380
2.8.2 Output Šignal	381
2.9 I/O Function & Connection	382
2.9.1 Stroke Limit & ESP	382
2.9.2 Tool Change Control	
293 Machine Zero Return	392
294 Spindle Control	400
2.9.5 Spindle Wwitching Volume Control	403
2.9.6 Spindle Automatic Gearing Control	103
2.0.7 Spindle 9 point Orientation Eurotian	405
2.9.7 Opinitie o-point Orientation Function	100
2.3.0 Spinule US AXIS CURIOR FUNCTION	.400
2.9.0 Initial Experies Function	408
2.9.9 Kigia Tapping Function	410
	410
2.9.11 Spindle Positioning Function	411
2.9.12 External Cycle Start & Feed Hold	412
2.9.13 Cooling Control	413
2.9.14 Lubricating Control	414
2.9.15 Chuck Control	416
2.9.16 Tailstock Control	418

2.9.17 Low Pressure Detection	420
2.9.18 Hydraulic Control	420
2.9.19 Safety Door Detection	421
2.9.20 CNC Macro Variables	422
2.9.21 External Override	423
2.9.22 External MPG	423
2.9.23 Tri-color Lamp	424
2.9.24 Extended M Function	425
2.9.25 HOLD Control	425
2.9.26 Handle Interrupt	426
2.9.27 Chip-Removal Control	426
2.9.28 Working Indicator	427
2.9.29 Gear/tool Number Display	427
2.10 Commonly Use Sign of Electricity Drawing	427
CHAPTER 3 PARAMETERS	429
3.1 Parameter Description (by Sequence)	429
3.1.1 Bit Parameter	429
3.1.2 Data Parameter	439
3.1.3 PLC Parameters (Standard PLC Definition)	457
3.2 Parameter Description (by Function Sequence)	462
3.2.1 X, Z, Y, 4 <sup>11</sup> ,5 <sup>11</sup> Axis Control Logic	462
3.2.2 Acceleration & Deceleration Control	462
3.2.3 Precision Compensation	464
3.2.4 Machine Protection	466
3.2.5 Machine Zero Return	468
3.2.6 Thread Function	471
3.2.7 Spindle Control	472
3.2.8 Tool Compensation	4/6
3.2.9 Tool Life Management Function	476
3.2.10 Iool Wear Parameter	4//
3.2.11 Edit & Display	4//
3.2.12 Communication Setting	478
3.2.13 MPG Parameters	478
3.2.14 PLC AXIS CONTROL FUNCTION	479
3.2.15 Skip Function	479
3.2.16 Automatic Tool Setting Function	479
3.2.17 Input & Output Function in Metric/Inch System	480
3.2.18 Parameters Related to Arc Turning	480
3.2.19 Parameters Related to Addition	481
3.2.20 GSKLINK BUS Related to Absolute Encoder	482
CHAPTER 4 MACHINE DEBUGGING METHODS AND MODES	483
4.1 EOF & LIIIII.	403
4.1.1 ESP & LIMIL Selles-Commediation	403 102
4.1.2 Separately connection ESF & LITTIL	403 101
4.2 Drive Unit Utiliguidium	404 ۸٥۲
4.0 Geal Natio Aujustitietti	40J AQA
4.5 Mechanical (Machine) Zero Adjustment	00+ مور
4.6 Spindle Adjustment	00+ <u>۱</u> ۹۸
4.6 1 Spindle Encoder	00 <del>,</del>
4.6.2 Spindle Brake	00 <del>1</del>
4.6.3 Switch Volume Control of Spindle Speed	00 <del>-</del>
4 6 4 Analog Voltage Control of Spindle Speed	488
4 6 5 Spindle Speed Series Control	489 489
4.7 Backlash Offset	489
4.8 Tool Post Debugging	
4.9 Step/MPG Adjustment	
CHAPTER 5 DIAGNOSIS MESSAGE	
5.1 CNC Diagnosis	493

5.1.1 I/O Status & Data Diagnosis Message	493
5.1.2 CNC Motion State & Data Diagnosis Message	493
5.1.3 Diagnosis Keys	495
5.2 PLC State	495
5.2.1 X Address (Machine→PLC, Defined by Standard PLC Ladders)	496
5.2.2 Y Address (PLC→Machine, Defined by Standard PLC Ladders)	497
5.2.3 Machine Panel	499
5.2.4 F Address(CNC→PLC)	500
5.2.5 G Address (PLC→CNC)	507
5.2.6 Address A (Message Display Requiery Signal, Defined by Standard PLC Ladders)	514
CHAPTER 6 MEMORIZING PITCH ERROR COMPENSATION	517
6.1 Function Description	517
6.2 Specification	517
6.3 Parameter Setting	517
6.3.1 Pitch Compensation	517
6.3.2 Pitch Error Compensation Number	517
6.3.3 Pitch error compensation interval	518
6.3.4 Offset Value	518
6.4 Notes of Offset Setting	518
6.5 Setting Examples of Offset Parameters	518
6.5.1 Rotation Axis Pitch Error Compensation	521
IV Appendix	523
APPENDIX I GSK980TDi, GSK980TDi-V APPEARANCE DIMENSION	525
1.1 GSK980TDi Appearance Dimension	525
1.2 GSK980TDi-V Appearance Dimension	526
APPENDIX II OUTLINE DIMENSION of ACCESSIONAL PANEL	527
2.1 Outline Dimension of Accessional Panel AP01A	527
2.2 Outline Dimension of Accessional Panel AP03A	527
APPENDIX III OUTLINE DIMENSION of I/O Deconcentrator MCT01B	529
APPENDIX IV OUTLINE DIMENSION of I/O Deconcentrator MCT06R	531
APPENDIX V DELIVERY STANDARD PARAMETER	533
APPENDIX VI ALARM LIST	541

# I Programming



## CHAPTER 1 PROGRAMMING

#### 1.1 GSK980TDi Introduction

#### 1.1.1 Product Introduction

Being upgraded product of GSK980TDi, GSK980TDi CNC turning is the better choice. The updated development GSK980TDi Turning Machine CNC System made by **CNCmakers** is the new product based upon the GSK980TDi updated software/hardware, which owns the vertical and horizontal structures. GSK980TDi uses the GSKLINK bus technology, matches with the 17bit absolute encoder, carries out the automatic recovery of the system power-on, no-block mechanical zero return, servo parameter on-line modification or servo state on-line diagnosis, etc.





GSK980TDi-V

GSK980TDi

- 5 feed axes, 2 analogy spindle
- control precision 0.1µm, Max. speed 120m/min
- GSK980TDi standard configuration with GS2000T-LA1 series strong overloading servo unit, it is used the GSKLINK bus technology, matched with 17Bit absolute encoder
- The spindle orientation can be carried out by adapting the servo spindle, Rigid tapping, Cylindrical Interpolation or Polar Coordinate Interpolation.
- Used the GSKLINK bus technology, carried out the functions such as the power-on automatically recover of the coordinate system, Non-block mechanical zero return, Servo parameter on-line modification and servo state on-line diagnosis, etc.
- Built-in multi PLC programs, PLC ladder on-line display and real time monitor, as well the series I/O unit.
- It owns the MPG trial cutting, Teachine, MPG interruption functions.
- It owns the functions, such as the on-line machine tool debugging guide, miscellaneous programming, diagram dimension directly input and polygon turning, etc.
- MDI multi-block performance
- 64M program store space, 10000 components program, and support the U disk program

machining.

- 6-level operation Authorization Management, Multi-level Timed stop
- 8.4 inch true-color LCD supports multi-language display, such as Chinese, English and Russian, etc.

#### 1.1.2 Technical Specification

- Controllable axes
  - ◆ Controllable axes: 5 (X, Z, Y, 4<sup>th</sup>,5<sup>th</sup>)
  - ♦ Link axes: 3
  - PLC controllable axes: 5 (X, Z, Y,  $4^{th}$ ,  $5^{th}$ )

#### Feed axis function

- Least input increment: 0.001mm (0.0001inch) and 0.0001mm (0.00001inch)
- Least command increment: 0.001mm (0.0001inch) and 0.0001mm (0.00001inch)
- Position command range: ±99999999× least command unit
- Rapid traverse speed: 120m/min
- ◆ Rapid override: F0, 25%, 50%, 100%
- ◆ Feedrate override: 0~150% 16 grades to tune
- Interpolation mode: linear interpolation, arc interpolation(three-point arc interpolation), thread interpolation, ellipse interpolation, parabola interpolation,Cylindrical Interpolation、Polar Coordinate Interpolation and rigid tapping
- Automatic chamfer function

#### Thread function

- General thread(following spindle)/rigid thread
- Single/multi metric, inch straight thread, taper thread, end face thread, constant pitch thread and variable pitch thread
- Thread run-out length, angle, speed characteristics can be set
- ◆ Thread pitch: 0.01mm~500mm or 0.06 tooth/inch~2540 tooth/inch

#### Acceleration/deceleration function

- Cutting feed: linear
- Rapid traverse: linear, S
- Thread cutting: linear, exponential
- Initial speed, termination speed, time of acceleration/deceleration can be set by parameters

#### Spindle function

- The Max. spindle controllable number is 3, the top series spindle number is 3, the upmost analog spindle number is 2; support the multi-spindle control.
- 2-channel spindle encoder feedback, spindle encoder line can be set (100p/r~5000p/r)
- ♦ Transmission ratio between encoder and spindle: (1~255) : (1~255)
- ◆ Spindle speed: it is set by S or PLC, and speed range: 0r/min~9999r/min
- ◆ Spindle override: 50%~120% 8 grades tune
- Spindle constant surface speed control
- Rigid tapping

#### Tool function

- Tool length compensation
- Tool nose radius compensation (C)
- Tool wear compensation
- Tool life management
- Toolsetting mode: fixed-point toolsetting, trial-cut toolsetting, reference point return toolsetting, automatic toolsetting
- Tool offset execution mode: modifying coordinate mode, tool traverse mode

#### Precision compensation

- Backlash compensation
- Memory pitch error compensation

#### PLC function

- Two-level PLC program, up to 5000 steps, the 1<sup>st</sup> program refresh period 8ms
- PLC program communication download
- PLC warning and PLC alarm
- Many PLC programs (up to 16PCS), the PLC program currently running can be selected
- Basic I/O: 48 input signals /38 output signals

#### Man-machine interface

- ◆ 8.4" wide screen LCD, resolution: 800×600
- Chinese, English display
- Planar tool path display
- Real-time clock

#### Programming miscellaneous

- Aided programming
- Grammar check
- Two-dimensional tool path
- Path preview

#### Operation management

- Operation mode: edit, auto, MDI, machine zero return, MPG/single, manual, program zero return
- Multi-level operation privilege management
- Alarm record

#### Program edit

- Program capacity: 64MB, 10000 programs (including subprograms and macro programs)
- Edit function: program/block word search, modification, deletion
- Program format: ISO command, statement macro command programming, relative coordinate, absolute coordinate and compound coordinate programming
- Program call: macro program call with parameter, 4-level program built-in

#### Communication function

- RS232: two-way transmitting part programs and parameters, PLC program, system software serial upgrade
- RJ45 access: File dual-direction transportation, such as the Component program,

parameters, PLC program, etc.

USB: U file operation, U file directly machining, PLC program, system software U upgrade

#### Safety function

- Emergency stop
- Hardware travel limit
- Software travel check
- Data backup and recovery

#### ■ G command table

Command	Function	Command	Function	Command	Function
G00	Rapid traverse (positioning)	G28	Reference point return	G66	Macro program modal call
G01	Linear interpolation	G30	2 <sup>nd</sup> , 3 <sup>rd</sup> , 4 <sup>th</sup> reference point return	G67	Macro program modal call cancel
G02	CW arc interpolation	G31	Skip function	G71	Axial roughing cycle (flute cycle)
G03	CCW arc interpolation	G32	Constant pitch thread cutting	G72	Radial roughing cycle
G04	Dwell, exact stop	G32.1	Rigid thread cutting	G73	Closed cutting cycle
G05	Three-point arc interpolation	G33	Z tapping cycle	G70	Finishing cycle
G6.2	Ellipse interpolation (CW)	G34	Thread cutting with variable lead	G74	Axial grooving cycle
G6.3	Ellipse interpolation (CCW)	G36	Automatic tool compensation X	G75	Radial grooving cycle
G7.2	Parabola interpolation (CW)	G37	Automatic tool compensation Z	G76	Multiple thread cutting cycle
G7.3	Parabola interpolation (CCW)	G40	Tool nose radius compensation cancel	G80	Rigid tapping state cancel
G12.1	Polar coordinate interpolation	G41	Tool nose radius compensation left	G83	Axial drilling cycle
G7.1	Cylinder interpolation	G42	Tool nose radius compensation right	G84	Axial rigid tapping
G15	Polar coordinate command cancel	G50	Workpiece coordinate system setting	G87	Radial drilling cycle
G16	Polar coordinate command	G52	Local workpiece coordinate system	G88	Radial rigid tapping
G17	Plane selection command	G54	Workpiece coordinate system 1	G90	Axial cutting cycle
G18	Plane selection command	G55	Workpiece coordinate system 2	G92	Thread cutting cycle
G19	Plane selection command	G56	Workpiece coordinate system 3	G92.1	Rigid thread cutting cycle
G10	Data input ON	G57	Workpiece coordinate system 4	G94	Radial cutting cycle
G11	Data input OFF	G58	Workpiece coordinate system 5	G96	Constant surface speed control
G20	Input in inch	G59	Workpiece coordinate system 6	G97	Constant surface speed control cancel

			Exact stop begins between		
G21	Input in metric	G61	blocks	G98	Feed per minute
C22	Stored travel check	C64	Cancle the exact stop between	<u> </u>	Feed per revolution
GZZ	ON	604	blocks	G99	
000	Stored travel check	005	Macro command non-modal		
G23	OFF	G65	call		

#### 1.1.3 Environment & Conditions

GSK980TDi storage delivery, working environment as follows:

Item	Working conditions	Storage delivery conditions	
Ambient temperature	0°C∼45°C	-40°C∼+70°C	
Ambient humidity	≤90%(no freezing)	≤95%(40°C)	
Atmosphere pressure	86 kPa $\sim$ 106 kPa	86 kPa $\sim$ 106 kPa	
Altitude	≤1000m	≤1000m	

#### 1.1.4 Power Supply

GSK980TDi can normally run in the following AC input power supply. Voltage: within(0.85~1.1)×200V (rated AC input voltage); Frequency: 49Hz~51Hz continuously changing

#### 1.1.5 Guard

GSK980TDi guard level is not less than IP20.

#### 1.2 CNC System of Machine Tools & CNC Machine Tools

CNC machine tool is an electro-mechanical integrated product, composed of Numerical Control Systems of Machine Tools, machines, electric control components, hydraulic components, pneumatic components, lubricant, cooling and other subsystems (components), and CNC systems of machine tools are control cores of CNC machine tools. CNC systems of machine tools are made up of computerized numerical control (CNC), servo (stepper) motor drive devices, servo (or stepper) motor etc.

Operational principles of CNC machine tools: according to requirements of machining technology, edit user programs and input them to CNC, then CNC outputs motion control commands to the servo (stepper) motor drive devices, and last the servo (or stepper) motor completes the cutting feed of machine tool by mechanical driving device; logic control commands in user programs to control spindle start/stop, tool selections, cooling ON/OFF, lubricant ON/OFF are output to electric control systems of machine tools from CNC, and then the electric control systems control output components including buttons, switches, indicators, relays, contactors and so on. Presently, the electric control systems are employed with Programmable Logic Controller (PLC) with characteristics of compact, convenience and high reliance. Thereof, the motion control systems and logic control

systems are the main of CNC machine tools.

GSK980TDi Turning Machine CNC system has simultaneously motion control and logic control function to control two axes of CNC machine tool to move, and has nested PLC function. Edit PLC programs (ladder diagram) according to requirements of input and output control of machine tool and then download them to GSK980TDi Turning Machine CNC system, which realizes the required electric control requirements of machine tool, is convenient to electric design of machine tool and reduces cost of CNC machine tool.

Software used to control GSK980TDi Turning Machine CNC system is divided into system software (NC for short) and PLC software (PLC for short). NC system is used to control the display, communication, edit, decoding, interpolation and acceleration/deceleration, and PLC system for controlling explanations, executions, inputs and outputs of ladder diagrams.

Standard PLC programs are loaded (except for the special order) when GSK980TDi Turning Machine CNC System is delivered, concerned PLC control functions in following functions and operations are described according to control logics of standard PLC programs, marking with "Standard PLC functions" in GSK980TDi Turning CNC System User Manual. Refer to Operation Manual of machine manufacturer about functions and operations of PLC control because the machine manufacturer may modify or edit PLC programs again.



Fig. 1-1

Programming is a course of workpiece contours, machining technologies, technology parameters and tool parameters being edit into part programs according to special CNC programming G codes. CNC machining is a course of CNC controlling a machine tool to complete machining of workpiece according requirements of part programs.

Technical flow of CNC machining is as following Fig. 1-2.



Fig. 1-2

## 1.3 Programming Fundamentals

#### 1.3.1 Coordinates Definition

Sketch map of CNC turning machine is as follows:



Fig. 1-3

9

I Programming

# **CNCmakers**

GSK980TDi uses a rectangular coordinate system composed of X, Z axis. X axis is perpendicular with axes of spindle and Z axis is parallel with axes of spindle; negative directions of them approach to the workpiece and positive ones are away from it.

There is a front tool post and a rear tool post of NC turning machine according to their relative position between the tool post and the spindle, Fig. 1-4 is a coordinate system of the front tool post and Fig. 1-5 is a rear tool post one. It shows exactly the opposite of X axes, but the same of Z axes from figures. In the manual, it will introduce programming application with the front tool post coordinate system in the following figures and examples.





Fig.1-4 Front tool post coordinate system

Fig.1-5 Rear tool post coordinate system

# 1.3.2 Machine Coordinate System, Machine Zero & Machine Reference Point

**Machine tool coordinate system** is a benchmark one used for CNC counting coordinates and a fixed one on the machine tool. **Machine tool zero** is a fixed point which position is specified by zero switch or zero return switch on the machine tool. Usually, the zero return switch is installed on max. stroke in X, Z positive direction. Machine reference point is located at the position at which the machine zero value adding the data parameter No.114/No.115 value. When No.114/No.115 value is 0, the machine reference point coincides with the machine zero. The coordinates of machine reference point is the No.120/No.121 value. Machine zero return/G28 zero return is to execute the machine reference point return. After the machine zero return/machine reference point return is completed, GSK980TDi machine coordinate system which takes No.120 value as the reference point, which is referred to I Programming, Section 3.13.

Note: Do not execute the machine reference point return without the reference point switch installed on the machine tool; otherwise, the motion exceeds the travel limit and the machine to be damaged.

## 1.3.3 Workpiece Coordinate System & Program Zero

The workpiece coordinate system is a rectangular coordinate system based on the part drawing, also called floating coordinate system. After the workpiece is installed on the machine, the absolute coordinates of tool's current position is set by G50 according to the workpiece's measure, and so the workpiece coordinate system is established in CNC. Generally, Z axis of the workpiece coordinate system coincides with the spindle axis. The established workpiece is valid till it is replaced by a new one. The system can set 6 workpiece coordinate systems G54~G59 in advance. Refer to I Programming, Section 3.18 about the details of workpiece coordinate system.

A sub workpiece coordinate system is created in a workpiece coordinate system, which is called as a local coordinate system. Refer to I Programming, Section 3.17 about the details of the local coordinate system.

The current position of workpiece coordinate system set by G50 is the program zero.

Note: Do not execute the machine reference point return without using G50 to set the workpiece coordinate system after power on, otherwise, the alarm occurs.



In the above figure, XOZ is the coordinate system of machine tool,  $X_1O_1Z_1$  is the workpiece coordinate system of X axis located at the heading of workpiece,  $X_2O_2Z_2$  is the one of X axis located at the ending of workpiece, O point is the machine reference point, A point is the tool nose and coordinates of A point in the above-mentioned coordinate systems is as follows:

A point in the machine tool coordinate system: (x, z);

A point in  $X_1O_1Z_1$  coordinate system: (x<sub>1</sub>, z<sub>1</sub>);

A point in  $X_2O_2Z_2$  coordinate system: (x<sub>2</sub>, z<sub>2</sub>).

#### 1.3.4 Interpolation Function

**Interpolation** is defined as a planar or three dimensional contour formed by path of 2 or multiple axes moving at the same time, also called **Contour control**. The controlled moving axis is called link axis when the interpolation is executed. The moving distance, direction and speed of it are controlled synchronously in the course of running to form the required Composite motion path. Positioning control is defined that motion end point of one axis or multiple axes instead of the motion path in the course of running is controlled.

GSK980TDi X and Z axis are link axes and 2 axes link CNC system. The system possesses linear, circular and thread interpolation function.

Linear interpolation: Composite motion path of X, Z axis is a straight line from starting point to end point.

Circular interpolation: Composite motion path of X, Z axis is arc radius defined by R or the circle center (I, K) from starting point to end point.

Thread interpolation: Moving distance of X or Z axis or X and Z axis is defined by rotation angle of spindle to form spiral cutting path on the workpiece surface to realize the



thread cutting. For thread interpolation, the feed axis rotates along with the spindle, the long axis moves one pitch when the spindle rotates one rev, and the short axis and the long axis directly interpolate.

Example:



Fig. 1-7

... G32 W-27 F3; (B $\rightarrow$ C; thread interpolation) G1 X50 Z-30 F100; G1 X80 Z-50; (D $\rightarrow$ E; linear interpolation) G3 X100 W-10 R10; (E $\rightarrow$ F; circular interpolation) ... M30;

## 1.3.5 Absolute Programming & Incremental Programming

Specify coordinate values of path's end point or target position in programming and there are 3 kinds of programming method according to coordinate values in programming: absolute programming, incremental programming and compound programming.

Programming with X/Z axis absolute coordinate value to program (present with X, Z) is defined to be the absolute programming;

Programming with X/Z axis incremental movement (present with U, W) is defined to be the incremental programming;

In the system, X, Z axis separately uses the absolute programming and incremental program, which is called the compound programming.

Example:  $A \rightarrow B$  linear interpolation



FIQ. 1-0

Absolute programming: G01 X200 Z50;

Incremental programming: G01 U100 W-50;

Compound programming: G01 X200 W-50; or G01 U100 Z50

Note: When there are command address X/ U or Z/ W at the same time, X/Z command value is valid. Example: G50 X10 Z20;

G01 X20 W30 U20 Z30; [End point of the block (X20, Z30)]

#### 1.3.6 Diameter Programming & Radius Programming

Programming methods of X coordinate values are divided into: diameter programming and radius programming.

Diameter programming: when NO.001 Bit2 is 0, X input command value is in diameter and X coordinate is in diameter at the moment;

Radius programming: when NO.001 Bit2 is 1, X input command value is in radius and X coordinate is in radius at the moment.

Addresses relevant to diameter or radius programming

Addrose	Explanation	Diameter	Radius	
Audiess	Explanation	programming	programming	
x	X coordinate	In diameter	In radius	
~	G50 setting X coordinate	in diameter	Intadius	
	X increment	In diameter	In radius	
0	X finishing allowance in G71, G72, G73	In diameter	In radius	
R	Moving distance of tool retraction when cutting to the end point in G74	In diameter	In radius	

Except for addresses and data in Table 1-1, others (arc radius, taper in G90) are unrelated to diameter or radius programming, and their input values in X direction are defined by the radius. Note: The diameter programming is used except for the special description in the following explanation.

#### 1.4 Structure of an NC Program

User needs to compile part programs (called program) according to command formats of CNC system. CNC system executes programs to control the machine tool movement, the spindle starting/stopping, the cooling and the lubricant ON/OFF to complete the machine of workpiece.

Program example:



O0001	;	(Program name)
N0005	G0 X100 Z50;	(Rapidly positioning to A point)
N0010	M12;	(Clamping workpiece)
N0015	T0101;	(Changing No.1 tool and executing its offset)
N0020	M3 S600;	(Starting the spindle with 600 r/min)
N0025	M8	(Cooling ON)
N0030	G1 X50 Z0 F600;	(Approaching B point with 600mm/min)
N0040	W-30 F200;	(Cutting from B point to C point)
N0050	X80 W-20 F150;	(Cutting from C point to D point)
N0060	G0 X100 Z50;	(Rapidly retracting to A point)
N0070	T0100;	(Canceling the tool offset)
N0080	M5 S0;	(Stopping the spindle)
N0090	M9;	(Cooling OFF)
N0100	M13;	(Releasing workpiece)
N0110	M30;	(End of program, spindle stopping and Cooling OFF)

The tool leaves the path of  $A \rightarrow B \rightarrow C \rightarrow D \rightarrow A$  after the above-mentioned programs are executed.

#### 1.4.1 General Structure of Program

A program consists of blocks. A block begins with a block number (it can be omitted) and several words ending with ";".

#### Program name

There are most 10000 programs stored in GSK980TDi. To identify it, each program has only one program name (there is no the same program name) beginning with command address O and the following 4 digits.

Program number (0000 $\sim$ 9999, the leading zero can be omitted) Address O

#### Word

A word is the basic command unit to command CNC system to complete the control function, composed of an English letter (called command address) and the following number (operation command with/without sign). The command address describes the meaning of its following operation

command and there may be different meaning in the same command address when the different words are combined together. All words of GSK980TDi are in Table 1-2.



Table 1-2 Word table

Address	Command value range	Function meaning	Unit
0	0~9999	Program name	
N	0~9999	Block number	
G	00~99	Preparatory function	
x	-999999999~99999999	X coordinate	Relevant to IS-B, IS-C
~	0~99999.999(s)	Pause time	
Z	-999999999~99999999	Z coordinate	Relevant to IS-B, IS-C
Y	-999999999~99999999	Y coordinate	Relevant to IS-B, IS-C
	-999999999~99999999	X increment	Relevant to IS-B, IS-C
	0~99999.999(s)	Pause time	
U	-99999~99999	X finishing allowance in G71,G72, G73	Relevant to IS-B, IS-C
	1~99999	Cutting depth in G71	Relevant to IS-B, IS-C
	-999999999~99999999	X tool retraction clearance in G73	Relevant to IS-B, IS-C
	-999999999~99999999	Z increment	Relevant to IS-B, IS-C
	1~99999	Cutting depth in G72	Relevant to IS-B, IS-C
W	-99999~99999	Z finishing allowance in G71,G72, G73	Relevant to IS-B, IS-C
	-999999999~99999999	Z tool retraction in G73	Relevant to IS-B, IS-C
V	-999999999~99999999	Y increment	Relevant to IS-B, IS-C
	-999999999~99999999	Arc radius	Relevant to IS-B, IS-C
	1~99999	Tool retraction in G71, G72	Relevant to IS-B, IS-C
	1 $\sim$ 9999 (times)	Roughing cycle times in G73	
R	1~99999	Tool retraction clearance in G74, G75	Relevant to IS-B, IS-C
	1~999999	Tool retraction clearance from end point in G74, G75	Relevant to IS-B, IS-C
	1~99999999	Finishing allowance in G76	Relevant to IS-B, IS-C
	-999999999~99999999	Taper in G90, G92, G94, G96	Relevant to IS-B, IS-C
I	-999999999~999999999	X vector between arc center and starting point	Relevant to IS-B, IS-C
	0.06~25400 (tooth/inch)	Metric thread teeth	
К	-999999999~999999999	Z vector between arc center and starting point	Relevant to IS-B, IS-C

# **CNCmakers**

Address	Command value range	Function meaning	Unit
	0~8000 (mm/min)	Feedrate per minute	
F	0.0001~500(mm/r)	Feedrate per rev	
	0.001~500 (mm)	Metric thread lead	
S	0~9999 (r/min)	Spindle speed specified	
5	00~04	Multi-gear spindle output	
Т	01~32	Tool function	
	00~99	Miscellaneous function output,	
М		program execution flow	
	9000~99999	Subprogram call	
	0~9999999 (0.001s)	Pause time	
	0~9999	Calling times of subprogram	
		number	
	0~999	Subprogram call times	
Р	0~9999999	X circle movement in G74, G75	Relevant to IS-B, IS-C
		Thread cutting parameter in G76	
	0~99999	Initial block number of finishing in	
		the compound cycle command	
	1~9999999	G7.3	Relevant to IS-B, IS-C
	0~9999	End block number of finishing in	
		the compound cycle	
	0~9999999	Z circle movement in G74, G75	Relevant to IS-B, IS-C
	1~9999999	First cut-in depth in G76	Relevant to IS-B, IS-C
	1~9999999	Min. cut-in depth in G76	Relevant to IS-B, IS-C
Q	0~360000	Offset angle between one-turn	
		signal and starting point of thread	
		cutting at the initial angle in G32	
	0~9999	Angle between long axis of the	
	00000	Angle between long evic of the	
	0/~99999	ellipse and Z in G7.2 G7.3	
	0~99999999	Length of long radius of ellipse in	
A		G6.2, G6.3	Relevant to IS-B, IS-C
R	0~99999999	Length of short radius of ellipse in	Relevant to IS P IS C
		G6.2, G6.3	
H	01~99	Operand in G65	

#### Block

A block which is basic unit of CNC program consists of a sequence of words, ending with ";" or "\*" . There is the character ";" or "\*" between blocks. ";" is used to separate blocks in the manual as follows:



One block may be with a number of words or only with "; "ending character(EOB) instead of words. There must be one or more blank space between many words.

There is only one for other addresses except for N, G, S, T, H, L in one block, otherwise the system alarms. The last word in the same address is valid when there are more N, G, S, T, H, L in the same block. The last G code is valid when there are more G codes which are in the same group in one block.

#### **Block number**

A block number consists of an address N and its following 4-digit: N0000 $\sim$ N9999, and the leading zero can be omitted. The block number must be at the beginning of block, otherwise the block is invalid.

The block number can be omitted, but there must be the block number when the program calls/skips the target block. The increment of block number is at will and it better to increase or decrease the sequence of block number in order to conveniently search and analyze programs.

When "Automatic number" in the switch window is set to "ON", block numbers will be automatically created incrementally and their increment is defined by  $N_0.42$ .

#### Character for block skip

Insert "/" in the front of block and startup when some block cannot be executed (cannot be deleted), and the system skips the block and executes the next one. The block with "/" in the front of it is executed if the block skip switch is not started.

#### Character for end of a program

"%" is an ending character of program. "%" is a mark of communication ended when the program is transmitted. The system will automatically insert "%" at the end of program.

#### **Program Note**

To make it convenient for the user to search, read the program, the program note can be edited followed each program, and its note locates within the bracket following with the block. Only the English Letters and Numbers can be edited the notes on the CNC; but the Chinese can be performed on the PC. The CNC can be displayed the Chinese note after the program loads to the CNC.

#### 1.4.2 Main Program & Subprogram

To simply the programming, when the same or similar machining path and control procedure is used many times, its program commands are edited to a sole program to call. A program which calls the program is the main program and the called program (end with M99) is subprogram. They both take up the program capacity and storage space of system. The subprogram has own name, and can be called at will by the main program and also can run separately. The system returns to the main program to continue when the subprogram ends as follows.



#### 1.5 Program Run

#### 1.5.1 Sequence of Program Run

Running the current open program must be in Auto mode. GSK980TDi cannot open two or more programs at the same, and runs only program any time. When the first block is open, the cursor is located in the heading of the first block and can be moved in Edit mode. In the run stop state in Auto

mode, the program starts to run by the cycle start signal (Image is pressed or external cycle start signal) from a block pointed by current cursor, usually blocks are executed one by one according to their programming sequence, the program stops running till executing M02 or M30. The cursor moves along with program running and is located at the heading of the current block. Sequence and state of program running are changed in the followings:

- The program stops running after pressing *constant* or emergent stop button;
- The program stops running when the system or PLC alarms;
- The program runs and single block stops (the program run stops after the current block runs completely) in Edit, MDI mode, and then a block pointed by the current cursor starts running

after the system switches into Auto mode, is pressed or external cycle start signal is switched on;

• The program stops running in Manual(Jog), Handwheel (MPG), Single Block, Program Reference Point Return, Machine Reference Point Return mode and it continuously runs

from current position after the system is switched into Auto mode and is pressed or the external cycle start signal is switched on;

• The program pauses after pressing is witched off,

and it continuously runs from current position after pressing or the external cycle start signal is switched on;

• When Single Block is ON, the program pauses after every block is executed completely, and

then it continuously runs from the next block after is pressed or the external cycle start signal is switched on;

- Block with "/" in the front of it is not executed when the block skipping switch is ON;
- The system skips to the target block to run after executing G65;
- Please see I Programming, Section Three G Commands about execution sequence of G70~73;
- Call corresponding subprograms or macro program to run when executing M98 or M9000~M9999; the system returns to main program to call the next block when executing M99(if M99 specifies a target block number, the system returns to it to run) after the subprograms or macro programs run completely;
- The system return to the first block to run and the current program is executed repetitively when M99 is executed in a main program.

#### 1.5.2 Execution Sequence of Word

There are many words (G, X, Z, F, R, M, S, T and so on) and most of M, S, T is transmitted to PLC by NC explaining and others are directly executed by NC. M98, M99, M9000 $\sim$ M99999, S word used to specify the spindle speed r/min, m/min is directly executed by NC.

NC firstly executes G and then M commands when G codes and M00, M01, M02 and M30 are in the same block.

NC firstly executes G and then M commands( without transmitting M signal to PLC) when G codes and M98, M99, M9000 $\sim$ M9999 are in the same block.

When G codes and M, S, T executed by PLC are in the same block, PLC defines M, S, T and G to be executed simultaneously, or execute M, S, T after G codes. Please see User Manual of machine manufacturer for execution sequence of commands.

Execution sequence of G, M, S, T in the same block defined by GSK980TDi standard PLC program is as follows:

M3, M4, M8, M10, M12, M32, M41, M42, M43, M44, SDD, TDDDD and G codes are executed simultaneously;

M5, M9, M11, M13, M33 after G codes are executed;

M00, M01, M02, M30 after other commands of current block are executed.

#### 1.6 Basic Axis Incremental System

The incremental system includes least input increment (input) and least command increment (output). Least input increment is the least movement unit of programming movement distance, and least command increment is the least unit of tool traversing on the machine. The two increment systems use mm, inch or deg.

The basic axes include X, Z, and their incremental system has IS-B, IS-C selected by No.00.1 ISC.



1-IS-C (0.1µ level)

#### 1.6.1 Incremental system speed of basic axis

	μ level (IS-B)		0.1µ level (IS-C)	
	Metric machine	Inch machine	Metric machine	Inch machine
	(mm/min)	(inch/min)	(mm/min)	(inch/min)
speed	120,000	12,000	120,000	12,000

## 1.6.2 Incremental System Unit of Basic Axis

In different incremental system and different metric/inch, the least input/output increment is different as follows:

µ level	(IS-B)	Least input	Least command
		increment (input)	increment (output)
	metric input(G21)	0.001 (mm)	0.001 (mm)
Metric machine		0.001 (deg)	0.001 (deg)
Metric machine	inch input(G20)	0.0001 (inch)	0.001 (mm)
		0.001 (deg)	0.001 (deg)
	motria input (C21)	0.001 (mm)	0.0001 (inch)
Inch machine		0.001 (deg)	0.001 (deg)
menmaenne	inch input (C20)	0.0001 (inch)	0.0001 (inch)
	inch input (G20)	0.001 (deg)	0.001 (deg)

0.1µ leve	el (IS-C)	Least input	Least command
		increment (input)	increment (output)
	metric input (G21)	0.0001 (mm)	0.0001 (mm)
Metric machine		0.0001 (deg)	0.0001 (deg)
Metho machine	inch input (G20)	0.00001 (inch)	0.0001 (mm)
		0.0001 (deg)	0.0001 (deg)
	metric input (G21)	0.0001 (mm)	0.00001 (inch)
Inch machine		0.0001 (deg)	0.0001 (deg)
menmaenine	inch input (G20)	0.00001 (inch)	0.00001 (inch)
		0.0001 (deg)	0.0001 (deg)

Least input increment (input) using the metric or the inch is specified by G20 or G21 or is completed by modifying #001 increment bit.

Least command increment (output) using the metric or the inch is determined by the machine, and is set by#004 output increment.

## 1.6.3 Incremental System Data Range of Basic Axis

In different incremental system and pulse output frequency, the corresponding different data range is as follows:

Incremental system		Command data input range		Data format
	motric input (C21)	-99999.999 ~ 99999.999	(mm)	5.3
µ level (IS-B)		-99999.999 ~ 99999.999	(deg)	5.3
	inch input (G20)	-9999.9999 ~ 9999.9999	(inch)	4.4

|--|

		-9999.999 ~ 9999.999 (deg)	4.3
	motria input (C21)	-9999.9999 ~ 9999.9999 (mm)	4.4
0.1µ level	metric input (G21)	-9999.9999 ~ 9999.9999 (deg)	4.4
(IS-C)	inch input (C20)	-999.99999 ~ 999.99999 (inch)	3.5
	inch input (G20)	-999.9999 ~ 999.9999 (deg)	3.4

Note : 5.3 in the above table means 5-bit integer and 3-bit decimal. And other data likes these.

## 1.6.4 Incremental System Data Range & Unit of Basic Axis

#### • Speed parameter

Linear axis speed parameter unit is determined by the machine type. i.e.: metric machine speed unit: mm/min, inch machine is: 0.1inch/min.

Linear axis speed parameter range is determined by the machine type and incremental system type.

Machine type	Incremental system	Linear axis speed unit	Parameter range	Rotary axis speed unit	
Metric machine	µ level(IS-B)	mm/min	10~ 15000		
	0.1µ level (IS-C)	11111/11111	10~ 15000	dea/min	
Inch machine	µ level (IS-B)	0.1inch/min	5~58000	ueg/min	
	0.1µ level (IS-C)	0.11101/11111	5~5800		

Data parameter No. 027(cutting upper speed):

Rotary axis does not execute the metric/inch conversion, the rotary axis speed unit is deg/min; the parameter range is the same that of metric machine.

The different incremental system switch may cause the set max. run speed in the data parameter exceeding max. range permitted by the system, so, the operator should modify the speed parameter to avoid the unexpected when the first power-on after switch.

#### • Incremental parameter

The unit and range of linear axis incremental parameter are determined by the machine type and incremental system type as follows:

	Machine type	Incremental system	Linear axis incremental unit	Linear axis parameter range
	Metric machine	µ level (IS-B)	0.001mm	-99, 999.999~ 99,999.999
		0.1µ level (IS-C)	0.0001 mm	-9, 999.9999~ 9,999.9999
	Inch machine	µ level (IS-B)	0.0001inch	-9, 999.9999~ 9,999.9999
		0.1µ level (IS-C)	0.00001 inch	-999.99999~ 999.99999

The rotary axis does not execute the metric/inch switch, the unit of rotary axis incremental parameter is determined by the incremental system type. The range of rotary axis incremental parameter is the same that of the metric machine.

Machine type	Incremental system	Rotary axis speed unit	Rotary axis parameter range
Metric, Inch	µ level (IS-B)	0.001°	0~ 99999.999
machine	0.1 µ level (IS-C)	0.0001°	0~ 9999.9999
#### Programming value input range

Linear axis coordinate data unit is determined by the metric/inch input system. i.e. metric input is mm; inch input is inch;

Linear axis coordinate data range is determined by metric/inch input system and incremental system. The range is the same that of the command data input range as follows:

Incremental system		Linear axis coordinate data range
ulevel (IS-B)	Metric input (G21)	-99999.999 ~ 99999.999(mm)
	Inch input (G20)	-9999.9999 ~ 9999.9999(inch)
0 1u level (IS-C.)	Metric input (G21)	-9999.9999 ~ 9999.9999(mm)
	Inch input (G20)	-999.99999 ~ 999.99999(inch)

The rotary axis does not execute the metric/inch switch, the rotary axis coordinate data unit is deg. The range of programmed value is shown below:

Input type	Incremental system	Rotary axis coordinate data range
Metric inch input	µ level (IS-B)	-99999.999 ~ 99999.999 (deg)
Metric, merrinput	0.1µ level (IS-C)	-9999.9999 ~ 9999.9999(deg)

#### Offset data

Offset data unit is determined by metric/inch input system. i.e. metric input is mm; inch input is inch.

Offset data range is limited to 9999999 and is determined by the metric/inch input system and incremental system as follows:

Input type	Incremental system	Offset data unit	Offset data range
Metric input(G21)	μ level (IS-B)	mm	±9999.999
	0.1µ level (IS-C)		±999.9999
Inch input (G20)	µ level (IS-B)	inch	±999.9999
	0.1µ level (IS-C)		±99.99999

#### • Pitch data compensation

Linear axis pitch compensation unit and range are determined by the machine type and incremental system type as follows:

	Incremental system	Linear axis data unit	Linear axis pitch
Machine type	moremental system		compensation data range
Metric machine	µ level (IS-B)	0.001mm	-2550~2550
	0.1µ level (IS-C)	0.0001mm	-2550~2550
Inch machine	μ level (IS-B)	0.0001inch	-2550~2550
menmachine	0.1µ level (IS-C)	0.00001inch	-2550 $\sim$ 2550

The rotary axis does not execute the metric/inch switch; the rotary axis pitch compensation unit is determined by the least input unit as follows.

Machina type	Incremental system	Rotary axis pitch	Rotary axis pitch
		compensation unit	compensation range
Metric inch machine	µ level (IS-B)	0.001°	0~255
	0.1µ level (IS-C)	0.0001°	0~2550

1.6.5 Program Address Value Unit & Range of Incremental System of Basic Axis

#### • Pitch definition and range:

	Command	µ level (IS-B)	0.1µ level (IS-C)	Unit
Metric input (G21)	F	0.001~500.000	0.0001~500.00	mm/tooth[lead]
	I	0.06~25400	0.06~2540	tooth[lead]/inch
Inch input (G20)	F	0.0001~50.00	0.00001~50.0	inch/tooth[lead]
	I	0.06~2540	0.06~254	tooth[lead]/inch

#### • Speed F definition

G98 m/min: feed per minute: F unit: mm/min G99 feed per rev: F definition and range are as follows:

Incremental system	Address	Metric input	Inch input
IS-B system	F (G98)	0 $\sim$ 999999.999 (mm/min)	0 $\sim$ 999999.999 (mm/min)
IS-C system		0 $\sim$ 99999.9999 (mm/min)	0 $\sim$ 99999.9999 (mm/min)
IS-B system	F (G99)	0∼500 (mm/r)	0∼500 (mm/r)
IS-C system		0∼50 (mm/r)	0∼50 (mm/r)

# 1.7 Additional Axis Incremental System

Least incremental system in  $\mu$  level (IS-B) or 0.1 $\mu$  level (IS-C) , the additional axis does not execute the link, and is not used alone. When the least incremental output of additional axis is 0.01 in the low precision requirement and the feedrate must be fast, and so the working efficiency largely increases. The least incremental system of additional axis does not sometime consist with the current least incremental system. The system adds the optional function of the least incremental system of the additional axis (Y, 4<sup>th</sup>, 5<sup>th</sup> axis) .

Additional axis incremental system is set by No..187 as follows:

187		nIS1	nIS0			
	-					

nIS1, nIS0: select the least incremental system of each additional axis (n means the axis name of each additional axis)

	nIS0	Incremental system of axis	Least
11101	1150	incremental system of axis	input/output
0	0	Same with current incremental	
0	0	system of basic axis (XY)	
0	1	IS-A	0.01
1	0	IS-B	0.001
1	1	IS-C	0.0001

Note: The least I/O in the above table is expressed without considering the metric/inch and rotary axis.

#### 1.7.1 Additional Axis of Current Incremental System

IS-B or IS-C: The relative speed and data range of additional axis is the same that the described in Section 1.6.

#### 1.7.2 Additional Axis of IS-A Incremental System

IS-A: The max. speed of additional axis is separate 10 times and 100 times of IS-B and IS-C. The relative data and parameter range are same those of the incremental system of current basic axis (refer to Section 1.6).

# CHAPTER 2 MSTF COMMAND

#### 2.1 M (Miscellaneous Function)

M command consists of command address M and its following  $1\sim 2$  or 4 bit digits, used for controlling the flow of executed program or outputting M commands to PLC.

M <u>\_\_\_\_</u>

Command value (00~99, 9000~9999, the leading zero can be omitted)

Command address

M98, M99, M9000 $\sim$ M9999 is executed by NC separately and NC does not output M commands to PLC.

M02, M03 are for ending of programs defined by NC, and NC outputs M commands to PLC which can control spindle OFF, cooling OFF and so on.

M98, M99, M9000 $\sim$ M9999 are for calling programs, M02, M30 are for ending of program which are not changed by PLC. Other M commands output to PLC and their function are defined by PLC. Please refer to User Manual from machine manufacturer.

There is only one M command in one block, otherwise the system alarms.

Commands	Functions
M02	End of program
M30	End of program
M98	Call subprograms
M99	Return from a subprogram; it is executed repeatedly when the program
	ends in M99(the current program is not called by other programs)
M9000~M9999	Call macro programs(their program numbers are more than 9000)

Table 2-1 M commands to control program execution

#### 2.1.1 End of Program M02

Command format: M02 or M2

Command function: In Auto mode, after other commands of current block are executed, the automatic run stops, and the cursor stops a block in M02 and does not return to the start of program. The cursor must return to the start of program when the program is executed again.

Besides the above-mentioned function executed by NC, M02 function is also defined by PLC ladder diagram as follows: current output of CNC is reserved after M02 is executed.

# 2.1.2 End of Program run M30

Command format: M30

Command function: In Auto mode, after other commands of current block are executed in M30, the automatic run stops, the amount of workpiece is added 1, the tool nose radius compensation is cancelled and the cursor returns to the start of program (whether the cursor return to the start of program or not is defined by parameters).

If No.005 Bit 4 is set to 0, the cursor does not return to the beginning of program, and the cursor

returns immediately after the program is executed completely when No.005 Bit 4 is set to 1.

Except for the above-mentioned function executed by NC, M30 function is also defined by PLC ladder diagram as follows: the system closes M03, M04 or M08 signal output and outputs M05 signal after M30 is executed.

# 2.1.3 Subprogram Call M98

Command format:

М98 Рососаааа



Called subprogram number (  $0000 \sim 9999$  ) . The leading zero of subprogram number can be omitted when the calling times is not input; the subprogram number must be with 4 digits when the calling times is input.. Call times: 1~9999. The calling times cannot be input when it is 1.

Command function: In Auto mode, after other commands are executed in M98, CNC calls subprograms specified by P, and subprograms are executed 9999 times at most. M98 is invalid in MDI mode.

### 2.1.4 Return From Subprogram M99

Command format: M99 P0000

- Executed block after returning to the main program is 0000 $\sim$  9999, and its leading zero can be omitted.

Command function: After other commands of current block in the subprogram are executed, the system returns to the main program and continues to execute next block specified by P, and calls a block following M98 of current subprogram when P is not input. The current program is executed repeatedly when M99 is defined to end of program (namely, the current program is executed without calling other programs). M99 is invalid in MDI mode.

Example: Execution path of calling subprogram (with P in M99) as Fig. 2-1. Execution path of calling subprogram (without P in M99) as Fig. 2-2.







Fig. 2-2

Subprogram calls can be nested up to four levels as shown in Fig. 2-3.



#### 2.1.5 Macro Program Call M9000~M9999

Command format: Moooo

\_\_\_\_\_9000~99999

Command function: call macro programs corresponding to command values (O9000~O9999).

Macro programs:  $O9000 \sim O9999$  programs are for machine manufacturer, used for editing subprogram with special functions, called macro programs. The system must have 2-level operation level (machine manufacturer) when editing  $O9000 \sim O9999$ , and macro programs calling commands are executed to call with  $3\sim5$  operation level. M9000 $\sim$ M9999 are invalid in MDI mode.

#### 2.1.6 M commands Defined by Standard PLC Ladder Diagram

Other M commands are defined by PLC except for the above-mentioned ones(M02, M30, M98, M99, M9000~M9999). The following M commands are defined by standard PLC, and GSK980TDi Turning Machine CNC system is used for controlling machine tool. Refer to commands of machine manufacturer about functions, significations, control time sequence and logic of M commands.

M commands defined by standard PLC ladder diagram.

Command	Function	Remark
M00	Program pause	
M01	Program optional stop	
M03	Spindle clockwise (CW)	Eurotiona interleaked
M04	Spindle counterclockwise (CCW)	and states reserved
*M05	Spindle stop	and states reserved
M08	Cooling ON	Functions interlocked
*M09	Cooling OFF	and states reserved
M10	Tailstock forward	Functions interlocked
M11	Tailstock backward	and states reserved
M12	Chuck clamping	Functions interlocked
M13	Chuck releasing	and states reserved
M14	Spindle position control	Functions interlocked
*M15	Spindle speed control	and states reserved
M20	Spindle clamping	Functions interlocked
*M21	Spindle releasing	and states reserved
M24	The 2 <sup>nd</sup> spindle position control	Functions interlocked
*M25	The 2 <sup>nd</sup> spindle speed control	and states reserved
M32	Lubricating ON	Functions interlocked
*M33	Lubricating OFF	and states reserved
*M50	Spindle orientation cancel	
M51	Spindle orientate to No. 1 point	
M52	Spindle orientate to No. 2 point	
M53	Spindle orientate to No. 3 point	Functions interlocked
M54	Spindle orientate to No. 4 point	and states reserved
M55	Spindle orientate to No. 5 point	and States reserved
M56	Spindle orientate to No. 6 point	
M57	Spindle orientate to No. 7 point	
M58	Spindle orientate to No. 8 point	
M63	The 2nd spindle rotation CCW	Eurotiona intorlockod
M64	The 2nd spindle rotation CW	and states reserved
*M65	The 2nd spindle stop	dilu siales ieseiveu
*M41, M42,	Spindle automatic dear shifting	Functions interlocked
M43, M44	Spinule automatic gear shinting	and states reserved

#### Table 2-2 M commands

Note: Commands with "\*" defined by standard PLC is valid when power on.

#### 2.1.7 Program Stop M00

Command format: M00 or M0

Command function: After M00 is executed, the program stops and the system displays "*Pause*", and then the program continuously runs after the cycle start key is pressed.

#### 2.1.8 Program Optional Stop M01

Command format: M01 or M1

and its indicator lights and the Command function: in AUTO, MDI mode, it is valid. Press system enters the optional stop state, at the moment, the program stops run and the system displays "PAUSE" after M01 is executed, after the cycle start key is pressed, the program continuously runs. When the program optional stop switch is not open, the program does not pause even if M01 runs.

#### 2.1.9 Spindle CW, CCW & Stop Control M03, M04, M05

Command format: M03 or M3

M04 or M4;

M05 or M5.

Command function: M03: Spindle CW rotation;

M04: Spindle CCW rotation;

M05: Spindle stop.

Note: Refer to time sequence of output defined by standard PLC ladder in **III INSTALLATION & CONNECTION.** 

#### 2.1.10 Cooling Control M08, M09

Command format: M08 or M8; M09 or M9: Command function: M08: Cooling ON; M09: Cooling OFF.

Note: Refer to time sequence and logic of M08, M09 defined by standard PLC ladder in **III INSTALLATION & CONNECTION.** 

#### 2.1.11 Tailstock Control M10, M11

Command format: M10; M11: Command function: M10: tailstock going forward; M11: tailstock going backward. Note: Refer to time sequence and logic of M10, M11 defined by standard PLC ladder in **III INSTALLATION & CONNECTION** 

#### 2.1.12 Chuck Control M12, M13

Command format: M12;

M13:

Command function: M12: chuck clamping;

M13: chuck releasing.

Note: Refer to time sequence and logic of M12, M13 defined by standard PLC ladder in **III INSTALLATION & CONNECTION.** 



#### 2.1.13 Spindle Position/Speed Control Switch M14, M15

Command format: M14;

M15;

Command function: M14: Spindle is in the position control mode from speed control mode;

M15: Spindle is in speed control mode from the position control mode.

Note: Refer to time sequence and logic of M14, M15 defined by standard PLC ladder in III INSTALLATION & CONNECTION.

#### 2.1.14 Spindle Clamped/Released M20, M21

Command format: M20;

M21;

Command function: M20: Spindle clamped

M21: Spindle released

Note: Refer to time sequence and logic of M20, M21 defined by standard PLC ladder in III INSTALLATION & CONNECTION.

#### 2.1.15 The 2<sup>nd</sup> Spindle Position/Speed Switch M24, M25

Command format: M24;

M25;

Command function: M24: The 2<sup>nd</sup> spindle is switched from the speed control mode to the position control mode;

M25: The 2<sup>nd</sup> spindle is switched from the position control mode to the speed control mode.

Note: Refer to time sequence and logic of M24, M25 defined by standard PLC ladder in III INSTALLATION & CONNECTION.

#### 2.1.16 Lubricating Control M32, M33

Command format: M32;

M33;

Command function: M32: Lubricating ON;

M33: Lubricating OFF.

Note: Refer to time sequence and logic of M32, M33 defined by standard PLC ladder in III INSTALLATION & CONNECTION.

#### 2.1.17 Spindle Automatic Gear Change M41, M42, M43, M44

Command format: M4n; (n=1, 2, 3, 4)

Command function: When the system executes M4n, the spindle changes to gear n.

Note: Refer to time sequence and logic of M41, M42, M43, M44 defined by standard PLC ladder in III INSTALLATION&CONNECTION.

#### 2.1.18 Spindle 8-point Orientation M50~M58

Command format: M5n; (n=0 $\sim$ 8)

Command function: M50: Cancel orientation state;

M5n(n=0 $\sim$ 8): The spindle oriented to No. n point.

Note: Refer to time sequence and logic of M50∼M58 defined by standard PLC ladder in Ⅲ INSTALLATION & CONNECTION.

2.1.19 The 2<sup>nd</sup> Spindle Rotation CCW/CW, Stop M63, M64, M65

Command format: M63;

M64;

M65;

Command function:

M63: spindle rotation CCW; M64: spindle rotation CW; M65: spindle stop.

Note 1: The sequence of M63, M64, M65 defined by the standard PLC is the same that of M03, M04, M05. Note 2: The function is enabled when the 2nd spindle function is valid.

#### 2.2 Spindle Function

S command is used for controlling spindle speed and this GSK980TDi has two modes to control it:

Spindle speed switching value control:  $S_{\Box\Box}$  (2 digits command value) is executed by PLC, and PLC outputs switching value signal to machine tool to change spindle speed with grades.

Spindle speed analog voltage control:  $S_{\Box\Box\Box\Box}$ (4 digits command value)specifies actual speed of spindle and NC outputs 0~10V analog voltage signal to spindle servo or converter to realize stepless spindle speed.

#### 2.2.1 Spindle Speed Switching Value Control

Spindle speed is controlled by switching value when No.001 BIT4 is set to 0. There is only one S command in a block, otherwise the system alarms.

Their executing sequence is defined by PLC when S command and word for moving function are in the same block. Please refer to *User Manual* from machine manufacturer.

When spindle speed is controlled by switching value, GSK980TDi Turning CNC system is used for machine tool and the time sequence and logic of executing S command is according to *User Manual* from machine manufacturer. Refer to S command defined by standard PLC of GSK980TDi as follows:

Command format: S

 $00\sim04$ (the leading zero can be omitted): No.1 $\sim$ No.4 gear of spindle speed is controlled by switching value.

In spindle speed switching value control mode, after S signal transmits to PLC, the system dwells time defined by No.081, then return FIN signal, and the dwell time is called runtime of S command.





Start to execute the following word or block

S01, S02, S03, S04 output are reserved when resetting CNC.

S1 $\sim$ S4 output are invalid when CNC is switched on. The corresponding S signal output is valid and reserved, and others are cancelled at the same time when executing one of S01, S02, S03, S04. When executing S00, S1 $\sim$ S4 output are cancelled and only one of S1 $\sim$ S4 is valid at the same time.

# 2.2.2 Spindle Speed Analog Voltage Control

Spindle speed is controlled by analog voltage when No.001 BIT4 is set to 1. Command format: S  $\square \square \square$ 

 $0000 \sim 9999$  (the leading zero can be omitted.):Spindle speed analog voltage control

**Command function:** The spindle speed is defined, and the system outputs  $0\sim10V$  analog voltage to control spindle servo or converter to realize the stepless timing. S command value is not reserved, and it is 0 after the system is switched on.

When the spindle speed analog voltage control is valid, there are 2 methods to input the spindle speed: the spindle fixed speed is defined by S command( r/min), and is invariant without changing S command value, which is called constant speed control(G97 modal); other is the tangent speed of tool relative to the outer circle of workpiece defined by S command, which is called constant surface speed control (G96 modal), and the spindle speed is changed along with the absolute coordinates value of X absolute coordinates in programming path when cutting feed is executed in the constant surface speed.

Please refer to Section 2.2.4.

The system can execute 4 gears spindle speed. Count the analog voltage value corresponding to the specified speed according to setting value(corresponding to No.037 $\sim$ No.040) of max. spindle speed (analog voltage is 10V)of current gear, and then output to spindle servo or converter to ensure that the spindle actual speed and the requirement are the same.

After the system is switched on, the analog output voltage is 0V. The analog output voltage is reserved (except that the system is in cutting feed in the surface speed control mode and the absolute value of X absolute coordinates is changed) after S command is executed. The analog output voltage is 0V after S0 is executed. The analog output voltage is reserved when the system resets and emergently stops.

#### 2.2.3 Spindle Speed Series Control

When the Bit 4 of the state parameter No. 001 sets to 1, and the Bi7 of the No. 195 sets to 1, the spindle speed is the series control.

#### Command format:S \_\_\_\_

\_\_0000 $\sim$ 9999 (the leading zero can be omitted.): Spindle speed series

control

**Command function:** The spindle speed is defined, CNC directly controls the spindle servo drive unit by delivering the series data based upon the bus to carry out the stepless speed

of the spindle. S command value is not reserved, and it is 0 after the system is switched on.

When the spindle speed analog voltage control is valid, there are 2 methods to input the spindle speed: the spindle fixed speed is defined by S command( r/min), and is invariant without changing S command value, which is called constant speed control(G97 modal); other is the tangent speed of tool relative to the outer circle of workpiece defined by S command, which is called constant surface speed control (G96 modal), and the spindle speed is changed along with the absolute coordinates value of X absolute coordinates in programming path when cutting feed is executed in the constant surface speed.

Please refer to Section 2.2.4.

The system can execute 4 gears spindle speed. Count the analog voltage value corresponding to the specified speed according to setting value(corresponding to No.037 $\sim$ No.040) of max. spindle speed (analog voltage is 10V)of current gear, and then output to spindle servo or converter to ensure that the spindle actual speed and the requirement are the same.

# 2.2.4 Constant Surface Speed Control G96, Constant Rotational Speed Control G97

Command format: G96 S_; (S0000 $\sim$ S9999, the leading zero can be omitted.)
Command function: The constant surface speed control is valid, the cutting surface speed is
defined (m/min) and the constant rotational speed control is cancelled.
G96 is modal G code. If the current modal is G96, G96 cannot be input.
Command format: G97 S_; (S0000 $\sim$ S9999, the leading zero can be omitted.)
Command function: The constant surface speed control is cancelled, the constant rotational
speed control is valid and the spindle speed is defined (r/min). G96 is
modal G code. If the current modal is G97, G97 cannot be input.
Command format: G50 S_; (S0000 $\sim$ S9999, the leading zero can be omitted.)
Command function: define max. spindle speed limit (r/min) in the constant surface speed control

G96, G97 are the modal word in the same group but one of them is valid. G97 is the initial word and the system defaults G97 is valid when the system is switched on.

and take the current position as the program reference point.

When the machine tool is turning it, the workpiece rotates based on the axes of spindle as the center line, the cutting point of tool cutting workpiece is a circle motion around the axes, and the instantaneous speed in the circle tangent direction is called **cutting surface** (for short **surface speed**). There are different surface speed for the different workpiece and tool with different material.

When the spindle speed controlled by the analog voltage is valid, the constant surface control is valid. The spindle speed is changed along with the absolute value of X absolute coordinates of programming path in the constant speed control. If the absolute value of X absolute coordinates adds, the spindle speed reduces, and vice verse, which make the cutting surface speed as S command value. The constant speed control to cut the workpiece makes sure all smooth finish on the surface of workpiece with diameter changing.

Surface speed=spindle speed ×  $|X| \times \pi \div 1000$  (m/min)

Spindle speed: r/min

|X|: absolute value of X absolute coordinate value, mm  $\pi \approx 3.14$ 



Fig. 2-4

In G96, the spindle speed is changed along with the absolute value of X absolute coordinates value of programming path in cutting feed (interpolation), but it is not changed in G00 because there is no actual cutting and is counted based on the surface speed of end point in the program block.

In G96 (constant surface speed control), Z coordinates axis of workpiece system must consist with the axes of spindle (rotary axis of workpiece), otherwise, there is different between the actual surface speed and the defined one.

G96 control is valid, G50 S\_ can limit max. spindle speed (r/min). The spindle actual speed is the limit value of max. speed when the spindle speed counted by the surface speed and X coordinates value is more than the max. spindle speed set by G50 S\_. After the system powers on, max. spindle speed limit value is not defined and its function is invalid. Max. spindle speed limit value defined by G50 S\_ is reserved before it is defined again and its function is valid in G96. Max. spindle speed defined by G50 S\_ is invalid in G97 but its limit value is reserved.

Note: When NO.043 (lowest spindle speed in constant surface speed control) is set to 0 and G50 S0 is executed, the spindle speed is limited to 0 r/min (the spindle does not rotate).

When the constant surface speed is controlled by the system parameter No.043, the spindle speed is lower limit, which is higher than one counted by the surface speed and X axis coordinates value.

Example:



Fig. 2-5

O0001	•	(Program name)
N0010	M3 G96 S300;	(Spindle rotates clockwise, the constant surface speed control is
		valid and the surface speed is 300 m/min)
N0020	G0 X100 Z100;	(Rapid traverse to A point with spindle speed 955 r/min)
N0030	G0 X50 Z0;	(Rapid traverse to B point with spindle speed 1910 r/min)
N0040	G1 W-30 F200;	(Cut from B to C with spindle speed 1910 r/min)
N0050	X80 W-20 F150;	(Cut from C to D with spindle speed 1910 r/min and surface speed
		1194 r/min)
N0060	G0 X100 Z100;	(Rapid retract to A point with spindle speed 955 r/min)
N0110	M30;	(End of program, spindle stopping and cooling OFF)
N0120	%	

Note 1: S value commanded in G96 is also reserved in G97. Its value is resumed when the system is in G96 again; Example:

- G96 S50; (Cutting surface speed 50m/min)
- G97 S1000; (Spindle speed 1000 r/min)
- G96 X3000; (Cutting surface speed 50m/min)
- Note 2: The constant surface speed control is valid when the machine tool is locked (X, Z do not move when their motion command are executed);
- Note 3: To gain the precise thread machining, it should not be adopted with the constant surface speed control but the constant rotational speed (G97) in the course of thread cutting;
- Note 4: From G96 to G97, if none of S command (r/min) is commanded in the program block in G97, the last spindle speed in G96 is taken as S command in G97, namely, the spindle speed is not changed at this time;
- Note 5: In G96, when the spindle speed counted by the cutting surface speed is more than max. speed of current spindle gear (system parameter No.037~No.040), at this time, the spindle speed is limited to max. one of current spindle gear.

#### 2.2.5 Spindle Override

When the spindle speed analog voltage control is valid, the spindle actual speed can be tuned real time by the spindle override and is limited by max spindle speed of current gear after the spindle override is tuned, and it also restricted by limited values of max. and min. spindle speed in constant surface speed control mode.

The system supplies 8 steps for spindle override ( $50\% \sim 120\%$  increment of 10%). The actual steps and tune of spindle override are defined by PLC ladder and introductions from machine manufacturer should be referred when using it. Refer to the following functions of GSK980TDi standard PLC ladder.

The spindle actual speed specified by GSK980TDi standard PLC ladder can be tuned real time by the spindle override tune key at 8 steps in  $50\% \sim 120\%$  and it is not reserved when the spindle override is switched off. Refer to the operations of spindle override in II **OPERATION**.

#### 2.2.6 Multiple Spindle Control Function

GSK980TDi can control up to two analog spindles. One S code is used to command one of them which are selected by PLC signal and which have the gear change function.

Because GSK980TDi has only one spindle encoder interface, the 2<sup>nd</sup> spindle has no encoder feedback and the spindle speed is not displayed.

Being the speed command, S code is sent to the spindle selected by the spindle selection signal (SWS1, SWS2 < $G27 \pm 0$ ,  $G27 \pm 1$ ), and each spindle rotates with the specified speed. When the

spindle has not received the spindle selection signal, it rotates with the previous speed, which makes the spindle rotates with different speed in different time. Each spindle has its own stop signal and enabling signal.

When N001 # 4 is set to 1, setting MSEN (N196 # 4) to 1 can start the multiple spindle control function.

The spindle control has several methods which are set by MSI (№196#7) as follows:

• Multiple spindle control method A

maker

When SWS1 signal selects the 1<sup>st</sup> spindle, SIND signal is used to determine that the spindle analog voltage is controlled by PLC or CNC, R011 to R121 signals are used to set the spindle analog voltage. These signals do not influence the 2<sup>nd</sup> spindle.

Multiple spindle control method A is shown below.



• Multiple spindle control method B

Each spindle has separate SIND signal.

When the spindle selection signal, the 1<sup>st</sup> spindle or the 2<sup>nd</sup> spindle SIND signal is set to 1, SIND signals separately determine each spindle to be controlled by PLC or CNC.

Multiple spindle control method B is shown below.



• Multiple spindle control function being invalid

When the multiple spindle control is invalid, the control method is shown below.



#### 2.2.7 Cs Contour Control Funciton

Controlling a spindle speed is called as the spindle rotation control (the spindle rotates by the speed command), and controlling the spindle position is called as the spindle contour control (the spindle rotates by the movement command). The function of the spindle contour control is that of Cs contour control. Being the servo feed axis, the spindle rotates and orients by the position movement command, and executes the interpolation with other feed axes to machine the contour curve.

#### 2.2.8 Spindle Positioning Function

In the turning machining, the spindle rotates at one certain speed, therefore, the workpiece installed on the spindle revolved and machined. In this case, the spindle control state is called "Spindle Rotation Mode". Compare to the others, moves one angle for the spindle, so that the workpiece installed on the spindle positions at one angle, which is regarded as "Spindle Positioning Function". In this case, the controllable state of the spindle is called "Spindle Positioning Mode". Generally, the spindle positioning axis is mechanically clamped to use after the positioning operation is performed, and therefore, the relation operations between the spindle clamping and releasing may be performed before/after the positioning.

The spindle positioning function can be devided into 3 steps based upon the operation:

• Release the spindle rotation method, shift to the spindle positioning mode

Shift the spindle to its positioning method by executing the specific M code (Parameter setting), and then set up a reference position.

- The positioning spindle operation in the spindle positioning method.
- Spindle positioning can be performed the position of arbitrary angle by axis address, which can be used the absolute and relative commands. It is better not to perform with the shared block other than the G00 or G50 command.

For example, suppose the controllable axis is C axis:

- G00 C45.000
- G00 H-60.000
- Release the spindle positioning method, shift to the operation of the spindle rotation method.

Shift the spindle to the spindle rotation method by performing the specific M code (Parameter Setting).

Compare the spindle positioning function with the Cs axis contour controllable function, regardless of the linkage interpolation with other axes; generally, the mechanical equipment clamping can be used when the position is completed.

Especially note, the spindle positioning function and Cs axis contour controllable function can not be simultaneously used.

#### 2.3 Tool Function

#### 2.3.1 Tool Control

T functions of GSK980TDi: automatic tool change and executing tool offset. Control logic of automatic tool change is executed by PLC and tool offset is executed by NC.

Command format:

Tool offset number (00-32, the leading zero cannot be omitted) Target tool number (01-32, the leading zero cannot be omitted)

Command function: The automatic tool post rotates to the target tool number and the tool offset of tool offset number commanded is executed. The tool offset number can be the same as the tool number, and also cannot be the same as it, namely, one tool can corresponds to many tool offset numbers. After executing tool offset and then  $T_{\Box\Box}00$ , the system reversely offset the current tool offset and the system its operation mode from the executed tool length compensation into the non-compensation, which course is called the canceling tool offset number and the tool offset number displayed by T command is the state before the system is switched off.

Only one T command is in a block, otherwise the system alarms.

Toolsetting is executed to gain the position offset data before machining (called tool offset), and the system automatically executes the tool offset after executing T command when programs are running. Only edit programs for each tool according to part drawing instead of relative position of each tool in the machine coordinate system. If there is error caused by the wearing of tool, directly modify the tool offset according to the dimension offset.



Fig.2-6 tool offset

The tool offset is used for the programming. The offset corresponding to the tool offset number in T command is added or subtracted on the end point of each block. Tool offset in X direction in diameter or radius is set by No.004 Bit4. For tool offset in diameter or radius in X direction, the external diameter is changed along with diameter or radius when the tool length compensation is changed.

Example: When the state parameter No.004 Bit4 is set to 0 and X tool length compensation value is 10mm, the external diameter of workpiece is 10mm; when No. 004 is set to 1 and X tool length compensation value is 10mm, the external diameter of workpiec is 20mm. Fig.2-5 is the course of creating, executing and canceling tool offset in traverse mode.



Fig. 2-7 Creation, execution and cancellation of tool length compensation G01 X100 Z100 T0101; (Block 1, start to execute the tool offset)

G01 W150;

(Block 2, tool offset Block 2, tool offset)

G01 U150 W100 T0100; (Block 3, canceling tool offset)

There are two methods defined by No.003 Bit4 to execute the tool length compensation:

Bit4=0: The tool length compensation is executed by the tool traversing;

Bit4=1: The tool length compensation is executed by modifying the coordinates;

Example:

Та	ble	2-4
īα	DIC	4-7

Tool offsot number	Y	7
Tool oliset number	~	2
00	0.000	0.000
01	0.000	0.000
02	12.000	-23.000
03	24.560	13.452

State of T	State of T	State of T
T0100	T0202	T0303
Coordinates	Coordinates	Coordinates
displaying	displaying	displaying
(Incremental	(Incremental	(Incremental
coordinates)	coordinates)	coordinates)
U: 0.000	U: 12.000	U: 24.560
W: 0.000	W: -23.000	W: 13.452
(Absolute	(Absolute	(Absolute
coordinates)	coordinates)	coordinates)
X: 0.000	X: 0.000	X: 0.000
Z: 0.000	Z: 0.000	Z: 0.000
№ 01 tool without the tool compensation	Change №2 tool and execute its offset by the tool traversing with 12mm in X positive direction and 23mm in Z negative direction	Change №3 tool and execute its offset by the tool traversing with 12.56mm in X positive direction and 36.452mm in Z positive direction

Fig. 2-8 Tool traversing mode





Fig. 2-9 Modifying the coordinates mode

In Edit and Auto mode, a sole T word in executing tool offset (it is not with the motion command in the same block) is relative to No.004 BIT3 setting (as Fig.2-8 and Fig.2-9). When No.003 Bit4=1 and a sole T command is executed, the tool offset number is displayed in poor, which is cleared out(tool offset number is still displayed in poor when tool offset is not executed for one axis, the previous bit of tool offset number is for X axis tool compensation and the next one is for Z axis tool compensation) after executing tool offset.

Example: When No.003 Bit4 is 1 and a sole T0101 is executed, the system displays after executing Z axis as follows:

ROGRAM -> M	DI PROGRA	AM		0000	0 N0000	MODAL INFO	RMATION	CLEA
(ABSOLUTI X -16.1	E <b>1</b> 0000 1	EREL U	ATIVE] 0.0000	SRPM: SSPM: SMAX:	0000 0000 9999	600 697 6 640 623 6 664 618 6 N00 80000	98 G21 67 G54 15 G13.1 1.0	AL
2 04.1	1333		04.1333	SMIN:	0000	201 MAIN INFOR	mm/min mm/min	In Inter
1 1					_	JOG.F	1260	DE
						FED OVRI	100%	5
						RAP OVRI	100%	UND
						SPI OVRI	100%	Gi
						PART CNT	0	- 24.0
						CUT TIME	00:00:24	MARCO
-	-						09:59:53	EDIT

Executing a sole T0101 and tool offsets of two axes are not executed

GRAM -> MD1 PRO	GRAM	00000 N000	0 MODAL INFORMATION
[ABSOLUTE] -16.0000 15.7333	[RELATIVE] U 0.0000	SRPM: 000 SSPM: 000 SMAX: 999 SMIN: 000	C00 G97 G98 G21 6 G40 G23 G67 G54 6 G64 G18 G15 G13.1 W00 S0000 L6 6 F D. 0000 mm/min
[010000]			MAIN INFORMATION
-			JOG.F 1260 FED OVR1 1005 RAP OVR1 1005
			SPI OVRI 1005 PART CNT 1884
	_	_	CUT TIME 65:25:58

Executing W0 after T0101, X tool offset is not executed but that of Z is done

When T command and the motion command are in the same block and execute tool offset by modifying coordinates, the motion command and T command are executed at the same time, the system executes by adding the current tool offset to coordinates of motion command and whether the traverse speed is employed the cutting feedrate or the rapid traverse speed defined by the motion command.

When T command and the motion command are in the same block and execute tool offset by traversing tool, the motion command or T command is executed separately. Firstly tool change is executed and then the motion command is executed. The tool offset is executed at current rapid traverse speed.

The tool offset is cancelled after one of the following operations is executed:

- 1. Execute  $T \square \square 00$  command;
- 2. Execute G28 or manual machine reference point return (only the tool offset of coordinate axis which is executed machine reference point return is cancelled, and another one which is not executed machine reference point return is not cancelled);

When No.084 is not 1 (2 $\sim$ 32) and target tool number is not equal to current display tool number, the control sequence and logic of tool post is defined by PLC ladder diagram after commanding T command, please see User Manual of machine tool manufacturer. GSK980TDi standard PLC ladder diagram defines as follows: clockwise rotation for selecting tool, counterclockwise rotation for tool post clamping, directly inputting tool selection signal for tool change. Please refer to III **INSTALLATION & CONNECTION**.

When the system is employed with line-up tool post, No.084 should be set to 1 and different tool number is executed by different tool offset as T0101, T0102, T0103.

#### 2.3.2 Tool Life Management

1. Starting tool life management function

The state parameter No.002 Bit0 (TLIF) is the market whether the tool life management function is valid or not, the corresponding tool life management window is not displayed when it is invalid.

	002									Tool life management
--	-----	--	--	--	--	--	--	--	--	----------------------

Bit 0 Tool life management function is not valid.

1 Tool life management function is valid.

#### 2. Tool life management display window



TOOL-LIFE



Press repetitively into the tool life management display window

#### 1) "Tool compensation->tool life" window

The current window displays the life management data of current used tool life management and defined tool groups. The window is shown below:

MDI					50000 TO	101
URRENT	LIFE MANAGEMEN TOOL STATE:	ſ			01017 N0000	ADD GROUP
TOOL	NO.   GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEL GROUP
ROUP DE 01 02	FINED:					ADD TOOL
NO	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	DEL FOOL
01 02	0103 0104	200 300	0 0	COUNT	USABLE USABLE	SWITC
				-		COUNT CLR.
					-	SKIP TOOL
		_			15:18:36	WORE:
OFFSET &WEAR	MACRO VAR.	OFFSET USE	R-DFLT RO VAR TOOL-	LIFE		

Current tool state: display the current used tool life management data;

Tool number: current used tool and tool compensation number;

COUNT CLR.

UNIT:

Group: the group where the tool is;

Life: tool life data, the specified value can be time or number of times according to the different

count N value; press Used: used tool life data.

Life unit: count unit of tool life, N1 is the used time (unit: minute), N0 is the used times (unit:

times) . Press MIN to change the count unit of the tool.

to record the time or clear the times.

display the tool state (0-not be used, 1-being used, 2-used, 3-skip). State:

to change the tool state to skip when the tool is not used in the current window. Press

Defined group: It only display defined group number and the undefined group number is not displayed. The displayed group back lighted means that all tool life in this group is over.

#### 2) Creating and displaying tool group number

- A. In tool group state display window, press GROUP, group number, and the system display the tool group life data, and when the group does not exist, it is defined to the new group number( the parameter switch is ON in MDI mode).
  - Note: After the new group is defined, GSK980TDi will automatically define the first tool, for example, the new defined group number is 01, the display is as follows:

MDI					50000 TO1	01
1001 ->	LIFE MANAGEMEN	T			00000 N0000	ADD
CURRENT 1	TOOL STATE:					GRUUP
TOOL	IO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEL GROUP
ROUP DEF	INED:				1	ADD TOOL
NO	TOOL FORESET	INC	HEED	LICE MALT	CTATE	DEL
AU.	R000 800P SET	a	0 OCLU	COUNT	OVED	TUOL
01	0000		0	COONT	OFER	SWITC
				- 2		COUNT CL.R.
						SKIP TOOL
						¥
			_			MORE

- B. Press SHITCH to move the cursor to Defined Group Number.
- C. Press or it is select the group number in Defined Group Number, and to gradually display content of each group number.

#### 3. Definition of tool life data

There are two ways to set the tool life data: 1) compile NC programs and run the program setting; 2) input directly in the tool life management window.

#### 1) Compile NC programs and run program setting

Command format: G10 L3

Command function: set to be the tool life manage data input mode

Command format: G11

Command function: cancel the tool life management data input mode

Program	Meaning	Remark
O0020 (O0020)		T_: tool and tool offset number;
G10 L3;	Set to be the tool life management data input mod	
P01;	Tool group number, too group number setting range(1 $\sim$ 32)	N_: tool life count mode, N0 is the used time(minute) to count tool
T0101 L500 N0;	Tool number, life, mode(number of times) setting	life and N1 is the used number of times to count the tool
T0201 L600 N1;	Tool number, life and mode(min) setting	life(unit: min)
P02;	Another tool group number	
T0303 L200 N0;		L_: tool life data, the specified value
T0304 L300 N0;		according to the different count
G11;	Cancel the tool life management data input mode	N value
M30;		

Note 1: The tool group numbers specified by P may not be the continuous, but it is better to gradually increase the sequence number to easily search the tool group number.

Note 2: The tool life is 0 when the life data L\_ is omitted, and the tool mode is 0 (minute) when the specified

mode  $N_{\rm i}$  is omitted, at the time, the system only counts and doest not alarm for the output.

- Note 3: Other commands between G10 L3 and G11 are ignored.
- Note 4: Running the tool life preset program (such as O0020) completely clear all previous life data and preset the life data according to the program requirements.
- Note 5: Prevent the life data from being modified manually when the part programs are running until the run state stops (except for running the tool life preset programs).

Note 6: All tool life data is stored when power-down.

#### 2) Input tool life management data in the tool life management window

Input directly the tool life management data in tool compensation- >tool life window in MDI mode, parameter switch ON and 3-level operation limit. **A. alter data:** 

In tool compensation -> tool life window, press switch to move the tool to the life position, input

directly data, such as 500, press to confirm the input. Press  $\checkmark$   $\rightarrow$   $\downarrow$   $\uparrow$  to complete data input (tool offset, life) .

MDI					SOODO TO	<b>S</b> 1
100L -> CURRENT	LIFE MANAGEMEN TOOL STATE:	r			00000 N0000	ADD
TOOL	NO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEL GROU
ROUP DE	FINED:					ADD
NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	.DEL TOOL
01	0000	500	0	COUNT	USABLE	SWIT
						COUN CLR.
						SKIP
					B 14-00-47	₩ MORE
OFFSET &WEAR	MACRO VAR.	OFFSET USER CD. MAC	OFLT TOOL-	LIFE		

#### B. Inserting data:

Insert any serial number in the current page, press 100L -->[01~08] --> insert a new line, and the initial value definition is as follows:

Serial number	Tool offset	Life	Used	Mode	State
N	0000	0	0	0	Over

a) Insert the front and the previous serial number moves backward.

IRRENT	LIFE MANAGEMEN	I			00000 N0000	AL GR
TOOL	NO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	Di
OUP DE	FINED:					GR
01						Ť
NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	D
01	0000	0	0	COUNT	OVER	-
02	0000	500	0	COUNT	USABLE	SW
						CO
						CI
						SK
						10
						♦
-	Statement and statements	-	and the second s	and the subscription of	# 13-48-00	MO

b) Insert the middle and the previous sequence number moves backward.

					SUUUU IUT	101
<mark>00L →</mark> Irrent	TOOL STATE:	I		-	00000 N0000	ADD GROUP
TOOL	NO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEL GROUP
ROUP DE	FINED:					ADD TOOL
NO	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	DEL TOOL
01	0000	0	0	COUNT	OVER	0
02	0000	500	0	COUNT	USABLE	SWITCH
						COUNT CLR.
						SKIP TOOL
						♦
_	and the second second	and the Property lies	-	-	E 13-48-45	MORE

c) Insert behind

MDI					<b>S0000 TO</b>	101
100L -> URRENT	LIFE MANAGEMEN TOOL STATE:	T			00000 00000	ADD GROUP
TOOL	NO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEL
ROUP DE	FINED:					400
01						TOOL
NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	DEL
01	0000	0	0	COUNT	OVER	-
02	0000	0	0	COUNT	OVER	SWIT
03	0000	500	0	COUNT	USABLE	onti
04	0000	0	0	COUNT	OVER	COUN CLR.
						SKIF
						∢
				-	B 13:49:01	MORE
OFFSET &WEAR	MACRO VAR.	OFFSET USEF	R-DFLT RO VAR TOOL-	LIFE		

#### C. Delete data:

a) Delete data in all groups.

In tool compensation-> tool life window, press

					S0000 T01	<u>0</u> 1
tool -> Current t	LIFE MANAGEMEN FOOL STATE:	T			00000 N0000	ADD
TOOL	IO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEL GROUP
ROUP DEF	FINED:				-	ADD
						DEL
NO. 01	TOOL&OFFSET	UTFE 0	USED	COUNT	OVER	TOOL
				-		SWITC
						COUNT CLR.
				-		SKIP TOOL
						¥
OFFSET	MACRO VAR.	OFFSET USER	DFLT TOOL-	LIFE	⊞ 13:50:59	MORE
unchu		Befor	re opera	ation		



	MLI					20000 10	101
	$100L \rightarrow$	LIFE MANAGEME	NT			00000 N0000	ADD
	TOOL	NO. GROUP NO	LIFE	USED	LIFE UNIT	STATE	GRUUP
	TONE	ino. uncor no		UNLO		UNITE	GROUP
	GROUP DE	FINED:					ADD
							TOOL
	NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	DEL
							2
							SWITC
							COUNT
							OVID
	-						TOOL
				_			♦
	D. OFESET	- [ ···	OFFSET USER	-DEL T		₩ 13:50:09	MORE
	*****	MACRO VAR.	CD. MACH	TOOL-I	IFE		
			Afte	r opera	tion		
DEL GROUP	>i	nnut seria	al numbe	or [02]	>	DATA	
	MDI	iput sene				<b>S0000 T0</b>	101
	100L ->	LIFE MANAGEME	NT			00000 N0000	ADD
	TOOL	NO.   GROUP NO	. LIFE	USED	LIFE UNIT	STATE	DEL
							GROUF
	GROUP DE	FINED:					ADD
	01 02						
	NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	TOOL
	01	0000	0	0	COUNT	OVER	9
						1	SHITC
			1		-		CLR.
							SKIP
							100L
				-	1	* 13:50:59	MORE
	OFFSET	MACRO VAR.	OFFSET USER	DFLT TOOL -L	IFE		
	* ATTEAK		+ CU. MACH	U VAR		_	
			Delo	re opera	tion		-
	MDI				1	50000 10	101
		TOOL STATE:	NI			00000 00000	ADD
	TOOL	NO.   GROUP NO	LIFE	USED	LIFE UNIT	STATE	DEL
	CDOUD DC	E INED -					GROUP
	01 03	TINLO:					ADD TOOL
		_		_	_	_	DEL
	NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	TOOL
		MININ	U	0	COUNT	UVER	12
	01						(AM A P )
	01				1		SWITC
	01				-		SWITC COUNT CL.R.
	01						SWITC COUNT CLR. SKIP
	01						SWITC COUNT CLR. SKIP TOOL
	01					8 13-51-15	SWITC COUNT CLR. SKIP TOOL WORF

After deletion

c) Delete any serial number in the current page(the parameter switch is ON)



NDI					SUUUU IUI	<u>0</u> 1
00L →	LIFE MANAGEMEN	T			00000 N0000	AD
RRENT	TOOL STATE:					GRO
TOOL	NO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEI
OUP DE	FINED:					ADI TOC
NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	DE
01	0000	0	0	COUNT	OVER	
02	0000	0	0	COUNT	OVER	SWI
	0000	500	0	COUNT	USABLE	
03	0000					
03 04	0000	0	0	COUNT	OVER	COU
03 04	0000	0	0	COUNT	OVER	COU CLE SKI TOO
03 04	0000	0	0	COUNT	OVER	

**Before deletion** 

					20000 101	51
	LIFE MANAGEMEN	1			00080 N0000	ADD
TOOL N	IO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DEL
ROUP DEF	INED:	_		_		ADD TOOL
NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	DEL TOOL
01	0000	0	0	COUNT	OVER	-
02	0000	0	0	COUNT	OVER	SHIT
03	0000	500	0	COUNT	USABLE	COUNI CLR. SKIP TOOL
						*
	-	-		-	# 13-52-35	MORE

After deletion

#### 4. Tool life function use

Command format:

Txx99: end of current used tool group, start the tool and execute the life management in XX group.

Txx88: cancel the tool offset in XX group

Two examples are as follows:

Application example:

O0000 (O0000)	
T0199;	End of previous tool group, and start the tool in 01 group
T0188;	Cancel tool offset in 01 group(current used tool offset)
T0508;	Use No.05 tool and 08 tool offset without life management
T0500;	Cancel No.05 tool offset
T0299;	End of No.05 tool and start the tools in 02 group
 T0199; 	End of tools in No.02 group, start tools in No.02 group, and start the next tool when there are many tools in No.01 group.

#### 5. Tool life count:

When the count result is for the used life value being more than or equal to the setting value of the life data, the next tool group number selects the standby tool in the commanded selection tool group and the new selected tool will be counted, the count will be continuously executed and the system alarms to output to PLC when all tool life in the tool groups reaches and there is no standby tools. Executing the counting in MDI mode is determined by No.002 Bit3 (MDITL).

002		_				MDITL		
MDITL=(	0 Tool	life mana	gement i	s invalid i	n MDI mo	ode.	1	

MDITL=1 Tool life management is valid in MDI mode.

The tool life count has two methods including time and number of times.

#### 1). Time count

Use the time (minute) to count the tool life in cutting feed mode(such as G01, G02, G03, G32, G33, G34 and so on), and do not count it in G00, G04, single block stop, machine lock, auxiliary lock, dry run and so on.

#### 2). Number of times count

There are two methods about the number of times count which is determined by No.002 Bit2 (LIFC).

002				LIFC	
	<b>T</b> 1110	 	 4		

LIFC=0 Tool life management count mode 1

Execute the tool select (Txx99) to change the tool number, execute the count in the cutting feed mode (except for machine lock, auxiliary lock, dry run state). The count is not executed when the tool number is changed and the system is not in the cutting feed mode.

Application example:



LIFC=1 Tool life management count 2 use once in 01 tool group

The tool group adds when the machining program runs to M30(M99), when the system resets halfway, the number of time does not add, the count is not executed in machine lock, auxiliary lock and dry run mode.

#### 6. G, F signals relevant to tool life function

1)Tool change signal TLCH (F064#0)

[Type] output signal

[Function] inform PLC that the last tool life ends of in this group

[Output condition] the signal is set to 1, the last tool life in one group ends, all other tool

life ends.

2)New tool selection signal TLNW (F064 # 1)

[Type] output signal

[Function] inform a new tool in some tool group has been selected

[Output condition] the signal is set to 1 and a new tool in some tool group has been selected.

3)Tool change reset signal TLRST (G048 #7)

[Type] input signal

[Function] clear all execution data

[Operation] when the signal is set to 1, the control unit clears the used tool life data of in all groups; The tool state is reset to the unused.

Note: when the automatic operation signal OP is "0", the tool change reset signal TLRST is valid.

4)Tool skip signal TLSKP (G048#5)

[Type] input signal

[Function] use the following two methods to change the tools which have not reached the life:

- a) When LIFJ (NO.2#4) is set to 1, the selection signals of the tool group number (G47#0~#4) specify the tool group number, then, the tool skip signal TLSKP becomes "1", the next T command skips the tool which is being used of the current group, and the tool which life has not reach in the group specified by G47#0~#4 is used.
- b) When LIFJ (NO.2#4) is set to 0, the group numbers specified by the tool group number signal (G47#0~#4) are invalid, the tool skip signal TLSKP becomes "1", the machine skips to the next tool in the current used tool group.

[Operation] when the signal is set to 1, the operation described in [Function] is executed. Note: When cycle start light signal(STL) and feed pause light signal(SPL) must be "0", inputting TLSKP signal is valid.

5)Tool group number selection signal TL01~TL16 (G47#0~#4)

[Type] input signal

[Function] when TLSKP is input, using the tool group selection signal TL01~TL16 specifies the tool group number with the binary system. The specified tool group number =  $G47#4\sim#0+1$ .

[Operation] specify the selected tool group



#### CHAPTER 3 G COMMANDS

#### 3.1 Commands

G command consists of command address G and its following  $1\sim2$  bits command value, used for defining the motion mode of tool relative to the workpiece, defining the coordinates and so on. Refer to G commands as Fig. 3-1.

G <u>\_\_</u>

G words are divided into 9 groups (00, 01, 02, 03, 06, 07, 12, 14, 16, 21). Except that commands

in the group 01 and 00 are not in the same block, G words in the different groups can be input to the same block and the last one is valid when two or more G words in the same group are input. The words in the different groups without the same parameter (word) can be in the same block and their functions are valid without sequence at the same time. The system alarms when G words do not belong to Table 3-1 or they are optional functions without being supplied.

Word	Group	Function	Remark
G00	01	Rapid traverse movement	Initial modal G command
G01		Linear interpolation	Modal G commands
G02		Circular interpolation(CW)	
G03		Circular interpolation(CCW)	
G05(G5.1)		Three-point circular interpolation	
G6.2		Ellipse interpolation (CW)	
G6.3		Ellipse interpolation (CCW)	
G7.2		Parabola interpolation (CW)	
G7.3		Parabola interpolation (CCW)	
G32		Thread cutting	
G32.1		Rigid thread cutting	
G33		Z tapping cycle	
G34		Variable pitch thread cutting	
G90		Axial cutting cycle	
G92		Thread cutting cycle	
G83		axle drilling cycle	1
G84		End rigid tapping	]
G87	1	radial drilling cycle	
G88		Side rigid tapping	



G94		Radial cutting cycle		
G04		Dwell time preset		
G7.1		Cylinder interpolation		
G10		Data input		
G11		Data input cancel		
G28		Machine reference point automatic return	Non-modal G commands	
G30		Machine 2nd, 3rd, 4th reference point return		
G31		Skip interpolation		
G36		Automatic tool compensation X		
G37	00	Automatic tool compensation Z		
G50	00	Setting workpiece coordinate system		
G52		Setting local coordinate system		
G65			_	
G70		Finishing cycle	_	
G71		Axial roughing cycle		
G72			_	
G73			_	
G74 G75		Radial grooving cycle	_	
G76		Multiple thread cutting cycle	_	
 G78		Enhancement thread cutting cycle		
G20	00	Inch select	Modal G command	
G21	06	Metric select	Initial mode G command	
G96		Constant surface speed ON	Modal G command	
G97	02	Constant surface speed OFF	Initial mode G command	
G98	03	Feed per minute	Initial mode G command	
G99	00	Feed per rev	Modal G command	
G40		Cancel cutter radius compensation	Initial mode G command	
G41	07	Tool nose radius compensation left contour		
		Tool nose radius compensation right	Modal G command	
G42		contour(antion)		
G22	09	Open the stored stroke limit detection 2	Non-modal G command	
G23		Close the stored stroke limit detection 2		
G66		Modal call		
G67	12	Modal call cancel	Modal G command	
G54		Workpiece coordinate system 1		
G55		Workpiece coordinate system 2	_	
G56		Workpiece coordinate system 3	1	
G57	14	Workpiece coordinate system 4	Modal G command	
G58		Workpiece coordinate system 5	1	
G59		Workpiece coordinate system 6		
G09		Exact stop between blocks	Non-modal G command	

G61		Exact stop begins between blocks	
G64		Cancel the exact stop between blocks	
G17		XY plane	Modal G command
G18	16	ZX plane	Initial mode G command
G19		YZ plane	Modal G command
G12.1	21	Polar coordinate interpolation	Non-modal G command
G13.1		Polar coordinate interpolation cancel	

#### 3.1.1 Modal, One-Shot & Initial Mode

G commands are divided into group 00, 01, 02, 03, 06, 07, 16, 21.

After G commands are executed, their defined functions and states are valid until they are changed by others in the same group, which commands are called modal G commands. After the modal G words are executed, and before their defined functions and states are changed, the G command cannot be input again when they are executed by the following block.

The defined function and state are valid one time after G command is executed, and the G word must be input again when it is executed every time, which command is called one-shot G command.

After the system is switched on, the valid modal G commands which are not executed their functions or states are called initial mode G command. Take it as the initial mode G command to be executed when it is not be input after the system is switched on.

#### 3.1.2 Omitting Words

To simplify the programming, their command values are reserved after executing words in Table 3-2. If the words are contained in the previous blocks, they cannot be input when the words are used with the same values and definitions in the following blocks.



Command	Function	Initial value when power-on	
address	Function		
U	Cutting depth in G71	No.51 parameter value	
U	Move distance of X tool retraction in G73	No.53 parameter value	
W	Cutting depth in G72	No.51 parameter value	
W	Move distance of X tool retraction in G73	No.54 parameter value	
R	Move distance of tool retraction in G71, G72 cycle No.52 parameter va		
R	Cycle times of stock removal in turning in G73	No.55 parameter value	
P	Move distance of tool retraction after	No.56 parameter value	
к	cutting in G74, G75		
R	Allowance of finishing in G76	No.60 parameter value	
R	Taper in G90, G92, G94, G96 0		
(G98) F	Feedrate per minute(G98) No.30 parameter va		
(G99) F	Feedrate per rev (G99) 0		
F	Metric pitch(G32, G92, G76) 0		
I	Inch pitch(G32, G92)	0	
S	Spindle speed specified(G97) 0		
S	Spindle surface speed specified(G96) 0		
S	Spindle speed switching value output 0		
Р	Finishing times of thread cutting in G76;	No.57 parameter value	
	Tool retraction width of thread cutting in G76	No.19 parameter value	
	Angle of tool nose of thread cutting in G76;	No.58 parameter value	
Q	Min. cutting value in G76	No.59 parameter value	

Table 3-2

- Note 1: For the command addresses with functions (such as F, used for feedrate per minute, feedrate per revolution and metric pitch and so on), they can be omitted not to input when executing the same function to definite words after the words are executed. For example, after executing G98 F\_ without executing the thread command, the pitch must be input with F word when machining metric thread.
- Note 2: They can be omitted not to input when the address characters X(U), Z(W) are the coordinates of end point of block and the system defaults the current absolute coordinates in X or Z direction to the coordinate value of end point of block.
- Note 3: The corresponding words must be input when the command addresses which are not in Table 3-2 are used.

Example 1:

O0001;	
G0 X100 Z100;	(rapid traverse to X100 Z100; the modal G0 is valid)
X20 Z30;	(rapid traverse to X20 Z30; the modal G0 is not input)
G1 X50 Z50 F300;	(linear interpolation to X50 Z50, feedrate 300mm/min; the modal G1 is valid)
X100;	(linear interpolation to X100 Z50, feedrate 300mm/min; Z coordinate is not input and is the current coordinates Z50; F300 is kept, G1 is modal and is not input)
G0 X0 Z0; M30;	(rapid traverse to X0 Z0 and the modal G0 is valid)

Example 2:				
O0002;				
G0 X50 Z5;	(rapid traver	(rapid traverse to X50 Z5)		
G04 X4;	(dwell 4 sec	(dwell 4 seconds)		
G04 X5;	(dwell 5 sec	(dwell 5 seconds again, G04 is non-modal and is needed to input again)		
M30;				
Example 3 (the firs	t run after power	-on) :		
O0003;				
G98 F500 G01 X100 Z100;		(Feedrate per minute 500mm/min in G98)		
G92 X50 W-20 F2 ;		(F value is a pitch and must be input in thread cutting)		
G99 G01 U10 F0.01		(Feedrate per revolution in G99 must be input again)		
G00 X80 Z50	M30;			

#### 3.1.3 Related Definitions

In the user manual, the definitions of Word are as follows except for the especial explanations: Starting point: position before the current block runs;

End point: position after the current block ends;

X: X absolute coordinates of end point;

U: different value of absolute coordinates between starting point and end point;

Z: Z absolute coordinates of end point;

W: different value of absolute coordinates between starting point and end point; F: cutting feedrate.

#### 3.2 Rapid Traverse Movement G00

**Command format:** G00 X(U) \_\_\_\_ Z(W) \_\_\_;

**Command function:** X, Z rapidly traverses at the respective traverse speed to the end points from their starting point. G00 is initial command as Fig.3-1.

X, Z traverses at the respective traverse speed, the short axis arrives the end point and the length axis continuously moves to the end point and the compound path may be not linear.

Command specification: G00 is initial mode;

X, U, Z, W range: ±99999999x least input increment;

Can omit one or all command addresses X(U), Z(W). The coordinate values of starting point and end point are the same when omitting one command address; the end point and the starting point are in the same position when all are omitted. X, Z are valid, and U, W are invalid when X, U, Z and W are in the same one block. X, U, Z, W rang is referred to Table 1-2 of Section 1.4.1, unit: mm//inch.

#### Command path:





The respective rapid traverse speed of X, Z is defined by the system parameter No.022, No.023, and their traverse speed can changed by rapid override key on the machine control panel.

Example: The tool rapidly traverses to B from A as Fig. 3-2.





(absolute programming) G0 X20 Z25; G0 U-22 W-18; (incremental programming) G0 X20 W-18; (compound programming) G0 U-22 Z25; (compound programming)

#### 3.3 Linear Interpolation G01

**Command format:** G01  $X(U) = Z(W) = F_{;}$ 

Command function: The movement path is a straight line from starting point to end point as Fig.3-3.

#### Command specification: G01 is modal.

Can omit one or all command addresses X (U), Z (W). The coordinate values of starting point and end point are the same when omitting one command address; the end point and the starting point are in the same position when all are omitted. X, U, Z, W rang is referred to Table 1-2 of Section 1.4.1, unit: mm//inch.

F command value is the vector compound speed of X and Z instantaneous speed and the actual cutting feedrate is the product between the feedrate override and F command value.

After F command value is executed, it has been reserved unless the new one is executed. Do not repeat it when the following G commands adopt functions of F word. Its range is referred to Table 1-2 of Section 1.4.1.

Note: In G98, F max. value cannot exceed the value set by the data parameter No.027(upper speed of cutting feed), otherwise, the system alarms.

Command path:



Example: Cutting path from  $\Phi$ 40 to  $\Phi$ 60 as Fig.3-4:



Fig. 3-4

#### 3.4 Circular Interpolation G02, G03

Command format:



#### **Command function:**

G02 movement path is clockwise (rear tool post coordinate system)/counterclockwise (front tool
post coordinate system) arc from starting point to end point as Fig. 3-5.

G03 movement path is counterclockwise (rear tool post coordinate system/clockwise (front tool post coordinate system) arc from starting point to end point as Fig. 3-6.

## Command path:



## **Command specification:**

G02, G03 are modal,

R is arc radius, range: ±99999999× least input increment;

I: X difference value between circle center and starting point of arc in radius;

K: Z difference value between circle center and starting point of arc;

Center point of arc is specified by address I, K which separately corresponds to X, Z, I, K expresses the vector (it is the increment value) from starting point to center point of arc as the following figure; I=Coordinates of center point-that of starting point in X direction; K= Coordinates of center point-that of starting point in Z direction;

I, K are with sign symbol. When directions of I, K are the same as those of X, Z, they are positive, otherwise, they are negative.

X, U, Z, W, R, I, K range is referred to Table 1-2 of Section 1.4.1, unit: mm/inch.



Arc direction: G02/G03 direction (clockwise/counterclockwise) is opposite on the front tool post coordinate system and the rear one as Fig.3-8:





### Notes:

- When I = 0 or K = 0, they can be omitted; one of I, K or R must be input, otherwise the system alarms.
- R is valid and I, K are invalid when they are input at the same time.
- R value must be equal to or more than half distance from starting point to end point, and the system alarms if the end point is not on the arc defined by R command;
- Omit all or one of X(U), Z(W); coordinates of starting point and end point of this axis are the same when omitting ones, the path is a full circle(360°) in G02/G03 when center point are specified by I,K; the path is 0(0°) when center point is specified by R.
- R should be used for programming. The system executes in  $R = \sqrt{I^2 + K^2}$  to ensure starting point and end point of arc path are the specified ones in I, K programming.
- When the distance from center point to end point is not equal to  $R(R = \sqrt{I^2 + K^2})$  in I,K programming, the system automatically adjusts position of center point to ensure starting point and end point of arc path are the specified ones; When the distance from center point to end point is more than 2R, and the system alarms.
- Arc is less than 360° when R is commanded, the arc is more than 180° when R is negative, and it is less than or equal to 180° when R is positive.
   Example: Arc cutting path from Φ45.25 to Φ63.06 shown in Fig. 3-9.

G02 X63.060 Z-24.071 R19.16 F300; or

G02 U17.701 W-24.071 R19.16 F300; or G02 X63.060 Z-24.071 I17.785 K-7.124; or

G02 U17 701 W-24 071 I17 785 K-7 124 F300





Program:

Compound programming in G02/G03:



Fig. 3-10 Circular programming example

Program: O0001 N001 G0 X40 Z5; N002 M03 S200; N003 G01 X0 Z0 F900; N005 G03 U24 W-24 R15; N006 G02 X26 Z-31 R5; N007 G01 Z-40; N008 X40 Z5; N009 M30;

(Rapidly traverse) (Start spindle) (Approach workpiece) (Cut R15 arc) (Cut R5 arc) (Cut φ26) (Return to starting point) (End of program)

# 3.5 Three-point Circular Interpolation G05, G05.1

Command format: G05(G05.1) X(U) Z(W) I K F\_
 Command function: when you do not know positions of the circular center of arc and the radius but coordinates of three points on the arc, you can use G5 to confirm the arc direction through the middle position between the initial point and end point.

## Command specification: G05(G05.1) is modal;

- I: incremental coordinate value(X) (radius value, direction) of the middle point where the circular passes corresponding to the starting point, range: ±99999999x least input increment;
- K: incremental coordinate value(Z, direction) of the middle point where the circular passes corresponding to the starting point, range: ±99999999x least input increment;
- X, U, Z, W, R, I, K range is referred to Table 1-2 of Section 1.4.1, unit: mm/inch.



Fig. 3-11 G05 code Middle point



## Notes:

- 1) Middle point: any one point except for the starting point and end point on the arc;
- 2) The system alarms when the three points are in the same line;
- 3) I=0 when it is omitted, K=0 when it is omitted; the system alarm when they are omitted simultaneously;
- 4) The meanings of I, K I are similar to their displacement values of the circle center coordinates corresponding to starting point ones in G02/G03;
- 5) G05 does not execute the whole circle machining;

Example: (machining semi-circle)



#### Ellipse Interpolation G6.2, G6.3 3.6



-X(U)\_\_\_Z(W)\_\_\_A\_\_B\_\_Q\_\_ G6.3

Command function: G6.2 motion path is the CW(rear tool post coordinates)/CCW(front tool post coordinates) ellipse.

G6.3 motion path is the CCW(rear tool post coordinates)/CW(front tool post coordinates) ellipse.

Command path:





Fig. 3-15 G6.2 path sketch map

Fig. 3-16 G6.3 path sketch map

## **Explanation:**

- A: Length of ellipse's long radius (0<A<= 99999.999mm, no sign )
- B: Length of ellipse's short radius (0<B<= 99999.999mm, no sign )
- Q: angle between the long axis and Z coordinate system of ellipse (CCW 0-999999999, unit: 0.001°)

Ellipse direction: defined by that of G6.2/G6.3, they are the reverse in the front and rear tool post coordinates.



Fig. 3-17 Front tool post coordinate system



Fig. 3-18 Rear tool post coordinate system

## Q value:

1) In the G18 plane, Q value is the gained viewing XZ plane along with the positive direction of Y axis in the Cartesian right-hand coordinate system, as well, it is an angle when the Z axis positively rotates to the the overlapping with the ellipse long axis along with the CW; refer to the following figure:



.

As for the above-mentioned four coordinates (Front tool-post), angle a is the symmetry axis based upon that it rotates to ellipse along with the Z axis CCW.



As for the above-mentioned four coordinates (Back tool-post), angle a is the symmetry axis based upon that it rotates to ellipse along with the Z axis CW.

Fig. 3-19

2) In the G17 panel, refer to the following figure:





As for the above-mentioned four coordinates (Front tool-post), angle a is the symmetry axis based upon that it rotates to ellipse along with the X axis CCW.



As for the above-mentioned four coordinates (Back tool-post), angle a is the symmetry axis based upon that it rotates to ellipse along with the X axis CW.

Fig. 3-20

3) In the G19 plane, refer to the following figure:



As for the above-mentioned four coordinates (Front tool-post), angle a is the symmetry axis based upon that it rotates to ellipse along with the Y axis CCW.



As for the above-mentioned four coordinates (Back tool-post), angle a is the symmetry axis based upon that it rotates to ellipse along with the Y axis CW.

Fig. 3-21

### Notes:

1) A, B are not modal parameter. They are 0 when they are not input. When A=0 or B=0, the system

alarms; when A=B, G02/G03 is executed to machine the circular;

- 2) Q value is a non-modal parameter, and it must be specified when it is used. When it is omitted, it is 0°, the long and the short axis are parallel or coincident ;
- Q unit is 0.001°, the angle between it and Z is 180°. When Q 180000 is input, Q180 or Q180.0 is input, they are 0.18°;
- 4) The angle defined by Q value is an angle along Z axis in G18 panel, it is an angle along Y axis in G19, an angle along X axis in G17.
- 5) When the distance between the starting point and end point is longer than the long axis, the system alarms;
- One or both of X(U), Z(W) can be omitted; omitting one of them indicates that the starting point and the end point of the axis are consistent; omitting the both indicates they are the same one;
- 7) Only machines the ellipse which is less than 180° (including 180°);
- G6.2/G6.3 are used to the compound cycle G70—G73, and their notes are the same those of G02, G03;
- 9) G6.2, G6.3 are used to C tool compensation.

Example: machine from Φ43.14 to Φ63.82:





Example: machine from  $\Phi$ 43.14 to  $\Phi$ 63.82:



Program:

G6.2 X63.82 Z-50.0 A48 B25 Q60000; or G6.2 U20.68 W-50.0 A48 B25 Q60000;

Fig. 3-23

G6.2/G6.3 compound program example :





Program: O0001
 N001 G0 X60 Z5;
 N002 M03 S200;
 N003 G01 X24.24 Z0 F100;
 N005 G6.3 X40 W-35 A44 B20;
 N006 G01 X32 Z-60;
 N007 Z-79;
 N008 G0 X60
 N009 Z5;
 N0010 M30;

(rapidly position) (spindle ON) (approach the workpiece) (cutting A44 B20 ellipse block)

(return to the starting point) (end of program)

# 3.7 Parabola Interpolation G7.2, G7.3

**Command function:** G7.2 motion path is the CW (rear tool post coordinates)/CCW(front tool post coordinates) parabola.

G7.3 motion path is the CCW (rear tool post coordinates)/CW(front tool post coordinates) parabola.

Command path:





G7.2, G7.3 are modal;

P is in the parabola standard equation  $Y^2=2PX$ , its range:  $1 \sim 9999999$ (unit: 0.001mm, without sign);

Q is the angle between the symmetrical axis of parabola and Z, and its range:  $0 \sim$  99999999 (unit: 0.001°).

**Parabola direction:** G7.2/7.3 interpolation directions in the front tool post coordinate system and the rear are reverse.



Fig. 3-27 Front tool post coordinate system



Fig. 3-28 Rear tool post coordinate system

### Q value:

1) In the G18 plane, Q value is the gained viewing XZ plane along with the positive direction of Y axis in the Cartesian right-hand coordinate system, as well, it is an angle when the Z axis positively rotates to the the parabola with the ellispse long axis along with the CW; refer to the following figure:





Fig. 3-29

2) In the G17 plane, Q value is the gained viewing XY plane along with the positive direction of Z axis in the Cartesian right-hand coordinate system, as well, it is an angle when the X axis positively rotates to the the parabola with the ellispse long axis along with the CW; refer to the following figure:



As for the above-mentioned four coordinates (Front tool-post), angle a is the symmetry axis based upon that it rotates to parabola along with the X axis CCW.



As for the above-mentioned four coordinates (Back tool-post), angle a is the symmetry axis based upon that it rotates to parabola along with the X axis CW.

Fig. 3-30

3) In the G17 plane, Q value is the gained viewing ZY plane along with the positive direction

of X axis in the Cartesian right-hand coordinate system, as well, it is an angle when the Y axis positively rotates to the the parabola with the ellispse long axis along with the CW; refer to the following figure:



As for the above-mentioned four coordinates (Back tool-post), angle a is the symmetry axis based upon that it rotates to parabola along with the Y axis CW.

### Fig. 3-31

### Notes:

1) P cannot be 0 or omitted, otherwise the system alarms;

2) P has no sign. If it has the negative sign, its absolute value is executed;

3) Q can be omitted, at the time; the symmetrical axis of the parabola is parallel with or coincident with Z;

4) The system alarms when the straight line on which the starting point and the end point is parallel with the symmetrical axis of the parabola;

5) G7.2, G7.3 can be used to the compound cycle G70 $\sim$ G73, and their notes are the same those of G02, G03;

Example: when the parabola P=100(the least increment is 0.0001mm), its symmetrical axis is parallel with Z. Its machining sketch map and programming are as follows:



Program: O0001(O0001) G00 X120 Z100 T0101 M03 S800; G00 X10 Z10; G00 X0; G01 Z0 F120 M08; X30; G7.3 X60 Z-40 P10000 Q0; G01 X90 Z-60; X110 Z-85; X120; M09; G00 X120 Z100 M05 S0; M30;

Fig.3-32

# 3.8 Plane Selection G17~G19

## Command format:

G17.....XY plane G18.....ZX plane G19.....YZ plane

**Command function:** use G commands to select the plane of the arc interpolation or the one of the cutter compensation

**Command explanation:** G17, G18, G19 are modal, and the plane does not change in the block without the command.

## Notes:

- 1) Firstly set the basic axis Y when the system selects G17, G19 plane;
- 2) Cannot switch the planes in C tool compensation;
- 3) G71~G76, G90, G92, G94 can be used in G18 plane;
- 4) The plane selection code can be in the same block with G codes in the other groups;
- 5) The movement command is not relevant to the plane selection;
- 6) Diameter or radius programming: currently, because there is only one bit parameter No 1.2 to select the diameter or the radius programming and is valid to only X axis, Z and Y axis use the only radius programming in G2, G3, and X axis is selected by the parameter;
- 7) The tool nose direction of C tool compensation is 0 in G17, G19.
- Angel Q in the oval and parabola command, in G18 panel, it is an angle along Y axis in G19, an angle along X axis in G17.

# 3.9 Polar Coordinate Interpolation G12.1, G13.1

**Command format:** G12.1----start polar coordinate interpolation method- (can be written to G112) --- (1)

G98 G01 X\_ C\_ G04 X\_ G41/G42 G1 X\_ C\_ G6.2/G6.3 X\_ C\_ A\_ B\_ Q\_ G7.2/G7.3 X\_ C\_ A\_ B\_ Q\_ G05 X\_ C\_ I\_ G02/G03 X\_ C\_ R\_ G40 G1 X\_ C\_ G65/G66/G67

G13.1----cancel polar coordinate interpolation method- (can be written to G113) --- (3)

**Command function:** Polar coordinate interpolation is a function that exercises contour control in converting a command programmed in a Cartesian coordinate system to the movement of a linear axis (movement of a tool) and the movement of a rotary axis (rotation of a workpiece). This method is useful in cutting a front surface and grinding a cam shaft on the machine.

Command explanation: G12.1, G13.1 are non-modal

Linear axis: X or Z, Y or 4<sup>th</sup> or 5<sup>th</sup> axis

Rotary axis: axes except for feed axis(Y or 4<sup>th</sup> or 5<sup>th</sup> axis)

Before starting the polar coordinate, set the linear axis and the rotary axis by No.235 and No.236.

Taking example of the linear axis X and the rotary axis 5<sup>th</sup>.

Polar coordinate interpolation plane: G12.1 starts the polar coordinate interpolation mode and selects a polar coordinate interpolation plane(below), and the polar coordinates are completed in the plane.



Fig.3-33 Polar coordinate interpolation plane

Note1: After G12.1 is used, the previous plane is cancelled and the system enters the polar coordinate interpolation plane, and after G13.1 is used, the plane is cancelled and the previous is recovered;

Note 2 : After the system resets, it cancels the polar coordinate interpolation and recovers the previous plane, and the cursor returns to the beginning of the program.

**Programming format:** create the rectangular coordinate system in the polar coordinate interpolation plane below:

# **CNCmakers**



Specified position

Current position

X: distance of linear axis, unit: mm/inch;

C: distance of rotary axis, unit: mm/inch;

The linear axis can use the diameter programming and the rotary axis uses only the radius;

The polar coordinates in the polar coordinate interpolation plane is prepared below:

X: length between current tool and the origin, its unit: mm/inch;

C: angle unit of current rotary axis: deg;

G16 is the polar coordinates of current coordinates being complied, and G15 is to cancel it. The Cartesian coordinate system is used without G16. G16/G15 is valid in the only polar coordinate interpolation.

The radius programming is applied to the linear axis and the rotary axis below:

•Length compensation: the length compensation is not applied to the rotary axis, and the length offset should be command before G12.1 mode, and cannot be changed in the polar coordinate interpolation.

•Tool radius compensation: the tool nose direction is 0.

•Machine motion: the linear axis is vertical to the rotary axis.

•Circular interpolation in the interpolation plane: the address of the arc radius is determined by

the 1st axis(linear axis) in the interpolation plane.

• When the linear axis is X or its parallel axis, I and J are used in Xp-Yp plane

• When the linear axis is Y or its parallel axis, J and K are used in Xp-Zp plane

• When the linear axis is Z or its parallel axis, K and I are used in Zp-Xp plane

The arc radius can also use R command.

•Command speed: tangential speed in the polar coordinate plane.

When the tool approaches the center of the workpiece, the speed component of C axis exceeds its maximum cutting federate (set by No.27). F value is calculated by the followings:

L: the distance (mm) between the center of the tool and that of the workpiece

**R**: maximum cutting feedrate of C axis (deg/min)

Conclusion:  $F \le L x R x \pi / 180 (mm/min)$ 

It is suggested that the workpiece should not be machined near the polar because the feedate override must be changed in some occasion to avoid the overload of the rotary axis.

• Movement along the axis in the non polar coordinate interpolation plane in the polar coordinate interpolation mode: The tool traverses normally along these axes and is not relevant

to the polar coordinate interpolation, the parameter specifies one axis to execute the polar coordinate interpolation before executing the polar coordinate interpolation, the axis which does not specify the polar coordinate can moves along the normal path in G00 or G01, but the axis which polar coordinate is not specified is disabled (i.e. the block is ignored and the axis does not move) in arc or ellipse command.

Radius

Angle

• **Coordinates display:** After G12.1 is executed, the absolute coordinates, the machine coordinates and the incremental coordinates display the actual position of the tool, the remaining distance to move in a block is displayed based on the coordinates in the polar coordinate interpolation plane, and after G13.1 is executed or the reset is done, the coordinates in the current system plane is displayed.

Note 1: G12.1, G13.1 are in Group 21, G12.1, G13.1, G16, G15 are in a separate line.

- Note 2: The tool change cannot be executed in G12.1-G13.1, the tool change operation and the positioning followed by the tool change must be performed before G12.1.
- Note 3: The system cannot start the polar coordinate interpolation during C tool compensation or in G99, otherwise, it alarms.

Note 4: When G12.1 is commanded, the tool position of the polar coordinate interpolation is at the angle of 0. 5) It is necessary to firstly perform the length offset value before starting it; otherwise, the alarm may occur.

Example:



# 3.10 Cylindrical Interpolation G7.1

**Command function:** The amount of travel of a rotary axis specified by an angle is once internally converted to a distance of a linear axis along the outer surface so that linear interpolation or circular interpolation can be performed with another axis. After interpolation, such a distance is converted back to the amount of travel of the rotary axis. The cylindrical interpolation function allows the side of a cylinder to be developed for programming (below).





## Command format:

Type I G07.1 C(c); (1) starting the cylindrical interpolation ... (2) ... G7.1 C0; (3) cancel the cylindrical interpolation



Code meaning: Code devides into 3 sections:

(1): Provide a column radius, the column interpolation begins;

(2): Provide the block of the its section of the defined finish-turning path or the finish-turning residual;

(3): Cancel the column interpolation

There are two programming types of cylinder interpolation,  $J(\Delta i)$ , L(d),  $R(\Delta d)$  and  $K(\Delta u)$  settings are not desired for the type I; the system operates based upon the block of the finish-turning path. Type II is the circular interpolation cycle; System is automatically calculated the rough-turning offset value, single feed value and path based upon the data such as the finih-turning allowance, total cutting value and cutting times, etc. The path of each cutting is the offset of the finishing-turning path, the cutting path is gradually closed to the path of the finish-turning, the last cutting path is the finish-turning one.

## **Command explanation:**

Cc: the radius of the cylinder;

Radius  $\neq 0$ : starts the cylindrical interpolation mode

Radius=0: cancels the cylindrical interpolation mode

its range: 0~999999999xleast input increment (unit: mm/inch)

- J(Δi): Total cutting value along X axis in the rough-turning,its range:±999999999vleast input increment(unit: mm/inch, diameter, with sign, when the symbol is positive, X axis infeeds along with the positive direction; when the symbol is negative, X axis infeeds along with the negative direction), type I setting does not desire;
- R(<u>Δd</u>): Tool-retraction value along X axis in the rough-turning, its range:±99999999×least input increment(unit: mm/inch, diameter, without sign symbol), type I setting does not desire;
- K(Δu): Finish-turning allowance along X axis, its range:-99999.999~99999.999(IS\_B) /-9999.9999~9999.9999(IS\_C) (unit: mm/inch, diameter, without sign symbol), the last rough-turning path offsets related to the X axis coordinate of the finish-turning, type I setting does not desire;

L(d): Cutting times (without including the finish-turning path) ,its range:1~9999 (unit: times), L5 means that the rough cutting cycle is completed for 5 times, the  $6^{th}$  times is finish turning cycle. If the cutting times is 1, the system will complete the rough cutting cycle based upon 2 times. Type I setting does not desire.

### Code path explanation: (Type II)

- 1) X axis rapidly moves to cycle start G from start point F;
- X axis is performed the feedrate to An point, in-feed value is Δd+n×Δu, which is performed the circular interpolation along with the path of the An->Bn->Cn->Dn (Note: n is the n<sup>th</sup> times cycle, the resolution n=1, 2, 3...)
- 3) X axis rapidly retreats to point E along  $Dn \rightarrow E$  path
- Tool returns to the cycle start G along E->G path (Note: X, Z and C axes are returned to the cycle start);
- 5) Repeated steps 2), till to the machining allowance along X axis is 0;



Fig.3-36

### Note:

1)G7.1 is non-modal;

- 2) The cylindrical interpolation mode is cancelled in power-on and reset;
- 3) The rotary axis executes a program by an angle, a rolling function of a rotary axis in the cylindrical interpolation mode will be automatically invalid, and a programming command value must be more than 360<sup>0</sup> when the interpolation range is more than one circle;
- 4) The tool nose radius compensation G41, G42 can be executed and their tool nose directions are 0;
- 5) A feedrate specified in the cylindrical interpolation mode is a speed on the developed cylindrical surface, its unit: mm/min or inch/min
- 6) In the cylindrical interpolation mode, the linear G1, the arc G2, G3 (arc radius is specified by R, its unit is mm or inch), ellipse G6.2, G6.3, parabola G7.2, G7.3 interpolation;
- 7) G00 positioning operation cannot be executed in a cylindrical interpolation mode;
- 8) Before executing the cylindrical interpolation mode, the tool nose radius compensation mode which is being executed is cancelled, the tool compensation is started or completed in a cylindrical interpolation mode;
- 9) Miscellaneous function T cannot be used in the cylindrical interpolation mode;
- 10) The feedrate in the cylindrical interpolation mode specifies G98(feed per minute);
- 11) G50 setting workpiece coordinate system in the cylindrical interpolation mode cannot be used;
- 12) A rotary axis and a linear axis of only current cylinder in the cylindrical interpolation is specified;
- **Plane selection:** Before a cylindrical interpolation, the plane where the interpolation is should be selected firstly, one axis in the plane is a linear axis in the cylindrical interpolation and another is a corresponding linear axis of the developed rotary axis (below).



② The rotary axis is set to X or its parallel axis in the cylindrical interpolation mode:



③ The rotary axis is set to Y or its parallel axis in the cylindrical interpolation mode:



(4) The rotary axis is set to Z or its parallel axis in the cylindrical interpolation mode:



### Fig.3-40

## **Relative parameters:**

Only rotary axis is specified in the cylindrical interpolation, and it can be a basic axis or an axis parallel to the basic axis. The axis name of three additional axes are set by NO.225, NO.226, NO.227 (Y: 89, A: 65, B: 66, C: 67), the attribute of an axis is set by NO.230, NO.231, NO.232 (see the following table).

Setting value	Meaning
0	It is not three basic axes and their parallel axis
1	X of three basic axes
2	Y of three basic axes
3	Z of three basic axes
5	An axis parallel to X axis
6	An axis parallel to Y axis
7	An axis parallel to Z axis

## Example:

No. 224 is set to 5, the cylindrical interpolation is executed in G18 plane, and the rotary axis of the cylindrical interpolation is set to the  $5^{th}$  axis (state parameter P187). The axis name of the  $5^{th}$  is C (data parameter No. 225), the axis is one parallel to X axis (NO.230). The radius of the cylinder is 57.299mm, and the developed cylindrical surface is shown below:

O0071 (taking example of the cylindrical interpolation G7.1)

# **CNCmakers**



Note: In the programming example of the type II, the overall cutting value is 10mm, the finish machining residual is 0.25mm, tool is 2mm distant from the workpiece along with X direction, the rough-turning cycle times is 4, finish-turning cycle times is 1; tool retreats from the start position (116.598,105,0) after the rough-tuning cutting is performed each time.

## 3.11 Chamfering Function

Chamfering function is to insert one straight line or circular between two contours to make the tool smoothly transmit from one contour to another one. GSK980TDi uses the linear and circular chamfering functions.

## 3.11.1 Linear Chamfering

Linear chamfering: insert one straight line in the linear contours, arc contours, linear contour and arc contour. The command address of linear chamfering is L, behind which data is the length of chamfering straight line. The linear chamfering must be used in G01, G02 or G03 command. Linear chamfering divides into two types, two types are mainly distinguished from the different definitions of the command value L in the program, one is L chamfering length, the other is length between the chamfering point and intersection point, which can be selected by state parameter No.181.0. In the following explanation, type I represents that L is chamfering length; type II is the length between the chamfering point and intersection point.

### 1). Linear to linear

Command format: G01 X(U)\_ Z(W)\_ L\_; G01 X(U)\_ Z(W)\_;

**Command format:** Insert a section of linear block between two straight line interpolation. **Command function:** insert one straight line between two linear interpolation blocks.





Command function: insert one straight line between the linear and circular interpolation blocks.





3). Circular to circular

Command format:	G02/G03	X(U)_	Z(W)_	$R_{-}$	L_;	
	G02/G03	X(U)_	Z(W)_	$R_{-}$	;	
	Or					
	G02/G03	X(U)_	Z(W)_	I_	K_	L_;
	G02/G03	X(U)_	Z(W)_	I_	K_;	

Command function: insert one straight line between two circular interpolation blocks.



block.



# 3.11.2 Circular Chamfering

Circular chamfering: insert one circular between linear contours, circular contours, linear contour and circular contour, the circular and the contour line are transited by the tangent. The command of circular chamfering is D, and the data behind the command is the radius of chamfering circular. The circular chamfering must be used in G01, G02 or G03.

## 1). Linear to linear

Command format: G01 X(U)\_ Z(W)\_ D\_; G01 X(U)\_ Z(W)\_;

**Command function:** insert one circular between two straight lines, the inserted circular block and two straight lines are tangent, the radius is the data behind the command address D.



2). Linear to circular

**Command function:** insert one circular between linear and circular, the inserted circular is tangent to the linear and the circular, and the radius is the data behind the command address D.

R Tangential point D Tangential point 3). Circular to circular Command format: G02/G03 X(U)\_ Z(W)\_ R\_ D\_; G02/G03 X(U)\_ Z(W)\_ R\_; or G02/G03 X(U)\_ Z(W)\_ R\_ D\_; G02/G03 X(U)\_ Z(W)\_ I\_ K\_; or G02/G03 X(U)\_ Z(W)\_ I\_ K\_ D\_; G02/G03 X(U)\_ Z(W)\_ I\_ K\_; or G02/G03 X(U)\_ Z(W)\_ I\_ K\_ D\_; G02/G03 X(U)\_ Z(W)\_ R\_;

**Command function:** insert one circular between two circular blocks, the inserted circular is tangent to the two circular blocks, and the radius is the data behind the command address D.



the radius is the data behind the command address D.



# 3.11.3 Special Cases

The chamfering function is invalid or alarms as follows:

### 1) Linear chamfering

Case 1. The chamfering function is invalid when two interpolation straight lines are in the same linear.



Case 2. CNC alarms when the chamfering linear is too long.

L1 i is the chamfering linear, and the length is  $L_1$ ;  $I_2$  is the third edge of the triangle which is formed by two interpolation straight lines, the length is  $L_2$ , CNC alarms when  $L_1$  is bigger than  $L_2$  as follows:



Case 3. Some linear block is too short

The chamfering linear length is L, CNC alarms when other end of the caculated chamfering linear is not in the interpolation linear(in the extension line of the interpolation linear).



#### 2) Circular chamfering

Case 1. The circular chamfering function is invalid when two interpolation straight lines are in the same block.





Case 2. CNC alarms when the chamfering circular radius is too big.

CNC alarms when the chamfering circular radius is D, max. circular radius of the tangential linear lines is R<sub>max</sub> which is less than D as follows.



Case 3. The circular chamfering function is invalid when the linear and the circular, or the circular and the linear are tangential.



Case 4. The circular chamfering function is invalid when one circular and another one are tangential.

The circular chamfering function is valid when the circular tangency is as follows:



# 3.12 Exact Stop Function Between Blocks

 

 Command format:
 G09 G61 G64
 .....

 Command
 Command specification

 G09
 the programmed axis of a block must exactly stop at the end point of the block, and the system continuously executes a next block., Non-modal G commands

<b>C61</b>	The blocks included the overall motions between the current block and the G64
901	are exactly performed, and then execute the next block, modal command.
G64	Cancel the G61 modal.

### Note:

- 1) G09, G61/G64 are disabled in the G71, G72 and G73 cycle procedure;
- 2) G09 is only enabled to the current block, if the cutting command generates in the block of the G09, execute the next block after this block is exactly stopped; if the cutting command does not generate in this block, the next block will not perform the exact stop;
- When the current parameter №0007.5 sets to "1", modal information column is fixedly displayed as G61, and the G64 shows disabling;
- 4) When the current parameter №0007.5 sets to "1", the G61/G64 position in modal information column is immediately displayed as G61; when the current parameter №0007.5 sets to "0", the G61/G64 position in modal information column is immediately displayed as G64, and then enters to the smooth state between the blocks.
- 5) When G64 are shared a block with cutting command, the G64 locates at the block which is cancelled the exact-stop in-position;
- 6) When G09, G64 and G61 are shared with a same block, the last G code is enabled;
- 7) Perform G64 code or power-on again, G61 modal is being cancelled.

### G09 code application example:

After the motion command of the block of the G09 command is performed, the next block command is then performed. The N2 block of the program 1 does not add the G09 command, smoothly transit between N2 block and N3 block; refer to the path in the Fig. 3-42. The N2 block of the program 2 adds G09 command. The command of N3 can be performed till the motion command of the N2 block is performed; refer to the path in Fig. 3-43.

Program 1: Program path is shown in the Fig. 3-42.



Fig. 3-43

### G61, G64 code application example:

G61 is modal command, the next block can be performed after the overall motion blocks between G61 and G64 are executed. There is G61 command in the program 3, smoothly transit between two blocks, and refer to the Fig. 3-44. The N2 block of the program 4 adds G61 command, N7 block adds G64 command, and therefore, after the overall motion blocks between N2 block and N7 block are performed, the next block is then executed; refer to the Fig. 3-45.

Program 3: Program path is shown as Fig.







# 3.13 Function of Directly Inputting Graphic Dimension

The function of directly inputting graphic dimension can make the user directly use the linear angle, chamfering value in the machining drawing to program.

**Command format:** Drawing dimension direct input function is only used the linear interpolation (G01), can specify the plane in G17 plane (XY plane), G18 plane (XZ plane), G19 plane(ZY plane). Taking example of G18 plane(XZ plane), the format changes when G17/G19 plane command is used:

G17 plane: "Z" $\rightarrow$ "X", "X" $\rightarrow$ "Y"

G19 plane: "Z" $\rightarrow$ "Y", "X" $\rightarrow$ "Z"

	Command format	Command path
1	G01 X2_ (Z2_) Q_	X (X2, Z2) (X1, Z1) Z
2	G01 Q1_ G01 X3_ Z3_ Q2_	$\begin{array}{c} \mathbf{X} \\ \mathbf{(X3, Z3)} \\ \mathbf{(X2, Z2)} \\ \mathbf{(X1, Z1)} \\ \mathbf{Z} \end{array}$
3	G01 Q1_ L_ G01 X3_ Z3_ Q2_	$\begin{array}{c} X \\ (X3, Z3) \\ Q2 \\ L \\ (X2, Z2) \\ (X1, Z1) \\ Z \end{array}$
4	G01 Q1_ D_; G01 X3_ Z3_ Q2_;	$\begin{array}{c} X \\ (X3, Z3) \\ Q2 \\ (X2, Z2) \\ (X1, Z1) \\ Z \end{array}$
5	G01 Q1_ L1_ G01 X3_ Z3_ Q2_ L2_ G01 X4_ Z4_	$\begin{array}{c} \mathbf{X} \\ \begin{array}{c} \mathbf{L}^{2} \\ (\mathbf{X}3, \mathbf{Z}3) \\ \hline \\ \mathbf{Q}^{2} \\ \mathbf{L}^{1} \\ (\mathbf{X}2, \mathbf{Z}2) \\ \mathbf{L}^{1} \\ (\mathbf{X}1, \mathbf{Z}1) \\ \mathbf{Z} \end{array}$







Fig. 3-46 Rear tool post coordinate system

Fig. 3-47 Front tool post coordinate system

Note:

 G00 and G01 commands are used for the drawing dimension direct input function; however, G00 only performs the positioning when using drawing dimension direction input function of the G00;

- 2) Prevent the excessive distance from calculating, in the command format 1, the angle tolerance value of the calculation intersection is  $\pm 1^{\circ}$  (Q value converts into  $0^{\circ} \sim 360^{\circ}$ ).
- 3)  $X_Q$  (If the angle Q (0° or 180°) value is within (0° or 180°) ±1°, the alarm may occur.)
- 4)  $Z_Q$  (If the angle Q (90° or 270°) value is within (0° or 180°) ±1°, the alarm may occur.)
- 5) When the intersection is calculated, the alarm may generate if the angle difference composes of two straight lines between ±1.
- 6) In a movement block following with the block which only specifies an angle command of which the coordinate (absolute command) and angle command values should be specified.

(Example):

N1 X\_ Q\_

N2 Q\_

N3 X\_ Z\_ Q\_

An absolute command value and angle command Q along the X or Z axis should be specified in N3 block; otherwsie, the alarm may occur.

- 7) In the consecutive drawing dimension direct input command, the G04 and the M, S and T blocks can be inserted, however, if there are 2 or more blocks are inserted, the alarm may occur.
- 8) In the copound canned cycle, use the program of the drawing dimension direct input between the sequence numbers specified by P or Q; however, the block specified by Q sequence number can not be stopped in the middle of consecutive drawing dimension direct input command.

## 3.14 Dwell G04

Command format:  $G04 P_Q$ ; or

**Command function:** each axis stops the motion, the modal of G commands and the reserved data, state are not changed, and execute the next block after dwelling the defined time. Within the G04 dwell time, receive the skip signal (it is determined by Q value), intermit the dwell and then perform the next block.

Command specification: G04 is non-modal.

G04 dwell time is defined by the word P\_\_, X\_\_ or U\_\_.

P Range is -99999999~99999999 (unit: ms).

X, U range is -9999.999~9999.999 (unit: s)

Q: Skip signal address selection, solution range  $1 \sim 4$ ,

### Notes:

- The system exactly stop a block when P, X, U, Q are not input.
- When P, X or U specifies a negative value, it means that the dwell time is 0.
- P is valid when P, X, U are in the same block; X is valid when X, U are in the same block.
- In the G04 code execution, perform the feed hold operation, the dwell shows at the upper left corner of the current page; however, the G04 timing does not stop, when the timing is executed, the cursor stops at the next program.

# 3.15 Machine Zero Function

# 3.15.1 Machine 1<sup>st</sup> Reference Point G28

Command format: G28  $X(U) \_ Z(W) \_$ ;

**Command function:** the tool rapid traverses to the middle point defined by X(U), Z(W) from starting point and then return to the machine zero.

## **Command specifications:**

G28 is non-modal.

- X, Z, Y: absolute coordinates of middle point;
- U, W, V: Z absolute coordinates of middle point;
- W: Difference value of absolute coordinates between middle point and starting point in Z direction.

Omit all or one of X(U), Z(W) as follows:

### Table 3-4

	Command	Function
G28	X(U)	X returns to machine zero and Z axis remains in the previous position
G28	Z(W)	Z returns to machine zero and X axis remains in the previous position
G28		in the previous positions and continuously execute the next block
G28	X(U) Z(W)	X, Z return to machine zero simultaneously

Running path(as Fig. 3-48) :

- (1) Rapid traverse to middle point of specified axis from current position(A point→B point) ;
- (2) Rapid traverse to reference point from the middle point(B point $\rightarrow$ R point);
- (3) If the machine is not locked, LED is ON when the machine reference point return is completed.



- Note 1: Do not execute G28 and machine zero return without the zero switch on the machine.
- Note 2: Machine zero returns in Jog mode and in G28 are the same and their deceleration signals and the signal every rotation must be detected;
- Note 3: X and Z move at the respectively rapid traverse speed from A to B and from B to R, and so the path is not always a straight line;
- Note 4: The system cancels the tool length compensation after executing G28 to perform the machine zero return;

# 3.15.2 Machine 2<sup>nd</sup>, 3<sup>rd</sup>, 4<sup>th</sup> Reference Point G30

Machine zero is fixed point in the machine tool, decided by the zero switch and zero return switch installed on the machine tool.

Machine reference point is located at the position after the machine zero offsets No.114 or No.115 value, when No.114, No.115 setting value is 0, the machine reference point coincides with the machine zero. The coordinates of machine reference point are No.120, No.121 setting value. Executing machine zero return is considered to executing the machine reference point return.

GSK980TDi has machine  $2^{nd}$ ,  $3^{rd}$ ,  $4^{th}$  reference point functions. Use separately No.122 $\sim$ No.127 to set X, Z machine coordinates of the machine  $2^{nd}$ ,  $3^{rd}$ ,  $4^{th}$  reference point.

The relationship between the machine zero, machine reference point, machine 2<sup>nd</sup>, 3<sup>rd</sup>, 4<sup>th</sup> reference point is as follows:



### **Command format:**

G30	P <u>2</u>	X(U)	Z(W);
G30	P <u>3</u>	X(U)	Z(W);

G30 P<u>4</u> X(U) \_\_ Z(W) \_ ;

**Command function:** the tool rapidly traverses with the rapid traverse speed to the middle point specified by X(U), Z(W)

Command specifications: G30 is non-modal.

X: X absolute coordinate of the middle point;

- U: difference value of X absolute coordinate value between the middle point and starting point;
- Z: Z absolute coordinate of the middle point;

W: difference point of Z absolute coordinate between the middle point and starting point. Omit one or all of X (U), Z(W) as follows:

Command	Function
G30 P <u>n</u> X(U)	X returns to the machine nth reference point, Z axis retains
G30 P <u>n</u> Z(W)	Z return to the nth machine reference point, X axis retains
G30	X and Z retain, go on executing the next program block
G30 P <u>n</u> X(U) Z(W)	X and Z return to the machine nth reference point simultaneously

Note 1: n in the above table is 2, 3 or 4;

Note 2: Do not check the deceleration, zero signal when you execute the machine 2<sup>nd</sup>, 3<sup>rd</sup>, 4<sup>th</sup> reference point.

**Command operations:** (taking example of returning to machine 2<sup>nd</sup> reference point as follows):

- (1) Rapidly traverse to the middle position of command axis from the current position (A point →B point);
- (2) Traverse from the middle point with the speed set by No.113 to the  $2^{nd}$  reference point set by No.122 and No.123 (B point  $\rightarrow$  R2 point);
- (3) When CNC is not in the machine lock state, the completion signal of reference point return ZP21 Bit0, Bit1 is high.



- Note 1: Execute the machine 2<sup>nd</sup>, 3<sup>rd</sup>, 4<sup>th</sup> reference point return after you manually execute the machine reference point return or G28 (machine reference point return).
- Note 2:  $A \rightarrow B$  and  $B0 \rightarrow R2$ , two axes separately traverse, and so their trails are linear or not.
- Note 3: CNC cancels the tool length compensation after you execute G30 to return 2nd, 3rd, and 4th reference point.
- Note 4: Must not execute G30 (machine 2nd, 3rd, 4th reference point return) when the zero switch is not installed on the machine.
- Note 5: Do not set the workpiece coordinate system when you execute the 2nd, 3rd, and the machine 4th reference point return.

# 3.16 Skip Interpolation G31

Command format: G31 X(U) Z(W)  $F_;$ 

**Command function:** in executing the command, when the outside skip signal (X3.5) is input, the system stops the command to execute the next block. The function is used to the dynamic measure (such as milling machine), toolsetting measure and so on of workpiece measure.

Command specifications: non-modal G command (00 group);

Note:

- 1) Cancel the tool nose radius compensation before using it;
- 2) Feedrate should not be set to too big to get the precise stop position;

# 3.16.1 Following Block Execution After Skip

1. The next block of G31 is the incremental coordinate programming shown in Fig. 3-51:





2. The next block of G31 is the absolute coordinate programming of one axis as Fig. 3-52:



Fig. 3-52

 The next block of G31 is the absolute coordinate programming of two axes shown in Fig. 3-53: Program: G31 Z200 F100 G01 X100 Z300



Fig. 3-53
# 3.16.2 Signals Relevant to G31

Skip signal: SKIP: X3.5 Type: input signal

Function: X3.5 ends the skip cutting. I.e. in a block containing G31, the skip signal becoming the absolute coordinate position of "1" is to be stored in the macro variable (#997~#999 separately corresponds to X, Z, Y)

Operation: when the skip signal becomes "0", CNC executes as follows:

When the block is executing G31, CNC stores the current absolute coordinates of each axis. CNC stops G31 to execute the next block, the skip signal detects its state instead of its RISING EDGE. So when the skip signal is "1", it meets the skip conditions.

Note: If G31 is not used, X3.5 input interface is used to the common input interface. The skip signal is valid, CNC immediately stops the feed axis (without acceleration/deceleration execution), and G31 feedrate should be as low as possible below 1000 mm/min to get the precise stop position.

3.16.3 Parameters Relevant to G31: Refer to III INSTALLATION & CONNECTION, Section 3.2.15.

# 3.17 Automatic Tool Offset G36, G37

Command format: G36 X\_;

G37 Z\_\_;

- **Command function:** when the command is executed to make the tool move to the measured position, the CNC automatically measures the difference between the current actual coordinates and the command coordinates to be the tool offset value. The function is used to the automatic toolsetting.
- **Explanations:** X absolute coordinate (only used to G36), Z absolute coordinate (only used to G37); Non-modal G command (00 group);

Cancel the tool nose radius compensation before using it;

Only use the absolute programming;

Define the workpiece coordinate system before using the command;

Specify the tool number and tool compensation number before using the command;

# 3.17.1 Signals Relevant to G36, G37 Automatic Tool Offset:

Measured position arrival signal:

XAE(X3.6) ————corresponding to G36

ZAE(X3.7) ————corresponding to G37

Type: input signal

**Function:** when the position measured by the program command is different from that where the tool actually reaches (i.e. at the time, the measured position arrival signal becomes "1"), the difference of the coordinates is added to the current tool compensation value to update the compensation value. When G36X\_(or G37Z\_) is executed, the tool firstly rapidly traverses to the

position measured by the command, and decelerates and temporarily stop the position before the measured position, and then, reaches to the measured position at the speed set by No.141. When the measured position arrival signal corresponding to G command becomes "1", and the tool is in the measured position range  $\pm \epsilon$ , CNC updates the offset compensation value and ends the block. When the measured position arrival signal does not become "1", and after the tool reaches the measured position distance  $\epsilon$ , the CNC alarms, ends the block and does not update the offset compensation value.



3.17.2 Parameters Relevant to G36, G37: Refer to INSTALLATION, Section 3.2.16.

# 3.17.3 G36, G37 Automatic Tool Offset Command Use

#### Feedrate and alarm

From the initial position to the measured position specified by Xa or Za in G36 or G37, the tool rapidly traverses to A zone and stops at T point (Xa– $\gamma x$  or Za– $\gamma z$ ), and then traverses to B, C and D at the feedrate set by No.141. The system alarms when the tool traverses in B zone and the measured point arrival signal of the end point is set to. CNC alarms when the tool stops at V point.



Example:

G50 X760 Z1100;create the workpiece coordinate systemT0101;define No. 1 tool and execute its tool compensation

G36 X200;	traverse to X toolsetting point (X toolsetting point coordinate: 200)
T0101;	execute X tool compensation again
G00 X204;	retract a little
G37 Z800;	traverse to Z toolsetting point (Z toolsetting point coordinate: 800)
T0101;	execute Z tool compensation again and the toolsetting is completed
M30;	



Note: Measure position arrival signal is enabled, the feed of CNC stop axis is immediately stopped (regardless of the acceleration or deceleration treatment). Therefore, in order to guarantee the accuracy of the stop position, the measure speed of the G36 or G37 should be set as low as possible; it is clamped at the speed when the federate exceeds 200mm/min.

# 3.18 Workpiece Coordinate System G50

Command format: G50 X(U) \_\_\_\_ Z(W) \_\_\_;

**Command function:** define the absolute coordinates of current position and create the workpiece coordinates system (called floating coordinates system) by setting the absolute coordinates of current position in the system. After G50 is executed, the system takes the current position as the program zero (program reference point), and the system returns to the point after executing the program zero return. After the workpiece coordinate system is created, input the coordinate values with the coordinate system in the absolute coordinates programming until the next workpiece coordinate system is created again (using G50).

### **Command specifications:**

- G50 is non-modal;
- X: New absolute coordinates of current position in X direction;
- U: Different value between the new absolute coordinates of current position in X direction and the absolute coordinates before executing commands;
- Z: New absolute coordinates of current position in Z direction;
- W: Different value between the new absolute coordinates of current position in X direction and

the absolute coordinates before executing commands;

In G50, when X(U) or Z(W) are not input, the system does not change current coordinates position as program zero; when X(U) and Z(W) are not input, the system takes the previous setting position as program zero.

Example:



As Fig.3-54, create the above-mentioned workpiece coordinate system and set (X100 Z150) to the reference point of program after executing "G50 X100 Z150".

Note: When No.003 Bit4 is 1(executing tool compensation by coordinates offset), T function is executed, motion command is not executed and the system creates workpiece coordinate system with G50, the displayed coordinate value are ones which are defined by G50 adding or subtracting tool compensation value which is not executed.

Current tool	Executing motion	Coordinate value after	No. 01 tool
compensation state	command	executing G50 X20 Z20	compensation value
	G0 X_ Z	X: 20 Z: 20	
T0100	Motion command	Coordinate value after	
or	not executed	executing G50 X20 Z20	X: 12
T0101		X: 8 Z: -3	Z: 23
10101	***	or	
		X: 32 Z: 43	

# 3.19 Local Coordinate System

When the programming is executed in a workpiece coordinate system, a sub workpiece coordinate can be created in the workpiece coordinate system, which is called as a local coordinate system.

### Command format: G52 X(U) Z(W)

**Command function:** when G52 is executed, all workpiece coordinate system can (G54~G59) set a local coordinate system. Origin of each local coordinate system is the specified position X(U)\_\_\_Z(W)\_\_\_ of each workpiece coordinate system. Corresponding relation of workpiece coordinate systems is shown below:



Origin of coordinate system

**Explanation:** G52 is in Group 00, and is simple. X(U) Z(W) is the position of origin of the specified local coordinate system in the current workpiece coordinate system. Results in absolute or incremental execution are the same.

#### Notes:

1. Setting of local coordinate system does not change a workpiece coordinate system and a machine

coordinate system.

- 2. Temporarily cancel tool nose radius compensation when G52 is executed.
- 3. After G52 is specified, the local coordinate system does not remain valid until the next G52 is specified. G52 does not perform movement when it is specified.
- 4. When a local coordinate system is cancelled, its zero and that of workpiece coordinate system are

consistent, i.e., command G52 X0 Z0 or G52 U0 W0.

5. When G50 sets a workpiece coordinate system, local coordinate systems of all workpiece coordinate

systems which axes are specified are cancelled. The local coordinate systems which coordinate axes are not specified are not cancelled when not all axes' coordinate value are specified.

6. Whether the local coordinate system is cancelled is determined by a parameter when reset, machine zero return or end of program.



In N3 block, a local coordinate system is created according to G55 workpiece coordinate system, and it is cancelled in the block N7.

## 3.20 Workpiece Coordinate System G54~G59

Command format: G54 workpiece coordinate system 1

- G55 workpiece coordinate system 2
- G56 workpiece coordinate system 3
- G57 workpiece coordinate system 4
- G58 workpiece coordinate system 5
- G59 workpiece coordinate system 6

**Command function:** one of G54~G59 is specified, one of workpiece coordinate system 1~6 is selected. After a workpiece coordinate system is specified, the specified point is in the specified workpiece coordinate system till a new workpiece

coordinate system is set.

#### Explanation: G54 $\sim$ G59 are modal.

In the system, each coordinate system should correspond to ZOFS1~ ZOFS6 of zero offset value of one workpiece coordinate system, relation between ZOFS1~ ZOFS6 and previous workpiece is shown below:



Absolute coordinate at machine zero

EXOFS: external workpiece coordinate zero (it is added to zero offset value of each workpiece coordinate system, its value is a part of tool compensation->setting in the workpiece coordinate system)

ZOFSn: zero offset value of each workpiece coordinate system ZOFS1 $\sim$ ZOFS6 (its value is a part of tool compensation->setting in the workpiece coordinate system)

When №11.7 (APRS) is set to 1, an absolute coordinate system is set after machine zero return, and then EXOFS and ZOFSn setting values are offset. Current workpiece coordinate setting after zero return is shown: new workpiece coordinates=current absolute coordinates- (ZOFSn + EXOFS).

#### G54 $\sim$ G59 workpiece coordinate system switch

Specifying G54~G59 can switch 6 workpiece coordinate systems to make the system work in

# **CNCmakers**

different workpiece systems. Absolute coordinate variation of current position is the origin offset value between the new workpiece coordinate system and the old. Namely: new absolute coordinates =current absolute coordinates - (ZOFS new – ZOFS old)

### Example:

Example 1:

Absolute coordinates after zero return is (0,0); EXOF=(0,0) ; ZOFS1=(-10,-10);

Absolute coordinate values after zero return in G54: 0 - (-10 + 0) = 10;

Example 2:

Absolute coordinate values after zero return: (20,20); EXOF=(5,5) ; ZOFS2=(10, 10); Absolute coordinate values after zero return in G55: 20 - (10 + 5) = 5;

Example 3:

Current absolute coordinates (10,10); EXOF=(5,5) ; ZOFS1=(-10,-10); ZOFS2 = (-30,-30); absolute coordinate values from G54 to G55: 10- (-30-(-10)) = 30

#### Notes:

- 1. When №12.7 (APRS) is set to 0, the absolute coordinate system after machine zero return is not set, and the EXOF and ZOFSn offset cannot be executed because the workpiece coordinate system is not set again.
- 2. Modification setting of EXOFS and ZOFSn are valid only in non-run state, namely, setting values of each workpiece coordinate system cannot be modified when a program is running.
- 3. The workpiece coordinate system offset is immediately valid after values of EXOFS and ZOFSn are modified.
- 4. Whether the incremental coordinates include offset values of the coordinate system is set by№05.1 (PPD).
- 5. In tool nose radius compensation mode, compensation is cancelled temporarily in G54~G59, and is recovered in the next movement command.
- 6. When G54~G59 and G50 are in the same block, G54~G59 are invalid, but G50 is valid.
- 7. When G50 sets the coordinate system, origin of the current workpiece system is modified. So, there is an offset value of origins between a new coordinate system set by G50 and previously current coordinate system. The offset value should be added to offset values of origins of all workpiece coordinate systems, i.e. all workpiece coordinate systems move the same values, which are shown below:



Offset value A are all workpiece coordinate systems, which are shown below:



# 3.21 Fixed Cycle Command

To simplify programming, the system defines G command of single machining cycle with one block to complete the rapid traverse to position, linear/thread cutting and rapid traverse to return to the starting point:

G90: axial cutting cycle;

G92: thread cutting cycle;

G94: radial cutting cycle;

G92 will be introduced in section Thread Function.

# 3.21.1 Axial Cutting Cycle G90

Command format:	G90 X(U) _	_ Z(W) _	_ F;	(	cylinder cutting)
	G90 X(U) _	_Z(W) _	_ R F	;	(taper cutting)

**Command function:** From starting point, the cutting cycle of cylindrical surface or taper surface is completed by radial feeding(X) and axial (Z or X and Z) cutting.

#### **Command specifications:**

G90 is modal;

Starting point of cutting: starting position of linear interpolation (cutting feed)

End point of cutting: end position of linear interpolation (cutting feed)

- X: X absolute coordinates of cutting end point
- U: Different value of X absolute coordinate between end point and starting point of cutting
- Z: Different value of Z absolute coordinate between end point and starting point of cutting
- W: Different value of Z absolute coordinate between end point and starting point of cutting
- R: Different value (radius value) of X absolute coordinates between end point and start point of cutting. When the signs of R is not the same that of U, R | ≤ | U/2 |; when R=0 or the input is default, the cylinder cutting is executed as Fig.3-17, otherwise, the cone cutting is executed as Fig. 3-18; unit: mm.

Ranges of X, U, Z, W, R are referred to Table 1-2 of Section 1.4.1, unit: mm/inch.

#### Cycle process:

- ① X rapidly traverses from starting point to cutting starting point;
- 2 Cutting feed (linear interpolation) from the cutting starting point to cutting end point;
- ③ X executes the tool retraction at feedrate (opposite direction to the above-mentioned ①), and return to the position which the absolute coordinates and the starting point are the same;
- ④ Z rapidly traverses to return to the starting point and the cycle is completed.

# **CNCmakers**



Fig. 3-56

Cutting path: Relative position between cutting end point and starting point with U, W, R, and tool path of U, W, R with different signs are shown in Fig. 3-19:

1) U>0, W<0, R>0



3) U>0, W>0, R<0,  $|R| \le |U/2|$ 





4) U<0, W>0, R>0,  $|R| \le |U/2|$ 











# 3.21.2 Radial Cutting Cycle G94

**Command format:** G94 X(U)  $Z(W) - F_{,}$ ; (face cutting)

G94 X(U) \_\_\_ Z(W) \_\_\_ R\_\_\_ F\_\_\_; (taper face cutting)

**Command function:** From starting point, the cutting cycle of cylindrical surface or taper surface is completed by radial feeding(X) and axial (Z or X and Z) cutting.

### **Command specifications:**

G94 is modal;

Starting point of cutting: starting position of linear interpolation (cutting feed). Unit: mm;

- End point of cutting: end position of linear interpolation (cutting feed). Unit: mm;
- X: X absolute coordinate of end point of cutting. Unit: mm;
- U: Different value of absolute coordinate from end point to starting point of cutting in X direction .Unit: mm;
- Z: Z absolute coordinates of end point of cutting, Unit: mm;
- W: Different value of X absolute coordinate from end point to starting point of cutting, Unit: mm;
- R: Different value(R value) of X absolute coordinates from end point to starting point of cutting. When the sign of R is not the same as that of U, R,  $|R| \le |W|$ .

Radial linear cutting is shown in Fig. 3-21, radial taper cutting is as Fig. 3-60.

Ranges of X, U, Z, W, R are referred to Table 1-2 of Section 1.4.1, unit: mm/inch.

### Cycle process:

- ① Z rapidly traverses from starting point to cutting starting point;
- 2 Cutting feed (linear interpolation) from the cutting starting point to cutting end point;
- ③ Z executes the tool retraction at the cutting feedrate (opposite direction to the above-mentioned ①), and returns to the position which the absolute coordinates and the starting point are the same;
- ④ The tool rapidly traverses to return to the starting point and the cycle is completed.



Fig. 3-59



Fig. 3-60

Cutting path: Relative position between cutting end point and starting point with U, W is shown in Fig.3-61:



Example: Fig. 3-62, rod Φ125×112



# 3.21.3 Caution of Fixed Cycle Commands

1) After X(U), Z(W), R are executed in the canned cycle command, their command values are value if X(U), Z(W), R are not redefined by executing a new canned cycle commands. The command values of X(U), Z(W), R are cleared if non-modal G command(00 Group) except for G04 or G00, G01, G02, G03, G32 is executed.

2) In MDI mode, the previous canned cycle can be executed by pressing the cycle start key after the canned cycle is completed.

3) Pause or single block is executed in G90, G94, the single block stops after the tool moves end point of current path.

# 3.22 Multiple Cycle Commands

Multiple cycle commands of the system includes axial roughing cycle G71, radial roughing cycle G72, closed cutting cycle G73, finishing cycle G70, axial grooving multiple cycle G74, axial grooving multiple cycle G75 and multiple thread cutting cycle G76. When the system executes these commands, it automatically counts the cutting times and the cutting path according to the programmed path, travels of tool infeed and tool retraction, executes multiple machining cycle (tool infeed  $\rightarrow$  cutting $\rightarrow$ retract tool $\rightarrow$ tool infeed ), automatically completes the roughing, finishing workpiece and the starting point and the end point of command are the same one.

The G76 multi-thread cutting cycle code will describe in the Section of the Thread Function.

# 3.22.1 Axial Roughing Cycle G71

 $\begin{array}{c} \mbox{G71 has two kinds of roughing cycle: type I and type II.} \\ \mbox{Command format: G71 U(Ad) R(e) F_ S_ T_; (1)} \\ \mbox{G71 P(ns) Q(nf) U(Au) W(Aw) K0/1 J0/1; (2)} \\ \mbox{N(ns) G0/G1 X(U)...;} \\ \mbox{N(ns) G0/G1 X(U)...;} \\ \mbox{N(ns) G0/G1 X(U) Z(W)...;} \\ \mbox{N(ns) G0/G1 X(U$ 

### Command function: G71 is divided into three parts:

(1) 1st blocks for defining the travels of tool infeed and retract tool, the cutting feedrate, the spindle speed and the tool function when roughing;

(2) 2nd blocks for defining the block interval, finishing allowance;

(3) 3rd blocks for some continuous finishing path, counting the roughing path without being executed actually when executing G71.

According to the finishing path, the finishing allowance, the path of tool infeed and tool retract, the system automatically counts the path of roughing, the tool cuts the workpiece in paralleling with Z, and the roughing is completed by multiple executing the cutting cycle tool infeed $\rightarrow$ cutting $\rightarrow$ tool retraction. The starting point and the end point are the same one. The command is applied to the formed roughing of non-formed rod.

### **Relevant definitions:**

- Finishing path: The above-mentioned Part 3 of G71(ns∼nf block)defines the finishing path, and the starting point of finishing path (starting point of ns block)is the same these of starting point and end point of G71, called A point; the first block of finishing path(ns block)is used for X rapid traversing or tool infeed, and the end point of finishing path is called to B point; the end point of finishing path(end point of nf block)is called to C point. The finishing path is A→B→C.
- **Roughing path:** The finishing path is the one after offsetting the finishing allowance( $\Delta u, \Delta w$ ) and is the path contour formed by executing G71. A, B, C point of finishing path after offset corresponds separately to A', B', C' point of roughing path, and the final continuous cutting path of G71 is B' $\rightarrow$ C' point.

 $\Delta$ d: It is each travel of X tool infeed in roughing, its value: 0.001~99.999 (IS\_B) /0.0001~99.9999 (IS\_C) (unit: mm/inch,radius value) without sign, and the direction of tool infeed is defined by move direction of ns block. The command value  $\Delta$ d is reserved after executing U( $\Delta$ d). The value of system parameter No.051 is regarded as the travel of tool infeed when U( $\Delta$ d) is not input.

- e: It is travel of X tool retraction in roughing its value: 0~99.999 (IS\_B) /0~99.9999 (IS\_C) (unit: mm/inch,radius value) without sign, and the direction of tool retraction is opposite to that of tool infeed, the command value e is reserved after R(e) is executed. The value of system parameter No.052 is regarded as the travel of tool retraction when R(e) is not input.
- ns: Block number of the first block of finishing path.
- nf: Block number of the last block of finishing path.

Programming

- $\Delta u$ : X finishing allowance is -99999.999~99999.999(IS\_B) /-9999.9999~9999.9999(IS\_C) (diameter, unit: mm/inch, with sign). X coordinate offset of roughing path compared to finishing path, i.e. the different value of X absolute coordinates between A' and A. The system defaults  $\Delta u$ =0 when U( $\Delta u$ ) is not input, i.e. there is no finishing allowance in X direction for roughing cycle.
- $\Delta$ w: Z finishing allowance is -99999.999~99999.999(IS\_B) /-9999.9999~9999.9999(IS\_C) (diameter, unit: mm/inch, with sign). the Z coordinate offset of roughing path compared to finishing path, i.e. the different value of Z absolute coordinate between A' and A. The system defaults  $\Delta$ w=0 when W( $\Delta$ w) is not input, i.e. there is no Z finishing allowance for roughing cycle.
- K: When K is not input or is not 1, the system does not check the program monotonicity except that the Z value of starting point and end point of the arc or ellipse or parabola or the arc is more than 180 degree; K=1, the system checks the program monotonicity.
- F: Feedrate; S: Spindle speed; T: Tool number, tool offset number.

M, S, T, F: They can be specified in the first G71 or the second ones or program ns $\sim$ nf. M, S, T, F functions of M, S, T, F blocks are invalid in G71, and they are valid in G70 finishing blocks.

### Type I:

- 1) Execution process: (Fig. 3-63)
- ① X rapidly traverses to A' from A point, X travel is  $\Delta u$ , and Z travel is  $\Delta w$ ;
- ② X moves from A' is ∆d( tool infeed), ns block is for tool infeed at rapid traverse speed with G0, is for tool infeed at feedrate F with G71, and its direction of tool infeed is that of A→B point;
- ③ Z executes the cutting feeds to the roughing path, and its direction is the same that of Z coordinate A→B point;
- X, Z execute the tool retraction e (45° straight line) at feedrate, the directions of tool retraction is opposite to that of too infeed;
- ⑤ Z rapidly retracts at rapid traverse speed to the position which is the same that of Z coordinate;
- ⑥ After executing X tool infeed (Δd+e)again, the end point of traversing tool is still on the middle point of straight line between A' and B'(the tool does not reach or exceed B'), and after executing the tool infeed (Δd+e)again, execute ③; after executing the tool infeed (Δd+e)again, the end point of tool traversing reaches B' point or exceeds the straight line between A'→B' point and X executes the tool infeed to B' point, and then the next step is executed;
- ⑦ Cutting feed from B' to C' point along the roughing path;
- ⑧ Rapid traverse to A from C' point and the program jumps to the next clock following nf block after G71 cycle is ended.



Fig. 3-63 G71 cycle path

2) Coordinate offset direction with finishing allowance:

 $\Delta u$ ,  $\Delta w$  define the coordinate offset and cut-in direction in finishing, and their sign symbol are as follows Fig. 3-64: B $\rightarrow$ C for finishing path, B' $\rightarrow$ C' for roughing path and A is the tool start-up point.



#### Fig.3-64

### Type II:

The type II is different from the type I as follows:

- 1) Relative definition: More one parameter than the type I.
- J: When J is not input or J is not 1, the system does not execute the run along the roughing contour; J=1: the system executes the run along the roughing contour.
- 2) The system does not execute the monotonous increasing or the monotonous decreasing along X external contour, and the workpiece can be up to 10 grooves as follows:







But, the Z external contour must be the monotonous increasing or the monotonous decreasing, and the following contour cannot be machined:



Z axis is not the monotonous change

- Fig. 3-66 (type  $\rm II$  )
- 3) The first tool cutting need not the vertical: The machining can be executed when Z is the monotonous change shape as follows:





4) After the turning, the system should execute the tool retraction, the retraction travel is specified by R (e) or No. 52 as follows:



Fig. 3-68 (type II ) 5) Command execution process: roughing path A->H



#### Notes:

- ns block is only G00, G01. When the workpiece is type II, the system must specify the two axes X(U) and Z(W), and W0 must be specified when Z does not move;
- 2. For type II, only X finishing allowance can be specified; when Z finishing allowance is specified, the whole machining path offsets, and it can be specified to 0;
- 3. For type II, after the current grooving is completed to execute the next, the tool approaches the workpiece(remark 25 and 26) in the remainder tool retraction distance at G1 speed; when the tool retraction is 0 or the remainder distance is less than the tool retraction, and the tool approaches the workpiece at G1 speed;
- 4. Some workpiece without remarking the type I or the type II adapts the both;
- For the finishing path(ns~nf block), Z dimension must be monotonous change(always increasing or decreasing), X dimension in the type I must be monotonous change and does not need in the type II;
- ns~nf blocks in programming must be followed G71 blocks. If they are in front of G71 blocks, the system automatically searches and executes ns~nf blocks, and then executes the next program following nf block after they are executed, which causes the system executes ns~nf blocks repetitively;
- 7. ns~nf blocks are used for counting the roughing path and the blocks are not executed when G71 is executed. F, S, T commands of ns~nf blocks are invalid when G71 is executed, at the moment, F, S, T commands of G71 blocks are valid. F, S, T of ns~nf blocks are valid when executing ns~nf to command G70 finishing cycle;
- In ns~nf blocks, there are only G commands: G00, G01, G02, G03, G04, G05, G6.2, G6.3, G7.2, G7.3, G96, G97, G98, G99, G40, G41, G42 and the system cannot call subprograms (M98/M99);
- 9. In ns $\sim$ nf ,the program block quantity cannot exceed 100;
- 10. G96, G97, G98, G99, G40, G41, G42 are invalid when G71 is executed, and are valid when G70 is executed;
- 11. When G71 is executed, the system can stop the automatic run and manual traverse, but return to the position before manual traversing when G71 is executed again, otherwise, the following path will be wrong;

- 12. When the system is executing the feed hold or single block, the program pauses after the system has executed end point of current path;
- △d,△u are specified by the same U and different with or without being specified P, Q commands;
- 14. There are no the same block number in ns~nf when compound cycle commands are executed repetitively in one program;
- 15. The tool retraction point should be high or low as possible to avoid crashing the workpiece.

#### **Cutter radius compensation:**

When the cutter radius compensation should be used in the compound cycle code (G70, G71, G72 or G73), the G41/G42 code should be specified at the 1<sup>st</sup> block (ns block) of the finish-turning path; otherwise, the cutter compensation will not be used in the compound cycle; it is not necessary to specify the G40 in the finish-turning path. The cutter radius compensation will authomatically cancel when the compound cycle is completed. Actually, when the cutter radius compensation is used in the compound cycle code, the CNC system is performed the cutter nose radius offset for the finish-turning path instead of entering the state of the cutter radius compensation. Therefore, the cutter radius compensation state on the position interface will not change.

The cutter radius compensation genterates before entering the compound cycle, temporarily cancel the cutter radius compensation; restore the cutter radius compensation when the cycle end tool leaves from the cycle start; refer to the following schematic:



When the compound the cycle is performed in the rough machining, perform the infeed along with the cycle start and  $1^{st}$  point offset vector point of the finish-turing path, and its feed value is  $\triangle d$ ; refer to the following figure:



Example: Fig. 3-73 (Type I)



Fig. 3-73

#### Program: O0004;

G00 X200 Z10 M3 S800;	(Spindle clockwise with 800 r/min)
G71 U2 R1 F200;	(Cutting depth each time 4mm, tool retraction 2mm [in
	diameter])
G71 P80 Q120 U0.5 W0.2;	(roughing ae, machining allowance: X, 1mm;Z, 2mm)
N80 G00 X40 S1200;	(Positioning)
G01 Z-30 F100 ;	(a→b)
X60 W-30;	(b $\rightarrow$ c) $a \rightarrow b \rightarrow c \rightarrow d \rightarrow e$ blocks for finishing pat
W-20;	(c→d)
N120 X100 W-10;	(d→e)
G70 P80 Q120;	(ae blocks for finishing path)
M30;	(End of block)

# 3.22.2 Radial Roughing Cycle G72



Command function: G72 is divided into three parts:

- (1) 1st blocks for defining the travels of tool infeed and tool retraction, the cutting speed, the spindle speed and the tool function in roughing;
- (2) 2nd blocks for defining the block interval, finishing allowance;
- (3) 3rd blocks for some continuous finishing path, counting the roughing path without being executed actually when G72 is executed.

According to the finishing path, the finishing allowance, the path of tool infeed and retract tool, the system automatically counts the path of roughing, the tool cuts the workpiece in paralleling with Z, and the roughing is completed by multiple executing the cutting cycle tool infeed $\rightarrow$ cutting feed $\rightarrow$ tool retraction. The starting point and the end point of G72 are the same one. The command is applied to the formed roughing of non-formed rod.

### **Relevant definitions:**

- Finishing path: the above-mentioned Part (3) of G71(ns∼nf block)defines the finishing path, and the starting point of finishing path (i.e. starting point of ns block)is the same these of starting point and end point of G72, called A point; the first block of finishing path(ns block)is used for Z rapid traversing or cutting feed, and the end point of finishing path is called to B point; the end point of finishing path(end point of nf block)is called to C point. The finishing path is A→B→C.
- Roughing path: The finishing path is the one after offsetting the finishing allowance Δu, Δw) and is the path contour formed by executing G72. A, B, C point of finishing path after offset corresponds separately to A', B', C' point of roughing path, and the final continuous cutting path of G72 is B'→C' point.

 $\Delta$ d: it is Z cutting in roughing, its value: 0.001~99.999 (IS\_B) /0.0001~99.9999 (IS\_C) (unit:

mm/inch) without sign symbol, and the direction of tool infeed is determined by ns block traverse direction. The value of system parameter No.051 is regarded as the tool infeed clearance when  $W(\Delta d)$  is not input.

- e: it is Z tool retraction clearance in roughing, its value: 0~99.999 (IS\_B) /0~99.9999 (IS\_C) (unit: mm) without sign symbol, and the direction of tool retraction is opposite to that of tool infeed, the specified value e is reserved after R(e) is executed. The value of system parameter No.052 is regarded as the tool retraction clearance when R(e) is not input.
- ns: Block number of the first block of finishing path.
- nf: Block number of the last block of finishing path.
- Δu: it is X finishing allowance in roughing, its range: -99999.999~99999.999(IS\_B)
   /-9999.9999~9999.9999(IS\_C) (X coordinate offset of roughing contour corresponding to the finishing path, i.e. X absolute coordinate difference between A' and A.(diameter, unit: mm/inch, with sign symbol).
- Δw: it is Z finishing allowance in roughing, its range: -99999.999~99999.999(IS\_B) /-9999.9999~9999.9999(IS\_C) (Z coordinate offset of roughing contour corresponding to the finishing path, i.e. Z absolute coordinate difference between A' and A.(diameter, unit: mm/inch, with sign symbol).
- When K is not input or is not 1, the system does not check the program monotonicity except that the Z value of starting point and end point of the arc or ellipse or parabola or the arc is more than 180 degree; K=1, the system checks the program monotonicity.
- F: Cutting feedrate; S: Spindle speed; T: Tool number, tool offset number.

M, S, T, F: They can be specified in the first G72 or the second ones or program ns $\sim$ nf. M, S, T, F functions of M, S, T, F blocks are invalid in G72, and they are valid in G70 finishing blocks.

#### **Execution process:**

- (1)X rapidly traverses to A' from A point, X travel is  $\Delta u$ , and Z travel is  $\Delta w$ ;
- ②X moves from A' is  $\Delta d$ ( tool infeed), ns block is for tool infeed at rapid traverse speed with G0, is for tool infeed at G72 feedrate F in G1, and its direction of tool infeed is that of A→B point;
- ③X executes the cutting feeds to the roughing path, and its direction is the same that of X coordinate B→C point;
- ④X, Z execute the tool retraction e (45°straight line)at feedrate, the directions of tool retraction is opposite to that of tool infeed ;
- ⑤X rapidly retracts at rapid traverse speed to the position which is the same that of Z coordinate;
- ⑥After Z tool infeed (Δd+e)again is executed, the end point of traversing tool is still on the middle point of straight line between A' and B'(the tool does not reach or exceed B'), and after Z executes the tool infeed (Δd+e)again, ③ is executed; after the tool infeed (Δd+e) is executed again, the end point of tool traversing reaches B' point or exceeds the straight line between A'→B' point and Z executes the tool infeed to B' point, and then the next step ⑦ is executed;
- ⑦Cutting feed from B' to C' point along the roughing path;
- ③Rapidly traverse to A from C' point and the program jumps to the next clock following nf block after G71 cycle is completed.





### **Command specifications:**

- ns~nf blocks in programming must be followed G72 blocks. If they are in the front of G72 blocks, the system automatically searches and executes ns~nf blocks, and then executes the next program following nf block after they are executed, which causes the system executes ns~nf blocks repetitively;
- ns~nf blocks are used for counting the roughing path and the blocks are not executed when G72 is executed. F, S, T commands of ns~nf blocks are invalid when G72 is executed, at the moment, F, S, T commands of G72 blocks are valid. F, S, T of ns~nf blocks are valid when executing ns~nf to command G70 finishing cycle;
- 3. The dimensions in X, Z direction must be changed monotonously (always increasing or reducing) for the finishing path;
- In ns~nf blocks, there are only G commands: G01, G02, G03, G04, G05, G6.2, G6.3, G7.2, G7.3, G96, G97, G98, G99, G40, G41, G42 and the system cannot call subprograms (M98/M99);
- 5. G96, G97, G98, G99, G40, G41, G42 are invalid when G72 is executed, and are valid when G70 is done;
- 6. In the ns $\sim$ nf, the program block quantity cannot exceed 100;
- When G72 is executed, the system can stop the automatic run and manual traverse, but return to the position before manual traversing when G72 is executed again, otherwise, the following path will be wrong;
- 8. When the system is executing the feed hold or single block, the program pauses after the system has executed end point of current path;
- △d, △w are specified by the same W and different with or without being specified P, Q commands;
- 10. There are no the same block number in ns~nf when compound cycle commands are executed repetitively in one program;
- 11. The tool retraction point should be high or low as possible to avoid crashing the workpiece.

#### Coordinate offset direction with finishing allowance:

 $\Delta u$ ,  $\Delta w$  define the coordinate offset and its direction of cut-in in finishing, and their sign symbol are as follows Fig. 3-29: B $\rightarrow$ C for finishing path, B' $\rightarrow$ C' for roughing path and A is the tool start-up point.



# The selection both type I and II

G72 owns type I and II. It is necessary to use the type II when the slot in the fir -turining shape.

The tool-retraction operation of the type I and II machining are different after the rough-turning is performed towards to the  $2^{nd}$  axis of the panel (It is the X axis on the ZX panel). Type I executes the tool-retraction along with the 45°, and the type II is performed the cutting along with the finish-turning. When there is no slot in the finish-turning shape, flexibly use based upon the tool-retraction method.

Select the type I or II in the 1<sup>st</sup> block (Block number is ns) of the finish-turning path.

#### 1) Type I selection

Only specify the command of the 1<sup>st</sup> axis of the panel (It is the Z axis on the ZX panel). There is no command of the 2<sup>nd</sup> axis (It is the X axis on the ZX panel) of the panel.

2) Type II selection

Specify the command of the 2<sup>nd</sup> axis (It is X axis on the ZX panel) and 1<sup>st</sup> axis (It is Z axis on the ZX panel) on the panel. If the movement does not on the 2<sup>nd</sup> axis of the panel instead of using the type II, the increment code specified the movement value is 0, which is programmed (It is U0 on the ZX panel).

#### The distinction between the G72 type II and G71 type II:

The differences from the G71 are shown below:

1) G72 moves the cutting workpiece by the 2<sup>nd</sup> axis paralleled with the panel (It is the X axis on the ZX panel).

2) It is not necessary that the shape is simply added or reduced of the 1<sup>st</sup> axis (It is the Z axis on the ZX panel) on the panel; the sunken part (slot) can be set. However, there is not alternative other than the simply change along with the 2<sup>nd</sup> axis (It is X axis on the ZX panel) direction on the panel.

3) In the finish-turning, the block parallels with the 2<sup>nd</sup> axis on the panel which is regarded as botton of the slot.

4) Tool is temporarily returned to the start after the overall rough machining cuttings of the  $2^{nd}$  axis on the panel are performed, and then the rough machining cutting is executed.

#### G72 code cutter radius compensation function:

Refer to the partial description of the G71 code cutter radius compensation function. **G72 code machining example (Type I)**:





### Program:

O0005;		
G00 X176 Z10 M03 S500	(Change No.2 tool and	execute its compensation, spindle
	CW rotation with 500 r/	/min)
G72 W2.0 R0.5 F300;	(Tool infeed 2mm, tool r	etraction 0.5mm)
G72 P10 Q20 U0.2 W0.1;	(Roughing ad,X roughir	ng allowance 0.2mm and Z 0.1mm)
N10 G00 Z-55 S800 ;	(Rapid traverse)	
G01 X160 F120;	(Infeed to a point)	
X80 W20;	(Machining a—b)	Blocks for finishing path
W15;	(Machining b—c)	}
N20 X40 W20 ;	(Machining c—d)	
G70 P050 Q020 M30;	(Finishing a—d)	)

# 3.22.3 Closed Cutting Cycle G73

Command format:	G73 U <u>(Δi)</u> W <u>(Δk)</u> R <u>(d)</u> F_ S_	T;	(1)
	G73 P <u>(ns)</u> _Q <u>(nf)</u> _U <u>(Δu)</u> _W <u>(Δw)</u> ;		(2)
	N <u>(</u> ns) ;		
	;		
	F;		
	S;	>	(3)
	;		
		J	
	N (nf) ;		

**Command functions:** G73 is divided into three parts:

- (1) Blocks for defining the travels of tool infeed and tool retraction, the cutting speed, the spindle speed and the tool function when roughing;
- (2) Blocks for defining the block interval, finishing allowance;

(3) Blocks for some continuous finishing path, counting the roughing path without being executed actually when executing G73.

According to the finishing allowance, the travel of tool retraction and the cutting times, the system automatically counts the travel of roughing offset, the travel of each tool infeed and the path of roughing, the path of each cutting is the offset travel of finishing path, the cutting path approaches gradually the finishing one, and last cutting path is the finishing one according to the finishing allowance. The starting point and end point of G73 are the same one, and G73 is applied to roughing for the formed rod. G73 is non-modal and its path is shown in Fig.3-77. **Relevant definitions:** 

- **Finishing path:** The above-mentioned Part 3 of G73 (ns $\sim$ nf block)defines the finishing path, and the starting point of finishing path (start point of ns block)is the same these of starting point and end point of G73, called A point; the end point of the first block of finishing path(ns block)is called B point; the end point of finishing path(end point of nf block) is called C point. The finishing path is A $\rightarrow$ B $\rightarrow$ C.
- **Roughing path:** It is one group of offset path of finishing one, and the roughing path times are the same that of cutting. After the coordinates offset, A, B, C of finishing path separately corresponds to A<sub>n</sub>, B<sub>n</sub>, C<sub>n</sub> of roughing path(n is the cutting times, the first cutting path is A<sub>1</sub>, B<sub>1</sub>, C<sub>1</sub> and the last one is A<sub>d</sub>, B<sub>d</sub>, C<sub>d</sub>). The coordinates offset value of the first cutting compared to finishing path is  $(\Delta i \times 2 + \Delta u, \Delta w + \Delta k)$  (diameter programming), the coordinates offset value of the last cutting compared to finishing path is ( $\Delta u$ ,  $\Delta w$ ), the coordinates offset value of the previous one is as follows:

$$(-\frac{\Delta i \times 2}{d-1}, -\frac{\Delta k}{d-1})$$

- Δi: It is X tool retraction clearance in roughing, and its range is ±99999999× least input increment (radius, unit: mm/inch, with sign symbol), Δi is equal to X coordinate offset value (radius value) of A1 point compared to Ad point. The X total cutting travel(radius value) is equal to |Δi| in roughing, and X cutting direction is opposite to the sign of Δi: Δi
   >0, the system executes X negative cutting in roughing. The No.053 value is regarded as X tool retraction clearance in roughing when U(Δi) is not input.
- $\Delta k$ : It is Z tool retraction clearance in roughing, and its range is -99999.999  $\sim$  99999.999(IS\_B) /-9999.9999  $\sim$  9999.9999(IS\_C) (radius, unit: mm/inch, with sign symbol),  $\Delta k$  is equal to Z coordinate offset value (radius value) of A1 point compared to Ad point. Z total cutting travel(radius value) is equal to  $|\Delta k|$  in roughing, and Z cutting direction is opposite to the sign of  $\Delta k$ :  $\Delta k > 0$ , the system executes Z negative cutting in roughing.The No.054 value is regarded as Z tool retraction clearance in roughing when W( $\Delta k$ ) is not input.
- d: It is the cutting times 1~9999 (unit: times). R5 means the closed cutting cycle is completed by 5 times cutting.No.055 value is regarded as the cutting times when R(d) is not input. When the cutting times is 1, the system completes the closed cutting cycle based on 2 times cutting.
- ns: Block number of the first block of finishing path.
- nf: Block number of the last block of finishing path.
- Δu: It is X finishing allowance and its range is -99999.999~99999.999(IS\_B) /-9999.9999~9999.9999(IS\_C) (diameter, unit: mm/inch, with sign symbol) and is the X coordinate offset of roughing path compared to finishing path, i.e. the different value of

X absolute coordinates of A<sub>1</sub> compared to A.  $\Delta u > 0$ , it is the offset of the last X positive roughing path compared to finishing path. The system defaults  $\Delta u=0$  when U( $\Delta u$ ) is not input, i.e. there is no X finishing allowance for roughing cycle.

 $\Delta w: \mbox{ It is Z finishing allowance and its range is-99999.999~99999.999(IS_B) /-9999.9999~9999.9999(IS_C) (diameter, unit: mm/inch, with sign symbol) and is the X coordinate offset of roughing path compared to finishing path, i.e. the different value of Z absolute coordinates of A<sub>1</sub> compared to A. <math>\Delta w > 0$ ,it is the offset of the last X positive roughing path compared to finishing path. The system defaults  $\Delta w=0$  when W( $\Delta w$ ) is not input, i.e. there is no Z finishing allowance for roughing cycle.

F: Feedrate; S: Spindle speed; T: Tool number, tool offset number.

M, S, T, F: They can be specified in the first G73 or the second ones or program ns $\sim$ nf. M, S, T, F functions of M, S, T, F blocks are invalid in G73, and they are valid in G70 finishing blocks. **Execution process:** (Fig. 3-77)

(1)  $A \rightarrow A_1$ : Rapid traverse;

② First roughing  $A_1 \rightarrow B_1 \rightarrow C_1$ :

 $A_1 \rightarrow B_1$ : Rapid traverse speed in ns block in G0, cutting feedrate specified by G73 in ns block in G1;

 $B_1 \rightarrow C_1$ : Cutting feed.

③  $C_1 \rightarrow A_2$ : Rapid traverse.

(4) Second roughing  $A_2 \rightarrow B_2 \rightarrow C_2$ :

 $A_2 \rightarrow B_2$ : Rapid traverse speed in ns block in G0, cutting feedrate specified by G73 in ns block in G1;

 $B_2 \rightarrow C_2$ : Cutting feed.

(5)  $C_2 \rightarrow A_3$ : Rapid traverse:

.....

No. n times roughing,  $A_n {\rightarrow} B_n {\rightarrow} C_n$  :

 $A_n \rightarrow B_n$ : ns Rapid traverse speed in ns block in G0, cutting feedrate specified by G73 in ns block in G1;

 $B_n \rightarrow C_n$ : Cutting feed.

 $C_n \rightarrow A_{n+1}$ : Rapid traverse;

.....

Last roughing,  $A_d \rightarrow B_d \rightarrow C_d$ :

 $A_d \rightarrow B_d$ : Rapid traverse speed in ns block in G0, cutting feedrate specified by G73 in ns block in G1;

 $B_d \rightarrow C_d$ : Cutting feed.

 $C_d \rightarrow A$ : Rapid traverse to starting point;



Fig. 3-77 G73 path

#### **Command specifications:**

- ns~nf blocks in programming must be followed G73 blocks. If they are in the front of G73 blocks, the system automatically searches and executes ns~nf blocks, and then executes the next program following nf block after they are executed, which causes the system executes ns~nf blocks repetitively.
- ns~nf blocks are used for counting the roughing path and the blocks are not executed when G73 is executed. F, S, T commands of ns~nf blocks are invalid when G71 is executed, at the moment, F, S, T commands of G73 blocks are valid. F, S, T of ns~nf blocks are valid when executing ns~nf to command G70 finishing cycle.
- 3. There are only G00, G01 in ns block.
- In ns~nf blocks, there are only G commands: G00, G01, G02, G03, G04, G05, G6.2, G6.3, G7.2, G7.3, G96, G97, G98, G99, G40, G41, G42 and the system cannot call subprograms (M98/M99).
- 5. In ns $\sim$ nf, the program block quantity cannot exceed 100;
- 6. G96, G97, G98, G99, G40, G41, G42 are invalid when G73 is executed, and are valid when G70 is executed.
- 7. When G73 is executed, the system can stop the automatic run and manual traverse, but return to the position before manual traversing when G73 is executed again, otherwise, the following path will be wrong.
- 8. When the system is executing the feed hold or single block, the program pauses after the system has executed end point of current path.
- △i, △u are specified by the same U and Δk, Δw are specified by the same U, and they are different with or without being specified P,Q commands.
- 10. G73 cannot be executed in MDI, otherwise, the system alarms.
- 11. There are no the same block number in ns~nf when compound cycle commands are executed repetitively in one program.
- 12. The tool retraction point should be high or low as possible to avoid crashing the workpiece.

#### Coordinate offset direction with finishing allowance:

 $\Delta i$ ,  $\Delta k$  define the coordinates offset and its direction of roughing;  $\Delta u$ ,  $\Delta w$  define the coordinate offset and the cut-in direction in finishing, and their sign symbols are as follows Fig. 3-32: A is tool start-up point, B $\rightarrow$ C for workpiece contour, B' $\rightarrow$ C' for roughing contour and B" $\rightarrow$ C" for finishing path.



#### G73 code cutter radius compensation function:

Refer to the parital description of the G71 code cutter radius compensation.

### G73 code machining example:



Fig.3-78

Program: O0006; G99 G00 X200 Z10 M03 S500

G99 G00 X200 Z10 M03 S500;	(Specify feedrate per rev and position starting point and start spindle)
G73 U1.0 W1.0 R3 ;	(X tool retraction with 2mm, Z 1mm)
G73 P14 Q19 U0.5 W0.3 F0.3 ;	(X roughing with 0.5 allowance and Z 0.3mm)
N14 G00 X80 W-40 ;	)
G01 W-20 F0.15 S600 ;	
X120 W-10 ;	
W-20 ;	Blocks for finishing
G02 X160 W-20 R20 ;	
N19 G01 X180 W-10 ;	
G70 P14 Q19 M30;	(Finishing)

### 3.22.4 Finishing Cycle G70

Command format: G70 P(ns) Q(nf);

Command function: The tool executes the finishing of workpiece from starting point along with the finishing path defined by ns∼nf blocks. After executing G71, G72 or G73 to roughing, execute G70 to finishing and single cutting of finishing allowance is completed. The tool returns to starting point and execute the next block following G70 block after G70 cycle is completed.

ns: Block number of the first block of finishing path.

nf: Block number of the last block of finishing path.

G70 path is defined by programmed one of ns $\sim$ nf blocks. Relationships of relative position of ns, nf block in G70 $\sim$ G73 blocks are as follows:

#### G71/G72/G73 .....;



#### **Command specifications:**

- 1. ns $\sim$ nf blocks in programming must be followed G70 blocks.
- 2. F, S, T in ns~nf blocks are valid when executing ns~nf to command G70 finishing cycle.
- 3. G96, G97, G98, G99, G40, G41, G42 are valid in G70;
- 4. When G70 is executed, the system can stop the automatic run and manual traverse, but return to the position before manual traversing when G70 is executed again, otherwise, the following path will be wrong.
- 5. When the system is executing the feed hold or single block, the program pauses after the system has executed end point of current path.

- 6. There are no the same block number in ns~nf when compound cycle commands are executed repetitively in one program.
- 7. In ns $\sim$ nf, the program block quantity cannot exceed 100;
- 8. The tool retraction point should be high or low as possible to avoid crashing the workpiece.

# 3.22.5 Axial Grooving Multiple Cycle G74

Command format: G74 R(e);

### G74 X(U) \_ Z(W) \_ P( $\Delta i$ ) Q( $\Delta k$ ) R( $\Delta d$ ) F\_;

**Command function:** Axial (X axis) tool infeed cycle compounds radial discontinuous cutting cycle: Tool infeeds from starting point in radial direction(*Z*), retracts, infeeds again, and again and again, and last tool retracts in axial direction, and retracts to the *Z* position in radial direction, which is called one radial cutting cycle; tool infeeds in axial direction and execute the next radial cutting cycle; cut to end point of cutting, and then return to starting point (starting point and end point are the same one in G74), which is called one radial grooving compound cycle. Directions of axial tool infeed and radial tool infeed are defined by relative position between end point X(U) *Z*(W) and starting point of cutting. G75 is used for machining radial loop groove or column surface by radial discontinuously cutting, breaking stock and stock removal.

#### Relevant definitions:

Starting point of axial cutting cycle: starting position of axial tool infeed for each axial cutting

cycle, defining with A<sub>n</sub>(n=1,2,3.....), Z coordinate of A<sub>n</sub> is the same that of starting point A, the different value of X coordinate between A<sub>n</sub> and A<sub>n-1</sub> is  $\Delta i$ . The starting point A<sub>1</sub> of the first axial cutting cycle is the same as the starting point A, and the X coordinate of starting point (A<sub>f</sub>) of the last axial cutting cycle is the same that of cutting end point.

End point of axial tool infeed: starting position of axial tool infeed for each axial cutting cycle, defining with  $B_n(n=1,2,3....)$ , Z coordinate of  $B_n$  is the same that of cutting end point, X coordinate of  $B_n$  is the same that of  $A_n$ , and the end point ( $B_f$ ) of the last axial tool infeed is the same that of cutting end point.

**End point of radius tool retraction:** end position of radius tool infeed (travel of tool infeed is  $\Delta d$ ) after each axial cutting cycle reaches the end point of axial tool infeed, defining with  $C_n(n=1,2,3....)$ , Z coordinate of  $C_n$  is the same that of cutting end point, and the different value of X coordinate between  $C_n$  and  $A_n$  is  $\Delta d$ ;

**End point of axial cutting cycle:** end position of axial tool retraction from the end point of radius tool retraction, defining with  $D_n(n=1, 2, 3....)$ , Z coordinate of  $D_n$  is the same that of starting point, X coordinate of  $D_n$  is the same that of C<sub>n</sub> (the different value of X coordinate between it and A<sub>n</sub> is  $\Delta d$ );

Cutting end point: it is defined by X(U)  $\_$  Z(W)  $\_$  , and is defined with B<sub>f</sub> of the last axial tool infeed.

R(e): it is the tool retraction clearance after each axial(Z) tool infeed, and its range is 0~99.999(IS-B)/0~99.9999(IS-C) (unit:mm,radius) without sign symbols. The specified

value is reserved validly after R(e) is executed. The NO.056 value is regarded as the tool retraction clearance when R(e) is not input.

- X: X absolute coordinate value of cutting end point B<sub>f</sub> (unit: mm).
- U: Different value of X absolute coordinate between cutting end point B<sub>f</sub> and starting point.
- Z: Z absolute coordinate value of cutting end point B<sub>f</sub> (unit: mm).
- W: Different value of Z absolute coordinates between cutting end point B<sub>f</sub> and starting point.
- $P(\Delta i)$ : radial(X) cutting for each axial cutting cycle , range:  $0 < \Delta i \le 9999999(IS_B)/0 < \Delta i \le 999999999$  (IS\_C) (unit: least input increment, diameter value, without sign symbol).
- **Q**( $\Delta k$ ): radial(Z) cutting for each axial cutting cycle, range:  $0 < \Delta k \le 9999999(IS_B)/0 < \Delta k \le 999999999$  (IS\_C) (unit: least input increment, diameter value, without sign symbol).
- R(Δd): radial (X) tool retraction after cutting to end point of axial cutting, range: 0~99999999× least input increment (unit: mm/inch, diameter value, without sign symbol).. The radial (X) tool retraction clearance is 0 when the system defaults the axial cutting end point. The system defaults the tool retraction is executed in positive direction when X(U) and P(Δi) are omitted.

#### Execution process: (Fig. 3-79)

- Axial (Z) cutting feed △k from the starting point of axial cutting cycle, feed in Z negative direction when the coordinates of cutting end point is less than that of starting point in Z direction, otherwise, feed in Z positive direction;
- (2) Axial (Z) rapid tool retraction e and its direction is opposite to the feed direction of (1);
- ③ X executes the cutting feed (Δk+e) again, the end point of cutting feed is still in it between starting point A<sub>n</sub> of axial cutting cycle and end point of axial tool infeed, Z executes the cutting feed (Δk+e)again and execute ②; after Z executing the cutting feed (Δk+e)again, the end point of cutting feed is on B<sub>n</sub> or is not on it between A<sub>n</sub> and B<sub>n</sub> cutting feed to B<sub>n</sub> in Z direction and then execute ④;
- ④ Radial(X) rapid tool retraction △d/2 to C<sub>n</sub>, when X coordinate of B<sub>f</sub> (cutting end point) is less than that of A (starting point), retract tool in X positive, otherwise, retract tool in X negative direction;
- (5) Axial(Z axial) rapid retract tool to Dn, No. n axial cutting cycle is completed. If the current axial cutting cycle is not the last one, execute (6); if it is the previous one before the last axial cutting cycle, execute (7);
- (6) Radial(X axial)rapid tool infeed, and it direction is opposite to ④ retract tool. If the end point of tool infeed is still on it between A and A<sub>f</sub> (starting point of last axial cutting cycle) after X executes the tool infeed (△d/2+△i/2), i.e. D<sub>n</sub>→A<sub>n+1</sub> and then execute ① (start the next axial cutting cycle); if X end point of tool infeed is not on it between D<sub>n</sub> and A<sub>f</sub> after tool infeed (△d/2+△i/2), rapidly traverse to A<sub>f</sub> and execute ① to start the first axial cutting cycle;
- ⑦ X rapidly traverse to return to A, and G74 is completed.





### **Command specifications:**

- The cycle movement is executed by Z(W) and P(Δk) blocks of G74, and the movement is not executed if only "G74 R(e);" block is executed;
- 2.  $\Delta d$  and e are specified by the same address and whether there are Z(W) and P( $\Delta k$ ) word or not in blocks to distinguish them;
- 3. The tool can stop in Auto mode and traverse in Manual mode when G74 is executed, but the tool must return to the position before executing in Manual mode when G74 is executed again, otherwise the following path will be wrong.
- 4. When the single block is running, programs dwell after each axial cutting cycle is completed.
- 5.  $R(\Delta d)$  must be omitted in blind hole cutting, and so there is no distance of tool retraction when the tool cuts to axial end point of cutting.

Example: Fig. 3-80



Fig.3-80

Program (suppose that the grooving tool width is 4mm, system least increment is 0.0001mm):

O0007; G0 X36 Z5 M3 S500; (Start spindle and position to starting point of machining) G74 R0.5; (Machining cycle) G74 X20 Z-20 P30000 Q50000 F50; (Z tool infeed 5mm and tool retraction 0.5mm each time; rapid return to starting point (Z5) after cutting feed to end point (Z-20), X tool infeed 3mm and cycle the above-mentioned steps) M30; (End of program)

### 3.22.6 Radial Grooving Multiple Cycle G75

```
Command format: G75 R(e);
```

G75 X(U) Z(W)  $P(\Delta i) Q(\Delta k) R(\Delta d) F_;$ 

**Command function:** Axial (*Z*) tool infeed cycle compounds radial discontinuous cutting cycle: Tool infeeds from starting point in radial direction, retracts, infeeds again, and again and again, and last tool retracts in axial direction, and retracts to position in radial direction, which is called one radial cutting cycle; tool infeeds in axial direction and execute the next radial cutting cycle; cut to end point of cutting, and then return to starting point (starting point and end point are the same one in G75), which is called one radial grooving compound cycle. Directions of axial tool infeed and radial tool infeed are defined by relative position between end point X(U) Z(W) and starting point of cutting. G75 is used for machining radial loop groove or column surface by radial discontinuously cutting, breaking stock and stock removal.

**Relevant definitions:** 

Starting point of radial cutting cycle: Starting position of axial tool infeed for each radial cutting cycle, defined by A<sub>n</sub>(n=1, 2, 3.....), X coordinate of A<sub>n</sub> is the same that of starting point A, the different value of X coordinate between A<sub>n</sub> and A<sub>n-1</sub> is <u>Δk</u>. The starting point A<sub>1</sub> of the first radial cutting cycle is the same as the starting point A, and Z starting point (A<sub>f</sub>) of the last axial cutting cycle is the same that of cutting end point.
End point of radial tool infeed: Starting position of radial tool infeed for each radial cutting

- **End point of radial tool infeed:** Starting position of radial tool infeed for each radial cutting cycle, defined by B<sub>n</sub> (n=1, 2, 3.....), X coordinates of B<sub>n</sub> is the same that of cutting end point, Z coordinates of B<sub>n</sub> is the same that of A<sub>n</sub>, and the end point (B<sub>f</sub>) of the last radial tool infeed is the same that of cutting end point.
- **End point of axial tool retraction:** End position of axial tool infeed (travel of tool infeed is  $\Delta d$ ) after each axial cutting cycle reaches the end point of axial tool infeed, defining with  $C_n(n=1,2,3....)$ , X coordinate of  $C_n$  is the same that of cutting end point, and the different value of Z coordinate between  $C_n$  and  $A_n$  is  $\Delta d$ ;
- End point of radial cutting cycle: End position of radial tool retraction from the end point of axial tool retraction, defined by D<sub>n</sub>(n=1, 2, 3.....), X coordinate of D<sub>n</sub> is the same that of starting point, Z coordinates of D<sub>n</sub> is the same that of C<sub>n</sub> (the different value

of Z coordinate between it and  $A_n$  is  $\Delta d$ );

- Cutting end point: It is defined by X(U) \_\_ Z(W) \_\_ , and is defined with B<sub>f</sub> of the last radial tool infeed.
- R(e) : It is the tool retraction clearance after each radial(X) tool infeed, its range is 0~99.999 (unit: mm, radius value) without sign symbols. The specified value is reserved validly after R(e) is executed and the data is switched and saved to No.056. NO.056 value is regarded as the tool retraction clearance when R(e) is not input.
- X: X absolute coordinate value of cutting end point B<sub>f</sub> (unit: mm).
- U: Different value of X absolute coordinate between cutting end point  $B_f$  and starting point.
- Z: Z absolute coordinate value of cutting end point  $B_f$  (unit: mm).
- W: Different value of Z absolute coordinate between cutting end point B<sub>f</sub> and starting point A(unit: mm).
- $P(\Delta i)$ : Radial(X) discontinuous tool infeed of each axial cutting cycle, its range:  $0 < \Delta i \le 9999999$ (IS\_B)/ $0 < \Delta k \le 99999999$  (IS\_C) (unit: least input increment, without sign symbol).
- Q(<u>Δk)</u>: Axial(Z) discontinuous tool infeed of each radial cutting cycle, its range: 0 < <u>Δk≤</u> 9999999(IS\_B)/0 < <u>Δk≤</u> 999999999 (IS\_C) (unit: least input increment, without sign symbol)..
- R(Δd): Axial (Z) tool retraction clearance after cutting to end point of radial cutting, its range: 0~99999999×least input increment (unit: mm/inch, without sign symbol).

The system defaults the tool retraction clearance is 0 after the radial cutting end point is completed when R ( $\Delta d$ ) is omitted.

The system defaults it executes the positive tool retraction when Z(W) and Q( $\Delta k$ ) are omitted.





#### Execution process: (Fig. 3-81)

- Radial (X) cutting feed △i from the starting point of radial cutting cycle, feed in X negative direction when the coordinates of cutting end point is less than that of starting point in X direction, otherwise, feed in X positive direction;
- ② Radial(X) rapid tool retraction e and its direction is opposite to the feed direction of ①;
- ③ X executes the cutting feed (Δi+e) again, the end point of cutting feed is still in it between starting point A<sub>n</sub> of radial cutting cycle and end point of radial tool infeed, X executes the cutting feed (Δi+e) again and executes ②; after X cutting feed (Δi+e) is executed again, the end point of X cutting feed is on B<sub>n</sub> or is not on it between A<sub>n</sub> and B<sub>n</sub> cutting feed to B<sub>n</sub> and then execute<sub>4</sub>;
- ④ Axial(Z) rapid tool retraction △d to C<sub>n</sub>, when Z coordinate of B<sub>f</sub> (cutting end point) is less than that of A (starting point), retract tool in Z positive, otherwise, retract tool in Z negative direction;
- ⑤ Radial (X) rapid retract tool to Dn, No. n radial cutting cycle is completed. The current radial cutting cycle is not the last one, execute ⑥; if it is the previous one before the last radial cutting cycle, execute ⑦;
- (6) Axial(X) rapid tool infeed, and it direction is opposite to (4) retract tool. If the end point of tool infeed is still on it between A and A<sub>f</sub> (starting point of last radial cutting cycle) after Z tool infeed ( $\triangle d + \triangle k$ ), i.e.  $D_n \rightarrow A_{n+1}$  and then execute (1) (start the next radial cutting cycle); if the end point of tool infeed is not on it between  $D_n$  and A<sub>f</sub> after Z tool infeed ( $\triangle d + \triangle k$ ), rapidly traverse to A<sub>f</sub> and execute (1) to start the first radial cutting cycle;
- ⑦ Z rapidly traverses to A, and G75 is completed.

#### **Explanation:**
- The cycle movement is executed by X(W) and P(Δi) blocks of G75, and the movement is not executed if only "G75 R(e); " block is executed;
- 2.  $\Delta d$  and e are specified by the same address R and whether there are X(U) and P( $\Delta i$ ) words or not in blocks to distinguish them;
- 3. The tool can stop in Auto mode and traverse in Manual mode when G75 is executed, but the tool must return to the position before executing in Manual mode when G75 is executed again, otherwise the following path will be wrong;
- 4. When the system is executing the feed hold or single block, the program pauses after the system has executed end point of current path;
- R(<u>Δd)</u> must be omitted in grooving, and so there is no tool retraction clearance when the tool cuts to radial cutting end point.

Example:



Program (suppose the grooving tool width is 4mm, the system least increment is 0.001mm): O0008;

G00 X150 Z50 M3 S500;	(Start spindle with 500 r/min)
G0 X125 Z-24;	(Position to starting point of machining)
G75 R0.5 F150;	(Machining cycle)
G75 X40 Z-50 P60000 Q30000	; (X tool infeed 6mm every time, tool retraction 0.5mm,
	rapid returning to starting point (X125) after infeeding
	to end point (X40), Z tool infeed 3mm and cycle the
	above-mentioned steps to continuously run programs)
G0 X150 Z50;	(Return to starting point of machining)
M30;	(End of program)

## 3.22.7 Drilling Cycle G83 or G87

Command format:	axle drilling G83	X(U)	C(H)	Z(W)_	_ P	Q	R	F	KM	_J <u>0/1</u> ;
radial dril	lling G87 Z(W)	C(H)	X(U)	P Q	R_	_ F_	_ K_	_ M	_ J <u>0/1</u> ;	

**Code meaning:** Drilling Cycle: Rapid traverse to the drilling position from start, then perform it along with the drilling hole direction) feed, retraction, re-feed... till to the botton of a hole, and then retreact to the drilling position, a drilling cycle is then completed; Position to the drilling position again, and then perform the next drilling cycle; stop at the drilling position after the last drilling operation is performed, the drilling cycle is then completed. The drilling cycle divides into axial drilling G83 and radial drilling G87, which is used in the axial drilling (Z axis) and radial drilling (X axis) separately.

#### Relevant definition: G83, G87 is modle G code

- G83: Axial drilling cycle G code, axial (Z axis) drilling;
- G87: Radial drilling cycle G code, axial (X axis) drilling;
- (X, C): Drilling position; -----G83
- Z: at the bottom of a hole; -----G83
- (Z, C); Drilling position; -----G87
- X: at the bottom of a hole; -----G87
- P: It is pause time at the bottom, modal data, initial default value is 0 (Unit: ms), its resolution is shown in the table 1-2 of Section 1.4.1.
- Q: In-feed value each time, its range:-9999999-9999999 (IS\_B) / -99999999-99999999 (IS\_C) (unit : least input increment, radius value); Evaluate its absolute value when inputting the negative value, modal data; the initial default value is 0. When the Q value is 0, directly feed to the botton of the hole.
- R: In-feed value after the in-feed for each time, its range:0~9999.999 (IS\_B)/ 0~999.9999 (IS\_C) (unit: mm/inch, radius value); Evaluate its absolute value when inputting the negative value, modal data; the initial default value is 1.
- F: Cutting feddrate, refer to the table 1-2 in the Section 1.4.1 for its resolution.
- K: Drilling repeated times can be omitted; it is regarded as 1 by default when ignores; refer to the table 1-2 in the Section 1.4.4 for its resolution. If the the drilling position is regarded as the relevant coordinate programming, drilling is performed at difference positions.
- M: The M code is used for clamping the indexing spindle; its code value is set by data parameter No.170, which can be omitted; it does not use the spindle clamping by default when it ignores.
- J: 0: High speed peck drilling cycle;1: Peck drilling cycle, modal data. Its initial value regardes as 0 by default.

#### Code performance procedure:

- I: High speed deep hole drilling cycle (J=0):
  - Rapidly position to the drilling start position (G83: X, C; G87: Z, C;), if the M code with clamping spindle exists, output Mα after the positioning is completed;
  - ② Cutting feed Q distance: P specification time dwells and then perform ⑥ if it reaches to the bottom of a hole;
  - ③ Rapid tool-retraction R distance: If it reaches to the drilling start position during the tool-retraction, it is then retreated to the drilling start position;
  - Cutting feed (Q+R) distance: If it retracts to the drilling start position at the last time, and then cut the feed distance (Q+tool-retraction amount at last time);
  - **(5)** Cycle **(3)**(4) till to the bottom of a hole, dwell the P specification time;
  - (6) Rapid return to the drilling start position, if it executes the M code of spindle clamping,output the Mβ after the positioning is completed;
  - ⑦ If the cycle does not end instead of returning to the ①, the next machining cycle is then started;
- II: Deep hole drilling cycle (J=1):
  - Rapidly position to the drilling start position, (G83: X, C; G87: Z, C;), if the M code with clamping spindle exists, output the Mα after the positioning is completed;

- ② Cutting feed Q distance: P specification time dwells and then perform ⑦ if it reaches to the bottom of a hole;
- ③ Rapid perform the tool-retraction to the drilling start position;
- Rapid positioning to the R position distance from the last feeding depth (Point C in the drawing);
- 5 Cutting feed (Q+R) distance
- 6 Cycle 35 till to the bottom of a hole
- (7) Rapid return to the drilling start position, if it executes the M code of spindle clamping, output the M $\beta$  after the positioning is completed;
- If the cycle does not end instead of returning to the ①, the next machining cycle is then started;

Note:  $\alpha$  value is set in the data parameter No. 170,  $\beta = \alpha + 1$ ; therefore, the M codes in the PLC should be treated.



#### **Precautions:**

- 1) G83 or G87 is the modal G command of the group 01, which can be cancelled by the G command of group 01. The rest of the command words are the modal data other than the positioning place, cycle times and the M code of the clamping index spindle.
- 2) Do not use the cutter compensation C in G83 or G87 command, the cutter compensation may automatically retract when entering the drilling cycle, it may automatically recover after drilling.
- 3) It is necessary to select the G18 panel when performing the G83 or G87 command.
- 4) Fail to perform the G83, G87 command in the G71~G73 commands or polar coordinate

mode.

- 5) The drilling of G83, G87 command should be set as linear axis. (G83 drilling axis is regarded as the 2<sup>nd</sup> axis, G87 treats as the 1<sup>st</sup> one).
- 6) When the in-feed amount Q of each time is 0, perform the common drilling cycle. The drillingmachining will directly feed to the botton of a hole, and then moves to the start position at the rapid traverse rate.

## 3.23 Thread Cutting Commands

GSK980TDi CNC system can machine many kinds of thread cutting, including metric/inch single, multi threads, thread with variable lead and tapping cycle. Length and angle of thread run-out can be changed, multiple cycle thread is machined by single sided to protect tool and improve smooth finish of its surface. Thread cutting includes: continuous thread cutting G32, thread cutting with variable lead G34, Z thread cutting G33, Thread cutting cycle G92, Multiple thread cutting cycle G76.

The machine used for thread cutting must be installed with spindle encoder whose pulses are set by No.070m. Drive ratio between spindle and encoder is set by No.110 and No.111. X or Z traverses to start machine after the system receives spindle signal per rev in thread cutting, and so one thread is machined by multiple roughing, finishing without changing spindle speed.

The system can machine many kinds of thread cutting, such as thread cutting without tool retraction groove. There is a big error in the thread pitch because there are the acceleration and the deceleration at the starting and ending of X and Z thread cutting, and so there is length of thread lead-in and distance of tool retraction at the actual starting and ending of thread cutting.

X, Z traverse speeds are defined by spindle speed instead of cutting feedrate override in thread cutting when the pitch is defined. The spindle override control is valid in thread cutting. When the spindle speed is changed, there is error in pitch caused by X and Z acceleration/deceleration, and so the spindle speed cannot be changed and the spindle cannot be stopped in thread cutting, which will cause tool and workpiece to be damaged.

## 3.23.1 Thread Cutting with Constant Lead G32

 $\label{eq:command_format: G32 X(U)_ Z(W)_ F(I)_ J_ K_ Q_ \\$ 

**Command function:** The path of tool traversing is a straight line from starting point to end point as Fig.3-82; the longer moving distance from starting point to end point(X in radius value) is called as the long axis and another is called as the short axis. In course of motion, the long axis traverses one lead when the spindle rotates one revolution, and the short axis and the long axis execute the linear interpolation. Form one spiral grooving with variable lead on the surface of workpiece to realize thread cutting with constant lead. Metric pitch and inch pitch are defined respectively by F, I. Metric or inch straight, taper, end face thread and continuous multi-section thread can by machined in G32.

#### **Command specifications:**

G32 is modal;

Pitch is defined to moving distance when the spindle rotates one rev(X in radius);

Execute the straight thread cutting when X coordinates of starting point and end point are the same one(not input X or U);

Execute the end face thread cutting when X coordinates of starting point and end point are the same one(not input Z or W);

Execute the cutting taper thread when X and Z coordinates of starting point and end point are

#### different;

#### **Related definitions:**

- F: Metric pitch is moving distance of long axis when the spindle rotates one rev: 0.001 mm $\sim$ 500 mm. After F is executed, it is valid until F with specified pitch is executed again.
- I: Teeth per inch. It is ones per inch(25.4 mm) in long axis, and also is circles of spindle rotation when the long axis traverses one inch(25.4 mm) :0.06tooth/inch~25400tooth/inch. After I is executed, it is valid until I with specified pitch is executed again. The metric, inch input both express the teeth per inch thread.
- J: Movement in the short axis in thread run-out, its range: (-999999999-99999999) × least input increment with negative sign; if the short axis is X, its value is specified with the radius; J value is the modal parameter.
- K: Length in the long axis in thread run-out, its range: 0~99999999× least input increment. If the long axis is X, its value is in radius without direction; K is modal parameter.
- Q: Initial angle(offset angle)between spindle rotation one rev and starting point of thread cutting:  $0\sim360000$  (unit: 0.001 degree). Q is non-modal parameter, must be defined every time, otherwise it is  $0^0$ .

Q rules:

- 1. Its initial angle is 0° if Q is not specified;
- 2. For continuous thread cutting, Q specified by its following thread cutting block except for the first block is invalid, namely Q is omitted even if it is specified;
- 3. Multi threads formed by initial angle is not more than 65535;
- 4. Q unit : 0.001<sup>°</sup> . Q180000 is input in program if it offsets 180<sup>°</sup> with spindle one-turn; if Q180 or Q180.0, it is 0.18°.

Difference between long axis and short axis is shown in Fig. 3-82.





Notes:

1. J, K are modal. The thread run-out is previous J, K value when they are omitted in the next block in continuous thread cutting. Their mode are cancelled when no thread

cutting are executed;

- 2. There is no thread run-out when J, or K are omitted; K=J is the thread run-out value when K is omitted;
- 3. There is no thread run-out when J=0 or J=0, K=0;
- 4. The thread run-out value J=K when J $\neq$ 0,K=0;
- 5. There is no thread run-out when J=0 or  $K\neq 0$ ;

6. When parameter No.107 set to 0, its tail-retraction angle is matched with the J or K ratio. When the parameter No.107 does not set to 0, the tail-retraction speed of the short axis is set by parameter value, and the tail-retraction angle is determined by thread cutting speed and short axis tail-retraction speed;

- If the current block is for thread and the next block is the same, the system does not test the spindle encoder signal per rev at starting the next block to execute the direct thread cutting, which function is called as continuous thread machining;
- After the feed hold is executed, the system displays "Pause" and the thread cutting continuously executes not to stop until the current block is executed completely; if the continuous thread cutting is executed, the program run pauses after thread cutting blocks are executed completely;
- 8. In Single block, the program stops run after the current block is executed. The program stops running after all blocks for thread cutting are executed;
- 9. The thread cutting decelerates to stop when the system resets, emergently stop or its drive unit alarms.

**Example:** Pitch: 2mm.  $\delta 1 = 3mm$ ,  $\delta 2 = 2mm$ , total cutting depth 2mm divided into two times cut-in.





Program:

O0009;

G00 X27.4286	Z3;	(First cut-in 1mm)
G32 X48.8571	W-75 F2.0;	(First taper cutting)
G00 X55;	(Too	l retraction)
W75;	(Z re	eturns to the starting point)
X26.4286;		(Second tool infeed 0.5mm)
G32 X47.4286	W-75 F2.0;	(Second taper thread cutting)
G00 X55;	(Tool	l retraction)
W75 ;	(Z re	turns to the starting point)
M30;		

## 3.23.2 Rigid Thread Cutting G32.1

## $\label{eq:command_format: G32.1 X(U) Z(W) C(H) F(I) S_;$

**Command function:** The traditional thread interpolation calculates the current distance of the movement of the feed axis based on the feedback pulse count of the position encoder installed on the spindle, which can realize the feed axis to follow the thread interpolation mode of the spindle. Its disadvantages are that there is a big error in the thread lead in acceleration/deceleration. In the rigid thread interpolation mode, the working of the spindle motor is the same that of the servo motor, and the interpolations between the feed axis and the spindle execute the thread interpolation to get the thread with high precision.

#### **Command explanation:**

- G32.1 : Rigid thread interpolation command;
- C : Start angle of thread interpolation;
- (X,Z) : End point coordinates of thread interpolation;
- F(I) : Thread lead, F(I) > 0 right-hand thread, F(I) < 0 left-hand thread;
- J: Movement in the short axis in thread run-out, its range: (-999999999-99999999) × least input increment with negative sign; If the short axis is X, its value is specified with the radius; J value is the modal parameter.
- K: Length in the long axis in thread run-out, its range: 0~99999999x least input increment. If the long axis is X, its value is in radius without direction; K is modal parameter.
- S: spindle speed;

#### **Explanations:**

- 1) G32.1 is in Group 01;
- 2) When there is the C movement command in a block, the spindle firstly positions the start point of C axis before turning the thread;
- 3) Start points of X, Z, C axis must be the same one in the repetitive machining;
- 4) G32.1 cannot specify the thread run-out, and the feed axis and the spindle stops simultaneously at the end point of the thread;
- 5) The input range of the programmed address value in G32.1 is the same that of the general thread turning command (G32);
- 6) When G32.1 is executed, the pause signal is disabled temporarily and the spindle override is fixed to be 100%.

Command path is shown below:



Fig. 3-84 G32.1 path

#### Notes:

- 1) The spindle must be in the position control mode when it works;
- In multiple spindle control function, G32.1 is used only between the 1<sup>st</sup> spindle and the feed axis, and their uses and the related parameter settings are the same those of the rigid tapping;
- In G32.1, CNC does not check whether the current spindle is the position control mode or the speed control mode. So, the servo control axis of the 1<sup>st</sup> spindle is set to Cs working mode to avoid the coordinate overflow;
- Absolute coordinates of C axis are set to the cycle mode to avoid the coordinate overflow;
- The speed control mode is switched to the position control mode in the spindle control mode. Please execute that the spindle returns to the reference point or use G50 to set the start point of the current C axis;
- Example: Supposing M14: the spindle is switched to the position control mode; M15: the spindle is switched to the speed control mode.

The thread is the right-hand, its lead is 2mm, the spindle speed is 500 r/m in thread cutting, thread cutting length is 20mm, and its programming format is shown below:

00132 (0132);

G00 X100 Z100; //position to the safe position to change the tool

T0101; //change a thread tool (supposing No. 01 is the thread tool)

- G00 X25 Z2; //position to the thread starting point (supposing the shape has been made at the last tool)
- M14; //switch the spindle from speed control mode to position control mode (it is 0<sup>-</sup> position after switch)
- G50 C0; // set the zero of the rotary axis(it is important to set it because the operation is relevant to the start angle of the following thread turning)

G32.1 Z-20 F2 S500 M08; //thread turning; the speeds of the spindle and the feed axis are0 in

end point

- G00 X100; //tool retraction
- Z100; //return to tool change position

M15;	//switch the spindle from position control mode to speed control mode
;	//execution the 2 <sup>nd</sup> machining procedure
;	
M30;	//end of program

## 3.23.3 Arc Threading Cutting Code G32.2 or G32.3

Code format: G32.2

G32.3 X(U)\_\_\_Z(W)\_\_\_R\_\_ (I\_\_K\_\_) F\_\_Q\_\_

**Code function:** The movement path of arc thread is a section of arc from start to end; The coordinate axis with bigger shifting value where from the start to end is regarded as long axis; the other one is called short axis. The long axis moves a lead while the spindle rotates one cycle during the operation. A constant pitch helical slot generates on the workpiece surface when the tool cuts the workpiece, so that the constant pitch thread machining is carried out. The F command is used for the provided thread pitch, the arc thread machining of the constant pitch can be performed by executing the G32.2 / G32.3 command.

#### **Code explanations:**

- 1) G32.2/G32.3 is modal;
- 2) The leading of the thread is the displacement value (The displacement value along X axis is based upon the radius value) of one cycle for the spindle.
- 3) When bit 7 of parameter No.202 is set to 0, arc thread follows with the feedback signal of spindle encoder; when the bit 7 of the state parameter No.202 is 1, arc thread cutting feed is performed the linkage interpolation with the servo spindle; in this case, the spindle, there is not alternative other than the servo spindle;
- 4) G32.2 CW arc thread machining, G32.3 CCW arc thread machining; the judgement methods for the CW, CCW and G02, G03 arc maching command are identical;

#### Q use rules:

- 1) When the bit 7 of state parameter No. 202 sets to 1, Q value is disabled; in this case, the start angle of the thread can be directly specified by C address;
- 2) If the Q does not specify, namely, it is regarded as start angle 0 by default;
- 3) The overall threads of the mult-pitch formed by start angle indexing should be less than 65535.
- 4) Q's unit is 0.001 degree, if it offsets 180 degree to the spindle one-turn signal, input Q180000 to the program; if the Q180 or Q180.0 is input, it separately regards as 0.18 degree.

The schematic of the command execution path is shown below:



#### **Precautions:**

- 1) R value is enabled when R is simultaneously specified with I or K;
- 2) The specified arc block by arc thread must be performed within the certain area (The area of which the X or Z axis is separately regarded as long axis); refer to the following figure:



3) The arc specified by arc thread, if its long axis changes, the alarm may occur; refer to the following figure:



## 3.23.4 Thread Cutting with Variable Lead G34

Command format: G34 X(U) Z(W) F(I) J K R ;
 Command function: The motion path of tool is a straight line from starting point of X, Z to end point specified by the block, the longer moving distance from starting point to end point(X in radius value) is called as the long axis and another is called as the short axis. In course of motion, the long axis traverses one lead when the spindle rotates one rev, the pitch increases or decreases a

specified value per rev and one spiral grooving with variable lead on the surface of workpiece to realize thread cutting with variable lead. Tool retraction can be set in thread cutting.

F, I are specified separately to metric, inch pitch. Executing G34 can machine metric or inch straight, taper, end face thread with variable pitch.

## **Command specifications:**

G34 is modal;

Meanings of X(U), Z(W), J, K are the same that of G32;

F: Specify lead, and its range is referred to Table 1-2;

I: Specify thread teeth per inch, and its range is referred to Table 1-2;

- R: Increment or decrement of pitch per rev, R=F1- F2, with direction; F1>F2, pitch decreases when R is negative; F1<F2, pitch increases when R is positive (as Fig. 3-41);
- R: ±0.001~±500.000 mm/pitch (metric thread);

 $\pm 0.060 \sim \pm 2540$  tooth/inch (inch thread).

The system alarms when R exceeds the above-mentioned range or the pitch exceeds permissive value or is negative owing to R increases or decreases.



Fig. 3-85 Variable pitch thread

#### Note: It is the same as that of G32.

Example: First pitch of starting point: 4mm, increment 0.2mm per rev of spindle.





Use macro variables to simplify programming when G34 is used many times.  $\delta 1 = 4mm, \delta 2 = 4mm$ , total cutting depth 4mm, total cutting cycle 15 times; first tool infeed 0.8mm, gradual decreasing cutting every time 0.2mm, min. infeed 0.2mm.

Program: O0010;

G00 X60 Z4 M03 S500; G65 H01 P#102 Q800; G65 H01 P#103 Q0; N10 G65 H02 P#104 Q#103 R1;

First tool infeed: assignment #102=0.8mm Cycle count: assignment #103=0 Cycle count starting: #104=#103+1 #103=#104 G65 H01 P#103 Q#104; G65 H81 P30 Q#104 R15; G00 U-10: G65 H01 P#100 Q#102; G00 U-#100; G34 W-78 F3.8 J5 K2 R0.2; G00 U10: Z4: G00 U-10; G65 H03 P#101 Q#100 R0.2; G65 H01 P#102 Q#101; G65 H86 P20 Q#102 R0.2; G65 H80 P10; N20 G65 H01 P#102 R0.2; G65 H80 P10; N30 :

Total cutting cycle times: #104=15,jump to block N30 Tool infeed to  $\Phi$ 50 Cutting infeed: #100=#102 Tool infeed Variable pitch cutting Tool retraction Z returns to starting point Decreasing of cutting feed again: #101=#100-0.2 Assignment again #102=#101 Infeed: Jump to block N20 when #102  $\leq$  0.2mm Unconditionally jump to block N10 Min. infeed: #102=0.2

## 3.23.5 Z Thread Cutting G33

#### Command format: G33 Z(W)\_\_\_ F(I)\_\_\_ L\_\_;

**Command function:** Tool path is from starting point to end point and then from end point to starting point. The tool traverses one pitch when the spindle rotates one rev, the pitch is consistent with pitch of tool and there is spiral grooving in internal hole of workpiece and the internal machining can be completed one time.

Unconditionally jump to block N10

#### Command specification: G33 is modal command;

- Z(W): When Z or W is not input and starting point and end point of Z axis are the same one, the thread cutting must not be executed;
- F: Thread pitch, and its range is referred to Table 1-2;
- I: Specify thread teeth per inch, and its range is referred to Table 1-2;
- L: Multi threads: 1~99 and it is modal parameter. (The system defaults it is single thread when L is omitted)

#### Cycle process:

- 1) Z tool infeed (start spindle before G33 is executed);
- 2 M05 signal outputs after Z reaches the specified end point in programming;
- ③ Test spindle after completely stopping;
- ④ Spindle rotation (CCW) signal outputs (reverse to the original rotation direction);
- (5) Z executes the tool retracts to starting point;
- ⑥ M05 signal outputs and the spindle stops;
- 0 Repeat the steps  $\textcircled{0}{\sim}\textcircled{6}$  if multi threads are machined.

**Example:** Fig. 3-87, thread M10×1.5



Fig.3-87

Program:

O0011;	
G00 Z90 X0 M03;	Start spindle
G33 Z50 F1.5;	Tap cycle
M03	Start spindle again
G00 X60 Z100;	Machine continuously
M30	

- Note 1: Before tapping, define rotation direction of spindle according to tool rotating. The spindle stops rotation after the tapping is completed and the spindle is started again when machining thread continuously.
- Note 2: G33 is for rigid tapping. The spindle decelerates to stop after its stop signal is valid, at the moment, Z executes continuously infeeds along with the spindle rotating, and so the actual cutting bottom hole is deeper than requirement and the length is defined by the spindle speed and its brake in tapping.
- Note 3: Z rapid traverse speed in tapping is defined by spindle speed and pitch is not relevant to cutting feedrate override.
- Note 4: In Single block to feed hold, the tapping cycle continuously executes not to stop until the tool returns to starting point when the system displays "Pause".
- Note 5: The thread cutting decelerates to stop when the system resets, emergently stop or its driver alarms.

## 3.23.6 Rigid Tapping G84, G88

 $\label{eq:command_format: End face rigid tapping G84 X(U) \_ C(H) \_ Z(W) \_ P \_ F(I) \_ K \_ M \_;$ 

Side rigid tapping G88 Z(W)\_\_ C(H)\_\_ X(U)\_\_ P\_\_ F(I)\_\_ K\_\_ M\_\_;

#### Command explanations: modal G codes

- G84: End face tapping cycle G code
- G88: Side tapping cycle G code
- (X, C): Tapping hole position; -----G84
- Z: Hole bottom position of tapping; -----G84
- (Z, C): Tapping hole position; -----G88
- X: Hole bottom position of tapping hole; -----G88
- P: Pause time (ms) when tapping to the hole bottom
- F(I): Thread lead, F(I) > 0 right-hand tapping, F(I) < 0 left-hand tapping, and its range is referred to Table 1-2
- K: Repetitive count of tapping. When the incremental programming is used to the tapping hole position, the tapping is performed in the different hole position, and its range is referred to Table 1-2
- M: Used to clamp the graduation spindle.

#### Rigid tapping method:

- M29 S\_ before G84/G88 is specified below M29 S\_; G84(G88) X\_C\_(Z\_C\_) Z\_(X\_) P\_ F\_ K\_ M\_;
- M29 S\_ in the same block is commanded below G84(G88) X\_C\_(Z\_C\_) Z\_(X\_) R\_ P\_ F\_ K\_ M29 S\_;

#### Notes :

For the above 2<sup>nd</sup> method, the machine zero return is executed before the spindle executes the tapping, otherwise, the method cannot be used. In M29, CNC cannot select a spindle to execute the tapping. The rigid tapping needs to be clamped when the spindle positioning is completed, the method also cannot be used because M codes cannot be in the same block;

- 2) The axis movement command cannot be use between M29 and G84/G88;
- 3) M29 cannot be specified repetitively in rigid tapping;
- 4) In multiple spindle rigiding tapping, a spindle used to the rigid tapping must be selected before M29, and it cannot be switched before the rigid tapping state is cancelled;

Operations is shown below:



#### **Execution explanations:**

- 1) Operation 1: positioning to the hole position (starting point of rigid tapping);
- 3) Operation 2: start the rigid tapping;
- 4) Operation 3: pause time P in rigid tapping in hole bottom;
- 5) Operation 4: the rigid tapping returns to the hole bottom (starting point of rigid tapping;
- 6) When the block for rigid tapping specifies M code used to clamp the spindle, M $\beta$  is output.

#### Note: $\alpha$ value is set in No170, $\beta = \alpha + 1$ , so, these corresponding M codes in PLC are executed.

#### **Rigid tapping sequence**

Taking example of G84 right-hand tapping, explain the creation, execution and cancellation of rigid tapping.

Creation and execution of rigid tapping



The spindle rotation operation is defined that the rotary axis is switched to the position control mode(i.e. send the position mode switch signal to the servo spindle), and the system checks the position mode arrival signal of the servo spindle.

#### **Rigid tapping cancellation**

The cancellation methods of rigid tapping are shown below:

1) G80 cancels the rigid tapping mode;

- 2) G codes commands other cycles;
- 3) Other G codes in Group 01;
- 4) CNC resets.

## The falling edge of F76.3 signal cancels the rigid tapping mode signal.

1) RTCRG(№186#2) is set to '1' when:

The system executes directly the next block instead of waiting the rigid tapping mode signal RGTAP<G61  $\pm$  0> to become '0'.

Rigid tapping cancellation is shown below:



#### 2) RTCRG(№186#2) is set to '0' when:

Wait the rigid tapping mode signal RGTAP<G61 $\pm$ 0> to become '0' and then execute the next block. Rigid tapping cancellation is shown below:



#### Notes:

- 1) In rigid tapping, when the tapping direction is changed (i.e. G84 and G88 are switched), the system specifies again the hole bottom position of the tapping, otherwise, the unexpected result rises;
- 2) The rigid tapping G command is in Group 01, it is cancelled temporarily in the rigid tapping state, and then is recovered it after the tapping is done;
- 3) The dry run function is disabled in rigid tapping;
- 4) In the rigid tapping, the machine lock function is valid; the tapping axis and the spindle do not move when the machine lock function is enabled;
- 5) When the reset is executed in the rigid tapping, the rigid tapping state is released and the spindle returns to the previous state before the rigid tapping;
- 6) In rigid tapping, when the tapping block is executed and the tapping returns, the feed hold/single block run function is disabled temporarily till the tapping return completes;
- 7) In rigid tapping mode, the backlash compensation is performed to compensate the dry run of the spindle rotation(CW, CCW). It is set in parameters №34. The backlash compensation along the tapping axis is performed in general method;
- In multiple spindle tapping, the 1<sup>st</sup> spindle is used to the graduation and the 2<sup>nd</sup> to the tapping.
   After the 1<sup>st</sup> spindle graduation is completed, the spindle must be clamped on the machine

and the machine clamping/releasing M code can be specified in the rigid tapping. M code used to clamp the spindle is added in G84/G88, i.e. the system can output two kinds of M code. M code used to clamp the spindle is set in the data parameter (№170). M code used to the releasing is the setting value +1 of №170;

9) Setting RTORI (state parameter №186#7) to 1 can execute the reference point return of the spindle before the system starts the rigid tapping.

## 3.23.7 Thread Cutting Cycle G92

**Command function:** Tool infeeds in radial(X) direction and cuts in axial(Z or X, Z) direction from starting point of cutting to realize straight thread, taper thread cutting cycle with constant thread pitch. Thread run-out in G92: at the fixed distance from end point of thread cutting, Z executes thread interpolation and X retracts with exponential or linear acceleration, and X retracts at rapidly traverse speed after Z reaches to end point of cutting as Fig. 3-88.

#### **Command specifications:**

G92 is modal;

Starting point of cutting: starting position of thread interpolation;

End point of cutting: end position of thread interpolation;

- X: X absolute coordinate of end point of cutting, unit: mm;
- U: different value of X absolute coordinate from end point to starting point of cutting, unit: mm;
- Z: Z absolute coordinate of end point of cutting, unit: mm;
- W: Different value of X absolute coordinate from end point to starting point of cutting, unit: mm;
- R: Different value(radius value) of X absolute coordinate from end point to starting point of cutting. When the sign of R is not the same that of U,  $R \le U/2$ , unit: mm;
- F: Thread lead, its range: 0< F ≤500 mm. After F value is executed, it is reserved and can be omitted;
- I: Thread teeth per inch, its range: 0.06tooth/inch~25400tooth/inch , it is reserved and it can be omitted not to input after I specified value is executed;
- J: Movement in the short axis in thread run-out, its range 0~99999999x least input increment, unit: mm/inch, without direction ( automatically define its direction according to starting position of program), and it is modal parameter. If the short axis is X, its value is specified by radius;
- K: Movement in the long axis in thread run-out, its range: 0~99999999x least input increment, unit: mm/inch, without direction ( automatically define its direction according to starting position of program), and it is modal parameter. If the long axis is X, its value is specified by radius;
- L: Multi threads:  $1 \sim 99$  and it is modal parameter. (The system defaults it is single thread when L is omitted).





The system can machine one thread with many tool infeed in G92, but cannot do continuous two thread and end face thread. Definition of thread pitch in G92 is the same that of G32, and a pitch is defined that it is a moving distance of long axis(X in radius) when the spindle rotates one rev.

Pitch of taper thread is defined that it is a moving distance of long axis(X in radius). When absolute value of Z coordinate difference between B point and C point is more than that of X (in radius), Z is long axis; and vice versa.

Cycle process: straight thread as Fig.3-88 and taper thread as Fig.3-89.

- ① X traverses from starting point to cutting starting point;
- 2 Thread interpolates (linear interpolation) from the cutting starting point to cutting end point;
- ③ X retracts the tool at the cutting feedrate (opposite direction to the above-mentioned ①), and return to the position which X absolute coordinate and the starting point are the same;

④ Z rapidly traverses to return to the starting point and the cycle is completed.

#### Notes:

- 1) Length of thread run-out is specified by №019 when J, K are omitted;
- 2) Length of thread run-out is K in the long direction and is specified by №019 when J is omitted;
- 3) Length of thread run-out is J=K when K is omitted;

- 4) There is no thread run-out when J=0 or J=0, K=0;
- 5) Length of thread run-out is J=K when  $J\neq 0, K=0$ ;
- 6) There is no thread run-out when  $J=0, K\neq 0$ ;
- 7) When parameter No. 107 sets to 0, the tail-retraction angle is matched with the J or K ratio. When the No. 107 does not set to 0, the tail-retraction speed of the short axis is regarded as parameter setting value, and the tail-retraction angle is determined by thread cutting speed and short axis tail-retraction speed;
- 8) After executing the feed hold in thread cutting, the system does not stop cutting until the thread cutting is completed with *Pause* on screen;
- 9) After executing single block in thread cutting, the program run stops after the system returns to starting point(one thread cutting cycle is completed);
- 10) They are executed as the positive values when J, K negative values are input;
- 11) Thread cutting decelerates to stop when the system resets, emergently stops or its driver alarms.

**Command path:** relative position between thread cutting end point and starting point with U, W, R and tool path and thread run-out direction with different U, W, R signs below:



Example: Fig.3-91





Program:

O0012;	
M3 S300 G0 X150 Z50 T0101;	(Thread tool)
G0 X65 Z5;	(Rapid traverse)
G92 X58.7 Z-28 F3 J3 K1;	(Machine thread with 4 times cutting, the first tool infeed
	1.3mm)
X57.7 ;	(The second tool infeed 1mm)
X57;	(The third tool infeed 0.7mm)
X56.9;	(The fourth tool infeed 0.1mm)
M30:	

## 3.23.8 Rigid Thread Cutting Cycle G92.1

Command format:G92.1 $X(U)_Z(W)_F_L_S_;$	(Metric straight thread cutting cycle)
G92.1 X(U)_ Z(W)_ I_ L_ S_;	(Inch straight thread cutting cycle)
G92.1 X(U)_Z(W)_R_F_L S_;	(Metric taper thread cutting cycle)
$G92.1 X(U) \_ Z(W) \_ R \_ I \_ L  S_;$	(Metric taper thread cutting cycle)
Command function: Perform the radial (X axis) in-feed	d or axial (Z axis or X and Z axes) cutt

**ommand function:** Perform the radial (X axis) in-feed or axial (Z axis or X and Z axes) cutting from the cutting start, simultaneously, the work of the spindle motor is identical with the feed servo motor, as well the thread interpolation is performed by interpolation between the feed axis and spindle; therefore, the higher accuracy thread is then gained to achieve the cutting cycle of the straight thread of the constant pitch or the cone thread.

## Command specification:

G92.1 is modal;

Starting point of cutting: starting position of thread interpolation;

- End point of cutting: end position of thread interpolation;
- X: X absolute coordinate of end point of cutting, unit: mm;
- U: Different value of X absolute coordinate from end point to starting point of cutting, unit: mm;
- Z: Z absolute coordinate of end point of cutting, unit: mm;
- W: Different value of X absolute coordinate from end point to starting point of cutting, unit: mm;
- R: Different value (radius value) of X absolute coordinate from end point to starting point of cutting. When the sign of R is not the same that of U,  $R \le U/2$ , unit: mm;

- F: Thread lead,. After F value is executed, it is reserved and can be omitted; F (1) > 0 right-hand thread, F (1) < 0 left-hand thread;
- L: Multi threads:  $1 \sim 99$  and it is modal parameter. (The system defaults it is single thread when L is omitted)
- S: The speed of thread cutting and modal value can be specified the spindle speed before this block;





The system can machine one thread with many tool infeed in G92.1, but cannot do continuous two thread and end face thread. Definition of thread pitch in G92.1 is the same that of G32, and a pitch is defined that it is a moving distance of long axis(X in radius) when the spindle rotates one rev.

Pitch of taper thread is defined that it is a moving distance of long axis(X in radius). When absolute value of Z coordinate difference between B point and C point is more than that of X (in radius), Z is long axis; and vice versa.

Cycle process: straight thread as Fig.3-92 and taper thread as Fig.3-93.

- X axis rapidly moves to the cutting start B from the cycle start A. Spindle positions to the start angle if it is the multi-head thread. Refer to the motion ① in the Fig. 3-92 or 3-93;
- 2 The feed axis is interpolated to end C with the spindle thread from the cutting start B,

the feed axis and spindle are entirely stopped at the end C.Refer to the motion (2) in the Fig. 3-92 or 3-93;

- ③ X axis retracts to the point D from C at the rapid traverse rate, refer to motion ③ in the Fig. 1 or 3-93;
- ④ Z axis retreats to A from point D at the rapid traverse rate, simultaneously, the spindle positions to the initial angle of the cycle machining, and then the cycle is ended, refer to the motion ④ in the Fig. 3-92 or 3-93.

#### Precautions:

1) The spindle, there is not alternative other than to work at the position controllable mode;

2) In the case of the multi-spindle controllable function, G92.1 is only used between the 1<sup>st</sup> spindle simultaneous feed, the usage and relevant parameter setting is identical with the rigid tapping;

3) When performing the G92.1 command, CNC system will not detect whether the current spindle is on the position or speed controllable method, therefore, when using this command, it is better to set the 1<sup>st</sup> spindle servo controllable axis as the Cs axis working mode to guarateen the safety;

4) The absolute coordinate value of the spindle controllable axis (C axis) should be set as cycle method to avoid the coordinate value flowing;

5) When the spindle controllable method shifts to the position method from speed controllable method, it is better to perform the spindle reference point return operation or set the start position of the current controllable axis (C axis) by G50.

6) Both the feed axis and spindle are performed the interpolation from the start of the cutting to the end. The spindle and feed axis are stopped at the thread interpolation end position, instead of performing the tail-retraction operation;

7) Spindle returns to the initial angle when the cycle is completed, for example, the current position of the spindle is  $30^{\circ}$  before the cycle, the single cycle is then ended; spindle returns to  $30^{\circ}$  in the motion ④; the positioning direction is identical with the spindle rotation direction of which when the thread interpolation is performed.

8) During the multi-head thread, spindle positions to the outside of its corresponding start angle by the current thread head when the motion (1) is performed. For example: the current position of the spindle is 30°, machine the 6-head thread, when machining at the 2nd theard head, the spindle positions at the 90° when performing the motion (1), as well it returns to 30° again when performing the motion (4);

9) After executing the feed hold in thread cutting, the system does not stop cutting until the thread cutting is completed with Pause on screen;

10) After executing single block in thread cutting, the program run stops after the system returns to starting point(one thread cutting cycle is completed);

11) Thread cutting decelerates to stop when the system resets, emergently stops or its driver alarms.

**Command path:** relative position between thread cutting end point and starting point with U, W, R and tool path and thread run-out direction with different U, W, R signs below:

1) U>0, W<0, R>0 2) U<0, W<0, R<0



## 3.23.9 Thread Reparation Function G92 P1 or G92.1 P1

Code format: G92 X(U)\_Z(W)\_R\_F(I)\_L\_P\_S\_; G92.1 X(U)\_Z(W)\_R\_F(I)\_L\_P\_S\_; (Follow thread reparation) (Interpolation thread reparation)

**Code function:** When the machine tool matches with the frequency-conversion spindle, the damaged thread can be recovered using the G92 P1 code; the long axis moves a lead while the spindle rotates one cycle, its motion procedure is identical with the G92. When the machine tool matches with the servo spindle, the damaged thread can be recovered using the G92.1 P1 code, and the thread interpolation can be performed by the interpolation between the feed axis and spindle, its motion procedure is identical with the G92.1.

#### Code explanations:

Modal command;

Starting point of cutting: starting position of thread interpolation;

End point of cutting: end position of thread interpolation;

- X: X absolute coordinate of end point of cutting, unit: mm;
- U: Different value of X absolute coordinate from end point to starting point of cutting, unit: mm;
- Z: Z absolute coordinate of end point of cutting, unit: mm;
- W: Different value of X absolute coordinate from end point to starting point of cutting, unit: mm;
- R: Different value (radius value) of X absolute coordinate from end point to starting point of cutting. When the sign of R is not the same that of U,  $R | \le | U/2 |$ , unit: mm;
- F: Thread lead. After F value is executed, it is reserved and can be omitted; F (I) > 0 right-hand thread,F (I) < 0 eft-hand thread;
- L: Multi threads:  $1 \sim 99$  and it is modal parameter. (The system defaults it is single thread when L is omitted)

P: Thread recovery mark: 0: Do not perform the reparation function, 1: Perform the reparation function;

S: The revolving speed of the thread cutting and the modal value can be specified the spindle speed before this block;

#### **Operation methods:**

- Thread reparation function usage: Before using the thread recovery, set the Bit 4 of state parameter No.174 to "1", the function is then performed; the setting of Bit 5 of state parameter No.174 can be recovered the mode of the thread.
- 2) Thread reparation position record: In the Manual, MPG or single-step mode, shift the spindle into the position controllable method (Do not use this controllable method when using follow thread reparation), move the tool to the measure position by the X, Z axis or spindle; cutter nose should be coincided with the tooth cavity as much as possible by moving the tool, refer to the following figure:



In this case, enter to the position interface by Thread , to the absolute coordinate page by

soft function button; press the REC.POS soft function button, the system is then automatically recorded the coordinate information of this position and the angle of the spindle. The recorded position information is performed the M30 code in the program, alternatively, when the main program is ended with M99 code; here, the recorded position is regarded as already used by the system, the recorded value is then cleared; if the thread needs recover again, it is necessary to record the position again. This operation will directly affect the accuracy of the thread recovery, therefore, it is better to overlap the cutter nose of the tool and the thread slot as much as possible.

3) Thread recovery performance: Perform the thread recovery operation by using the G92.1 or G92 code; the system may automatically perform the thread recovery operation based upon the recorded position previously.

#### **Precautions:**

- When the thread reparation function is disabled, P1 parameter is specified in G92, G92.1 code, the system is then automatically ignored;
- 2) When the thread reparation function is enabled, P1 does not specify in the G92, G92.1 code or the value of other Non-1, the system will not perform the reparation function;
- 3) When the thread recovery function is enabled, as well the P1 parameter is specified in G92 or G92.1 code; the system alarm may occur when the thread recovery position record does not prform in the Manual, MPG or Single-step mode;
- 4) When the multi-block G92, G92.1 code is used to repair the thread, the P1 parameter only should be specified in the G92, G92.1 code of the 1st block, the thread machining start angle calculated by system may be succeeded to the subsequent G92, G92.1 thread block;
- 5) When the coordinate of the measure position long axis does not between the start and end points of which the thread block long axis is specified by P1, the alarm is then generated.
- 6) When the thread is recovered by G92 P1, the Bit 5 of state parameter No.174 should be set to 1; when the thread is recovered by G92.1 P1, the Bit 5 of state parameter No.174 should be set to 0.
- 7) When the thread reparation is performed, the numerical value of the data parameter No.191 should be calibrated (This value is the tolerance value (EPO) at the stable

position where the axis operation speed of servo drive along each axis is 1m/min); otherwise, the recovered thread may be generated an offset;

## 3.23.10 Multiple Thread Cutting Cycle G76

 Command format:
 G76 P(m) (r) (a)
 Q(△dmin)
 R(d);

 G76 X(U)
 Z(W)
 R(i)
 P(k)
 Q(△d)
 F(I)
 ;

**Command function:** Machining thread with specified depth of thread (total cutting depth) is completed by multiple roughing and finishing, if the defined angle of thread is not 0°, thread run-in path of roughing is from its top to bottom, and angle of neighboring thread teeth is the defined angle of thread. G76 can be used for machining the straight and taper thread with thread run-out path, which is contributed to thread cutting with single tool edge to reduce the wear of tool and to improve the precision of machining thread. But G76 cannot be used for machining the face thread. Machining path is shown in Fig. 3-94:

#### **Command specifications:**

X: X absolute coordinate (unit: mm) of thread end point;

U: Different value (unit: mm) of X absolute coordinate between thread end point and starting point;

Z: Z absolute coordinate (unit: mm) of thread end point;

W: Different value (unit: mm) of Z absolute coordinate between thread end point and starting point;

**P(m):** Times of thread finishing:  $00 \sim 99$  (unit: times). The value of system parameter No057 is regarded as finishing times when m is not input. In thread finishing, every feed cutting amount is equal to the cutting amount d in thread finishing dividing the finishing times m;

**P(r):** Width of thread run-out 00 $\sim$ 99(unit: 0.1×L,L is the thread pitch). The value of system parameter №019 is the width of thread run-out when r is not input. The thread run-out function can be applied to thread machining without tool retraction groove and the width of thread run-out defined by system parameter №019 is valid for G92, G76;

**P(a):** Angles at taper of neighboring two tooth, range: 00~99, unit: deg(°). The system parameter №058 value is regarded as angle of thread tooth. The actual angle of thread in defined by tool ones and so a should be the same as the tool angle;

 $\Delta Q(\Delta dmin)$ : Minimum cutting travel of thread roughing, range:  $0 \sim 999999($  IS-C)/  $0 \sim 99999($  IS-B),(unit: least input increment, radius value). When  $(\sqrt{n} - \sqrt{n-1}) \times \Delta d < \Delta dmin, \Delta dmin$  is regarded as the cutting travel of current roughing and the subsequent rough-machining cutting value and the in-feed depth will not calculate based upon the formula any more. Setting  $\Delta dmin$  is to avoid the too small of roughing amount and too many roughing times caused by the cutting amount deceleration in thread roughing. When Q ( $\Delta dmin$ ) is not input, the system data parameter NO.059 value is taken as the least cutting amount;

**R(d):** It is the cutting amount in thread finishing, range:  $00 \sim 99.999(IS_B) /00 \sim 99.9999(IS_C)$  (unit: mm/inch, radius value without sign symbols), the radius value is equal to X absolute coordinates between cut-in point Be of thread finishing and Bf of thread roughing.. The value of system parameter Nº060 is regarded as the cutting travel of thread finishing when R(d) is not input;

**R(i):** It is thread taper and is the different value of X absolute coordinate between thread starting point and end point, rang: -99999.999-9999.999(IS\_B) /-9999.9999-9999.9999(IS\_C) (unit:: mm/inch, radius value). The system defaults R(i)=0(straight thread) when R(i) is not input;

**P(k):** Depth of thread tooth, the total cutting depth of thread, range:  $1 \sim 999999999($ unit: least input increment, radius value, without sign symbols). The system alarms when P(k) is not input;

**Q**( $\Delta$ **d**): Depth of the 1<sup>st</sup> thread cutting, range: 1~99999999 unit: Least input increment, radius value, without sign symbols). The system alarms when  $\triangle d$  is not input;

F: metric thread pitch, its range is referred to Table 1-2;

I: thread teeth per inch for inch thread, its range is referred to Table 1-2.

J: Movement amount (run-out amount) (unit: mm/inch, without direction) in the short axis when thread run-out; when the short axis is X, its value is designated by radius and is simple parameter;

K: Movement amount (run-out amount) (unit: mm/inch, without direction) in the long axis when thread run-out; when the long axis is X, its value is designated by radius and is simple parameter.

Note: J, K are not compiled in G76, its thread run-out method is the same that of the previous, i.e. the thread run-out is executed according to P® or No.19; when J or, K, or J, K are compiled, the thread run-out method is the same those of G32, G92.



Fig. 3-94

Cut-in method as follows: Fig. 3-95:



Fig. 3-95

Pitch is defined to moving distance (X radius value) of long axis when the spindle rotates one rev. Z is long when absolute value of coordinate difference between C point and D point in Z direction is more than that of X direction ( radius value, be equal to absolute value of i); and vice versa

#### Execution process:

- The tool rapidly traverses to B<sub>1</sub>, and the thread cutting depth is △d. The tool only traverses in X direction when a=0; the tool traverses in X and Z direction and its direction is the same that of A→D when a≠0;
- ② The tool cuts threads paralleling with C→D to the intersection of D→E (r≠0: thread run-out);
- ③ The tool rapidly traverses to E point in X direction;
- ④ The tool rapidly traverses to A point in Z direction and the single roughing cycle is completed;
- (5) The tool rapidly traverses again to tool infeed to  $B_n$  ( is the roughing times), the cutting depth is the bigger value of  $(\sqrt{n} \times \triangle d)$ ,  $(\sqrt{n-1} \times \triangle d + \triangle d_{min})$ , and execute (2) if the cutting depth is less than(k-d); if the cutting depth is more than or equal to(k-d), the tool infeeds(k-d) to  $B_f$ , and then execute (6) to complete the last thread roughing;
- ⑥ The tool cuts threads paralleling with C→D to the intersection of D→E (r≠0: thread run-out);
- X axis rapidly traverses to E point;
- ⑧ Z axis traverses to A point and the thread roughing cycle is completed to execute the finishing;
- After the tool rapidly traverses to B(the cutting depth is k and the cutting travel is d), execute the thread finishing, at last the tool returns to A point and so the thread finishing cycle is completed;
- If the finishing cycle time is less than m, execute (9) to perform the finishing cycle, the thread cutting depth is k and the cutting travel is 0; if the finishing cycle times are equal to m, G76 compound thread machining cycle is completed.

#### Notes:

- 1) In thread cutting, execute the feed hold, the system displays *Pause* after the thread cutting is executed completely, and then the program run pauses;
- 2) The thread cutting decelerates to stop when the system resets and emergently stop or the driver alarms;
- 3) Omit all or some of G76 P(m) (r) (a)  $Q(\triangle d_{min})$  R(d). The omitted address runs according to setting value of parameters;
- 4) m, r, a used for one command address P are input one time. Program runs according to setting value of №57, 19, 58 when m, r, a are all omitted; Setting value is a when address P is input with 1 or 2 digits; setting values are r, a when address P is input with 3 or 4 digits;
- 5) The direction of  $A \rightarrow C \rightarrow D \rightarrow E$  is defined by signs of U,W, and the direction of  $C \rightarrow D$  is defined by the sign of R(i). There are four kinds of sign composition of U, W corresponding to four kinds of machining path as Fig. 3-96.

Example: Fig. 3-96, thread M68×6.



00013:

O0013; (system least input incre	ment is 0.0001mm)
G50 X100 Z50 M3 S300;	(Set workpiece coordinate system, start spindle and specify spindle speed)
G00 X80 Z10;	(Rapid traverse to starting point of machining)
G76 P020560 Q1500 R0.1;	(Finishing 2 times, chamfering width 0.5mm, tool angle 60°, min. cutting depth 0.15, finishing allowance 0.1)
G76 X60.64 Z-62 P36800 Q18000 F6	6; (Tooth height 3.68, the first cutting depth 1.8)
G00 X100 Z50 ; M30;	(Return to starting point of program) (End of program)

## 3.23.11 Enhancement Thread Cutting Cycle G78

Command format:G78 P(m)(r)(a)  $Q(\triangle dmin)$  R(d) J\_ K\_ D\_ L\_ E\_; G78 X(U)\_ Z(W)\_ R(i) P(k)  $Q(\triangle d)$  F(I)\_;

**Command function:** Machining thread with specified depth of thread (total cutting depth) is completed by multiple roughing and finishing, if the defined angle of thread is not 0°, thread run-in path of roughing is from its top to bottom, and angle of neighboring thread teeth is the defined angle of thread. G78 owns that the thread procession and tail-retraction function can be selected the single-side blade thread cutting or dual-side blade alternative cutting, which is contributed to thread cutting with single tool edge to reduce the wear of tool and to improve the precision of machining thread. G78 can be used for machining the straight and taper thread, But G78 cannot be used for machining the face thread.

#### **Command specifications:**

X: X absolute coordinate of thread end point;

- U: Different value of X absolute coordinate between thread end point and start point;
- Z: Z absolute coordinate of thread end point;
- W: Different value of Z absolute coordinate between thread end point and start point;
- **P** (m): Cutting depth selection 0: Equidistance in-feed; 1: Diminishing in-feed (The decreasing in-feed is identical with the G76 in-feed method).

The cutting value of each time of the equidistant in-feed is  $Q(\triangle d)$ , the cutting value of

each time of the decreasing in-feed is  $(\sqrt{n} - \sqrt{n-1}) \times \Delta d$  (n is the cutting times). The specified value m reservation is enabled after the P(m) is executed, and then write the m value to the data parameter No. 061.

**P**(r): Cutting method 0: Blade cuts in along with the netrual line of the thread theeth; 1: Blade cuts in along with the left of the thread theeth;

2: Blade cuts in along with the right of the thread theeth; 3: Blade cuts in along thread teeth with left/right in turn;

The specified value R reservation is enabled after the P(r) is executed; and then write the r value to the data parameter No. 062.

- P(a): Angles at taper of neighboring two tooth, range: 00~99, unit: deg (°). The system parameter №058 value is regarded as angle of thread tooth. The actual angle of thread in defined by tool ones and so a should be the same as the tool angle;
- $\Delta$ Q( $\Delta$ dmin): Minimum cutting travel of thread roughing, range: 0~999999( IS-C)/ 0~

99999( IS-B),(unit: least input increment, radius value). When  $(\sqrt{n} - \sqrt{n-1}) \times \Delta d < \Delta dmin, \Delta dmin is regarded as the cutting travel of current roughing and the subsequent rough-turning cutting value and the in-feed depth will be not calculated based upon the formula any more. Setting <math>\Delta dmin$  is to avoid the too small of roughing amount and too many roughing times caused by the cutting amount deceleration in thread roughing. When Q ( $\Delta dmin$ ) is not input, the system data parameter NO.059 value is taken as the least cutting amount;

- R(d): It is the cutting amount in thread finishing, range: 00 ~ 99.999(IS\_B ) /00 ~ 99.9999(IS\_C) (unit: mm/inch, radius value without sign symbols), the radius value is equal to X absolute coordinates between cut-in point Be of thread finishing and Bf of thread roughing.. The value of system parameter №060 is regarded as the cutting travel of thread finishing when R(d) is not input;
- J: Movement amount (run-out amount) (its value range: 0~9999999999vleast input increment, unit: mm/inch, without direction) in the short axis when thread run-out; when the short axis is X, its value is designated by radius and is simple parameter;
- K: Movement amount (run-out amount) (its value range: 0~999999999vleast input increment unit: mm/inch, without direction) in the long axis when thread run-out; when the long axis is X, its value is designated by radius and is simple parameter.
- **D**: Finish-turning times, its range:0~99;
- L: Head quantity of multi thread, its value range: 1~99 and it is modal parameter. (The system defaults it is single thread when L is omitted);
- E: The rotation distance value along with X, its range:-9999.9999~9999.9999 (unit: mm, radius value, without sign symbol)
- R(i): It is thread taper and is the different value of X absolute coordinate between thread start point and end point, rang: -99999.999-9999.999(IS\_B) /-9999.9999~9999.9999(IS\_C) (unit:: mm/inch, radius value). The system defaults R(i)=0(straight thread) when R(i) is not input;
- P(k): Depth of thread tooth, the total cutting depth of thread, range: 1~99999999(unit: least input increment, radius value, without sign symbols). The system alarms when P(k) is not input;
- Q(△d): Depth of the 1<sup>st</sup> thread cutting, range: 1~999999999 (unit: least input increment,

maker

radius value, without sign symbols). The system alarms when  $\triangle d$  is not input; F: metric thread pitch, its range is referred to 1.4.1 Table 1-2;

I: thread teeth per inch for inch thread, its range is referred to 1.4.1 Table 1-2. Command path:

 $\mathbf{P}(\mathbf{r})=0$ : Cut in from the middle of the teeth



Cut-in method as follows:



P(r)=1: Left cut-in method

## **CNCmakers**





**P**(r)=2: Right cut-in method



Cut-in method as follows:



## P(r)=3: Shifting cut-in method between left and right



Cut-in method as follows:



the rotation function:



# 3.24 Constant Surface Speed Control G96, Constant Rotational Speed Control G97

The detailed is referred to Section 2.2.3.

## 3.25 Feedrate per Minute G98, Feedrate per Rev G99

**Command format:** G98 F\_; (its range is referred to Section 1.6.5, the leading zero can be omitted, feed rate per minute is specified, mm/min)

**Command function:** cutting feed rate is specified as mm/min, G98 is the modal G command. G98 cannot be input if the current command is G98 modal.

**Command format:** G99 F\_; (its range is referred to Section 1.6.5, the leading zero can be omitted)

**Command function:** Cutting feed rate is specified as mm/min, G99 is the modal G command. G99 input may be omitted if current state is G99. The actual cutting feedrate is gotten by multiplying the F command value (mm/r) to the current spindle speed(r/min). If the spindle speed varies, the actual feedrate changes too. If the spindle cutting feed amount per rev is specified by G99 FXXXX , the even cutting texture on the surface of workpiece will be gotten. In G99 state, a spindle encoder should be fixed on the machine tool to machine the workpiece.

G98, G99 are the modal G commands in the same group and only one is valid. G98 is the initial state G command and the system defaults G98 is valid when the system turns on.

Reduction formula of feed between per rev and per min:

 $F_m = F_r \times S$ 

F<sub>m</sub>: feed per min (mm/min);

 $F_r$ : feed per rev (mm/r);

S: spindle speed (r/min).

After the system turns on, the feedrate is ones set by №030 and F value is reserved after F is executed. The feed rate is 0 after F0 is executed. F value is reserved when the system resets and

emergently stops. The feedrate override is reserved when the system is turned off.

- Note: In G99 modal, there is the uneven cutting feed rate when the spindle speed is lower than 1 r/min; there is the follow error in the actual cutting feed rate when there is the swing in the spindle speed. To gain the high machining quality, it is recommended that the selected spindle speed should be not lower than min. speed of spindle servo or converter.
- Cutting feed: The system can control the motions in X, Z direction contributed that the motion path of tool and the defined path by commands (line straight, arc ) is consistent, and also instantaneous speed on the tangent of motion path and F word is consistent, which motion control is called cutting feed or interpolation. The cutting feedrate is specified by F, the system divides the cutting feedrate specified by F according to the programming path into vector in X, Z direction, also controls the instantaneous speed in X, Z direction to contribute that the combined speed of vector in X, Z direction is equal to F command value.

$$f_{x} = \frac{d_{x}}{\sqrt{d_{x}^{2} + d_{z}^{2}}} \bullet F$$

$$f_{z} = \frac{d_{z}}{\sqrt{d_{x}^{2} + d_{z}^{2}}} \bullet F$$

$$f_{z} = \frac{d_{z}}{\sqrt{d_{x}^{2} + d_{z}^{2}}} \bullet F$$

$$F = \frac{d_{z}}{\sqrt{d_{z}^{2} + d_{z}^{2}}} \bullet F$$

Example: In Fig. 2-97, the data in the brackets are the coordinates for each point (it is the diameter in X axis), the system parameter No.022 is 3800, the system parameter No.023 is 7600, the rapid override and feedrate override are 100%.





Program as follows:

G50 X160 Z80; (Create a workpiece coordinate system)

G0 G98 X50 Z0; (Rapid traverse from A to B through M point. A→M: X-axis rapid traverse speed 7600mm/min, Z-axis 7600mm/min in Z direction, M→B: X-axis rapid traverse

speed 0mm/min, Z-axis 7600mm/min in Z direction

G1 W-30 F100; (B $\rightarrow$ C, X-axis rapid traverse speed 0mm/min, Z-axis 100mm/min)

- X100 W-20; (C $\rightarrow$ D, X-axis rapid traverse speed 156mm/min, Z-axis 62mm/min)
- X140;  $(D \rightarrow E, X-axis rapid traverse speed 200mm/min, Z-axis 0mm/min)$

G3 W-40 R20; (EFG circular interpolation, E point: X axis instantaneous speed 200mm/min,

Z axis 0mm/min

F point: X-axis instantaneous speed 0mm/min,

Z axis 100mm/min)

W-10;  $(G \rightarrow H, X \text{ axis rapid traverse speed 0 mm/min}, Z \text{ axis 100mm/min})$ M30;

The system supplies 16 steps for spindle override ( $0\% \sim 150\%$ , increment of 10%).PLC ladder defines tune ways of spindle override and whether the actual feedrate override steps is reserved or not after the system is switched off, which is referred by user manual from machine manufacturer when using the system. Refer to the following functions of GSK980TDi standard PLC ladder.

The cutting feedrate can be tuned real time by the feedrate override key on the operator panel or the external override switch, and the actual cutting feedrate is tuned at 16 steps in  $0\sim150\%$  (increment of 10%) but it is invalid for thread cutting to tune the feedrate override. Refer to II **OPERATION** about cutting feedrate override.

#### **Related parameters:**

System parameter No.027: the upper limit value of cutting feedrate(they are the same in X, Z direction, diameter/min in X direction);

System parameter No.029: exponential function for time constant of acceleration/deceleration when cutting feed and manual feed;

System parameter No.030: initial (ultimate) speed of acceleration/deceleration in exponential function when cutting feed and manual feed.

## 3.26. Additional Axis Function

## 3.26.1 Additional Axis Start

Additional axis: Y, 4<sup>th,</sup> 5<sup>th</sup>. They can be set to the linear axis or rotary axis. Whether the selected additional axis is valid is determined by the state bit parameter 187, and the axis name is changed by data parameter 225; taking example of Y is as follows:

## 3.26.2 Motion of Additional Axis

- 1) rapidly traverse: G00 Y(V)\_\_\_
- 2) feed motion: (G98/G99) G01 Y(V)\_\_ F\_\_
- 3) tapping: G33 Y(V)\_\_\_ F(I)\_\_\_
- 4) machine zero return: G28 Y(V)\_\_\_
- 5) machine 2<sup>nd</sup>, 3<sup>rd</sup>, 4<sup>th</sup> reference point return: G30 P2(3,4) Y(V)\_\_\_
- 6) G50 setting a coordinate system: G50 Y(V)\_\_\_
- 7) Manual/Step/MPG feed, program zero return, manual machine zero return.
- Note 1: Axis name is Y, absolute coordinate programming axis is Y, relative coordinate programming axis is V. Axis name is C, absolute coordinate axis name is C, relative coordinate axis name is H. When axis name is A or B, the relative coordinate programming axis name and absolute coordinate programming axis name are the same.
- Note 2: The additional axis Y does not execute X/Z interpolation motion;
- Note 3: Y(V) in G00, G28 , X(U) , Z(W) are in the same block, and each rapidly traverses with their separately specified speed;
- Note 4: Y(V) in G50 , X(U) , Z(W) are in the same block;
- Note 5: Y(V) in G01, X(U) , Z(W) are not in the same block, otherwise, the system alarms;
- Note 6: Use the modal F of X/Z when G01 traverse speed of Y is not specified; the time constant is set by №29.
# 3.26.3 Additional Axis Coordinates Display



# 3.27 Macro Commands

GSK980TDi provides the macro command which is similar to the high language, and can realize the variable assignment, and subtract operation, logic decision and conditional jump by user macro command, contributed to compiling part program for special workpiece, reduce the fussy counting and simplify the user program.

## 3.27.1 Macro Variables

## • Presentation of macro variables

Present with "#"+ macro variables number.;

Format: # i(i=100,102,103,.....);

Alternatively, the variable is specified by "#"+[Expression]

Format:# [i] (i = #100 + #102 + #103)

Example:#105, #109, # [#125 + #100 \* #111].

#### • Variable Type

The variable is divided into four types according to the variable number:

Number NO.	Variable type	Function
#0	Null variable	The variable is null and is not valued.
#1~#33	Local variable	The local variable is used to store data in the macro program, such as result. When the system is turned off, the local variable is initialized to be null. When the macro program is called, the argument values to the local.
#100~#199 #500~#999	Share variable	The share variable has the same meaning in the different macro program. When the system is turned off, the variable #100~#199 is initialized to be null, #500~#999 is saved and is not lost.
#1000~	System variable	System variable

#### • Macro variables reference

1. Macro variables can replace command values

Format: < Address > + "# i" or < Address > + "- # I". It shows the system takes variable value

or negative value of variable value as address value.

Example: F#103...when #103=15, its function is the same that of F15;

Z-#110...when #110=250, its function is the same that of Z-250;

2. Macro variables can replace macro variables values.

Format: "#"+"9"+macro variables number

Example: if #100 = 205, #105 = 500,

The command function of X#9100 is the same as X500;

The command function of X-#9100 is the same as X-500

Note 1: If macro variables values exceed the maximum rang of command values, they cannot be used. For example: #130 = 120, M#130 exceeds the maximum command value.

#### • Null variable

When the variable value is not defined, it is null, the variable #0 is always null and only is read instead of writing.

1). Reference

When an undefined variable (null variable) is referred, the address is ignored.

	#1= <null></null>	#1=0
	G00 X100 Z#1 is equal to G00 X100	G00 X100 Z#1 is equal to G00 X100 Z0
$\sim$	poration	

#### 2). Operation

Except for using <null variable > to value, the <null variable> used to operation in other conditions is the same as that of "0".

#1= <null></null>	#1=0
#2=#1	#2=#1
↓(execution result)	↓(execution result)
#2= <null></null>	#2=0
#2=#1 * 5	#2=#1 * 5
↓(execution result)	↓(execution result)
#2=0	#2=0
#2=#1+#1	#2=#1+#1
↓(execution result)	↓(execution result)
#2=0	#2=0

3). Condition expression

<null>s in EQ(=) & NE( $\neq$ ) are different to "0".

#1= <null></null>	#1=0
#1 EQ #0	#1 EQ #0
$\downarrow$	$\downarrow$
Valid	Invalid
#1 NE #0	#1 NE #0
$\downarrow$	$\downarrow$
Invalid	Invalid
#1 GE #0	#1 GE #0
$\downarrow$	$\downarrow$
Valid	Invalid
#1 GT #0	#1 GT #0
$\downarrow$	$\downarrow$
Invalid	Invalid

#### • Variable display

1 -> MA	CRO [PUBLIC	VARIABLE]			00000 N	0000	PUB
NO.	DATA	NO.	DATA	NO.	DATA	-	VAR
100		112		124			LOCAL
101		113		125			VAR
102		114		126			
103		115		127			SYS
104		116		128			
105		117		129			
106		118		130			
107		119		131			
108		120		132			
109		121		133			
110		122		134			FIND
111		123		135			
110 111 100 Stor	e variable.Re	122 123 set 0 when po	wer on,	134 135		2	FI

- (1) In macro window, the variable being displayed to the null means it is null, i.e. it is not defined.
- (2) The share variable (#100~#199, #500~#999) values are displayed in the macro variable window, and is also displayed the window, the data is input directly to value the share variable.

#### • System variable

(1) Interface signal: CNC only executes G and F signals. Whether there are I/O to correspond to it is defined by PLC.

Variable No.	Function
#1000~#1015	Correspond G54.0~G54.7, G55.0~G55.7 signal states
#1032	Correspond G54, G55 signal states
#1100~#1115	Correspond F54.0~G54.7, F55.0~F55.7 signal states
#1132	Correspond F54, F55 signal states
#1133	Correspond F56, F57, F58, F59 signal states

#### (2) Tool compensation system variable:

Compensation	X comp va	ensation alue	Z compo va	ensation alue	Tool t compens	ip radius sation value	Imagery tool tip	Y com	pensation value
No.	Wear	Geometric shape	Wear	Geometric shape	Wear	Geometric shape	position T	Wear	Geometric shape
1	#2001	#2701	#2101	#2801	#2201	#2901	#2301	#2401	#2451
 32	 #2032	 #2732	 #2132	 #2832	 #2232	 #2932	 #2332	 #2432	 #2482

#### (3) Machined workpiece number:

Variable No.	Function
#3901	Machined workpiece number(completion)
#3902	The Max. machining numbers

#### (4) System modal information variable

Variable	Function		
No.	Function		
#4001	G00, G01, G02, G03, G05, G32, G33, G34, G80,	No. 1 group	

	G84, G88, G90, G92, G94, G124(G06.2),	
	G126(G06.3),G132(G32.1),G144(G07.2),G146(G07.3)	
#4002	G96, G97	No. 2 group
#4005	G98, G99	No. 3 group
#4006	G20, G21	No. 6 group
#4007	G40, G41, G42	No. 7 group
#4012	G66, G67	No. 12 group
#4013	G54,G55,G56,G57,G58,G59	No. 14 group
#4016	G17,G18,G19	No. 16 group
#4109	F command	
#4113	M command	
#4114	Serial No.	
#4115	Program No.	
#4119	S command	
#4120	T command	

(5) System variable of coordinate position information:

Variable No.	Position signal	Coordinate system	Tool compensation value	Read in running	
#5001~#5005	End point of block	Workpiece coordinate system	Not including	Possible	
#5021~#5025	Current position	Machine coordinate system	Including	impossible	
#5041~#5045	Current position	Workpiece coordinate system	mendaling	impossible	

- Note: The position listed in the above table separately corresponds orderly to X, Y, Z, 4<sup>th</sup>, 5<sup>th</sup> axis. For example: #5001 meanings to be X position information, #5002 meanings to be Y position information, #5003 meanings to be Z position information and #5004 meanings to 4<sup>th</sup> position information and #5005 meanings to 5<sup>th</sup> position information.
  - (6) The system variable of MPG interruption value: Readable variable

Variable No.	Function
#5121	The 1 <sup>st</sup> axis MPG interruption value
#5122	The 2 <sup>nd</sup> axis MPG interruption value
#5123	The 3 <sup>rd</sup> axis MPG interruption value
#5124	The 4 <sup>th</sup> axis MPG interruption value
#5125	The 5 <sup>th</sup> axis MPG interruption value

(7) Compensation values of workpiece coordinate systems

Variable No.	Function
#5201~#5205	External workpiece zero offset value of 1 <sup>st</sup> ~5 <sup>th</sup> axis
#5221~#5225	G54 workpiece zero offset value of 1 <sup>st</sup> ~5 <sup>th</sup> axis
#5241~#5245	G55 workpiece zero offset value of 1 <sup>st</sup> ~5 <sup>th</sup> axis
#5261~#5265	G56 workpiece zero offset value of 1 <sup>st</sup> ~5 <sup>th</sup> axis
#5281~#5285	G57 workpiece zero offset value of 1 <sup>st</sup> ~5 <sup>th</sup> axis



#5301~#5305	G58 workpiece zero offset value of 1 <sup>st</sup> ~5 <sup>th</sup> axis
#5321~#5325	G59 workpiece zero offset value of 1 <sup>st</sup> ~5 <sup>th</sup> axis

Note: Message described in the above table separately corresponds to X, Y, Z, the 4<sup>th</sup>, 5<sup>th</sup> axis. For example, #5201 means the offset message of X axis, #5202 means the one of Y axis, #5203 means the one of Z axis,#5204 means the one of the 4th axis, #5205 means the one of the 5th axis.

(	8	) Aı	opl	ica	tion <sup>.</sup>
	Ο,	,	υμι	ica	uon.

D0100; (#100 is the machined workpiece number, its	O9580;
nitial value=0)	G65 H23 P#101 Q#4120 R100; (obtain the
G00 X100 Z100;	tool offset No.)
T0101;	IF[#101==0]GOTO10; (Do not modify the
IF[#100<100]GOTO10; (has continuously machined	wear value when the tool offset is
100?)	regarded as 0)
G65 P9580 U-0.01 W-0.01; (call the macro program	#102=2000+#101; (X wear macro
compensation tool wear)	variable)
N10 G00 X50 Z50;	#103=2100+#101; (Z wear macro
;	variable)
;	#9102=#9102+#21; (modify X wear)
;	#9103=#9103+#23; (modify Z wear)
Machine program;	T#4120; (call a new tool offset value)
;	N10 M99;
T0202;	
IF[#100<100]GOTO20; (has continuously machined	
100?)	
G65 P9580 U-0.01 W-0.01; (call the macro program	
compensation tool wear)	
N20;	
,	
;	
#100=#100+1; (machined workpiece number +1)	
IF[#100==101]THEN #100=0;	
M30;	

# 3.27.2 Operation & Jump Command G65

## Command format:

G65 H<u>m</u> P<u># i</u> Q<u># j</u> R<u># k;</u>

## Command significance:

m: operation or jump command, range 01 ${\sim}99.$ 

- #i: macro variables name for storing values.
- # j: macro variables name 1 for operation, can be constant.
- # k: macro variables name 2 for operation, can be constant.

# i = #j O # k

— Operation sign specified by Hm

Note: Macro variable name has no "#" when it is presented directly with constant.

Command format	Functions	Definitions		
G65 H01 P#i Q#j	Assignment	# i = # j assign value of j to i		
G65 H02 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Decimal add operation	# i = # j + # k		
G65 H03 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Decimal subtract operation	# i = # j - # k		
G65 H04 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Decimal multiplication operation	# i = # j×# k		
G65 H05 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Decimal division operation	# i = # j÷# k		
G65 H11 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Binary addition	# i = # j OR # k		
G65 H12 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Binary multiplication(operation)	# i = # j AND # k		
G65 H13 P <u>#i</u> Q <u>#i</u> R <u>#k</u> ;	Binary exclusive or	# i = # j XOR # k		
G65 H21 P <u>#i</u> Q <u>#i</u> ;	Decimal square root	$\#i = \sqrt{\#j}$		
G65 H22 P <u>#i</u> Q <u>#i</u> ;	Decimal absolute value	# i =  # j		
G65 H23 P <u>#i</u> Q <u>#j</u> R <u>#k;</u>	Decimal remainder	Remainder of $\# i = (\#j \div \# k)$		
G65 H24 P <u>#i</u> Q <u>#i</u> ;	Decimal into binary	# i = BIN(# j )		
G65 H25 P <u>#i</u> Q <u>#i</u> ;	Binary into decimal	# i = DEC(# j )		
G65 H26 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Decimal multiplication/division operation	# i = # i×# j÷# k		
G65 H27 P <u>#i</u> Q <u>#j</u> R <u>#k;</u>	Compound square root	$\# i = \sqrt{\# j^2 + \# k^2}$		
G65 H31 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Sine	# i = # j×sin(# k)		
G65 H32 P <u>#i</u> Q <u>#j</u> R <u>#k;</u>	Cosine	# i = # j×cos(# k)		
G65 H33 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Tangent	# i = # j×tan(# k)		
G65 H34 P <u>#i</u> Q <u>#i</u> R <u>#k;</u>	Arc tangent	# i = ATAN(# j / # k)		
G65 H80 P <u>n;</u>	Unconditional jump	Jump to block n		
G65 H81 P <u>n</u> Q <u>#i</u> R <u>#k;</u>	Conditional jump 1	Jump to block n if # j = # k,otherwise		
G65 H82 P <u>n</u> Q <u>#i</u> R <u>#k;</u>	Conditional jump 2	Jump to block n if # j $\neq$ # k, otherwise the system executes in order		
		lump to block n if $\#$ i > $\#$ k		
G65 H83 Pn O#i R#k <sup>.</sup>	Conditional jump 3	otherwise the system executes in		
000 1100 1 <u>11</u> Q <u>#1</u> IX <u>#I</u> ,		order		
		lump to block n if # i < # k		
C65 H81 Pn O#i R#k	Conditional jump 4	Sump to block if if $\# j < \# k$ ,		
000 1104 1 <u>11</u> Q <u>#1</u> IX <u>#K</u> ,		order		
		$\lim_{k \to \infty} t_k = t_k$		
G65 H85 P <u>n</u> Q <u>#i</u> R <u>#k;</u>	Conditional jump 5	the system executes in order		
G65 H86 Pn O#i R#k·	Conditional jump 6	Jump to block n if # j ≤# k, otherwise		
Соранов Р <u>п</u> Q <u>#</u> ] К <u>#к;</u> Сопditional jump		the system executes in order		
G65 H99 P <u>n;</u>	P/S alarm	(500+n) alarms		

#### Macro command list

**Operation commands** 

1) Assignment of macro variables: # I = # J

## <u>G65 H01 P#I Q#J</u>

(Example) G65 H01 P# 101 Q1005;(#101 = 1005)G65 H01 P#101 Q#110;(#101 = #110)G65 H01 P#101 Q-#102;(#101 = -#102)

# **CNCmakers**

2) Decimal add operation: # I = # J+# K	
<u>G65 H02 P#I Q#J R#K</u>	
(Example) G65 H02 P#101 Q#102 R15; (#1	101 = #102+15)
3) Decimal subtract operation: # I = # J $-$ # K	
<u>G65 H03 P#I Q#J R# K</u>	
(Example) G65 H03 P#101 Q#102 R#103; (#1	01 = #102#103)
4) Decimal multiplication operation: $\# I = \# J \times \# K$	
<u>G65 H04 P#I Q#J R#K</u>	
(Example) G65 H04 P#101 Q#102 R#103; (#1	01 = #102×#103)
5) Decimal division operation: $\# I = \# J \div \# K$	
<u>G65 H05 P#I Q#J R#K</u>	
(Example) G65 H05 P#101 Q#102 R#103; (#1	01 = #102÷#103)
6) Binary logic add(or) : # I = # J.OR. # K	
<u>G65 H11 P#I Q#J R#K</u>	
(Example) G65 H11 P#101 Q#102 R#103; (#1	01 = #102.OR. #103)
7) Binary logic multiply(and) : # I = # J.AND. # K	
<u>G65 H12 P#I Q#J R#K</u>	
(Example ) G65 H12 P# 201 Q#102 R#103; (#	101 = #102.AND.#103)
<ol> <li>Binary executive or: # I = # J.XOR. # K</li> </ol>	
<u>G65 H13 P#I Q#J R#K</u>	
(Example) G65 H13 P#101 Q#102 R#103; (#1	01 = #102.XOR. #103)
9) Decimal square root: # I = $\sqrt{\#J}$	
G65 H21 P#I Q#J	
(Example) G65 H21 P#101 Q#102 : (#101	$=\sqrt{\#102}$ )
(10)  Decimal absolute value:  # =   #	(1102)
G65 H22 P#I Q#J	
(Example) G65 H22 P#101 Q#102 · (#101	1 =   #102  )
11) Decimal remainder: $\#I = \#J - TRUNC(\#J/\#K) \times \#K$	TRUNC: Omit decimal fraction
G65 H23 P#I O# I R#K	
(Example) G65 H23 P#101 O#102 R#103 (#10	)1 = #102- TRUNC (#102/#103)x#103
(2) Decimal converting into binary: $\# I = BIN (\# I)$	
G65 H24 P#I Q#J	
(Example) G65 H24 P#101 Q#102 · (#10	(1 = BIN(#102))
13) Binary converting into decimal: # I = BCD (# J)	
G65 H25 P#I Q#J	
(Example) G65 H25 P#101 Q#102 : (#10	01 = BCD(#102) )
14) Decimal multiplication/division operation: $\# I = (\# I \times I)$	# J) ÷# K
G65 H26 P#I Q#J R# k	, , , , , , , , , , , , , , , , , , ,
(Example) G65 H26 P#101 Q#102 R#103: (#1	01 =(# 101×# 102) ÷#103)
$(15) \circ (11) = (11) \circ $	
15) Compound square root: $\#I = \sqrt{\#J^2 + \#K^2}$	
G65 H27 P#I Q#J R#K	
(Example) G65 H27 P#101 Q#102 R#103: (#1	$01 = \sqrt{\#102^2 + \#103^2}$
16) Sine: # I = # J•SIN(# K) (Unit: ‰)	,
G65 H31 P#I Q#J R#K	
(Example) G65 H31 P#101 Q#102 R#103: (#1	01 = #102•SIN(#103) )
( $($ $)$ (	/ /

17) Cosine: # I = # J•COS(# K) (Unit: ‰)	
G65 H32 P#I Q#J R# k	
(Example) G65 H32 P#1Q#102 R#103;	
18) Tangent: # I = # J•TAM(# K) (Unit: ‰)	
<u>G65 H33 P#I Q#J R# K</u>	
(Example) G65 H33 P#101 Q#102 R#103; (#101 = #102•TAM(#103) )	
19) Cosine: # I = ATAN(# J /# K) (Unit: ‰)	
<u>G65 H34 P#I Q#J R# k</u>	
(Example) G65 H34 P#101 Q#102 R#103; (#101 =ATAN(#102/#103) )	
Jump commands	
1) Unconditional jump	
<u>G65 H80 Pn; n: Block number</u>	
(Example) G65 H80 P120; (jump to N120)	
2) Conditional jump 1 #J.EQ.# K ( = )	
<u>G65 H81 Pn Q#J R# K; n: Block number</u>	
(Example) G65 H81 P1000 Q#101 R#102;	
The program jumps N1000 when # $101 = #102$ and executes in order when #101 $\neq$ #102.	
3) Conditional jump 2 #J.NE.# K ( ≠ )	
G65 H82 Pn Q#J R# K; n: Block number	
(Example) G65 H82 P1000 Q#101 R#102;	
The program jumps N1000 when # 101 $\neq$ #102 and executes in order when #101 = #102.	
4) Conditional jump 3 #J.GT.# K ( $>$ )	
<u>G65 H83 Pn Q#J R# K; n: Block number</u>	
(Example) G65 H83 P1000 Q#101 R#102;	
The program jumps N1000 when # 101 $>$ #202 and executes in order when #101 $\leq$	
#102.	
5) Conditional jump 4 #J.LT.# K ( $<$ $=$ )	
G65 H84 Pn Q#J R# K; n: Block number	
(Example) G65 H84 P1000 Q#101 R#102;	
The program jumps N1000 when # $101 < #102$ and executes in order when #101≥#102.	
6) Conditional jump 5 #J.GE.# K ( $\geq$ )	
G65 H85 Pn Q#J R# K; n: Block number	
(Example) G65 H85 P1000 Q#101 R#102;	
The program jumps N1000 when # 101 $\leq$ #1 and executes in order when #101 $\leq$ #102.	
7) Conditional jump 6 #J.LE.# K ( $\leq$ )	
G65 H86 Pn Q#J R# K: n: Block number	
(Example) G65 H86 P1000 Q#101 R#102;	
8) P/S alarm	
G65 H99 Pi; i: alarm number +500	

(Example) G65 H99 P15;

P/S alarm 515.

- Note 1: The alarm content (/\*\*\*) can be omitted. When this alarm content is omitted, only the alarm occurs, and the alarm content is null.
- Note 2: Block number can be specified by variables. Such as: G65 H81 P#100 Q#101 R#102;

The program jumps to block that its block number is specified by #100.



# 3.27.3 Program Example with Macro Command

Differences between user macro program call (G65, G66) and subprogram call (M98) are as follows:

1. G65, G66 can specify the argument data and send them to macro program and M98 has no such function.

2. G65, G66 can change the level of local variable and M98 has no such function.

3. G65, G66 only follows N and only P or H follows them.

## 3.27.3.1 One-Shot Call G65

#### Command format: G65 P\_ L\_ <argument>\_;

Macro program specified by P is called, the argument (data) is sent to the user macro program body.

#### Command explanation:

P —— called macro program number

L —— called times (it is 1 when it is omitted, it can be the repetitive times from 1 to 9999)

<Argument> \_\_\_\_ data sent to macro program is valued with the corresponding local variable.

Nest call: G65 call has four-level nest.



Specifying argument: the argument can be specified by two forms.

Method 1: Use the letter besides G, L, O, N, P, and each is only specified one time, and the last which is specified many times is valid.

Argument address and corresponding variable No. table in method 1

Address	Variable No.	Address	Variable No.	Address	Variable No.
A	#1	I	#4	Т	#20
В	#2	J	#5	U	#21
С	#3	K	#6	V	#22
D	#7	М	#13	W	#23
E	#8	Q	#17	Х	#24
F	#9	R	#18	Y	#25
Н	#11	S	#19	Z	#26

Note: The addresses which are not needed to specify can be omitted, the corresponding local variable of the omitted address is valued by <Null>.

Method II: Use A, B, C and li, Ji, Ki (I is 1~10), the used letter and executed times (I, J, K) automatically decides the corresponding variable number of argument. The argument in the method specifies A, B, C one time for each and I, J, K up to 10 times (10 times replacing the more).

Address	Variable No.	Address	Variable No.		Address	Variable No.
А	#1	K <sub>3</sub>	#12		J <sub>7</sub>	#23
В	#2	$I_4$	#13		K <sub>7</sub>	#24
С	#3	$J_4$	#14		l <sub>8</sub>	#25
I <sub>1</sub>	#4	$K_4$	#15		J <sub>8</sub>	#26
J <sub>1</sub>	#5	l <sub>5</sub>	#16		K <sub>8</sub>	#27
K <sub>1</sub>	#6	$J_5$	#17		9	#28
l <sub>2</sub>	#7	K <sub>5</sub>	#18		J <sub>9</sub>	#29
J <sub>2</sub>	#8	I <sub>6</sub>	#19		K <sub>9</sub>	#30
K <sub>2</sub>	#9	$J_6$	#20		I <sub>10</sub>	#31
l <sub>3</sub>	#10	K <sub>6</sub>	#21	1	J <sub>10</sub>	#32
$J_3$	#11	<sub>7</sub>	#22		K <sub>10</sub>	#33

Argument address and corresponding variable No. table in method II

Note 1: The subscripts of I, J, K are used to confirming the specified sequence of argument, and are not written in the actual programming.

Note 2: The system can identify the variable number according to the present sequence and times of I, J, K in the method.

Note 3: CNC internal can automatically identify the argument specifying mode I and II. When the two modes are specified, the later specified is valid.

#### 3.27.3.2 Modal Call G66

Command format: G66 P\_ L\_ <Argument>\_;

**Command explanation:** P \_\_\_\_ called macro program number

L \_\_\_\_ called times (It is 1 when it is omitted, it can be the repetitive times from 1 to 9999)

<Argument> \_\_\_\_ data sent to macro program is valued with the corresponding local variable.

**Nest call:** G66 call has four-level nest.

Note:

- 1) Macro program is called firstly after G66 block is executed.
- 2) The macro program is called again after G00, G01, G02, G03, G05 are executed (after G66 is executed and before the modal call is cancelled).
- 3) Call the value which is updated from the argument to the local variable.
- 4) G65 call will automatically cancel G66 modal call.
- 3.27.3.3 Modal Call Cancel G67

Command format: G67; Command explanation: cancel G66 modal macro program call Application: O2005(O2005) ; G00 X100 Z50; G66 P0100 L2 A2 B20 C20 I30 J20 K20; call P0100 two times when the system executes the block

G01 X80 Z50; call P0100 two times (update the local variable according to the argument) after

the system has executed the blockG67;cancel G66 modal callG01 X20 Z50;the system does not call P0100 after it executes the blockM30;

## 3.28 Statement Macro Command

## 3.28.1 Arithmetic & Logic Operation

	Arithmetic and logic operative series of the	ation
Function	Expression format	Remark
Definition or assignment	#i = #j	
addition	#i = #j + #k	
subtraction	#i = #j - #k	
multiplication	#i = #j * #k	
division	#i = #j / #k	
Or	#i = #j OR #k	Logic operation is executed by
And	#i = #j AND #K	the history system
Exclusive Or	#i = #j XOR #K	the billary system
Square root	#i = SQRT[#j]	
Absolute value	#i = ABS[#j]	
Rounding-off	#i = ROUND[#j]	
FUP	#i = FUP [#j]	
FIX	#i = FIX [#j]	
Natural logarithm	#i = LN[#j]	
Exponential function	#i = EXP[#j]	
Sine	#i = SIN[#j]	
Arc sine	#i = ASIN[#j]	Angle unit is specified by
Cosine	#i = COS[#j]	degree For example: 00°30'
Arc cosine	#i = ACOS[#j]	is everyossed by 90.5°
Tangent	#i = TAN[#j]	is expressed by 90.5
Arc tangent	#i = ATAN[#i]/ [#j]	
BCD to BIN	#i = BIN[#j]	Llood for switching with PMC
BIN to BCD	#i = BCD[#j]	Used for switching with PMC

#### Relative explanation:

1. Angle unit

Angle units of SIN, COS, ASIN, ACOS, TAN and ATAN are degree (°). For example:  $90^{\circ}30$  ' means to be  $90.5^{\circ}$  (degree).

- 2. Arc sine # i=ASIN[#j]
  - i. result output range:
    - No.180#7 NAT is set to 1: 90°~ 270°;
    - No.180#7 NAT is set to 0: -90°~ 90°;
  - ii. when #j exceeds the range from -1 to 1, the system alarms P/S.
  - iii. the constant replaces the variables #j.
- 3. Arccosine # i =ACOS[#j]
  - i. Result output range 180°~ 0°.

- ii. When #j exceeds the range from -1 to 1, the system alarms P/S.
- iii. The constant replaces the variables #j.
- 4. Arc tangent #i=ATAN[#j]/[#k]

Specify the lengths of two sides and separate them with a slash "/".

i. Result output range:

When No.180#7 NAT is set to 1: 90°~ 270°;

[For example] #1=ATAN[-1]/[-1]: #1=225°;

When No.180#7 NAT is set to 0 -90°~ 90°;

[For example]#1=ATAN[-1]/[-1]: #1=45.0°;

- ii. The constant replaces the variables #j.
- 5. Natural logarithm #i=LN[#j]
  - The constant replaces the variables #j
- 6. Exponential function #i=EXP[#j]

The constant replaces the variables #j

7. ROUND function

When arithmetical operation or logic operation IF or WHILE includes ROUND, ROUND rounds in the first decimal place.

For example: #1=ROUND[#2]: #2=1.2345, the variables 1 is 1.0.

8. FUP FIX

After CNC executes the operation, the result integer absolute value is bigger the previous absolute value, which is called FUP; the result integer absolute value is less than the one, which is call FIX. Pay more attention to the negative execution.

Example:

Hypothetically, #1=1.2, #2= -1.2 When #3=FUP[#1] is executed, 2.0 is assigned to #3. When #3=FIX[#1] is executed, 1.0 is assigned to #3. When #3=FUP[#2] is executed, -2.0 is assigned to #3. When #3=FIX[#2] is executed, -1.0 is assigned to #3.

## 3.28.2 Transfer & Cycle

In the program, the system uses GOTO and IF statement to change the control flow. There are three types of transfer and cycle operation.

- 1. GOTO statement (unconditional transfer).
- 2. Condition control IF statement.
- 3. WHILE cycle statement.

#### 1) Unconditional transfer (GOTO statement )

Transfer to the block which serial number is n. The system alarms when others exceeds the range from 1 to 99999, and it specifies the serial number with the statement.

Format: GOTO n; n: serial number(1~99999) Example: GOTO 1; GOTO #101;

#### 2) Conditional control (IF statement)

GOTO format: IF[ conditional statement]GOTO n;

When the specified conditional statement is valid, the system transfers to the block which serial number is n; When the specified conditional statement is valid, the system executes the next block.

#### Example:





THEN format: IF[conditional expression]THEN<macro program statement >;

When the condition expression is valid, the system executes only one statement following THEN. Example: IF[#1 EQ #2] THEN #3=0;

When #1 value is equal to the #2, 0 is assigned to the variable #3; when they are not equal, the system orderly executes the followings instead of the assignment statement after THEN.

Conditional expression: the conditional expression must include the conditional operator, two sides of conditional operator can be variable, constant or expression, and it must be closed with the brackets '[' ']'.

Conditional operator: the system uses the conditional operators listed in the following table.

Conditional operator	Meaning
EQ or = =	Equal to (=)
NE or <>	Not equal to (≠)
GT or >	More than (>)
GE or >=	More than or equal to (≥)
LT or <	Less than (<)
LE or <=	Less than or equal to (≤)

Example: IF[3<>2]GOTO 2; its meaning: when 3 is not equal 2, the system skips to N2 block;

IF[#101>=7.22]THEN #101=SIN30; its meaning: when #101 is more than or equal to 7.22, the system executes the assignment after THEN. i.e. the sine value of 30 degree is assigned to the variable #101.

Typical program: the following program counts the sum of the integer 1~10.

#### O9500

#1=0;the sum is initialized to be 0
#2=1;the summand number is initialized to be 1
N1 IF[#2 GT 10]GOTO2; the system skips to N2 when the summand is more than 10
#1= #1+#2;count the sum of two numbers
#2= #2+1; the summand adds 1
GOTO1; unconditionally skip to the block N1
N2 M30; end of program

#### 3) Cycle (WHILE statement)

Specify one conditional expression after WHILE. When the specified conditional is valid, the system executes the blocks between DO and END; otherwise, the system skips to the block after END.

Example:



Explanation: when the specified condition is valid, the system executes the block between DO and END; otherwise, executes the block after END. The two tabs after DO and END are consistent, and the tab value can be 1, 2 or 3, otherwise, the system alarms.

**Nest:** the tab (1~3) in DO, END can be used many times. But the system alarms when there is the intercross repetitive cycle in the program.



## 3.29 Metric/Inch Switch

Command format: G20; (inch input)

G21; (metric input)

**Explanation**: input/output unit of CNC system is divided into two, i.e., metric unit: mm and inch unit: inch.

Input unit of modifying the system has also:

Modifying BIT0 (metric/inch): 0: metric input 1: inch input

No. 001# 0 completely corresponds to G20/G21, namely, the parameter also changes when G20/G21 is executed; G20/G21 mode also changes when the parameter is modified, and the alarm prompt occurs after modification. Parameters relevant to metric/inch are referred to Installation & Connection, Section 3.2.17.

#### Notes

#### (1) No.001 # 0(INI) input increment unit change

After the input increment unit is changed (inch/metric input), the following unit system is changed: (i.e.: mm<>inch; mm/min<>inch/min):

- F specifies the feedrate (mm/min<>inch/min), thread lead (mm <>inch)
- position command (mm<>inch)
- tool compensation value (mm<>inch)
- ◆ MPG graduation unit (mm<>inch)
- movement distance in incremental feed (mm<>inch)
- some data parameters, including №.45~ №.46、 №.56、 №.59、 №.60、 №.114、 №.120~
   №.123、 №.140、 №.154; the unit is 0.001mm (IS-B) in the metric input system, is 0.0001inch(IS-B) in the inch input system. For example, the same parameter NO.47 setting value is 100m, it means to be 0.1mm in the metric input system (G21), and it means 0.01inch in the inch input system (G20).
- (2) The machine coordinates will automatically switch after the input increment unit change is switched:
- (3) No.004 # 0(SCW) output command unit change

SCW=0: the system minimal command increment uses the metric output (0.001mm)

SCW=1: the system minimal command increment uses the inch output (0.0001inch)

Some data parameter meanings will be changed when the output control bit parameter SCW is changed:

- Speed parameter:
  - Metric machine: mm/min
  - Inch machine: 0.1 inch/min

Example: when the speed is set to 3800, the metric machine is 3800 mm/min and the inch machine is 380 inch/min.

Speed parameters: №.22、 №.27、 №.28、 №.30~№.33、 №.41、 №.107、 №.113;

Position(length) parameter

metric machine: 0.001 mm

inch machine: 0.0001 inch

When the setting is 100, the metric machine is 0.1mm and the inch machine is 0.01 inch.

Position parameters: №.34, №.45~ №.47, №.99 and all pitch error compensation parameter;

Note 1: When the minimal input increment unit and the minimal command unit are different, the maximal error is the half of minimal command unit. The error cannot be accumulated.

Note 2: The current system increment is IS-B in the above explanation.

## 3.30 Stored Stroke Limit 2 Detection G22 or G23

G23;

**Code function:** Set the stored stroke limit 2 detection. Make out a fixed area, and specify the inner or outer side (Bit 2 of parameter No.172 setting) of this area as the limit area. An alarm issues when the machine tool coordinate enters into the limit area.

Code explanation: G code of the group 9

- G22: Open the stored stroke limit detection 2
- G23: Close the stored stroke limit detection 2
- X\_Y\_Z\_: The limit coordinate value along positive direction, after the command is performed, this data is then converted into the corresponding value to save in the data parameter No.100. When the data does not input, the value of the data parameter No.100 is regarded as the limit coordinate value along the positive direction based upon the stored stroke limit detection.
- I\_J\_K\_: The limit coordinate value along negative direction, after the command is performed, this data is then converted into the corresponding value to save in the data parameter No.101. When the data does not input, the value of the data parameter No.101 is regarded as the limit coordinate value along the negative direction based upon the stored stroke limit detection.

#### **Precautions:**

- The limit coordinate values of the stored stroke limit detection 2 are the coordinate values of the machine tool coordinates;
- 2) When the Bit 4 of state parameter No. 172 sets to 0, the limit function is disabled, the modal is fixed as G23; the alarm may issue by using the G22/G23 command;
- 3) The initial modal is G23 when the system power is turned on;
- 4) The inner/outer prohibition of the setting range is set by bit 2 of parameter No. 172;
- 5) When the bit 1 of state parameter No. 172 sets to 1, if the stored stroke limit detection 2 sets as inner limit, the limit function is then enabled after the overall axes are returned to zero following with the system power is turned on; if it sets as the outer limit, after the system ON, the limit function of an axis is enabled after this axis returns to zero;
- 6) G22/G23 coe can not be shared a same block with other G and MST codes; otherwise, the alarm issues.
- G22 code only can be changed the limit area of the X, Z or Y axis, if the limit area of the rest of the axes should be altered, which can be set by the data parameter No. 100 or No.101;
- 8) When the prohibition area of the stored stroke limit detection 2 is set, as well when the positive stroke is less than or equals to the negative one and the external prohibition is selected, the overall areas are the forbidden areas;
- 9) When the prohibition area of the stored stroke limit detection 2 is set, as well when the positive stroke is less than or equals to the negative one and the internal prohibition is selected, the overall areas are the movable areas;
- 10) Set whether an axis is performed the stored stroke detection 2 by the bit 2 of parameter No.190.

## 3.31 G Code Macro Program Call

Code format:  $G_{\Box\Box\Box\Box} L_ < Agrument >_$ 

**Code value** (0~9999)

Code explanation: Code value: It is set by data parameter №.86~№.95;

L: The called times (It defaults to 1 if it omits, which can be specified the repeated times from 1 to 9999);

<Argument>: The data converted to the macro program, its value is assigned to the corresponding local variable, it is same that the G65 calls macro program.

Code value and the setting of program number call:

Data parameter No.86~No.95 set the used G code in the macro command call, use the set G code, that is, the macro program call using G code can be defined. If the data parameters No.86~No.95 are set to 0, this function will be then disabled. The callable macro programs are O9010~O9019, the corresponding relationships between parameter number and program number are as follows:

Para. No.	Program No.	Para. No.	Program No.
86	O9010	91	O9015
87	O9011	92	O9016
88	O9012	93	O9017
89	O9013	94	O9018
90	O9014	95	O9019

**For example:**  $N_{0.86} = 100$ ,  $N_{0.87} = 103$ , then:

G00 X0 Z0;

...; M30;

G100; //Call the No. O9010 macro program G103; // Call the No. O9011 macro program

#### Precaution:

The allowable range of the data parameters No. 86~No. 95 setting value is  $0\sim$ 9999, when the setting value is identical with the G code, this function is automatically disabled.

## 3.32 Editable Parameter Read/Write G10 L52

Code format: G10 L52; N_/K_/D_/DT_/DC_ R(W)_; N_ P_ R(W)_;	Set the parameter read or write method Read/write program of the system/K/D/DT/DC parameters Read/write program of axis, spindle or channel parameter
G11;	Cancel the parameter read/write
Code explanation: N_ : Parameter number	er;
K_ : K parameter num	ber of PLC;
D_ : D parameter num	ber of PLC;
DT_ : DT parameter nu	mber of PLC;
DC_ : DC parameter nu	umber of PLC;
R(W) _: R is the read add	ress from parameter, which only can be regarded
as the macro variable numb	per; W is the write-in value from parameter, which
can be treated as the co	nstant or marco variable; When the read/write

parameter is the state one, its value from reading/writing is binary, and the others are decimal system;;

P\_: The axis number 1 to the top controllable axis number (from 1 to the

Max. channel number) can be used for reading the axis, spindle or channel parameter;

#### **Precautions:**

- In the parameter write/read method, simultaneously, when two or more command words (including the repeated display for a same command word) of N\_/K\_/D\_/DT\_/DC\_ are displayed at the same line, system alarm is then shown: 178 alarm, parameter (N\_/K\_/D\_/DT\_/DC\_) (including the inexistent specified parameter) does not specify in the parametr read/write mode or the parameter is repeatedly specified;
- 2) In the parameter write/read method, when block specifies the operation command (R/W), but it does not exist any one command word of the N\_/K\_/D\_/DT\_/DC\_, alternatively, there is the command word without data, system alarm is then shown: 178 alarm, parameter (N\_/K\_/D\_/DT\_/DC\_) (including the inexistent specified parameter) does not specify in the parametr read/write mode or the parameter is repeatedly specified;
- 3) In the parameter write/read method, when the block specifies the parameter number, but it does not exist in R/W operation command or R, W exist at the same time, system alam is then shown: 177 alarm; the read/write method does not specify or the read/write method is repeatedly specified in the parameter read/write method;
- 4) In the parameter write/read method, if there are command words other than the \_/P\_/K\_/D\_/DT\_/DC\_ R\_/W\_, ignore it, the command operations except from the parameter reading/writing will not be performed;
- Specify P value in the block, if the axis corresponding set parameter does not exist, igore it;
- 6) When reading or writing the axis parameter or spindle parameter, if the P value does not occur, the system alarm is then displayed: 178 alarm; the axis number does not specify when reading/writing the axis parameter;
- 7) The system can not set the parameter with 2 authority levels or above if it is under the 3 or less authories. If the program exists the block to be modified the parameter with 2 or more authority levels, the system alarm is then displayed: 174 alarm, the current authority prohibits to be modified the parameter;
- In the parameter write/read method, R\_ can only be accompanied with macro variable, otherwise, the alarm occurs: 180 alarm, as well, R only can be specified the marco variable in this method;
- 9) When writing the bit parameter, if the W\_ is followed with the operation number other than the binary constant and macro variable, the system alarm is then displayed: 176 alarm. The W value or the macro variable value followed with the W are not the enabled binary value;
- 10) When writing the bit parameter, when the value followed with the W exceeds the corresponding parameter range, the system alarm is then displayed: 175 alarm; The W value or the macro variable value followed with the W are not the enabled binary value;
- 11) The dual-channel system forbids other channels to perform the machining procedure in the parameter read/writing state; otherwise, the system alarm is then displayed: 186 alarm; the other channels can not performed the machining procedure during the parameter is read or written;
- 12) The parameter read/write function+n can not be used together with the tool life span administration function.

#### Programming example:

1) State parameter read, write example

Program	Explanation		
#101 = 10000000;	Macro variable No. 101 is the setting value of the		
	state parameter No.2.		
G10 L52;	Set the parameter read or write method		
N1 R#100;	Read the state parameter No.1 to the macro		
	variable No.100.		
N1 W00000010;	Set the state parameter No.1 as 00000010.		
N2 W#101;	Set the state parameter No.2 as the value of the		
	macro variable No.101.		
G11;	Cacnel the read or write method of the parameter.		

#### 2) Data parameter read/write example

Program	Explanation
#101 = 50;	Marco variable #101 is the setting value of the
	data parameter No.31.
G10 L52;	Set the parameter read or write method
N30 R#100;	Read data parameter No.30 to the macro variable
	# 100.
N30 W200;	Set the data parameter No.30 as 200.
N31 W#101;	Set the data parameter No. to the value of the
	macro variable #101.
G11;	Cacnel the read or write method of the parameter.

#### 3) Axle type parameter read or write example

Program	Explanation		
#103=00000101;	Macro variable #103 is the setting value of the data parameter		
	No.188 along with the 1 <sup>st</sup> axis (X axis).		
#104=100;	Macro variable # 104 is the setting value of the data parameter		
	No.23 along with the 5 <sup>th</sup> axis (C axis).		
#105=6000;	Macro variable #105 is the setting value of the data parameter		
	No.38 along with the 2 <sup>nd</sup> axis (S2).		
G10 L52;	Set The read or write method of parameter.		
N187 P1 R#100;	Read the 1 <sup>st</sup> axis parameter value of the axle-type state		
	parameter No, 187 to the macro variable $#100$ .		
N187 P5	Set the axle type state parameter No.187 along with the 5 <sup>th</sup> axis		
W01100001;	is 01100001.		
N188 P1 W#103;	Set the 1 <sup>st</sup> axis of the axle type state parameter No.188 to the		
	value of the macro variable #103		
N22 P1 R#101;	Read the 1 <sup>st</sup> axis parameter value of the axle type data		
	parameter No.22 to the macro variable #101.		
N22 P2 W8000;	Set the 2 <sup>nd</sup> axis parameter of the axle type data parameter		

			No.22 as 8000.
N23	P5	W#104;	Set the 5 <sup>th</sup> axis of the axle type data parameter No.23 to the
			value of the macro variable #104
N37	P1	R#102;	Read the 1 <sup>st</sup> axis parameter value of the axle type data
			parameter No.37 to the macro variable $\pm 102$ .
N37	P3	W8000;	Set the 3 <sup>rd</sup> axis parameter of the spindle data parameter No.37
			as 8000.
N38	P2	W#105;	Set the 5 <sup>th</sup> axis of the spindle data parameter No.38 to the
			value of the macro variable #105
G11;			Cacnel the read or write method of the parameter.

Note: The read/write programming method of the K parameter is consistent with the one of the system state parameter; The read/write programming method of the D/DT/DC parameters are coincident with the one of the system data parameter.



# CHAPTER 4 TOOL NOSE RADIUS COMPENSATION (G41, G42)

## 4.1 Application

### 4.1.1 Overview

Part program is compiled generally for one point of tool according to a workpiece contour. The point is generally regarded as the tool nose A point in an imaginary state (there is no imaginary tool nose point in fact and the tool nose radius can be omitted when using the imaginary tool nose point to program) or as the center point of tool nose arc ( as Fig. 4-1). Its nose of turning tool is not the imaginary point but one arc owing to the processing and other requirement in the practical machining. There is an error between the actual cutting point and the desired cutting point, which will cause the over- or under-cutting affecting the part precision. So a tool nose radius compensation is needed in machining to improve the part precision.



Fig. 4-1 Tool



## 4.1.2 Imaginary Tool Nose Direction

Suppose that it is generally difficult to set the tool nose radius center on the initial position as Fig. 4-3; suppose that it is easily set the tool nose on it as Fig. 4-4; The tool nose radius can be omitted in programming. Fig. 4-5 and Fig.4-6 correspond separately to the tool paths of tool nose center programming and imaginary tool nose programming when tool nose radius is executed or not.

# **CNCmakers**





Fig. 4-3 Programming with tool nose



Tool path is shown in Fig.4-5 when the tool nose center programming is executed.



Fig. 4-5-1 the tool nose center path is the same that of programmed path without tool radius compensation Fig. 4-5-2 precise cutting with tool radius compensation

The tool path is shown in Fig. 4-6 when imaginary tool nose programming is executed



Fig. 4-6-1 the imaginary tool nose path is the same that of programmed path without tool radius compensation Fig. 4-6-2 precise cutting with tool radius compensation

The tool is supposed to one point in programming but the actual cutting blade is not one ideal point owing to machining technology. Because the cutting blade is not one point but one circular, machining error is caused which can be deleted by tool nose circular radius compensation. In actual machining, suppose that there are different position relationship between tool nose point and tool nose circular center point, and so it must create correct its direction of imaginary tool nose.

From tool nose center to imaginary tool nose, set imaginary tool nose numbers according to tool direction in cutting. Suppose there are 10 kinds of tool nose setting and 9 directions for position relationship. The tool nose directions are different in different coordinate system (rear tool post coordinate system and front tool post coordinate system) even if they are the same tool nose direction numbers as the following figures. In figures, it represents relationships between tool nose and starting point, and end point of arrowhead is the imaginary tool nose; T1~T8 in rear tool post



coordinate system is as Fig. 4-7; T1 $\sim$ T8 in front tool post coordinate system is as Fig. 4-8. The tool nose center and starting point for T0 and T9 are shown in Fig. 4-9.

Fig. 4-7 Imaginary tool nose number in rear tool post coordinate system

# **CNCmakers**



Fig. 4-8 Imaginary tool nose number in front tool post coordinate system



## 4.1.3 Compensation Value Setting

Preset imaginary tool nose number and tool nose radius value for each tool before executing tool nose radius compensation. Set the tool nose radius compensation value in *OFFSET* window (as Fig. 4-1), R is tool nose radius compensation value and T is imaginary tool nose number.

number	X	Z	R	Т
000	0.000	0.000	0.000	0
001	0.020	0.030	0.020	2
002	1.020	20.123	0.180	3
032	0.050	0.038	0.300	6

Table 4-1 CNC tool nose radius compensation value display window

# Note: X tool offset value can be specified in diameter or radius, set by No.004 Bit4 ORC, offset value is in radius when ORC=1 and is in diameter when ORC=0.

In toolsetting, the tool nose is also imaginary tool nose point of Tn (n=0~9) when taking Tn(n=0~9) as imaginary tool nose. For the same tool, offset value from standard point to tool nose radius center (imaginary tool nose is T3) is different with that of ones from standard point to imaginary tool nose(imaginary tool nose is T3) when T0 and T3 tool nose points are selected to toolsetting in rear tool post coordinate system, taking tool post center as standard point. It is easier to measure distances from the standard point to the tool nose radius center than from the standard point to the imaginary tool nose, and so set the tool offset value by measuring distance from the standard point to the imaginary tool nose (itool nose direction of T3).





## 4.1.4 Command Format



Commands	Function specifications	Remark
G40	Cancel the tool nose radius compensation	
G41	Tool nose radius left compensation is specified by G41 in rear tool post coordinate system and tool nose radius right compensation is specified by G41 in front tool post coordinate system	See Fig.4-11 and 4-12
G42	Tool nose radius right compensation is specified by G42 in rear tool post coordinate system and tool nose radius left compensation is specified by G42 in front tool post coordinate system	

# 4.1.5 Compensation Direction

Specify its direction according to relative position between tool nose and workpiece when executing tool nose radius compensation is shown in Fig. 4-11 and Fig.4-12.





Fig. 4-11 Compensation direction of rear coordinate system



Fig. 4-12 Compensation direction of front coordinate system

## 4.1.6 Notes

- In tool nose radius compensation mode, the system will alarm when it executes 7 block or more than blocks without motion Command.
- Tool nose radius R is without negative value, otherwise there is a mistake running path.
- Tool nose radius compensation is created and cancelled in G00 or G01 instead of G02 or G03, otherwise, the system alarms.
- The system cancels the tool nose radius compensation mode when pressing key or execute M30
- G40 must be specified to cancel offset mode before the program is ended, otherwise the tool path offsets one tool nose radius.
- The system executes the tool nose radius compensation in main program and subprogram but must cancel it before calling subprogram (before execute M98) and then create it again in the subprogram.
- The system does not execute the tool nose radius compensation in G74, G75, G76 and cancel it temporarily.
- The system executes the tool nose radius compensation in G90, G94, it offsets one tool nose radius (based upon the imagine cutter nose No.0) for G41 or G42.

• The compensation mode will be automatically retreated by performing the G71, G72 or G73, if the tool nose compensation should be used in the G71, G72 or G73 code, it can be rebuilt at the 1<sup>st</sup> part of the finish machining block.

## 4.1.7 Application

Machine a workpiece in the front tool post coordinate system as Fig. 4-13. Tool number: T0101, tool nose radius R=2, imaginary tool nose number T=3.



For toolsetting in Offset Cancel mode, after toolsetting, Z axis offsets one tool nose radius and its direction is relative to that of imaginary tool nose and toolsetting point, otherwise the system excessively cuts tool nose radius when it starts to cut.

Set the tool nose radius R and imaginary tool nose direction in "**TOOL OFFSET&WEAR**" window as following:

		Table 4-3	$\frown$	$\frown$
No.	Х	Z	R	( T )
001			2.000	3
002				
007				
008				

Program:

G00 X100 Z50 M3 T0101 S600;

G42 G00 X0 Z3; G01 Z0 F300; X16; Z-14 F200; G02 X28 W-6 R6; G01 W-7; (Position, start spindle, tool change and execute tool compensation) (Set tool nose radius compensation) (Start cutting) X32; Z-35; G40 G00 X90 Z40; G00 X100 Z50 T0100; M30;

(Cancel tool nose radius compensation)

## 4.2 Tool Nose Radius Compensation Offset Path

## 4.2.1 Inner & Outer Side

**Inside** is defined that an angle at intersection of two motion blocks is more than or equal to  $180^{\circ}$ ; **Outside** is  $0 \sim 180^{\circ}$ .



3 steps to execute tool nose radius compensation: tool compensation creation, tool compensation execution and tool compensation canceling.

Tool traverse is called tool compensation creation (starting tool) from offset canceling to G41 or G42 execution.

Note1: Meanings of S, L, C in the following figures are as follows: S——Stop point of single block; L——linear; C——circular.

Note2: Tool movement path is marked with the tool nose direction 0 in the following figures.

Note3: Tool path is described in rear tool post coordinate system and tool compensation direction G41 in the following figures.

# 4.2.2 Tool Traversing when Starting Tool

#### (a) Tool traversing inside along corner( $\alpha \ge 180^\circ$ )

1) Linear  $\rightarrow$  linear

2) linear  $\rightarrow$  circular



(d) Tool traversing outside along corner , linear  $\rightarrow$  linear ( $\alpha$  ≤ angle set by No. 237)



# 4.2.3 Tool Traversing in Offset Mode

Offset mode is called to ones after creating tool nose radius compensation and before canceling



# Offset path without changing compensation direction in compensation mode (a) Tool traversing inside along corner(α≥180°)



5) Inner side machining and scaling up compensation valid for acute angled being less than  $\alpha$   $(\alpha :$  set by No. 237) .







(c) Tool traversing outside along corner( $\alpha < 90^\circ$ )

1) Linear→linear









#### • Offset path of changing compensation direction in compensation mode

The compensation direction can be changed in compensation mode in special cutting. There is no inside and outside cutting when the system changes the compensation direction. The following are the path of tool running when the compensation changes are changed:

1) Linear→linear

2) Linear→circular



I Programming

5) No intersection when compensation is executed normally

When the system executes G41 and G42 to change the offset direction between block A and B, a vector perpendicular to block B is created from its starting point.

i) Linear----Linear


Fig. 4-15a Linear—linear, no intersection (changing compensation direction) ii ) Linear ---circular









# 4.2.4 Tool Traversing in Offset Canceling Mode

In compensation mode, when the system executes a block with one of the followings, it enters compensation canceling mode, which is defined to compensation canceling of block.

- 1. Execute G40 in a program;
- 2. Execute M30.

The system cannot execute G02 and G03 when canceling C tool compensation (tool nose radius compensation), otherwise the system alarms and stops run.

In compensation canceling mode, the system executes the block and ones in the register for tool nose radius compensation. At the moment, the run stops after one block is executed when single block is ON. The system executes the next one but does not read its following one when pressing CYCLE START button again.



#### (b) Tool traversing outside along corner(180°>α≥90°)



(d) Move along outer side of acute angle being less than  $\alpha$ , linear $\rightarrow$ linear ( $\alpha \leq$  angle set by No. 237)



# 4.2.5 Tool Interference Check

"Interference" is defined that the tool cuts workpiece excessively and it can find out excessive cutting in advance, the interference check is executed even if the excessive cutting is not created, but the system cannot find out all tool interferences.

#### (1) Fundamental conditions

1) The tool path direction is different that of program path (angle is  $90^{\circ}$ ~270°).

2) There is a big difference ( $\alpha$ >180°) for two angles between starting point and end point of tool nose center path, and between starting point and end point of program path.

Example: linear machining



Fig. 4-16b Machining interference (2)

(2) Executing it without actual interference



Fig. 4-17 Executing interference (1)

Directions of block B and tool nose radius compensation path are opposite without interference, the tools stops and the system alarms.

2) Concave channel less than compensation value





Directions of block B and tool nose radius compensation path are opposite without interference, the tools stops and the system alarms.

# 4.2.6 Commands for Canceling Compensation Vector Temporarily

In compensation mode, the compensation vector is cancelled temporarily in G50, G71~G76 and is automatically resumed after executing the commands. At the moment, the compensation is cancelled temporarily and the tool directly moves from intersection to a point for canceling compensation vector. The tool directly moves again to the intersection after the compensation mode is resumed.

#### • Setting coordinate system in G50



Fig. 4-19 Temporary compensation vector in G50 Note: SS indicates a point at which the tool stops twice in Single mode.

#### • Reference point automatic return G28

In compensation mode, the compensation is cancelled in a middle point and is automatically resumed after executing the reference point return in G28.





#### • G71~G75 compound cycle; G76, G92 thread cutting

When executing G71 $\sim$ G76, G96 thread cutting, the system does not execute the tool nose radius compensation and cancel it temporarily, and there is G00, G01,in the following blocks, and the system automatically recovers the compensation mode.

#### • G32, G33,G34 thread cutting

They cannot run in the tool nose radius compensation mode, otherwise, No.131 alarm occurs ".....CANNOT USED TO C COMPENSATION".



Fig. 4-21 Cancel compensation vector temporarily in G71~G76

#### • G32, G33, G34 constant thread cutting

They cannot be executed in tool nose radius compensation mode, otherwise, No. 131 alarm

occurs ".....the command cannot be used in C compensation mode."

#### • G90, G94 (taking an example of G42)

Compensation method of tool nose radius compensation in G90 or G94:

- A. Cancel the previous tool nose radius compensation;
- B. Create the previous C compensation before cutting, and the path ① in the following figure creates the previous radius compensation mode;
- C. The paths 2, 3 in the following figure are the radius compensation cutting;
- D. The path 4 in the following figure can cancel the radius compensation, and the tool returns to the cycle starting point; there is G00,G01 in the following block, and the CNC automatically recovers the compensation mode.



Fig. 4-22 Offset direction of G90 tool nose radius compensation



Fig. 4-23 Offset direction of G94 tool nose radius compensation



# **II** Operation



# CHAPTER 1 OPERATION MODE AND DISPLAY INTERFACE

#### 1.1 **Panel Division**

GSK980TDi, GSK980TDi-V CNC system uses an integrated panel, which is divided as follows:



GSK980TDi-V panel division

# 1.1.1 State Indication

●X	• Y	D D Z	🗭 4th	<b>□</b>	Indicator for axis zero return completion
	ALM	READY	RUN		Three-color light

# 1.1.2 Edit Keypad

Press key	Name	Function
11	RESET key	CNC reset, feed, output stop etc.
D     N     G       X     Z     U     W       M <sub>L</sub> S <sub>1</sub> T <sub>=</sub>	Address key	Address input
$\begin{array}{c c} H_{Y} & F_{E} & R_{V} & L_{D} \\ \hline I_{A} & J_{B} & K_{C} & P_{G} \end{array}$		Double address key, switching them by pressing it repetitively
	symbol	Key to three addresses,, switching them by pressing it repetitively
789456123O0	Number key	Number input
• < >	Decimal point	Decimal point input
Real Provide American Science Provide American	Input key	Parameter, compensation value and other data input
	Output key	Communication output
	Change key	Switching message, display
Alter Dater	Edit key	Inserting, altering, deleting programs, fields in EDIT working mode( compound key, switching them by pressing it repetitively)
	EOB key	Inputting the end character of block
	Cursor move keys	controlling cursor move

Press key	Name	Function
	Window key	Switch the page in the same display page

# 1.1.3 Menu Display

Menu key	Remark
	To enter Position interface including RELATIVE POS, ABSOLUTE POS, POS &
	PRG, INTEGRATED POS, MPG interrupted page.
	• "ABSOLUTE POS" page can display the current absolute coordinates, clear
	out machining count, machining time, as well, it can be set the Max. workpiece
	number, current number, and the tool-change safety position;
	<ul> <li>"POS &amp; PRG" page can display current coordinate information and current run</li> </ul>
	program;
POSIDION	• "RELATIVE POS" page can display current relative coordinates, clear relative
	coordinates;
	• "INTEGRATED POS" can display current coordinate information; the
	reference position along each axis can be set under the 2 <sup>nd</sup> level authority;
	• The input/output equivelant amount along each axis can be displayed based
	upon the MPG interruption on its MPG interruption page, which can be
	eliminated the interruption amount along each axis.
	To enter Program interface including program content, program list, Marco variable
	note, program state page
	<ul> <li>Edit/search current open programs in program content page;</li> </ul>
	• Edit MDI programs, display coordinates, override and modal state in MDI
_	page;
PROGRAM	• Display, preview, open, copy machining programs in CNC in local catalog
	page;
	• The noted macro variable note name can be viewed on the macro variable
	note page;
	<ul> <li>Display, preview, open and copy machining programs in U disk in U disk</li> </ul>
	catalog page
	Enter tool onset interface including onset setting, macro variables, workpiece
	Set/accreb tool offact value and wear value in tool offact actting page
员上。	<ul> <li>Set/search tool onset value and wear value in tool onset setting page,</li> <li>Set/search CNC means variables in means variable page.</li> </ul>
DIFSET	<ul> <li>Set/search CNC macro variables in macro variable page;</li> <li>Set/search OF4, OF0, searchingto, sustant and macro variable page;</li> </ul>
	• Set/search G54~G59 coordinate system and zero offset value in workpiece
	coordinate system page;
	Set/search use information of current tool life
	Enter alarm interface including alarm information, alarm log page
	• Search Cive alarm, Cive warning, PLC alarm, PLC warning, Servo alim, in
ALARM	viewed by celecting some one clarm or procession and troubleshoulings call be
	Display elerm/warning history record in elerm log name
	<ul> <li>Display alarm/warning history record in alarm log page</li> </ul>

# **CNCmakers**

<ul> <li>machine tool debugging, GSKLink, setting IP page</li> <li>Set switch, level and parameters in CNC setting page;</li> <li>Set system clock, data in system clock page;</li> <li>Search/management files in CNC/U disk, copy/resume files in file management page</li> <li>Rapid grouping can be performed in the machine tool debugging page, so that the each functions for the machine tool can be easily debugged;</li> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Search/set the urrent diagnosis information of the CNC in the diagnosis page.</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		Enter Setting interface including CNC setting, system clock, file management,							
<ul> <li>Set switch, level and parameters in CNC setting page;</li> <li>Set system clock, data in system clock page;</li> <li>Search/management files in CNC/U disk, copy/resume files in file management page</li> <li>Rapid grouping can be performed in the machine tool debugging page, so that the each functions for the machine tool can be easily debugged;</li> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set data parameters in the state parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine tool diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		machine tool debugging, GSKLink, setting IP page							
<ul> <li>Set system clock, data in system clock page;</li> <li>Set system clock, data in system clock page;</li> <li>Search/management files in CNC/U disk, copy/resume files in file management page</li> <li>Rapid grouping can be performed in the machine tool debugging page, so that the each functions for the machine tool can be easily debugged;</li> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters in the state parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set the drive parameter along each axis on the servo parameter page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		<ul> <li>Set switch, level and parameters in CNC setting page;</li> </ul>							
<ul> <li>Search/management files in CNC/U disk, copy/resume files in file management page</li> <li>Rapid grouping can be performed in the machine tool debugging page, so that the each functions for the machine tool can be easily debugged;</li> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		<ul> <li>Set system clock, data in system clock page:</li> </ul>							
<ul> <li>Control and generation and on the one of the order of and, topy/recame the order of and, topy/recame the order of the management page</li> <li>Rapid grouping can be performed in the machine tool debugging page, so that the each functions for the machine tool can be easily debugged;</li> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis, Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		<ul> <li>Search/management files in CNC/U disk copy/resume files in file</li> </ul>							
<ul> <li>Rapid grouping can be performed in the machine tool debugging page, so that the each functions for the machine tool can be easily debugged;</li> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis. Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>	•	management nage							
<ul> <li>Including tooping can be performed in the machine tool debugging page, so that the each functions for the machine tool can be easily debugged;</li> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>	CC SETING	<ul> <li>Rapid grouping can be performed in the machine tool debugging page, so that</li> </ul>							
<ul> <li>Each controllable axis of the system corresponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis \ Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		the each functions for the machine tool can be easily debugged:							
<ul> <li>Each controllable axis of the system conseponding the drive and motor can be set in GSKLink page;</li> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis \ Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		<ul> <li>Each controllable axis of the system corresponding the drive and motor can be</li> </ul>							
<ul> <li>Set the IP page for using the relevant parameter setting of the RJ45 internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis PLC state, PLC monitor, PLC data, Program</li> </ul>		set in GSKI ink page.							
<ul> <li>Set the fit page for dang the relevant parameter setting of the RXX internet access communication</li> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis, Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		<ul> <li>Set the IP page for using the relevant parameter setting of the P 1/5 internet.</li> </ul>							
<ul> <li>Enter Parameter interface including state parameters, data parameter, often-used parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis. Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		access communication							
<ul> <li>Enter l'arameter interface including state parameters, data parameters, onen-deed parameters, servo parameters, and pitch compensation page.</li> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page;</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis. Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		Enter Parameter interface including state parameters, data parameter, often-used							
<ul> <li>Search/set state parameters in the state parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		parameters serve parameters and pitch compensation page							
<ul> <li>Search/set state parameters in the state parameter page,</li> <li>Search/set data parameters in the data parameter page;</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> </ul>		parameters, servo parameters, and pitch compensation page.							
<ul> <li>Search/set data parameters in the data parameter page,</li> <li>Search/set user's customized parameters in the often used parameter page;</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis \ Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		<ul> <li>Search/set state parameters in the data parameter page;</li> <li>Search/set data parameters in the data parameter page;</li> </ul>							
<ul> <li>Search/set user's customized parameters in the other used parameter page,</li> <li>Search/set pitch error compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis. Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>	PARAMETER	<ul> <li>Search/set user's customized parameters in the often used parameter page;</li> </ul>							
<ul> <li>Search/set pitch end compensation data of each axis in the pitch compensation page.</li> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis, Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		<ul> <li>Search/set bitch error compensation data of each axis in the pitch.</li> </ul>							
<ul> <li>View/set the drive parameter along each axis on the servo parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		compensation page							
<ul> <li>View/set the drive parameter along each axis on the serve parameter page.</li> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis, Serve diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Serve diagnosis can be viewed serve operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		<ul> <li>View/set the drive parameter along each axis on the serve parameter page.</li> </ul>							
<ul> <li>Enter Diagnosis interface including the system diagnosis, system information, Machine tool diagnosis Servo diagnosis page</li> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		View/set the drive parameter along each axis on the serve parameter page.							
<ul> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		Enter Diagnosis interface including the system diagnosis, system mormation,							
<ul> <li>Search the current diagnosis information of the CNC in the diagnosis page.</li> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		Constant the surrent discussion information of the CNC in the discussion page							
<ul> <li>Search the product information, ladder information and ladder state.</li> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>	<b>F</b>	<ul> <li>Search the product information of the CNC in the diagnosis page.</li> <li>Search the product information ladder information and ladder state.</li> </ul>							
<ul> <li>Machine diagnosis can be directly inspected the working state of machine tool's each component;</li> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>	DIABNOBIS	<ul> <li>Search the product information, ladder information and ladder state.</li> <li>Machine, diagnosis, can be directly increased the working state of machine.</li> </ul>							
Servo diagnosis can be viewed servo operation state of each axis.      PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program		<ul> <li>iviacnine diagnosis can be directly inspected the working state of machine tool's each component;</li> </ul>							
<ul> <li>Servo diagnosis can be viewed servo operation state of each axis.</li> <li>PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program</li> </ul>		tool's each component;							
PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program		Servo diagnosis can be viewed servo operation state of each axis.							
		PLC page includes three subpages: PLC state, PLC monitor, PLC data, Program							
PLC state page can search states of X, Y, F, G, R, A, C, I;	[BIC]	PLC state page can search states of X, Y, F, G, R, A, C, I;							
PLC monitor page can monitors the execution state of current ladder on-line;	PLC	<ul> <li>PLC monitor page can monitors the execution state of current ladder on-line;</li> </ul>							
• PLC data page can search/set K, D, DT, DC value.		PLC data page can search/set K, D, DI, DC value.							
• The registered PLC program can be selected in the program list page, and		• The registered PLC program can be selected in the program list page, and							
then start the operation.		then start the operation.							
Enter Graph page to display the movement path of X, Z axis	GRAPH	Enter Graph page to display the movement path of X, Z axis							
Entering to the system help page can be captured the helf information, such as	G	Entering to the system help page can be captured the helf information, such as							
the programming, operation and installation.	HELP	the programming, operation and installation.							

# 1.1.4 Machine Panel

The key functions on GSK980TDi machine panel are defined by PLC program (ladder), the detailed function meanings are referred to machine manufacturer manual.

The functions of this GSK980TDi machine panel keys defined by standard PLC program are as follows:

Кеу	Name	Function explanation	Operation mode	
(III	Feed hold	Dwell commanded by	Auto MDI mode	
FEED HIDLEL	key	program, MDI code		
	Cycle Start	Cycle start commanded by	Auto, MDI mode	
TREESTATI	key	program, MDI code		
F. OVERFRIDE	Feedrate		Auto MDI Edit Machine zero	
WW100%	Override	Adjusting feedrate	return, MPG, Step, Manual,	
, k. DVEHRDE	keys		Program zero return mode	
F. OVERADE				
ЛX1 ЛX10 ЛX100 ЛX1000	Rapid		Auto, MDI, Machine zero return,	
₩ F0 ₩ 25% ₩ 50% ₩100%	override	Adjusting rapid traverse	Manual, Program zero return	
	keys		mode	
	o ·			
LP%+	Spindle	spindle speed adjustment	Auto, Edit, MDI, Machine zero	
- <b>D</b> %	kevs	(spinule analog control	Program zero return mode	
S. OVERHIE	Keye			
	Manual tool		Machine zero return, Manual,	
D S I CHANGE	change kev	manual tool change	Step, MPG, Program zero return	
	onange key		mode	
00	JOG key	spindle jog on/off	Marking and action Manual	
C/S	C/S Switch	switch spindle speed/	Step, MPG, Program zero return	
		position control	mode	
	Lubricating	For lubricating ON/OFF		
TTC-MEN AND	КСУ		Auto, Edit, MDI, Machine zero	
6ª	Cooling key	For cooling ON/OFF	return, Manual, Step, MPG,	
DOOLING			Program zero return mode	
			Auto, Edit, MDI, Machine zero	
UK CHARGE	Chuck key	Chuck clamping/releasing	return, Manual, Step, MPG,	
			Program zero return mode	
- i+i	Hydraulic		Auto, Edit, MDI, Machine zero	
HOVERALLIE:	key		Program zero return mode	
S DW		For spindle CCW	Machine zero return Manual	
	Spindle	For spindle stop	Step, MPG, Program zero return	
S STOP	control keys	For spindle CW	mode	
S CON				
20.	Rapid	For rapid traverse /feedrate	Auto MDI Manual mode	
RAFID	traverse key	switching		



Кеу	Name	Function explanation	Operation mode	
	X feed key			
	Z feed key	Positivo/pogativo	Machina zoro rotura Stan	
R. D	Y feed key	movement of each axis in	Manual, Program zero return	
Q 45 1	The 4 <sup>th</sup> feed key	Manual, Step mode	mode	
್ತ್ರಿ ೨	Cs feed key			
	MPG axis selection key	Each axis selection in MPG mode	MPG mode	
<b>J</b> X11 月 X10 月 X100 月 X1000 10 F0 10 25% 10 50% 10100%	MPG/Step increment and Rapid override selection key	Move amount per MPG scale 0.001/0.01/0.1 mm Move amount per step 0.001/0.01/0.1 mm Rapid override F0, F50%, F100%	Auto, MDI, Machine zero return, Manual, Step, MPG, Program zero return mode	
Distance Bible	Optional stop	Execute M01 to pause when the optional stop is enabled	Auto, MDI, and MPG trial-cut mode	
SMGLE	Single Block switch	For switching of block/blocks execution, Single block indicator lights up if Single mode is active	Auto, MDI mode	
SKIP	Block Skip switch	For skipping of block headed with"/"sign, if its switch is set for ON, the Block Skip indicator lights up	Auto, MDI mode	
KALONE LDD	Machine Lock key	If the machine is locked, its indicator lights up, and X, Z axis output is inactive.	Auto, MDI, Edit, Machine zero return, Manual, Step, MPG, Program zero return mode	
MST CKO MS1100	M.S.T. Lock key	If the miscellaneous function is locked, its indicator lights up and M, S, T function output is inactive.	Auto, MDI mode	
DRY	Dry Run key	If dry run is active, the Dry run indicator lights up. Dry run for program/MDI codes	Auto, MDI mode	
Ent	Edit mode key	To enter Edit mode	Auto, MDI, Machine zero return, Manual, Step, MPG, Program zero return mode	

Кеу	Name	Function explanation	Operation mode
AUTO	Auto mode key	To enter Auto mode	MDI, Edit, Machine zero return, Manual, Step, MPG, Program zero return mode
ko)	MDI mode key	To enter MDI mode	Auto, Edit, Machine zero return, Manual, Step, MPG, Program zero return mode
	Machine zero return mode key	To enter Machine zero return mode	Auto, MDI, Edit, Manual, Step, MPG, Program zero return mode
C APPE	Step/MPG mode key	To enter Step or MPG mode (one mode by parameter)	Auto, MDI, Edit, Machine zero return, Manual, Program zero return mode
ANADALIAL .	Manual mode key	To enter Manual mode	Auto, MDI, Edit, Machine zero return, Step, MPG, Program zero return mode
PROJEKT	Program zero return mode key	To enter Program zero return mode	Auto, MDI, Edit, Machine zero return, Step, MPG, Manual mode
THUS LEAT	MPG trial-cut selection key	To enter MPG trial-cut mode	Auto, MDI, Edit, Machine zero return, Step, MPG, Manual, MPG trial-cut mode

# 1.2 Summary of Operation Mode

There are 8 modes in GSK980TDi, which are Edit, Auto, MDI, Machine zero, Step/MPG, Manual, Program Zero, and MPG trial-cut modes.

• Edit mode

In this mode, the operation of part program setup, deletion and alteration can be performed.

Auto mode

In this mode, the program is executed automatically.

MDI mode

In this mode, the operation of parameter input, command blocks input and execution can be performed.

• Machine zero mode

In this mode, the operation of X, Z machine zero return can be performed separately.

#### • MPG / Step mode

In the Step/MPG feed mode, the moving is performed by an increment selected by CNC system.

#### Manual mode

In this mode, the operation of Manual feed, Manual Rapid, feedrate override adjustment, Rapid override adjustment and spindle ON/OFF, cooling ON/OFF, Lubricating ON/OFF, spindle jog, manual tool change can be performed.

#### • Program zero return mode

In this mode, the operation of X, Z program zero return can be performed separately.

• MDP trail-cut mode

In this mode, rotating the MPG can control program's execution speed, which can check whether the machining program is correct.

# 1.3 Display Interface

The chapter introduces page switch, relationship between operation input and soft key, and concrete operation methods.

GSK980TDi has 9 function keys including POS, PRG, SET, etc. on its edit keyboard. Each function key corresponds to one interface which has many pages and operation soft keys, which are shown below:

# 1.3.1 POS Interface



1) ABSOLUTE POS display interface

The X, Z coordinates displayed are the absolute position of the tool in current workpiece coordinate system, these coordinates are memorized as power is down and the workpiece coordinate system is specified by G50.



Basic information in POSITION interface (taking an example of the above figure):

- ✓ G code : information of each G code;
- ✓ M : last executed M code;
- ✓ S :it is input spindle speed when analog spindle is executed, and input spindle's gear when the spindle is executed;
- ✓ L : call times of subprogram;
- ✓ F :the first half (0.000mm/min) is the actual speed, and the second half (200mm/min) is the command speed;
- ✓ JOG F.( JOG speed): theory speed value of current override in JOG mode;
- ✓ FED OVRI(Feedrate override):override selected by feedrate override switch;
- ✓ RAD OVRI (Rapid override): display currently rapid override;
- ✓ SPI OVRI (Spindle override): display the spindle override when NO.001 Bit1 is set to 1;
- ✓ PART CNT(Part counting) : part counting adds 1; when program executes the M code set by data parameter No.173;
- ✓ CUT TIME: the system counts the time when the automatic run is started, time unit is hour, minute and second in order.

#### 2) **RELATIVE POS display interface**

Displayed U, W coordinates are the current position relative to the reference point, and they are held on when power on. They can be cleared at any time. When No.005 Bit1=1, and the absolute coordinates are set by G50, the relative coordinates are set simultaneously.



3) INTEGRATED POS display interface

					50000 TO	000
INTEGRATE	D POS		00000 N000	0 MODAL INF	ORMATION	X AXIS
U	RELATIVE] 0.0000	LABS X	OLUTE] 0.0000	600 697 0 640 623 0 664 618 0 800 5000	G98 G21 G67 G54 G15 G13.1 0 L0	SETTING Z AXIS REF. SETTING
•	0.0000	Z	0.0000	F 0.000	0 mm/min 0 mm/min	
				MAIN INFO	RMATION	
1	MACHINE]	[D1S1	10 GO]	JOG.F	1260	
				FED OVR1	100%	
x	0.0000	X	0.0000	RAP OVR1	100%	
				SPI OVRI	100%	
Z	0.0000	Z	0.0000	PART CNT	0	
				CUT TIME	00:00:00	
				1	13:19:34	-
ABS	POS&PRG	LE_ALL	HANDLE			

4) POS&PRG display interface

In POS&PRG interface, it displays ABSOLUTE, RELATIVE coordinate of the current position (ABSOLUTE, DIST TO GO of current position and machine coordinates will be displayed when No.180 BIT0 is set to 1) as well as 7 blocks of current program together. During the program execution, the displayed blocks are refreshed dynamically and the cursor is located in the block being executed.

S &	PRG				00000 N0000	MODAL INF	ORMATION
ERE	LATIVET	[ABSOLUTE]		EM	ACHINE]	G00 G97 0 G40 G23 0	98 G21 67 G54
0	0.0000	x	0.0000	X	0.0000	G64 G18 C	615 G13.1 0 LØ
2	0.0000	Z	0.0000	Z	0.0000	F 0.000	ann/nin ann/nin
OGR.	AM					MAIN INFO	RMATION
1	00000(0.00	DIMM/D/	JOG.F	1260			
2	650 X300.	Z500.;	00			FED OVRI	100%
3	698 600 X	-200	RAP OVRI	100%			
5	690 U-10.	Z100.	SDI OVDI	1004			
6	G00 X90.:		OFT OTAT	100%			
7	G74 R0.5:		PART CNI	U			
8	G74 X0. ₩-	-10. P:	CUT TIME	00:00:02			
	-	-	-				15-09-43

#### 5) MPG interrupted page

When the Bit 1 of state parameter No.0012 sets to "1", the MPG interruption sub-page is then displayed on the position page; refer to the following figure:

MDI		50000 TOP	00
HANDLE INTERRUPTION	00000 N0000	MODAL INFORMATION	INTERRU
[INPUT UNIT] X 0.0000 mm	LOUTPUT UNIT] X 0.0000 mm	C00 C97 C98 C21 C40 C23 C67 C54 C64 C18 C15 C13.1 N00 S0000 L0	CLR INTERRU AMOUNT CLR
Z 0.0000 mm	Z 0.0000 mm	F 0.0000 mm/min 200 mm/min	-
		MAIN INFORMATION	1
[RELATIVE]	[0151 10 60]	JOG.F 1260	
		FED OVRI 100%	1
U 0.0000	X 0.0000	RAP OVRI 100%	
		SP1 OVR1 100%	
W 0.0000	Z 0.0000	PART CNT 0	
		CUT TIME 00:00:02	
	2 20	B 15:14:56	
	L THANDLE		

### 1.3.2 PRG Interface

Press *multi* to enter PRG interface, which includes



(the soft

kev.

function menu can be displayed when USB device is connected to the system). Press repetitively or press the corresponding soft function keys to switch interfaces. The following descriptions are aimed to program page set of the connected USB equipment of the GSK980TDi system.

#### 1) PRG CONTENT page

In the page, the program content including current block can be displayed. In Edit mode, the

program content can be viewed forward or backward by pressing

EC	TIC	S0000 T0000		
PROG	RAM -> LOCAL PROGRAM [00000] INSERI	00000 N0000 24		
1	00000(0.001MM/DA98/DA98A/步进);	A SEARC		
2	G50 X300, Z500.;	- CLAIN		
3	G98 G00 X100. Z200.;	-		
4	G90 U-10, W-200, F500.;	SEARC		
5	G90 U-10, Z100, R-2.5 F350,;			
6	G00 X90.;			
7	G74 R0.5;	LABE		
8	G74 X0. #-10. P3000 Q5000 R1.5 F300.			
9	G00 Z190.;			
10	G71 U2.5 R0.5;			
11	G71 P10 Q50 U1, ₩1, F250,;	23		
12	N10 G00 U-50.;	74.		
13	N20 G3 X60, Z180, 10, K-10, F150.;			
14	N30 G2 U5, Z155, R200, F200,:	DE DE		
15	N40 G01 X70, #-20, F50,	SEG		
16	N50 U20, Z130, F150,;			
17	G70 P10 Q50			
18	G00 X92.:	CALCU		
19	₩-100.;	*		
	lane as a	# 16-37-17 NORE:		
-				
PR				

#### 2) MDI program page

In MDI mode, the page can be displayed, and is value when the corresponding soft function key is pressed as follows:

MDI			50000 TO	000
PROGRAM -> MD1 PR	OGRAM	00000 N0000	MODAL INFORMATION	CLEAR
[ABSOLUTE] X 0.0001	[MACHINE] U 0.00	SRPM: 0000 01 SSPM: 0000 SMAX: 9999	C00 C97 C98 C21 C40 C23 C67 C54 C64 C18 C15 C13.1 W00 S0000 L0	
Z 0.0000 MD1[010000]	7 0.00	00 SMIN: 0000	F 0.0000 mm/min 200 mm/min MAIN INFORMATION	De DEL
1 601 7000 20	100100		JOG.F         1260           FED OVRI         100%           RAP OVRI         100%           SPI OVRI         100%           PART CNT         0	SEG. NO UNDO CM
	-		CUT TIME 00:00:02	MARCO EDIT
MDT PROG	CNC DIR.	120		

3) Local directory page

JOG \$0000 TO	000
PROGRAM -> LOCAL DIRECTORY 00000 N0000	2
TOTAL: 21 SPACE: 64.0 M USED: 1.7 M IDLE: 62.3 M	OPEN
NAME         SIZE         DATE         PROCRAM PREVIEW 00000           25         D00000         919 B         2015-11-16         00000 (0.001 MM/DA98/DA98A/步进)           000001         1.1 K         2015-11-16         G50 X300. Z500.         G50 X300. Z500.           000002         52 B         2015-11-16         G90 U-10. W-200. F500.         G90 U-10. W-200. F500.           000005         46 B         2015-11-16         G90 U-10. Z00. F500.         G90 U-10. Z00. F500.           000006         63 B         2015-11-16         G90 U-10. Z00. F500.         G00 X90. R-2.5 F350.           000006         63 B         2015-11-16         G00 Y30. R-2.5 F350.         G00 X90. R-2.5 F350.           000007         39 B         2015-11-16         G00 Y30. R-2.5 F350.         G00 Y30. R-2.5 F350.           00009         92 B         2015-11-16         G71 V2.5 F0.5         G70 P10. G50 U1. W1. F250.           00010         128 B         2015-11-16         G71 V2.5 F0.5         G70 P10 G50.         N30 G2 V5. Z155. R200. F200.           00011         612 B         2015-11-16         N30 G2 V5. Z155. R200. F200.         N40 G01 X70. W-20. F50.           00012         873 B         2015-11-16         N30 G2 V5. Z130. F150.         N50 U20. Z130. F150.           000112 <th>EIND(P) RENAME</th>	EIND(P) RENAME
PROG CONTENT PROG CONTENT PROG	NEXT

4) U disk directory page



#### **TOOL OFFSET Interface** 1.3.3

to enter the TOOL OFFSET interface which includes	■ OFFSET &₩EAR	MACRO VAR.	t OFFSET CD.
1		Bitter	

USER-DFLT (it enters the interface when No. 002 Bit0 is set to 1). Press repetitively or TOOL-LIFE corresponding keys to switch pages.

#### TOOL OFFSET&WEAR interface 1)

Press

There are 5 pages and 33 offset & wear No. (No.000~No.032) available for user in the interface,

kov

which can be shown as foll	lows	s by p	ressing		or 占	₽	key.	
	ED	IT					50000 TI	0000
	100	-> OFFSE	T & WEAR		00000 1	0000	COORDINATES	Billion
	NO.		×	Z	R	T		IN
	00	OFT	0.0000	0.0000	0.0000	0	[RELATIVE]	+ INP
	-		Second state	atsestara	10000	-		-
	01	OFT	0.0000	0.0000	0.0000	0	U 0.0000	RECO
		WEAR	0.0000	0.0000	0.0000	<u> </u>		X PO
	02	OFT	0.0000	0.0000	0.0000	0	₩ -0.0001	RECO
	MEAR         0.0000         0.0000         0.0000           02         0F1         0.0000         0.0000         0.0000           MEAR         0.0000         0.0000         0.0000         0           03         0F1         0.0000         0.0000         5.0000         3		Z PO					
	02	OFI	0.0000	0.0000	5.0000			1
	05	WEAR	0.0000	0.0000	0.0000	3	and the second	
		OFT	0.0000	0.0000	0.0000		[ABSOLUTE]	-
	04	WEAR	0.0000	0.0000	0.0000	0		
		OFT	0.0000	0.0000	0.0000		X 0.0000	
	05	WEAR	0.0000	0.0000	0.0000	0		LA TO
		OFT	0.0000	0.0000	0.0000		Z -0.0001	10
	86	WEAR	0.0000	0.0000	0.0000	0		54
		120014	-				# 16:40:41	FIND
	D- OFF	SET	tt- OFF	SET USER-DE	ut		PREV.	NEXT
	- SHE	AR MAC	CD.	MACRO	VAR	0.8	PAGE	PAGE

#### 2) MACRO interface

The macro variable divides into 5 sub-pages: Common variable, Local variable, System variable, Note list and Customized macro variable. There are 19 pages in this interface, which can be shown

Æ key. In Macro window there are 600 (No.100 $\sim$ No.199 and No.500 $\sim$ by pressing or No.999) macro variables which can be specified by macro command or set directly by keypad. The public variable page is shown below:

222

					20000	10000
1 -> ₩/	CRO [PUBLIC	VARIABLE]			00000 N	0000 PU
NO.	DATA	NO.	DATA	NO.	DATA	· VA
100		112		124		100
101		113		125		VA
102		114		126		
103		115		127		SY
104		116		128		
105		117		129		
106		118		130		
107		119		131		
108		120		132		
109		121		133		12
110		122		134		FIND
111		123		135		2
100 Stor	re variable.Re	set 0 when pe	ower on.		≣\ 16:49	1:54
OFFSET	unon un th	OFFSET	R-DFLT	100	PREV.	NEXT

The local variable page is shown below:

EDIT	S0000	T0000
NOTE LIST	00000 NO	000
NOTE FILE NAME REMAR	K	SELECT
》00009.EXT 注释式	[件例子	
		RENAME
		1
		REMARK
		×
		DELETE
		DELETE
		11
		Zistani)
FILE SIZE: 308 B		21
MODIFIED TIME: 2015-11	-16,11:51:42	5
	≅\ 16:54:	17 BACK
ANTERN MACRO VAR.	SET USER-DFLT MACRO VAR	

The system variable page is shown below:

NO.	VARIABLE NOTE	DATA	NO.	VARIABLE NOTE	DATA	Ц
500	注释1		701	注释12		
501	注释2	-	699	注释13		
502	注释3					
503	注释4					
504	注释5					
505	注释6					
506	注释7					
507	注释8					
508	注释9					1
509	往释10					
700	注释11					
00 ¥:	细注释1					

Note: The local variable and the system local are specified by macro codes instead of directly set by the keyboard in the page.

3) Workpiec coordinate system setting

FSET -> WORKF	IECE COORDINATE :	SYSTEM	COORDINATES	Bitter
EXT OFFSET	654 COORD. X 0.0000	G55 COORD. X 0.0000	2 [ABSOLUTE] X 0.0000	INF + INF CLE/
2 0.0000	Z 0.0000	Z 0.0000	Z -0.0001	ALI INPL MACI COOP
656 COORD.	657 COORD.	658 COORD.	[MACHINE]	
0.0000	X 0.0000	X 0.0000	X 0.0000	
0.0000	Z 0.0000	Z 0.0000	Z -0.0001	
	-		≝ 16:58:2·	4

#### 4) Tool life management

	L LEE MANAGEMEN				00000 100000	
URRENT	TOOL STATE:				00000 00000	AE
TOOL	NO. GROUP NO.	LIFE	USED	LIFE UNIT	STATE	DE GRO
ROUP DE	FINED:					AC
01 00						
NO.	TOOL&OFFSET	LIFE	USED	LIFE UNIT	STATE	ro
01	0101	4000	0:00	MINUTE	USABLE	-
02	0202	500	0	COUNT	USABLE	CW
03	0303	500	0	COUNT	USABLE	
04	0404	1000	0:00	MINUTE	USABLE	CO CI
				-		SK
						≽
			_		The second second	MOR

# 1.3.4 ALARM Interface

1) Alarm:



pressing repetitively , or the corresponding soft function.

#### 1) Alarm information page

ME	וכ	(1/2)	imain :	station	's comm	unic	ation re	ture		<b>S0000</b>	TØ	000
AL ARM	$\rightarrow$ INF	ORMATION							0	0000 N	0000	12
CNC .	ALM: 2.	CNC W	ARN: NO	. PLC	ALM: N	0. 1	PLC WARN:	NO.	ERVO	ALARM:	NO.	SWITC
ALM.	TYPE	ALM NO.					NOTE					
© CNC	ALM	6606	The bu CPØ st	s main age	statio	n's	communic	ation	retu	irns to		-
CNC	ALM	6611	MST da	ta los	5							
6611	Alarm r Trouble contact	easons:A shootins 2.chec	onormal :1.check k if the	bus com if the	municati connect	ion c ion	auses MST cable is around th	data OFF o le dev	loss r loo ice o	se r the	( ) ( )	
			-						į.	17:15	:00	
ALM.	in 1	ALM.	OPRAT	E			1					

Note: Alarm clearing: It can clear alarms by pressing

2) Alarm log page



# 1.3.5 Setting Interface



#### 1) CNC setting page

MDI	S0000 T000
WITCH SETTING	LEVEL SETTING
PARAMETER SWT.: 네 DN PROGRAM SWT.: 네 DN AUTO SEGMENT : & DFF	CURRENT LEVEL: 3 DEGRADE D INPUT PASSWORD: ALTER PASSWORD:
ARAMETER OPERATION	
CBACKUP PAR. (USER)	0
RESUME DEFAULT PAR.1(SERVO 1)	LEVEL)
TRESUME DEFAULT PAR.3(SERVO 0.	TP LEVEL)
MODIFY PARAMETER AND EDIT PROGRAM	₩ 08:40:33 0
CNC CLOCK DOC K FU	NC.

2) System clock page



3) Document management page



4) Machine function debugging page



5) GSKLink setting page

MDI							SNNNN IN	NNN
GSKL 1NK	CONNECTION S	ETTING					00000 N0000	14
NO.	DRIVER TYP	E A	DAPTIVE MOT	OR	AXIS	PR	OMPT	SETTIN
1	GS2025L	11	OSJT-MO40D(	(441)	X	Fee	d axis	NING
2	GS2025L	11	OSJT-MO40D(	(A41)	Z	Fee	d axis	SETTIN
Servo dr	ive l's corres 1 set servo dr	ponding a	uxis correspondin	g axis;	[Ghost s	etting]	automatically	
[Setting allocate	all servo dri	vers						
[Setting allocate	all servo dri	vers	_		-	_	* 08:55:05	

#### 6) IP page setting

		000000 110000
1P		00000 0000
10 1000000	100 2 100	
IP ADDRESS	197 . 108 . 7 . 135	
SUBNET MASK	255 . 255 . 0 . 0	
	192 168 11 254	
MILLI WATCHAT	102 1 100 1 11 1 204	
MAC ADDRESS	882288855888	
_	A COLUMN TWO IS NOT	÷ ≥ 08:42:00
		- 00.42.00

# 1.3.6 Parameter Interfaces



keys.

#### 1) Bit parameter page

MDI					<b>S0000</b>	T0000
PARAME LE	R -> BIT PARAM	ETER			00080 N0	1 DDA 000
NO.	DATA	NO.	DATA	NO.	DATA	
0001	0011010	0013	00000000	0184	00000001	SET
0002	00000011	0014	00011111	0185	00000000	PARM
0003	10010000	0017	00001000	0186	00000000	TO: MARS
0004	01000000	0018	00000000	0187 X	00000000	
0005	00010010	0020	00000000	2	00000000	
0006	00000000	0172	01101000	Y	00000010	
0007	10000000	0174	00001000	B	00000010	
0008	00011111	0175	00000000	C	01000010	811
0009	00000000	0180	00000000	0188 X	00000101	MODIF
0010	00011111	0181	11100000	Z	00000101	<b>1</b>
0011	00000000	0182	00000000	Y	01000101	FINDO
0012	10101011	0183	00000000	B	01000101	
0001 EIT7 Res	*** *** ACS HW served	L XRC ISC 1	NI		-	]_
	-				₿ 09:16:	:35
BIT PARM	DATA PARM	CLASS PARM	COMP	VQ M	PREV	PAGE

2) Data parameter page

MDI					50000 T	0000
PARAMETER	-> DATA PARAM	IE TER			00000 N000	0 ADD TO
NO.	DATA	NO.	DATA	NO.	DATA	A OFTEN
0015 X	1	0021 S2	0	0024	100	SET
man Z	1	\$3	0	0025	0	PARM
Y	1	0022 X	4000	0026	100	THE MUSIC
8	1	Z	8000	0027	8000	5
C	1	Y	8000	0028	200	
0016 X	1	B	8000	0029	100	
Z	1	C	180000	0030	200	
Y	1	0023 X	100	0031	1260	1
B	1	Z	100	0032 X	200	1 mm
C	1	Y	100	Z	400	<b>1</b>
0019	5	B	100	Y	400	F IND (P
0021 S1	0	C	100	B	400	~
C 0019 0021 S1 0015 Comma	1 5 0 and multiplier	Y B C for each axi	100 100 100	Z Y B	400 400 400	
	-				8 09:16:40	0
BIT PARM	DATA PARM		TCH SERVI	0	PREV PAGE	PAGE

#### 3) Common used parameter page

MDI			<b>S0000</b>	10000		
PARAMETER	-> CLASSFICA	TION PARAM	TER [AXIS SET	FING]	00000 N00	00 AXIS
NO.	DATA	NO.	DATA	NO.	DATA	SETTIN
0008	00011111	0188 B	01000101	0022 X	4000	COTAIN
0009	00000000	C	01000101	Z	8000	SETTIN
0013	00000000	0015 X	1	Y	8000	MACHIN
0175	00000000	Z	1	B	8000	ZERO
0187 X	00000000	Y	1	C	180000	RETOR
Z	00000000	B	1	0023 X	100	GSKL IN
¥	00000010	C	1	Z	100	SETTIN
B	00000010	0016 X	1	Y	100	THREAT
C	01000010	Z	1	B	100	CUTTIN
0188 X	00000101	Y	1	C	100	BKLAS
Z	00000101	B	1	0027	8000	COMP.
Y	01000101	Č	1	0029	100	PHO
0008 ETT BIT7 Rese	red	IR4 DIRY DIR	Z DIRX			ERROF COMP.
-	-				₿ 09:16:	47 MORE
BIT PARM	DATA PARM	CLASS #	PITCH SERV	0	PREV	NEXT

#### 4) Pitch compensation parameter page

PARAMETER -	> SCREW-PITCH C	OMPENSATION		COORDINATES	
XIS X		AXIS Z			
NO.	VALUE A	NO.	VALUE 🗠	Lipcoli	-
0000	0	0200	0	LADSOLU	NE1
0001	0	0201	0		-
0002	0	0202	0	X E	1.0000
0003	0	0203	0		-
0004	0	0204	0	Z	.0000
0005	0	0205	0		
0006	0	0206	0		15
0007	0	0207	0		
0008	0	0208	0	LMACHIT	(C)
0009	0	0209	0		20000
0010	0	0210	0	x	.0000
0011	0	0211	0		
0012	0	0212	0	Z E	.0000
0013	0 -	0213	0 -		
-	-		The Owner Designation		09:16:53

Note: When the system axis number is more than 2, pitch compensation parameter page will not display the "Coordinate information" window.

5) Servo parameter interface

SERVO PA	ARM		00000 N0000	SERVO STATU	S	DEL T
AXIS	1	Z AXIS		X AX	1S	VALU
NO. 0000	PARM VALUE	NO. 0000	PARM VALUE	ENABL ING	ENABLE	
0001	122	0001	122	CPO	0	SA
0002	0	0002	0	POS	0 00	BACKU
0003	0	0003	0	SPU	0.0010m	FARM
0004	21	0004	21	CURRENT	0.04	RECOVE
0005	0	0005	0	Z AX	(15	PARM
0006	2	0006	2	ENABLING	ENABLE	5
0007	2	0007	2	CPO	0	FINDO
0008	0	0008	0	POS	0	SELEC
0009	0.	0009	0	SPO	0.00rpm	MOTOR
0010	0 -	0010	0 -	CURRENT	0.0A	
0000 Pa de	rameter password mo fault parameter)	dificati	on(315:user parame	ter 385:debug	the motor's	-

# 1.3.7 Diagnosis Interface



#### 1) System diagnosis page

MDI					<b>S0000</b>	T0000
DIAGNOST	S -> CNC DATA S	ATE			00000 N0	000
NO.	DATA	NO.	DATA	NO.	DATA	
0000	0000000	0012	0	0024	00000000	ENCODED
0001	00000000	0013	Ø	0025	00000000	TEST
0002	00000000	0014	0	0026	00000000	
0003	00000000	0015	0	0027	00000000	
0004	00000011	0016	00000000	0028	00000000	
0005	00000000	0017	00000000	0029	00000000	
0006	00000000	0018	00000000	0030	00000000	_
0007	00000000	0019	00000000	0031	00000000	
0008	00000000	0020	00000000	0032	00000000	
0009	00000000	0021	00000011	0033	00000000	
0010	0	0022	00000000	0034	00000000	FIND(P)
0011	0	0023	00000000	0035	00000000	
0000 ESP BIT7 ESP	* signal (machine-	4 DECY DEC >PLC)	z decx			
	-				÷ 09:29:	.47
DGN	VERSION D	ACHINE 2	SERVO GSKLINH DGN DGN	{	PREV	PAGE

The page is used to detect CNC interface signal and its inner run state.

#### 2) System information page

YSTEM INFOR	MATION	LADDER INFORMAT	LON
RODUCT :	GSK980TD i	LADDER FILE :	STDPLC_EN.1d2
VER. :	¥6.03	LADDER DESIGN:	GSK, CHINA
VER. :	¥4.01.004	LADDER VER. :	V150430
DOT VER.:	¥4.2c	VERIFY CODE :	CBC1
YSTEM ID:	00000	CREATED DATE :	2015-11-16,01:18:37
LC VER. :	PLC-N3	LAST DATE :	2015-11-16,11:51:40
ADDER STATE		NOTE:	
C STATE:	RUN	GSK9801Di Seri	es Standard Ladder
IR CYCLE:	16		
IN.CYCLE:	16		
	16		



#### 3) Machine diagnosis page



4) Servo diagnosis page

MDI					SØ	000 T00	000
SERVO DGN					0008	0 N0000	
AXIS NAME	X AXIS	-	ALRS	ZSL	OSTA	GAIN	X AXIS
ENABLING	ENABLE		0	0	0	0	-
CONNECTION	CONNECTION		SRV	SFR	BREF	HTL	Z AXIS
MODE	POSITION	IN	0	0	0	0	
CPO	Ø					1	
POS	1			_	_	_	-
EPO	Ø					-	
SPD	0.00rpm		-			-	
CS	0.00rpm		ALM	ZSP	COIN	TAR	-
ABS	25474		0	1	0	1	SWITCH
HBS	1727	OUT	SAR	PAR	GAOT		
ENCODER	226386819	- 000	0	1	0		
CURRENT	0.0A						
TEP	39°C		-				
SERVO AXIS NAME		-		_	# 0	9:31:03	
COGN ST		SERVO DGN	GSKLINK DGN				

# 1.3.8 Graph Interface



to enter GRAPH interface.Graph page is shown below:

EDIT	S0000 T0000
TRACK DISPLAY	00000 N0000
00000(0.001MM/DA98/DA98A/步进)	ABSOLUTE (S)
G98 G00 X100, Z200,	X 0.0000 🥪
	CLEAR
	5
	200M+
	-6
	2004
	6
	(1)
	1
	CHANGE
	MOVEDIS
	GRAGH
And the second s	# 10:00:37 FEATURE
TRACK	
DISPLAY	

# 1.3.9 Ladder Interface Press to enter LADDER interface including pages STATE BATA ENDITOR ELIST which can be switched by pressing repetitively for corresponding soft keys.

#### 1) PLC I/O state page

LADDER	-> 1/0 STATE -	> X.Y.F			00000 N000	10 VVE
SIGNA	L	Y SIGNA	L	F SIGNAL		Actor
0	0000000	<u> </u>	00000000	~ 0	01000000	-
1	00000000	1	00000000	1	10000000	G.R.A
2	00000000	2	00000100	2	00000000	
3	00000000	3	00000000	3	01000000	C.T
4	00000000	4	00000000	4	00000000	
5	00000000	5	00000000	5	00000000	
6	00000000	6	00000000	6	00000000	
7	00000000	7	0000000	7	00000000	
8	00000000	8	00000000	8	00000000	
9	00000000	9	00000000	9	00000000	
10	00000000	10	00000000	10	00000000	FIND(P)
11	00000000	- 11	00000000	- 11	00000000	-
X0000 B1T0	T05 PRES ESP DIT Protection gate	W DECX DIOP switch	**** SACT			
					# 10:06:1	6

The page can display PLC I/O state information.

#### 2) PLC data page

ADDER $\rightarrow$	PLC DATA -> 1	( SETTING			00080 N0	000 K
NO.	DATA	NO.	DATA	NO.	DATA	SETT
K0000	0000000	K0012	00000000	K0024	00000000	n
K0001	00000000	K0013	00000000	K0025	00000000	SETT
K0002	00000011	K0014	00000000	K0026	00000000	
K0003	00000000	K0015	00001000	K0027	00000000	SETT
K0004	00000000	K0016	00000000	K0028	00000000	
K0005	00000000	K0017	00000000	K0029	00000000	DC
K0006	00000000	K0018	00000000	K0030	00000000	SETT
K0007	00000000	K0019	00000000	K0031	00000000	BI
K0008	00000000	K0020	00000000	K0032	00000000	MODI
K0009	00000000	K0021	00000000	K0033	00000000	33 EI
K0010	00000000	K0022	00000000	K0034	00000000	ADDRE
K0011	00110000	K0023	00000000	K0035	00000000	
0000 117						_
-	-	-	-	-	# 10:06:	23

PLC data includes K, D, DT, DC, which can be set in the page.

#### 3) Ladder monitor page

EDIT	S0000 T0000
LADDER -> MONITOR [WIN1 - Level1]	00690 N9000 FIND
NETHORI External exergency stop signal	03.4 (m)
KIO.5 METHORIZ: 02.4 	A3.7 FINO
NETVORS Overtravel process	PI SELECT CALL BLOCK
NETVORIA VT_AK31 Tool post R188.6	P178
NETHONES LIG SHIVE labe turret control logic Turret class status nonvolatile R189.5	P199
kill.1 KII.8 K8.1 R8.8	- HOME
	P299 C 1241 → ₩ 10:06:28 END

WIN2

₩TN1

WIN2

The monitor page can view states of current contact, coil ON/OFF state, values of timer and counter. They are displayed with a green background when they are ON, otherwise, they are the X0.5 Y25.2 same those of the page background.  $\dashv$  means the contact X0.5 is ON,  $\dashv$   $\rightarrow$  means Y25.2 is OFF.

- 1. Page program view
- In MONITOR page, the system can monitor simultaneously three windows, the ladder blocks

WIN3 P0 corresponded to each window can be viewed by separately pressing Level1 Level2 at the moment, the ladder corresponded to the selected block is displayed on the screen.

- 2. Window block selection
- Level1 Level2 (1) Select the window which needs to select blocks, press respectively

₩IN3 P0

to select the windows.

SELECT BLOCK (2)Press to select the window program. At the moment, the display page is shown below:

MDI		<b>S0000</b>	T0000
LADDER ->	> MONITOR [WIN1 - Level1]	00000 N00	000 🗸
NETWORK1 External en X9.3	ergency stop signal		
SELECT BL	OCK TO WIN 1	(	
ADDRESS	SYMBOL		CANCEL
Level1	Level1	Ą3.7	
Level2	Level2	( )	
PØ	JogMoving		
P1	Overtravel	CALL	-
P2	SafetyDoor		
P3	Gear_toolNumberDisplay	P170	
P4	SafetyDoorLock	CALL	3
P5	MPGtrialcut		
P10	lailstockControl	P190	
P12	ChuckControl	CALL	2   <u> </u>
P20	PressureControl		
P32			
P100	PanetkeyInput	P200	
F122	opmureoan v	CALL	귀드
		. 11:20:	<u>17                                     </u>
I/0 STATE	DATA MONITOR CLIST		

- (3) Move the cursor to select the ladder block for display.
- (4)Press and then return the previous menu, press **CANCEL** to cancel the selection operation to return to the previous menu.
- 3. Find parameters, commands and network
- (1) Select the required block window for finding commands, parameters and network, make the corresponding block display in the window, and find the command, parameters and network in the window.
- FIND ADDR to find the corresponding parameter, functional OMMAN (2) Respectively press command and network in the current displayed block, and move the cursor to the corresponding position.
- to locate the cursor to the home or end of the current block. (3) Press HOME

#### 4) File list page

	N LOGAL DIDERTO	N/ 00000 N0000	
ADDER -> FILE LIST	-> LUCAL DIRECTU	(Y 00000 N0000	
NAME	LADDER VERSION	NOTES	
980TD1系列瑞远机的	V151023	GSK980TDi系列瑞远梯形图	
10_TEST_PLC.1d2	V150331	GSK980TDi系列10测试梯形图	
STOPLC.LD2	¥150430	GSK980TDi系列标准梯形图	
STDPLC_EN.1d2	V150430	GSK980TDi Series Standard Ladder	
STDPLC_IOUNIT.1d2	V150429	GSK980TDi系列标准梯形图(配10单元)	
STDPLC IOUNIT EN.	¥150429	GSK980TDi Series Standard Ladder()	
			×
VERIFY CODE: A MODIFIED TIME: 2	E6E 015-11-16,11:51:3	FILE SIZE: 82.3 K	<u>P1.0</u>
			and a second sec

The ladder file list page displays all ladders and their relevant information included in the current system, and the new ladder can run in the page. The program name marked with  $\square$  is the current running ladder.

Note: The file list page is displayed when the above 2-level privilege is executed.



# CHAPTER 2 POWER ON/OFF AND PROTECTION

#### 2.1 System Power-on

Before GSK980TDi power on, the following items should be confirmed:

- 1. The machine is in a normal state.
- 2. The power voltage conforms to the requirement of the machine.
- 3. The connection is correct and secure.

The following window is displayed after GSK980TDi is turned on:



The current position (ABSOLUTE POS) page is displayed after GSK980TDi automatic detection and initiation are finished.



# 2.2 System Power-off

Before power is off, ensure that:

- 1. The feed axes of the CNC is at stop;
- 2. Miscellaneous functions (spindle, cooling etc.) are OFF;
- 3. Cut off CNC power prior to machine power cutting off.
- Note: Please refer to the machine manufacturer's manual about turn-off the machine's power supply.

# 2.3 Overtravel Protection

Overtravel protection should be used to prevent machine from being damaged due to the overtravel of X, Y, or Z.

# 2.3.1 Hardware Overtravel Protection

The stroke switches are fixed at the positive and negative maximum travel of the machine X, Z, Y axis respectively, they are connected by the following figure. Standard PLC program defines that the Bit7 of parameter K10 is whether the overtravel along each axis is enabled; Bit 6 is the overtravel signal LEVEL selection. If the overtravel occurs, the stroke switch acts to make GSK980TDi stop, and the emergency alarm issues.



When the hardware overtravel occurs, there will be an "overtravel stop" alarm in GSK980TDi. The steps to eliminate this alarm are: In the Manual or MPG mode, move the table reversely to detach the stroke switch (for positive overtravel, move negatively; vice versa).

2.3.2 Software Overtravel Protection

GSK980TDi sets the software overtravel protection of the machine tool by the stored stroke limit function. There are 3 stored stroke limit areas can be set in GSK980TDi. The oblique area is the forbidden one.



: the forbidden area

- 1) Open the limit function: Set the state parameter Bit 4 of No.172 to 0, and then open the limit detection function.
- Stored stroke limit detection 1: The limit area boundary is set by parameter (No.045, No.046), the external side of the setting range is limit area. Usually, this area is regarded as the Max. stroke range of the machine tool.
- 3) Stored stroke limit detection 2 (G22 G23): The limit area boundary is set by parameter

(No.100, No.101) or G22; the inner prohibition/outer forhibition of the setting range are set by Bit 2 of parameter No.172. This limit is enabled when the G22 is at the current modal, and the limit is disabled when the modal is G23. Refer to the program help G22/G23 command.

- 4) Stored stroke limit detection 3: The limit area boundary is set by parameter (No.102, No.103); the inner side of the setting range is limit area.
- 5) Whether the axis is performed the limit inspection: Bit 2 of parameter No.190 and Bit 3 of parameter No.190 can be set an axis whether it performs the stored stroke inspection 2 or 3. The stored stroke inspectin 2 or 3 is only judged the axis from the inspection. For example: When X or Z axis performs the judgement, and the Y axis does not, only detect whether the X or Z axis enters to the limit area.
- 6) Zero return enabled: When the state parameter Bit 1 of No. 172 sets to 1, it needs to return the reference position by manual or G28 after the power is turned on, the function is then enabled accordingly. After an axis is performed the zero return for the external limit area, and the limit area of this axis is immediately enabled; it is disabled of the axis that does not perform the zero return. For the inner limit area, the limit function is enabled after the overall axes executed the detection are performed the zero return.
- 7) Limit deceleration: State parameter Bit 0 of No.172 can be set a stop method when it reaches to the limit boundary. Deceleration stop near the forbidden area or immediately stop after entering to the forbidden area can be selected.
- Note 1 :If the positive stroke is less than or equals to the negative one in the setting forbidden area, the area is shown below:
  - 1) When the forbidden area is the stored stroke inspection 1 or the 2 from the external prohibition, the overall areas are treated as the forbidden area.

2) When the forbidden area is the stored stroke inspection 3 or the 2 from the internal prohibition, the overall areas are regarded as the moveable areas.

Note 2 : An alarm may occur if the reference position locates within the limit area when returning the reference position.

# 2.4 Emergency Operation

During the machining, some unexpected incidents may occur because of the user programming, operation and product fault etc. So the GSK980TDi should be stopped immediately for these incidents. This section mainly describes the resolutions that the system is capable of under the emergency situation. Please see the relative explanation on these resolutions under the emergency by machine manufacturer.

#### 2.4.1 Reset

Press key to reset GSK980TDi system when there are abnormal output and axis operations:

- 1 All axes motion stops;
- 2 M, S function output is inactive (the parameter sets whether the system automatically cuts off

signals of spindle rotation, lubricating, cooling by pressing 💋 key, defined by PLC ladder);

3 Automatic run ends, modal function and state remain.
## 2.4.2 ESP

During machine running, if the ESP button is pressed under the dangerous or emergent situation (external SP signal active), the CNC system enters into emergency status and the machine movement is stopped immediately. All the outputs such as the spindle running, cooling are cut off. If the emergency button is released, the emergency alarm is cancelled and the CNC resets.

- Note 1: The ESP alarm generates during the operation of the machine tool, Re-perform the machine zero return to get the correct position coordinate after the emergency alarm is cancelled (machine zero return is forbidden if there is no machine zero on the machine.).
- Note 2: Only Bit3 of the bit parameter No.172 is set to 0, is the external emergency stop active.

# 2.4.3 Feed Hold

Press key during the machine running to make the running pause. However, in threading cutting, tapping cycle state, the function cannot stop the running immediately.

#### 2.4.4 Power-Off

Under the dangerous or emergency situations during the machine running, the machine power should be cut off immediately to avoid the accidents. But it should be noted that there may be a large error between the CNC coordinates displayed and the actual position. So the tool-setting operation should be performed again.

# CHAPTER 3 MANUAL OPERATION

**Note!** The key functions of this GSK980TDi machine panel are defined by PLC program (ladders), please refer to the manual from the machine builder for their function significance.

Please note that the following functions for the machine panel keys are described based on the GSK980TDi standard PLC programs!

Press key, it enters Manual mode. In the mode, the system can perform the manual feed, spindle control, override adjustment, tool change etc..

## 3.1 Coordinate Axis Move

In Manual mode, 2 coordinate axes can perform manual feeding and rapid traverse.

## 3.1.1 Manual Feed



In Manual mode, press key to make the indicator enter the manual rapid traverse mode.

### 3.1.2 Manual Rapid Traverse



E)

and Z

feeds negatively or positively, and its feeding stops if the key is released; press

axis feeds negatively or positively, and its feeding stops if the key is released; press

and Y feeds negatively or positively, and its feeding stops if the key is released; press

and the 4<sup>th</sup> axis feeds negatively or positively, and its feeding stops if the key is released;

press or and the 5th axis feeds negatively or positively, and its feeding stops if the key is released. The rapid override time-tuning is enabled.

In Manual mode, press key to make the indicator OFF, and the rapid traverse is disabled and manual feed is executed.

Note 1: If no reference point return is performed after power on, as the rapid traverse switch is turned on (rapid indicator ON), the manual feedrate or rapid rate for the traverse is defined by the Bit0 of the bit parameter No.012 of this GSK980TDi system.

Note 2: In Edit/MPG mode, key is inactive.

## 3.1.3 Speed Regulation

Feedrate override (%)	Feedrate (mm/min)
0	0
10	126
20	252
30	378
40	504
50	630
60	756
70	882
80	1008
90	1134
100	1260
110	1386
120	1512
130	1638
140	1764
150	1890

#### Note : There is about 2% error for the data in the above table.

ЛX1 ЛX10 ЛX100 ЛX1000

In the manual rapid traverse, it can press MFD M25% M50% M100% key to alter the rapid override,

and there are 4 steps of F0, 25%, 50%,100% for the override.(F0 is set by data parameter No.032) The rapid override is active under the following conditions:

- (1) G00 rapid traverse
- (2) Rapid traverse in canned cycle
- (3) Rapid traverse in G28
- (4) Manual rapid traverse

## 3.2 Other Manual Operations

#### 3.2.1 Spindle CCW, CW, Stop Control

In Manual mode, the spindle rotates counterclockwise if pressing this key;



. In Manual mode, the spindle stops if pressing this key;

: In Manual mode, the spindle rotates clockwise if pressing this key.

#### 3.2.2 Spindle JOG



Example: At the moment, the spindle is in JOG state. Functional description:

Press to enter JOG mode, and the spindle JOG function ON/OFF is executed only when the spindle is in the state of stop.

In spindle JOG mode, by pressing key, the spindle rotates counterclockwise for jogging;

by pressing key, the spindle rotates clockwise for jogging. The jog time and speed are set by data parameter No.108 and No.109 respectively.

When the spindle JOG rotates,  $\Box$  is pressed to stop the spindle JOG rotation, the spindle brake signal is not output when the JOG rotation stops.

K10.4 is set to 1, the spindle JOG is valid in any mode. In Auto or MDI mode, the spindle is in the JOG rotation state, the program closes the spindle JOG rotation and the JOG function.

#### Parameter setting:

PLC parameter K104 1/0: the spindle JOG is valid in any mode/Manual, MPG, Zero return mode. Data parameter No.108: spindle JOG time

Data parameter No.109: rotary speed in spindle JOG.

#### 3.2.3 Cooling Control

In Manual mode, press this key, the cooling is switched on/off.

Parameter setting: PLC parameter K10.1 1/0: the spindle lubricating and cooling output remains/closes in reset.

## 3.2.4 Lubricating Control

#### **Function description:**

1. Non-automatic lubricating (DT017 =0)

When PLC DT013=0, it is the lubricating turn output. Pressing the can execute the output. And the lubricating is cancelled by pressing it again. M32 is to execute lubricating output, and M33 is to cancel lubricating output.

When PLC DT013 >1, it is timing lubricating output. Pressing the second can execute the output. And it is cancelled after a setting time by data parameter DT013; M32 is to execute lubricating output and the output is cancelled after a time set by DT013. If the setting time is not yet up, M33 is executed to cancel the lubricating output.

2. Automatic lubricating (DT017>0)

For automatic lubricating, the system executes the lubricating in the time set by DT017 and the stops the output. After lubricating interval time set by DT016, the output is done again, it does

repetitively like this. During the automatic lubricating, M32, M33 codes as well as the key are all active.

#### Parameter setting:

PLC parameter: K10.1 1/0: the spindle lubricating/cooling output remains/closes in reset;

PLC parameter:K16.2 1/0: whether the lubricating outputs in power-on when the automatic lubricating is valid;

PLC data DT005: M execution duration(ms);

PLC data DT013: lubricating start time (0-60000ms)(0:lubricating time is not limited);

PLC data: DT016 automatic lubricating interval time (ms);

PLC data: DT017: automatic lubricating output time (ms).

# 3.2.5 Chuck Control

. press it to switch the chuck releasing/clamping in any mode.

#### Function description:

When the chuck control is invalid, the system alarms in executing the chuck control M command; When the system checks the chuck clamping (K12.1=1), the spindle cannot be started when the chuck is not clamped, and the chuck cannot be released after the spindle is started;

When using the input signal controls the chuck operation, the spindle should stop and delay the time set by DT21, the control is valid.

#### Parameter setting:

PLC parameter: K12.0 1/0: chuck control valid/invalid;

PLC parameter: K12.1 1/0: do not check/check the chuck clamping before the spindle start;

PLC parameter: K12.2 1/0: chuck outer/inner control mode;

PLC parameter: K12.3 1/0: check/not chuck in-position signal;

PLC data: DT018: chuck pulse output width(ms);

PLC data: DT021: spindle stops, chuck operation enabling delays(ms).

# 3.2.6 Tailstock Control



In any mode, press it to switch the tailstock forward/backward.

#### **Function description:**

When the tailstock control is invalid, the tailstock control M command alarms;

When the tailstock and the spindle control is interlocked, before the spindle is started, the system check whether the tailstock forward is valid. After the spindle is started, the tailstock backward cannot be executed.

#### Parameter setting:

PLC parameter: K13.0 1/0: tailstock control valid/invalid

PLC parameter: K13.1 1/0: the spindle rotation and the tailstock forward/backward are/not interlocked

PLC parameter K13.2: 1/0: External tailstock control is enabled/disabled when the program is being operated.

## 3.2.7 Hydraulic Control

Function description:

When the hydraulic control function is valid, is pressed to control HPST output to start the hydraulic motor.

When the system is in non-run, the spindle stops and the speed is zero, **when** is pressed to close HPST output.

Parameter setting:

PLC parameter: K14.7 1/0: hydraulic control function valid/invalid

# 3.2.8 Manual Tool Change

In Manual mode, pressing the key can manually change tools in sequence (if current tool is No.1, it is changed for No.2 tool by pressing it; if current tool is No.4, it is changed for No.1 tool by pressing it.

## 3.2.9 Spindle Override

In Manual mode, if the spindle speed is controlled by analog voltage output, the spindle speed may be overrided.

Pressing  $\frac{10\%}{1000000}$ ,  $\frac{10\%}{10000000}$  can change the spindle speed in real-time to adjust 8 steps of 50% ~120

 $\%\;$  of the spindle override.



# CHAPTER 4 MPG/STEP OPERATION

In MPG/Step mode, the machine moves by a specified increment.

#### Note!

The key functions of this GSK980TDi machine panel are defined by PLC program (ladders), please refer to the manuals by the machine builder for their significance.

Please note that the following description for the key functions in this chapter is based on the GSK980TDi standard PLC program!

# 4.1 Step Feed

Set the system parameter No.001 Bit3 to 0, and press key to enter the STEP working mode, it displays as follows:



## 4.1.1 Increment Selection

Press  $\frac{11}{1000}$   $\frac{11}{1000}$   $\frac{11}{1000}$   $\frac{11}{1000}$  to select the move increment, the increment will be shown in the page. When the BIT7(SINC) of K016 is 1,  $\frac{11}{1000}$  step width value is inactive; when the BIT7 is 0,  $\frac{11}{1000}$   $\frac{11}{1000}$  are all active. For example, to press  $\frac{11}{1000}$  key, the window is shown as follows:



# 4.1.2 Moving Direction Selection



## 4.2 MPG Feed

Set the BIT3 of the system parameter No.001 to 1, and press key to enter the MPG mode, it displays as follows:



The MPG figure is shown as follows:



The handwheel (MPG) figure

#### 4.2.1 Increment Selection

	no rx1000 30 00100% key to select the mo	ove increment, the ir	ncrement will be shown in the
window. When the BIT	7(SINC) of PLC K016 is all active. For example.	to press	inactive; when BIT7 is 0,
follows:	• •	·	
	HND	50000 T00	308
	00001 N 0000	001 00000 MODAL INFORMATION 600 697 698 621 640 623 667 654 664 618 615 613.1 800 80000 10	PART CLR. TIME CLR.
	X 0.0000	F B. 8000 mm/min 200 mm/min MAIN INFORMATION JOC.F 1260	TOOL SAFETY SETTING
	Z 0.0000	HNDL INC         0.0108           RAP OVR1         100%           SP1 OVR1         100%           PART CNT         0           CIT THE         00-00-00	
	LABS L.POSAPRE L.REL L.ALL IN	INANDLE ITERRUPT	

## 4.2.2 Moving Axis & Direction Selection



The MPG feed direction is defined by its rotation direction. Generally, the MPG CW is for positive feed, and CCW for negative feed. In case of that MPG CW is for negative feed, CCW for positive feed, it may exchange the A, B signals of the MPG terminals. Bit0 $\sim$ Bit4 of NO. 013 selects the feed direction of MPG rotation.

L. ALL

L. POS&PRG L. REL

ABS

HANDLE

PART CNT

CUT TIME

0

00:00:00

II Operation

## 4.2.3 MPG Feedrate

The upper limit of the MPG feedrate is the rapid traverse rate of each axis, which can be set by data parameter No. 022.

When the state parameter No.013.6 = 0, and the MPG feedrate exceeds the rapid traverse rate, the exceeded pulse is ignored; the MPG scale is inconsistent with movement amount.

When the state parameter No.013.6 = 1, and the MPG feedrate exceeds the rapid traverse rate, the exceeded pulse does not ignore; the MPG scale is consistent with movement amount, but the axis may consecutively move when MPG stops.

## 4.2.4 Other Operations

#### 1) Spindle CCW, CW, stop control



In Manual mode, the spindle rotates counterclockwise if pressing this key;



110

: In Manual mode, the spindle stops if pressing this key;

2) Spindle JOG

: at the moment, the spindle is in JOG working mode.



#### 3) Cooling control

Refer to OPERATION, Section 3.2.3

#### 4) Lubricating control

Refer to OPERATION, Section 3.2.4

#### 5) Chuck control

Refer to OPERATION, Section 3.2.5

#### 6) Tailstock control

Refer to OPERATION, Section 3.2.6

#### 7) Hydraulic control

Refer to II OPERATION, Section 3.2.7

#### 8) Manual tool change



In MPG/Step mode, press it to change tools orderly.

#### 9) Spindle override tune

In MPG/Step mode, if the spindle speed is controlled by analog voltage output, the spindle speed may be overrided.

 $\frac{1}{1000000}$  can change the spindle speed in real-time to adjust 8 steps of 50%  $\sim$  120

% of the spindle override

Pressing som

# 4.2.5 Explanation Items

The correspondence of the handwheel scale to the machine moving amount is as follows table:

	Moving amount of each MPG scale			
MPG increment	0.001	0.01	0.1	1
Specified coordinate value	0.001mm	0.01mm	0.1mm	1mm

<sup>(</sup>Taking example of the least input increment 0.001mm)

Note 2: The MPG speed cannot be more than 5r/s, otherwise, the scale value is inconsistent with the movement amount.

Note 1: The MPG increment is related to the system's current metric/inch input state and the system's least input increment.



## CHAPTER 5 MDI OPERATION

In MDI mode, the operations of parameter setting, code words input and execution can be performed.

#### Note!

The key functions of this GSK980TDi machine panel are defined by PLC program (ladders), please refer to the manuals by the machine builder for their significance.

Please note that the following description for the key functions in this chapter is based on the GSK980TDi standard PLC program!

# 5.1 Block Input

Select MDI mode to enter PROGRAM->MDI page, to input an block G50 X50 Z100, the steps are shown below:

- 1) Press key to enter MDI mode;
- 2) Press , and then press PROG
  - to enter MDI program page below:

OGRAM -> MD1 PRO	GRAM	00001 N0000	MODAL INFORMATION	9
[ABSOLUTE] X 0.0000	[MACHINE] U 0.0000	SRPM: 0000 SSPM: 0000 SMAX: 9999	600 697 698 621 640 623 667 654 664 618 615 613.1 800 80000 10	
Z 0.0000	Z 0.0000	SMIN: 0000	F U. UUUU mm/min 200 mm/min MAIN INFORMATION	11
1 1			JOG.F 1260	122
			FED OVRI 100%	5
			RAP OVRI 100%	1
			SPI OVRI 100%	(cu
			PART CNT 0	1.0
			CUT TIME 00:00:00	MAR
			# 14:06:36	En

The page is shown as follows after above operations are completed:

OGRAM -> MDI PROC	RAM	00000 N0000	MODAL INFORMATION	1
[ABSOLUTE]           X         0.0000           Z         0.0000	[01ST TO GO] X 0.0000 # 0.0000	SRPM: 0000 SSPM: 0000 SMAX: 9999 SMIN: 0000	600 697 698 621 640 623 667 654 664 618 615 613.1 800 80000 L0 F D. DDDD mm/min 200 mm/min	
110100001			MAIN INFORMATION	E.
1 G50 Z100 X50	r	_	J0G.F 1260	
			FED OVRI 100%	5
			RAP OVRI 100%	
			SPI OVRI 100%	61
			PART CNT 0	
			CUT TIME 00:00:00	MA
			# 10-00-0F	E

Note: Up to 10-block programs can be input of the MDI program.

## 5.2 Block Execution

3 After the word is input, is pressed and the display is as follows: 50000 T0000 MDI G00 G97 G98 G21 [ABSOLUTE] [MACHINE] SRPM: G40 G23 G67 G54 0000 0.0000 G64 G18 G15 G13 1 0.0000 SSPM: aaaa 50000 L0 SMAX: 0000 mm/min 0.0000 0.0000 И SMIN: 000 200 mm/min MAIN INFORMATION 7100 X50 JOG.F 1260 FED OVRI 100% 10 RAP OVRI 100% SPI OVRI 180% C PART CNT 0 CUT TIME 00:00:00 14:08:42 CNC DIR. PROC P 3 TI NOLE STAR After the code words are input and THUT4 is pressed to display the block, key is pressed and Emergency Stop button may be to execute the input block. During the execution, pressed to terminate these code words execution.

## 5.3 Parameter Setting

In MDI mode, the parameter value can be altered after entering the parameter interface. The detailed is referred to **OPERATION, Chapter 11**.

### 5.4 Data Alteration



In the MDI mode, press the , then soft key, and then enter to the MDI program page.

ROGRAM -> MDI PROGRAM	00001 N0000	MODAL INFORM	ATION
[ABSOLUTE]         [MACHINE]           X         0.8000         11         0.0000           Z         0.0000         2         0.0000	SRPM: 0000 SSPM: 0000 SMAX: 9999 SMIN: 0000	C00 C97 C98 C40 C23 C67 C64 C18 C15 M00 S0000 L F 0. 0000 200	621 654 613.1 Ø mm/min mm/min
D1[010000]		MAIN INFORMA	TION
1 650 Z100 X50:		JOG.F	1260
3 10101;		FED OVRI	100%
4 G00 X50 Z0;		RAP OVRI	100%
5 M301		SP1 OVRI	100%
		PART CNT	0
		CUT TIME 0	0:00:00
	1 × 1	1 1	4:09:44

Soft button: Clear the overall contents of the MDI program input frame;

LABEL soft button: The movement cursor can be selected the block for the program after pressing this button, which uses matching with other function soft buttons;

copy soft button: Copy the block that locates at the cursor; it can be used matching with the

LABEL soft button;

PASTE: Paste the copied block to the next line of the cursor;

SEE.: Delete the block of which the cursor locates, which can be used matching with the soft button;

**~**)

soft button: Retract the previous edit operation of the MDI program, up to 10 times can be performed;

**REDD** soft button, Cancel the retract operation happed just last step;

soft button: Spring out the macro command list, insert the selected macro command at the cursor position;

## 5.5 Other Operations

1. Adjusting spindle override

In MDI mode, the spindle speed can be adjusted when the analog voltage output controls the spindle speed.



Pressing can adjust the spindle override to change the spindle speed, which can realize the 8 steps adjustment in real-time from  $50\% \sim 120\%$ .

2.Adjusting rapid override



**Λ** X100 **Λ** X1000 **M** 25% **M** 50% **M** 100% can execute the rapid traverse, which can realize the 4 steps Pressing <sup>1, X1</sup> adjustment in real-time.

3. Adjusting feedrate



can adjust the federate override to change the In MDI mode, pressing RONEFARDE, . OVERRIDE federate, which can realize 16 steps adjustment from  $0\sim$ 150%.

4. Feedrate override is available.

# CHAPTER 6 PROGRAM EDIT & MANAGEMENT

In Edit mode, a program can be created, selected, altered, copied and deleted, and the bidirectional communication of CNC to CNC, or CNC to PC can also be done.

To prevent the program to be altered or deleted accidentally, a program switch is set up for this GSK980TDi system. And it must be turned on before program editing. Please see details in Section 10.1.1 of the part.

The system provides multi-level user permission to facilitate the management. More than 4 levels (4 level, 3 level) can open the program switch to edit programs. See **OPERATION**, **Section 10.1.2**.

## 6.1 **Program Creation**

#### 6.1.1 Creating a Block Number

In the program, a block number can be added or not, the program is executed by the sequence. When the "AUTO SEG" switch in SWITCH SETTING window is OFF, CNC doesn't generate the block number automatically, but the blocks may be numbered manually.

When the "AUTO SEG" switch in SWITCH SETTING window is ON, CNC generates the block



number automatically, it automatically generates the next block number by pressing or in editing. The block number increment is set by the CNC data parameter No.042. (See details in **Section 10.1.1** of this part.)

				SOODO TOP	100
HITCH SETTING		LEVEL SETTING			~
PARAMETER SWT.: a PROGRAM SWT.: a AUTO SEGMENT : a	on on off	CURRENT LEVEL: INPUT PASSWORD: ALTER PASSWORD:	3	DEGRADE	COI SI SI
RAMETER OPERATION					A E
* RESUME PAR. (USER) * RESUME DEFAULT PAR.1(SE * RESUME DEFAULT PAR.3(SE	RVO 1 P RVO 0.1	LEVEL)			II II
IODIFY PARAMETER AND EDIT	PROGRAM		_	₩ 08:40:33	P
SETTING CLOCK	* FUN DEE	KC.	T IP		

### 6.1.2 Inputting a Program

Press to enter the Edit mode. Press to enter the Program interface, create a machining program before inputting a machining program. The creating method is shown below: Method 1:

1) Press address key , number key , number key , and , and , key by sequence (e.g. taking an example of creating program O0001, the leading 0 can be omitted when its name is input). Its display is shown below:

# **CNCmakers**



Method 2:

1) Pres

to enter the local directory page. The display is shown below:



ROGRAM -	> LOCAL	DIRECTORY		00002 N0000	0
TOTAL:	20	SPACE: 64.	0 M USED: 1.7 M	IDLE: 62.3 M	OPEN
NAME	SIZE	DATE	PROGRAM PREVIEW 00002	Ī	12 NEW
00000	919 B	2015-11-17	00002;		OPE
4 00002	52 B	2015-11-16	G94 U-35. W10. R5. F180.	a	
00003	40 B	2015-11-16	G00 U-1. W0.5;		DE
00004	130 B	2015-11-16	Maa:		UEL
00005	46 B	2015-11-16			
00006	63 B	2015-11-16			
00007	39 B	2015-11-16			100
00008	85 B	2015-11-16			F TANK (D)
00009	92 B	2015-11-16			FINDLE
00010	128 B	2015-11-16			DEMANE
00011	612 B	2015-11-16 -			TE REAL
00012	873 B	2015-11-16			
00018	246 B	2015-11-16			SAV
00021	524 B	2015-11-16			AS
EW 0 000	1				*
	-	-		# 15:20:43	MORE
PPDC		I ONC	TR. (5	PREV	NEXT

3) Press (or ) to create the new program. The current page is automatically switched into the program content page. Its display is shown below:

EDIT			S0000 1	0000		
PROGRAM 1	-> LOCAT	PROGRAM	3601] (	INSERI	00601 1000	00 HA SEARCH SEARCH LABEL CALCHL SEG. CALCHL
PROG CONTEN	101 101	CNC DIR.		CHECK	PREV PAGE	NEXT PAGE

Note: When a program is needed to create, the input program name exists, the system opens the file, otherwise, it automatically create a new one.

Input the edited part program one by one, the character will be displayed on the screen immediately as it is input(as for compound key, press this key repeatedly for alternate input),

after a block is finished, press or to terminate it.

Note: The unexpected power-off when the program is input, the program being edited cannot be saved.

#### 6.1.3 Searching a Character

#### 1. Scanning: To scan the character one by one by cursor

1) Press key to enter the Edit mode, then press key to enter the PRG CONTENT window;

2) Press key, the cursor shifts a row upward; if the number of the column where the cursor locates is over the total columns of the previous row, the cursor moves to the previous block

end (at ";" sign) after key is pressed;

3) Press key, the cursor shifts a row downward; if the number of the column where the

# **CNCmakers**

cursor locates is over the total columns of the next row, the cursor moves to the next block end (at ";"

sign) after the  $\checkmark$  key is pressed;

4) Press key, the cursor shifts a column to the right; if the cursor locates at the row end, it moves to the head of the next block;

5) Press key, the cursor shifts a column to the left; if the cursor locates at the row head, it moves to the end of the next block;

6) Press key to window upward, the cursor moves to the  $1^{st}$  row and  $1^{st}$  column of the previous window, if it windows to the head of the program, the cursor moves to the  $2^{nd}$  row and  $1^{st}$  column;

7) Press key to window downward, the cursor moves to the 1st row and 1st column of the next window, if it windows to the end of the program, the cursor moves to the last row and 1st column of the program;

# 2. Finding: To search for the specified character upward or downward from the cursor current location

The steps of finding is as follows:

1) Press to enter Edit mode, and press key to enter the PRG CONTENT window;

2) Press <u>SEARCH</u>, and input the required characters to be searched(can input one block). For example, finding "G00" page is shown below:

10000
00 74
SEAR
CANC
FI
E.
-
LAB
C C
E
74
122
<b>D</b>
SE
151
The second
CALC
*
45 MORE
NEXT

4) Press 4 key (4 or 4 is determined by the location of the character searched to the character where the cursor locates), it displays as follows:

	EDIT	S0000 T0000
	PROGRAM       >> LOCAL       PROGRAM       [00000]       INSERI         1       [00000(0,001HM/DA98/DA98A/±9:#);       2       650 X300. 7500.;         3       G98 G00 X100. 7200.;       4       690 U-10. #-200. F500.;         4       G90 U-10. #-200. F500.;       5       G90 U-10. #-200. F500.;         5       G90 U-10. #-200. F500.;       6       600 X90.;         7       G74 R0.5;       8       G74 X0. #-10. P3000 05000 R1.5 F300         9       B00 Z190.;       100.;       110. F250.;         10       G71 U2.5 R0.5;       11       G71 P10 050 U1. #1. F250.;         11       G71 P10 050 U1. #1. F250.;       13       N20 G3 X00. Z180. 10. K-10. F150.;         14       N30 G2 U5. Z155. R200. F200.;       15       N40 G01 X70. #-20. F50.;         15       N40 G01 X70. #-20. F50.;       18       N40 G401 X70. #-20. F50.;         16       N50 U20. Z130. F150.;       17       G70 P10 050:       18         18       G40 X32.;       SEARCH;       G40	COORDE NOODE SEARCH SEARCH FIND LABEL CLABEL
4)	After the finding, the CNC system is still in	FIND state, press or key again, the
ne	xt character can be found. Or press 🔤 k	ey to exit the FIND state.
5)	If the character is not found, the prompt of "S	Search fail" will be displayed.
Note :	During the searching, it doesn't search the char	acters in the called subprogram, and the character in
	subprogram is searched in subprogram.	
3.	Positioning the cursor to the specified I	ine
1)	Press to enter Edit mode, and press	to enter the PRG CONTENT page.
2)	Fress , and input the number (in	the line the display is shown below.
	For example, the cursor positions to the 10	Ine, the display is shown below:
	1       C00000(0,001HM/DA98/DA98/D498/D498/D498/D498/D498/D498/D498/D4	CHECK
3)	Press (or ), and the display pa	age is shown below:



#### 4. The method to return to the program head

1) In Program interface of the Edit mode, press key, the cursor returns to the program head;

2) Search the program head character by the methods in OPERATION, Section 6.1.3.

#### 6.1.4 Inserting a Character

Steps:

- 1) Press to enter PRG CONTENT page in Edit mode;
- 2) Press key to enter the INS mode (the cursor is an underline, and the "Insertion" shows at the title column), the window is as follows:



3) Input the character to be inserted (to insert G98 code before G50 in the above figure,



	IT	S0000 T0000
PROGR	AM -> LOCAL PROGRAM [00000] INSERT	00000 N0000 19
2	G98 G50 X300, Z500.;	A
3	G98 G00 X100. Z200.;	
4	G90 U-10. W-200, F500.;	1.0
5	G90 U-10, Z100, R-2.5 F350,;	RE
6	G00 X90.	
7	G74 R0.5;	ED ED
8	G74 X0. W-10. P3000 Q5000 R1.5 F300.;	NOTI
9	G00 Z190.;	- 18
10	G71 U2.5 R0.5;	
11	G71 P10 Q50 U1. W1. F250.	
12	N10 G00 U-50.;	COOR
13	N20 G3 X60, Z180, 10, K-10, F150,;	DISPL
14	N30 G2 U5. Z155. R200. F200.;	1000
15	N40 G01 X70. ₩-20. F50.;	INPUT
16	N50 U20. Z130. F150.:	bore
17	G70 P10 Q50;	
18	G00 X92.;	
19	₩-100.;	
20	G75 R0.5;	. ≈
	TARE USE ST. P. P. P. P. P. R. P. C.	# 15:45:37 MORE
PRO	NG CNC RA CHECK	

- Note 1: In the Insert mode, if the cursor is not located at the row head, a space will be automatically generated when inserting the code address; if the cursor is located at the row head, the space will not be generated, and it should be inserted manually.
- Note 2: In the Insert mode, if the previous bit before the cursor is a decimal point and the cursor is not located at the row end, input an address word, the "space" will be added automatically following the decimal point.
- 6.1.5 Deleting a Character

Steps:

- 1) Press to enter PRG CONTENT page in Edit mode;
- 2) Press key to delete the character before the cursor; press key to delete the character where the cursor locates.

#### 6.1.6 Altering a Character

There are 2 methods for the character alteration:

**Insertion:** First delete the character altered by the methods in Section 6.1.5, then insert the character required by the methods in Section 6.1.5 of this part.

#### Direct alteration:

- 1) Select the PRG CONTENT page in Edit mode;
- 2) Press key to enter the ALT state (the cursor is a backlight rectangle, and the "Modification" shows at the tile column), the display page is as follows:



3) Input the modified character(as the above figure, alter X300 to X250, input

2 5

		Ì	)
	P	Ĭ	
	ſ		

5)	input	the mouned	character (as	uie	above	ngure,	allei	×200	ιΟ	AZ50,	input

EC	IT	S0000 T0000
PROGR	AM -> LOCAL PROGRAM [00000] ALTER	00980 N8080 24
1	G50 X300, Z500.	IA SEAR
2	G98 G00 X100, Z200.;	
3	G90 U-10. ₩-200, F500.;	124
4	G90 U-10, Z100, R-2.5 F350.;	SEAF
5	G00 X90.;	
6	G74 R0.5;	
7	G74 X0. W-10. P3000 Q5000 R1.5 F300.;	LAE
8	G00 Z190.;	
9	G71 U2.5 R0.5;	
10	G71 P10 Q50 U1. W1. F250.:	
11	N10 G00 U-50.;	
12	N20 G3 X60, Z180, 10, K-10, F150.;	174
13	N30 G2 U5. Z155. R200. F200.;	
14	N40 G01 X70. #-20. F50.;	- C
15	N50 U20. Z130. F150.:	SE
16	G70 P10 Q50;	
17	G00 X92.;	1000
18	R-100.:	CALL
19	G75 R0.5:	. *
		# 15:59:55 MORE
PRC	G CNC A CHECK	PREV NEXT

Note : In ALTER state, the current character where the cursor locates is altered for the input one, and the cursor moves a byte forward;

## 6.1.7 Deleting a Single Block

), it displays as follows:

#### Single block deletion:

1) Press in Edit mode to enter program interface, and switch program content page.

2) Move the cursor to the head of the block to be deleted, then press **Multi-block deletion:** 

1) Select the edit operation mode, enter to the program page set by **button**, and then shift to the program content page;

2) Move the cursor to the beginning of the block to be deleted, press the **LABEL** soft button, and then move the selected block by cursor, the page is as follows:

ED	IT	S0000 T0000
PROGR	AM -> LOCAL PROGRAM [00000] INSERT	00000 N0000 34
1	00000(0.001MM/DA98/DA98A/步进);	A SEARC
2	G50 X300. Z500.	
3	C98 G00 X100. Z200.	2
4	G90 U 10, W 200, F500,	SEARC
5	G90 U-10. Z100. R-2.5 F350.	
6	C00 X90.	
7	G74 R0.5	LABE
8	G74 X0. #-10. P3000 05000 R1.5 F300.;	
9	G00 Z190.;	COP
10	G71 U2.5 R0.5:	
11	G71 P10 Q50 U1. ₩1. F250.;	
12	N10 G00 U-50.;	- TA-1
13	N20 G3 X60. Z180. 10. K-10. F150.;	100
14	N30 G2 U5. Z155. R200. F200.;	DE
15	N40 G01 X70. #-20. F50.;	BLOC
16	N50 U20, Z130, F150.;	
17	G70 P10 Q50;	
18	G00 X92.;	GALCO
19	<b>H</b> -100.;	
	the second s	# 16:15:48 MORE:
PRO		

4) Delete the selected block by Delete the selected block by

# 6.1.8 Copying & Pasting a Block

#### Single block copy/paste Steps:

- Sleps:
- 1) Select Edit mode, enter to the program page set by and then shift to the program content page;
- 2) Move the cursor to the required copy block, press **LABEL** and **COPY**, and the current block is copied;

3) Move the cursor to the required paste position, press \_\_\_\_\_, and the copied block is pasted. Single block copy/paste

Steps:

1) Select the Edit mode, enter to the program page set by and then shift to the program content page;

2) Move the cursor to the beginning of the block to be copied, press the LABEL soft button, and then move the selected block by cursor;

3) Copy the selected block by **COPY** soft button;

4) Move the cursor to the required paste position, press **PASTE**, and the copied block is pasted.

# 6.1.9 Canceling & Recovering a Program

#### Steps:

1) Select Edit mode, enter to the program page set by and then shift to the program content page, which is shown below::



Proce M

2)

Press MORE to enter the next menu, which is shown below:



- 3) When the current content is changed(after modification, copy or deletion), with is pressed to recover the previous content before the copy;
- 4) Recover and cancel are matched. Press **1000**, **REDO** to cancel the previous operation. Note: Up to 10 previous steps can be retreated by using the retraction function;

### 6.1.10 Circle Command Aided Programming

The cycle G command should be input more parameter commands. This function is the programming guiding function for each cycle command; Operator can easily finish the programming operation for the cycle command by the miscellaneous programming function. There are two methods to enter the miscellaneous function, refer to the following steps:

Method 1:

1) Press soft key enter to edit mode, press soft key, enter to the program page set and then shift to the program content page, so that the cursor does not the line of that the cycle command locates, which is shown below:



2) Open the program content sub-page by

50000 T0000 EDIT PRO G00 X100 Z100 T0101: 23 G00 X80 Z5: SEARC LABE DE SEG CALCUL ♦ MORE FONT A RETURN MARCO EDIT AUX PROG a M PREV PACE PAGE

soft button, which is shown below:

AUX PROG 3) Enter to the miscellaneous programming page by controlling the soft function button., which is shown below:





4) Perform the cutting-in direction selection on this page (Partial commands are regardless of the

cutting-in direction selection, but enter to the next page directly); enter to the next page by soft button; refer to the following figure:

EDIT	50000 T00	100
AUX PROG	00001 N0000	~
	G71 Axial roughing cycle G71 U(Åd) R(e) F G71 P(ns) Q(nf) U(Åu) ₩(Å₩) K J	EXIT SAVING EXIT DISCARD
	INPUT FINISHING BLOCK:	Dury
	βu - [Δd	CHANGE
X cutting in roughing.unit:se.radius.without	sign, (8, 881-99, 999(15_8)/8, 8881-99, 9999(15_0)	5
	₩ 17:05:39	BACK

5) Input the parameter numerical value in this page, the figure at the left is the machining schematic; the command parameter input frame is at the upper right coner; the command parameter to be input

can be selected by  $\square$ ,  $\square$ ,  $\square$ ,  $\square$  or  $\square$  button. When the command parameter is selected the left machining schematic, the corresponding address may display with red color; the numerical value then can be written into the input frame by its corresponding number buttons; write the

numerical value to the input frame by . The input frame (Only the G71, G72 or G73 owns the accuracy-machining block input frame) at the lower right corner is the one for inputting the accuracy-machining block. The cursor can be shifted between the command parameter input frame

and the one of the accuracy-machining block by and the one of the accuracy-machining block by or the soft button. A new program is then

created by soft button after inputting data; refer to the following figure:



AUX PROG programming help interface by and then record the stored data, which is shown below: 50000 T0000 EDIT



3) A new program is created by soft button after inputting the data, which is shown below:



## 6.1.11 Program Save

In Edit mode, after the program is edited or modified, although the system automatically save programs at regular time, shift to other working mode from edit or switch the current display page and the CNC will automatically save the current program.

Note: "\*" in the title bar is displayed when the program is not saved.

### 6.1.12 Macro Program Edit

Method 1:

Select the edit operation mode, enter to the program page set by	PROGRAM	and then	shift t	o the

program content page; enter to the macro edit state consecutively pressing the zeric; refer to the following figure:

EDIT			S0000 T0000
PROCRAM -> LOU 1 (100 = 1 2 (;	<u>CAL PROGRAM [0020</u>	0] MACRO =	00209 N0000 34 pr SEAR SEAR LAR Co Sec CALCI
PROG CONTENT	CNC DIR.	CHECK	B 09:05:04 NORE

Then it may input some special characters ( [, ], =, >, <, +, \*).

For example: To input character " [", it may press key repeatedly.

Method 2:

Edit operation method selection, enter to the program page set by set and then shift to the

program content page, press soft key, enter to the program content page, press soft button to open the macro edit function menu, which is shown below:

EDIT					50000 T00	00
PROCRAM -2	$\rightarrow$ LOCAL PR	OGRAM [O	3200] MAC	R0 *	00200 00000	IF
						6010
						THEN
						WHILE
						00
						OPR
						COMMAND
			l	L mar 1	₩ 09:18:38	EXIT
∧ RETURN	MARCO EDIT	AUX PROG	Ma the	FONT	PREV PAGE	PAGE

In this case, automatically enter to the macro edit state, some special characters, such as ([,], =, >,<, + and \*) can be input. The macro program command can be inserted by the function button at the right side, so that the macro edit is more simple and enabled Note: In the macro program edit state, program index or scan operation is unavailable.

## 6.1.13 Creating & Modifying a Program Annotation

GSK980TDi can add annotation to each line, and its steps are shown below:

- 1) Select Edit mode, press **s** to enter program interface and switch enter the program content page;
- 2) Press and the CNC automatically insert "()" into the end of line where the cursor is, and the display page is shown below:



3) Input annotation character into "(). For example, input "KUAI" character string, and the display page is shown below:



4) The modification of annotation is the same that of program content.

Note : The annotation added to the CNC could only be character. Actually, the CNC takes all content in "()" as annotation, so, adding other annotation can be executed by using PC editing, and then be transmitted to the CNC.

## 6.2 Deleting Programs

#### 6.2.1 Deleting a Program

Steps:

1) Select Edit mode, press is to enter program interface and switch enter the program content page;

number key

Ο

Ο

Ο

1

by sequence (taking

2) Press address key example of O0001);

	IT	50000 T000	0
ROGR	AM -> LOCAL PROGRAM [00000] INSERT	00000 N0000	24
1	00000(0.001MM/DA98/DA98A/步进);	4	SEARCH
2	G50 X300, Z500.;		OLMINO
3	G98 G00 X100. Z200.:		2
4	G90 U-10, W-200, F500.;		SEARCH
5	G90 U-10, 7100, R-2.5 F350,;	17	
6	G00 X90.;		-
7	G74 R0.5;		LABEL
8	G74 X0. H-10. P3000 05000 R1.5 F300.		è i
9	G00 Z190.;		
10	G71 U2.5 R0.5:	-	-
11	G71 P10 Q50 U1. W1. F250.;		Ö
12	N10 G00 U-50.;		Theat
13	N20 G3 X60, Z180, I0, K-10, F150.;		-
14	N30 G2 U5. Z155. R200. F200.;		DEL
15	N40 G01 X70. #-20. F50.		SEG.
16	N50 U20, Z130, F150.;		1
17	G70 P10 Q50;		all and
18	G00 X92.;		CALCUL
ROG	NAME 0 0001		*
		# 09:51:47	MORE
PRO	GENC CHECK	PREV PAGE	IEXT AGE

3) Press key, pop-up the dialog box as follows:

		EDIT		50000 T0000	
4) Met	Press and	PROGRAM         ->         LOCAL         PROGRAM           1         00000(0.001HH/DA98/T         2         650 X300, Z500.;           3         G98 G00 X100, Z500.;         3         698 G00 X100, Z500.;           4         G90 U-10, IH-200, F56         5         G90 U-10, Z100, R-2.           6         G00 X90.;         7         G74 R0,5;         8           7         G74 R0,5;         8         G74 X0, H-10, P3000           9         G00 Z190.;         10         G71 U2,5 R0.5;           10         G71 U2,5 R0.5;         11         G71 U2,5 R0.5;           11         G71 U2,5 R0.5;         13         N20 G3 X60, Z180, 16           12         N10 G00 U-50.;         130, F150, 175, 175, R22           13         N20 G3 X60, Z180, 160, 170, H-20, F         15           14         N30 G2 U5, Z130, F150, 120, 175, R22         15           15         N40 G01 X70, H-20, F         16         N60 U20, Z130, F150, 120, 120, 120, 120, 120, 120, 120, 12	000001 (NSER) DA98A/步进); 5 F350.; 050000 R1.5 F300.; F250.; 0. K-10. F150.; 10. F200.; 50.; NC ? NC ? S deleted; press	C00009 H0000 H SLAF SLAF SLAF SLAF SLAF SLAF SLAF SLAF	eletion is cancelled.
1)	Select Edit mod page;	e, press <b>Room</b> to e	enter program inte	rface, press to	enter the local program
2)	Press dor program and the	to select the display is shown b	e required deleted below:	program. For	example, select O0001
		PROGRAM -> LOCAL DIRECTORY TOTAL: 22 SPACE: 64. NAME SIZE DATE 00001 132 B 2015-11-18 00002 52 B 2015-11-18 00002 52 B 2015-11-16 00003 40 B 2015-11-16 00005 46 B 2015-11-16 00006 63 B 2015-11-16 00006 63 B 2015-11-16 00008 85 B 2015-11-16 00008 85 B 2015-11-16 00009 92 B 2015-11-16 00010 128 B 2015-11-16 00011 823 B 2015-11-16 00012 823 B 2015-11-16 00012 823 B 2015-11-16 00012 823 B 2015-11-16 00012 824 B 2015-11-16 00012 824 B 2015-11-16 00013 244 B 2015-11-16	0 M USED: 1.7 M PROGRAM PREVIEW 00001 G71 U2 R0.5 F100 G71 P10 020 U0.5 G00 Z200 G00 X100 Z100; T0101; G00 X80 Z5; G71 P10 028 U0.5 H0.5 G71 P10 028 U0.5 H0.5	000000         00000         0           IOLE:         62.3         0         0           IOLE:         62.3         N         0         0           IOLE:         62.3         N         0         N         N           IOLE:         62.3         N         0         N         N         N           IOLE:         62.3         N </td <td></td>	
3)	Press key	y, pop-up the dialog	) box as follows:	50000 T0000	
		PROGRAM         →         LOCAL         DIRECTORY           TOTAL:         22         SPACE:         64.           NAME         SIZE         DATE         2           00000         019         B         2015-11-18         00001         132         B         2015-11-18           00001         132         B         2015-11-16         00002         52         B         2015-11-16           00005         46         B         2015-11-16         00006         63         B         2015-11-16           00006         46         B         2015-11-16         00008         85         8         2015-11-16           00009         9         B         2015-11-16         00009         9         B         2015-11-16           00001         128         2015-11-16         00001         128         2015-11-16         00001         11         12         11         16           00011         612         B         2015-11-16         00001         14         14         14           VES         2         PROSRAM         00001         14         14         14           VES         147         140000001         14 <td>0 M USED: 1.7 M PROGRAM PREVIEW 00001 G71 U2 R0.5 F100 G71 P10 020 U0.5 G00 Z200 G00 X100 Z100 T0101: G00 X80 Z5. G71 U1 R0.5 F100 G71 P10 020 U0.5 H0.5</td> <td>00000 N0000         ₽           10LE: 62.3 M         0PEN           Image: Second s</td> <td></td>	0 M USED: 1.7 M PROGRAM PREVIEW 00001 G71 U2 R0.5 F100 G71 P10 020 U0.5 G00 Z200 G00 X100 Z100 T0101: G00 X80 Z5. G71 U1 R0.5 F100 G71 P10 020 U0.5 H0.5	00000 N0000         ₽           10LE: 62.3 M         0PEN           Image: Second s	

4) Press and O0001 program is deleted; press and the deletion is cancelled.

## 6.2.2 Deleting All Programs

#### Steps:

- 1) Refer to Section 6.2.1, Method 2 to enter the local program page;
- 2) Press MORE to enter the next menu and the display is shown below:

EDIT	50000 T00	00
PROGRAM -> LOCAL DIRECTORY	00000 N0000	DELETE
TOTAL: 22 SPACE: 64.0 M USED: 1.7 M	IDLE: 62.3 M	ALL
NAME         SIZE         DATE         PROGRAM         PREVIEW         00000           000000         919         8         2015         11-18         G71         U2         R9.5         F100		NAME
00001 132 B 2015-11-16 G0 Z200 00002 52 B 2015-11-16 G00 Z200 G00 Z200		TIME
00003 40 B 2015-11-16 G00 X100 Z100 00004 130 B 2015-11-16 T0101 00005 46 B 2015-11-16 T0101	,	
00006 63 B 2015-11-16 G71 U1 R0.5 F100 00006 739 B 2015-11-16 G71 U1 R0.5 F100	,	
00008 85 B 2015-11-16 00009 92 B 2015-11-16		
00010 128 B 2015-11-16 00011 612 B 2015-11-16		
00012 873 B 2015-11-16 00018 246 B 2015-11-16		_
00021 524 B 2015-11-16	# 18+82+12	A MORE
PROG	PREV	NEXT

### 6.3 Selecting a Program

When there are multiple programs in CNC system, a program can be selected by searching, scanning and direct confirmation.

## 6.3.1 Searching

3)

1) Select Edit or Auto mode, enter to the program page set by and then shift to the program content page;

2) Press SEARCH, (the short key is ) and the display is shown below:

ED	IT	50000 T0000
PROGR	AM -> LOCAL PROGRAM [00000] INSERI	00000 N0000 A
1	00000(0.001MM/DA98/DA98A/步进);	A SEARCI
2	G50 X300, Z500.;	
3	G98 G00 X100. Z200.;	12
4	G90 U-10. W-200. F500.;	SEARCI
5	G90 U-10, Z100, R-2.5 F350.;	
6	G00 X90.;	
7	G74 R0.5;	LABE
8	G74 X0. H-10. P3000 Q5000 R1.5 F300.	
9	G00 Z190.;	
10	G71 U2.5 R0.5:	
11	G71 P10 Q50 U1. #1. F250.;	0
12	N10 G00 U-50.;	- TA
13	N20 G3 X60. Z180. I0. K-10. F150.;	15
14	N30 G2 U5. Z155. R200. F200.;	DE
15	N40 G01 X70. #-20. F50.;	SEG
16	N50 U20, Z130, F150.;	
17	G70 P10 Q50;	
18	G00 X92.;	CALLU
PROG	NAME O	*
		# 10:10:06 MORE:
PRC	G CNC CHECK	PREV. NEXT

3) Input the program number in the pop-up dialogue box. For example, search O0001 program (the leading zero can be omitted when the program name is input) and the display is shown below:

E	DIT	50000 T0000
PRO	GRAM -> LOCAL PROGRAM [00000] INSERI	00000 N0000 A
	CODOD (0.001 HM/CDA88/CDA98A/2+3+);           C50 X300. 7500.;           C98 C00 X100. 7200.;           G98 C00. X100. 7200.;           G98 C00. X100. 7200.;           G98 C00. X100. 7200.;           G90 U-10. M-200. F500.;           G90 U-10. T100. R-2.5 F350.;           G00 X90.;           G74 X0. #-10. P3000 05000 R1.5 F300.;           G00 Z190.;           G71 U2.5 R0.5;           G71 U3.5 R0.2;           N10 G00 U-50;           N20 G3 X60, Z180, 10, K-10, F150;;           N30 G2 U5, Z185; N200, F200;;           N40 G01 X70, #-20, F50.;           N40 G01 X70, #-20, F50.;           G00 X92;;           G NAME D 0001	B 09:51:47
122	SONTEN] DIR.	PAGE PAGE
4) Press (or A, M, M, Imply), the searched program will be displayed. If the program		
does not exist, the CNC prompts "File does not exist".		
Note: Press or is to search programs in Edit mode. When there is no program, the CNC		
automatically creates programs; press $\checkmark$ or $\uparrow$ to execute the search, and the CNC prompts		

"The file does not exist" when there is not the program.

## 6.3.2 Scanning

- 1) Select Edit or Auto mode;
- 2) Press is to enter the program display page;
- 3) Press
- 4) Press d or to display the next or previous program;
5) Repeat step 3 and 4 to display the saved programs one by one.

## 6.3.3 Direct Confirmation

- 1) Select Edit or Auto mode (must be in non-run state);
- 2) Press

is pressed, which displays is shown below:

					20000 10	000
ROGRAM -	> LOCAL	DIRECTORY			00000 N0000	
TOTAL:	22	SPACE: 64.	ØM	USED: 1.7 M	IDLE: 62.3 M	0
NAME	SIZE	DATE	PROG	RAM PREVIEW 00001		1
00000	919 B	2015-11-18	G71	U2 R0.5 F100		1
00001	132 B	2015-11-18	G71	P10 020 U0.5		
00002	52 B	2015-11-16	G00	Z200		1
00003	40 B	2015-11-16	61 2	200		-
00004	130 B	2015-11-16	1010	A100 2100		
00005	46 B	2015-11-16	600	X80 75		
00006	63 B	2015-11-16	G71	U1 R0.5 F100		
00007	39 B	2015-11-16	G71	P10 020 U0.5 W0.5		in the
00008	85 B	2015-11-16	-			EIN
00009	92 B	2015-11-16				DC
00010	128 B	2015-11-16				Inc.
00011	612 B	2015-11-16				
00012	873 B	2015-11-16				-+
00018	246 B	2015-11-16				-
00021	524 B	2015-11-16				*
	-				# 09:55:28	MO
PROG	THE OF	I DONC	10 US	0	PREV	NEX
CONTENT	MC 10	-DIR.	4 mil		PAGE	PAG

to enter the program interface. When the system is not in "Local Directory",

- 3) Press  $\uparrow$ ,  $\checkmark$  to move the cursor to the program name which is to be selected.
- 4) Press (or ), and the selected program is opened and the CNC skips to "PRG. CONTENT" page.

Note: when the CNC is connected with the U disk, the above similar method is referred to open the program in the U disk.

# 6.4 Executing a Program

After the program to be executed is selected by the method in OPERATION, Section 6.3, select

the Auto mode, then press key (or external cycle start key), the program will be executed automatically.

# 6.5 Renaming a Program

Methods of renaming a program is divided into two: Method 1:

Select Edit mode, press is to enter the program interface, and in necessity press
 PROG CONTENT to enter PRG CONTENT page (must be in Insert, Alter state):

PROGRAM => LOCAL PROGRAM [00000] INSER1       0         1       [00000(0,001HM/0A986/DA98A/±#;#);       2         2       G50 X300, 2500.;       3       G98 G00 X100, 2200.;       4         4       G90 U-10, #-200, F500.;       5       G99 U-10, #-200, F500.;       5       G99 U-10, #-200, F500.;         5       G99 U-10, #-200, F500.;       6       G00 X90.;       7       G74 K0, #-10, P3000 C5000 R1.5 F300.;       8       G74 X0, #-10, P3000 C5000 R1.5 F300.;       8       G74 X0, #-10, P3000 C5000 R1.5 F300.;       8       G00 X90.;       7       G74 K0, #-10, P3000 C5000 R1.5 F300.;       8       G00 X90.;       7       G74 K0, #-10, F30.;       10       G71 102.5 R8.5;       11       G71 P10 G50 U-50.;       13       N20 G3 X60, Z180, 19, K-10, F150.;       13       N20 G3 X60, Z180, 19, K-10, F150.;       14       N40 G01 X70, #-20, F50.;       16       N40 G01 X70, #-20, F50.;       16       N50 U20, Z130, F150.;       17       G70 P10 G50;       18       G00 X32.;       19       #-100.;       19       #-100.;       19       #-100.;       19       #-100.;       19       #-100.;       10       #-100.;       10       #-100.;       10       #-100.;       10       #-100.;       10       #-100.;       10       #-100.;       10       #-100.;	COORGE NOODD AL PROG SEARCH SEARCH CALCH SEE CALCH SEE CALCH SEE CALCH SEE
1       1       1000000(0,001HM/DA86/DA88A/#5#);         2       C58 X300, 7500;         3       C98 C60 X100, 7200;         4       C90 U-10, #-200, F500;         5       C90 U-10, #-200, F500;         5       C90 U-10, #-200, F500;         6       C00 X80;         7       C74 R0.5;         8       C74 X0, #-10, P3000 05000 R1.5 F300.;         9       C00 1180;         10       C71 U2.5 R0.5;         11       C71 P10 050 U1. #1. F250;         12       N20 C3 X60, 7180, 10, K-10, F150;         13       N20 C3 X60, 7180, 10, K-10, F150;         14       N30 C2 U5, 2155, 200, F200;         15       N40 C01 X70, #-200, F50;         16       N50 U20, 2130, F150;         17       C70 P10 050;         18       C00 X92;         19       #-100;         19       #-100;         10       C01 X2, 30, F150;         17       C70 P10 050;         18       C00 X92;         19       #-100;         10       F100;         11       F150;         12       F100;         Press       Line         Eve	SCARCH SCARCH LABEL COLL SEG. CALCAL PAGE PAGE NEXT
3       C99 C00 X100. 7200.;         4       C90 U-10. #-200. F500.;         5       C99 U-10. #-200. F500.;         5       C99 U-10. #-200. F500.;         6       C00 X90.;         7       C74 R0.5;         8       C00 Z100.;         9       C00 Z100.;         10       C71 V2.5 R0.5;         11       C71 V2.5 R0.5;         12       N10 G00 U-50.;         13       N20 C3 X00. 7180. 10. K-10. F150.;         14       N30 62 U5. Z155. R200. F200.;         15       N40 G01 X70. #-20. F50.;         15       N40 G01 X70. #-20. F50.;         16       ODI X70. #-20. F50.;         17       C70 P10 G50;         18       G00 X32.;         19       #-100.;         10       C00 X32.;         19       #-100.;         10       Press         to input a new program name;         Press       Yes         Xempletee       Press         Xempletee       Press         Xempletee       Press         Xempletee       Press         Xempletee       Press         Xempletee       Press	CALCAL PAGE PAGE PAGE PAGE
4       C390 U-10. #-200. F300.;         6       C390 U-10. Z100. R-2.5 F350.;         6       C60 X30.;         7       C74 R0.5;         8       C47 X0.4 R-15;         10       C71 V2.5 R0.5;         11       C71 V2.5 R0.5;         12       N10 G60 U1.81. F250.;         12       N10 G60 U.50.;         13       N20 C3 X60. Z180. 10. K-10. F150.;         14       N30 G2 U5. Z155. F200. F200.;         15       N40 G01 X70. #-20. F50.;         15       N40 G01 X70. #-20. F50.;         16       M50 U20. Z130. F150.;         17       C70 P10 G50;         18       G00 X32.;         19       #-100.;         Image: State	ULABEL CALCAL SEG. CALCAL PAGE PAGE PAGE
6       C00       X90.;         7       C74       R0.5;         8       C00       Z190.;         10       C71       U2.5       R0.5;         11       C71       U2.5       R0.5;         12       N10       G60       U-50.;         13       N20       C3       X60.       T180.       10.       F150.;         13       N20       C3       X60.       T180.       10.       F150.;       11.         14       N30       C2       U2.5       Z150.       F200.       F200.;       11.       F150.;       F150.;       11.       F150.;       11.       F150.;       F150.;       F17.       F100.;       F17.       F100.;       F17.       F100.;       F17.       F100.;	LAKEL DEL SEG. CLUCAL WORE PACE PACE
7       674 80.5;         8       600 2190.;         10       671 102.5 80.5;         11       674 102.5 80.5;         12       N10 606 01.81.5 F300.;         13       N20 03 X00. 7180. 10.K-10. F150.;         14       N30 62 05.7 158.7 200.;         15       N40 601 X70. #-20. F50.;         16       050 020. 7130. 10.K-10. F150.;         17       676 P10 650;         18       600 X32.;         19       #-100.5;         17       670 P10 650;         18       600 X32.;         19       #-100.;         Press       to input a new program name;         Press       Fish         Version       Fish         8       Fish         9       Fish	Image: Section of the section of th
9       G00       2190.;         10       G71       102.5       R0.5;         12       N10       G00       0-50.;         13       N20       G2 X00718010K-10F150.;         14       N30       G2 V007180F200F200.;         15       N40       G01 X70#-20F50.;         16       M50       U207180F150.;         17       G70       P10         18       G00 X32.;       19         19       #-100.;       Image: Concentration of the state	BELL SEG. CALCAL WORE PAGE PAGE PAGE
00       071       070       080       01       071       070       080       01       071       070       080       01       071       070       080       01       071       070 <td>Image: Second second</td>	Image: Second
12       N10 G00 U-50.;         13       N20 G3 X60. 7180. 10. K-10. F150.;         14       N30 G2 U5. 7155. R200. F200.;         15       N40 G01 X70. #-20. F50.;         16       M50 U20. 7130. F150.;         17       G70 F10 G50;         18       G00 X92.;         19       #-100.;         CONC         CHECK         CONC         CHECK         PROG         CONC         CHECK         CHECK         CHECK         CHECK         PROG         CHECK	Et 16:37:17 MORE PAGE PAGE
Press to input a new program name; Press to input a new program name;	ENTISES77:17 MORE PREV PAGE NACE
Press to input a new program name; Press Sum. Press Press Sum. Press Sum. Press Press	SEG. C/ALCAL ₩ 18:37:17 MORE PAGE PAGE
Press to input a new program name; Press 2. Press 2.	HE 18:37:17 MORE
Press to input a new program name; Press 2 Press 2 Press 2 thod 2: Select Edit mode, press 2 to enter the program	₩ 16:37:17 MORE PAGE PAGE
Press to input a new program name; Press Žul. thod 2: Select Edit mode, press D to enter the program	Image: Windows         Morecomment           Image: Windows         Morecomment           Image: Windows         Morecomment           Image: Windows         Morecomment
Press to input a new program name; Press Select Edit mode press to enter the program	PROV PAGE PAGE
Press to input a new program name; Press	
Press to input a new program name; Press	
Press to input a new program name; Press	
Press thod 2: Select Edit mode press to enter the program	
Press Zww. hthod 2: Select Edit mode press to enter the program	
Select Edit mode press to enter the program	
Select Edit mode press it o enter the program	
Select Edit mode press it to enter the program	
Select Edit mode press mini to enter the program	
	m interface, and in necessity pre
to enter the local directory page:	
EDIT	S0000 T0000
PROGRAM -> LOCAL DIRECTORY C	00000 N0000 V
TUTAL: 22 SPACE: 04.0 M USED: 1.7 M TUER	DLE: 02.3 W OPEN
NAME SIZE DATE PROGRAM PREVIEW 00001	NEWS OPEN
00001 132 B 2015-11-18 G71 P10 020 U0.5	×
00002 52 B 2015-11-16 G1 Z200	(DEL)
00004 130 B 2015-11-16 G00 X100 Z100	
00005 46 B 2015-11-16 600 X80 Z5.	and the second sec
00006 63 B 2015-11-16 G71 U1 R0.5 F100	
00007 39 B 2015-11-16 G71 P10 020 00.5 W0.5	Jul .
	FIND(P)
00009 92 B 2015-11-16	FIND(P)
00009 92 B 2015-11-16 00010 128 B 2015-11-16	F IND(P) RENAME
00009 92 B 2015-11-16 00010 128 B 2015-11-16 00011 612 B 2015-11-16 00011 612 B 2015-11-16	FIND(P) RENAME
00009         92         8         2015-11-16           00010         128         8         2015-11-16           00011         612         8         2015-11-16           00012         873         8         2015-11-16           00018         246         B         2015-11-16	FIND(P) RENAME RESAVE AS:
00009       92       8       2015-11-16         00010       128       8       2015-11-16         00011       612       8       2015-11-16         00012       873       8       2015-11-16         00018       246       8       2015-11-16         00021       524       8       2015-11-16	FIND(P) REMANE RY AS V
00009 92 8 2015-11-16 00010 128 8 2015-11-16 00011 612 8 2015-11-16 00012 873 8 2015-11-16 00018 246 8 2015-11-16 00021 524 8 2015-11-16	FIND(P) (RENAME E. SAVE AS ₩ ₩ 09:55:28 ₩ 00:55 10:5
00009 92 8 2015-11-16 00010 128 8 2015-11-16 00011 612 8 2015-11-16 00012 873 8 2015-11-16 00018 246 8 2015-11-16 00021 524 8 2015-11-16 ₽ PROG CONTENT ■ CNC ■ CNC	#       FIND(P)         IRENAME       Image: SAVE         Image: SAVE       AS         Image: SAVE       MORE         Image: SAVE       MORE         Image: PAGE       PAGE
00009 92 8 2015-11-16 00010 128 8 2015-11-16 00011 612 8 2015-11-16 00012 873 8 2015-11-16 00018 246 8 2015-11-16 00021 524 8 2015-11-16 □ PROG CONTENT CONC	FIND(P) RENAME FL, SAVE AS ₩ 09:55:28 MORE PAGE PAGE

INIA INIA program name in the pop-up diaglog box, and at last press

Note: the method 1 is only used to the current program, and the method 2 is used to any programs.

#### **Copying a Program** 6.6

Methods of copying a program is divided into two: Method 1:

Select Edit mode, press to enter the program interface, and in necessity press 1) PROG CONTENT

to enter PRG CONTENT page (must be in Insert, Alter state):



- Ο 2) Press to input a new program name;
- Press 3)

Method 2:

to enter the program interface, and in necessity press Select Edit mode, press 1) CNC DIR.

to enter the local directory page:

E	DIT					S	0000 T00	000
PR	OGRAM -	> LOCAL	DIRECTORY			00	000 N0000	2
	TOTAL:	22	SPACE : 6	4.0 M	USED: 1.7 M	IOLE:	62.3 M	OPEN
	NAME 00000 00001 00002 00003 00004 00005 00006 00005 00006 00007 00008 00009 00010 00011 00012 00018 000018	\$17E 919 8 132 8 52 8 40 8 130 8 46 8 63 8 39 8 85 8 92 8 128 8 612 8 873 8 246 8 73 8 246 8	DATE 2015-11-18 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16 2015-11-16	PRO G71 G71 G71 G71 G70 G71 G70 G71	GRAM PREVIEW 000 U2 R0.5 F100 P10 Q20 U0.5 Z200 Z200 X100 Z100 01 X100 Z100 01 X80 Z5. U1 R0.5 F100 P10 Q20 U0.5 W0	01		NEWS NEWS DEL (DEL)
	00021	024 D	2013-11-10		_	8x	09:55:28	MORE
12	PROG		CNC DIR.	P 18		12	PREV PAGE	NEXT PAGE

2) Move the cursor to the program which is to be modified, press

SAVE and input a new

4 program name in the pop-up diaglog box, and at last press

Note: the method 1 is only used to the current program, and the method 2 is used to any programs.

#### 6.7 **Program Management**

,and then press Press to enter the local program display page. In the page, it lists the program names saved in CNC system, and it can display up to 15 names in a page. When

Ê to display the next page. the saved exceed 15 programs, it may press or



Explanations:

- 1) The area 1 is used to display the saved programs, the total memory capacity, the used capacity and the left;
- 2) The area is used to display the current program list;
- 3) The area 3 is used to preview the content of program where the current cursor is in the area 2;
- 4) The area 4 belongs to the soft function menu position. Pressing can display in order programs located at the area 2.

## 6.8 Counter Function

1、 press to enter the program content page.

2、Spring out the counter window by soft button; Alternatively, directly press the soft button; Alternatively, directly press the state the program content page, the calculator may appear, refer to the following figure:

EC	TI						S	0000	TØP	00
PROCK 1 2 3 4 5 6 7	XAM -> LOCAL P G50 X0 Z100; M03 S1000; T0101; G00 X20 Z10; G01 W-50 F20 G01 U10 W-5; G01 W-80;	ROGRAM [O	0000] INSE	RI	CALC	UL	00(	100 N	0000	AH PROC SEARCI SEARCI SEARCI
8 9 10 11 12	C01 U100 H-5 G01 H-15; G00 X180 Z15 M05; M30;	0:			N Inv U sin R cos	G 1/X W X <sup>V</sup> L	7 4 1	8 5 2	9 6 3	D There
					K tan T ctan CHG T	PVX / NLT C	± × DEL	O EOB CAN	IN + OUT SEND	DEL SEG. CALCUI
PRC CON	IG III III	CNC DIR.		CHECK TRACK				HI:40 PREV PAGE	:55	MORE

3. Control the corresponding button function on the MDI panel to perform the number input and calculation based upon the content of the calculator. The calculated result can be transmitted to the

program cursor on the MDI panel based upon the displayed **SEND** from calculator, and then retreat from the calculation function.

OUT

a) Press the internatively, it can be carried out by soft button.

# 6.9 Font Scaling

Enter to the program page set by Enter to the program content page by FROG soft button (It can not be entered in the MDI mode) if necessary, refer to the following figure:

HN	D	50000 T	0000
PROGR	AM -> LOCAL PROGRAM [00000]	00000 N000	0 84
1	0000000(0.001HH/DA98/DA98A/步进);		A
2	G50 X300. Z500.		
3	G98 G00 X100. Z200.:		12 A
4	G90 U-10. W-200. F500.;		-0,1-52
5	G90 U-10, Z100, R-2,5 F350,		1
6	G00 X90.		-
7	G74 R0.5;		- CARLE
8	G74 X0. #-10. P3000 05000 R1.5 F300.		10
9	G00 Z190.		- mar 1
10	G71 U2.5 R0.5:		
11	G71 P10 050 U1. W1. F250.;		G
12	N10 G00 U-50.;		TYANH.
13	N20 G3 X60. Z180. 10. K-10. F150.;		100
14	N30 G2 U5. Z155. R200. F200.;		111
15	N40 G01 X70. #-20. F50.:		
16	N50 U20. 2130. F150.		int interest
17	G70 P10 Q50:		-
18	G00 X92.		CALCUL
19	<b>#</b> -100.;		
	Anne als e		MODE
		1192392	MORIE
PRC CON	ITENT MOI CNC TO INC.	8	332

Open the next level optional menu by pressing the **CONTENT** soft button again; refer to the following figure:

HN	D \$0000 T00	000
PROGE	AM -> LOCAL PROGRAM [00000] 00000 N0000	84
1	0000000(0.001HH/DA98/DA98A/步进);	
2	G50 X300. Z500.	Lond .
3	G98 G00 X100. Z200.:	1 per
4	G90 U-10. W-200. F500.;	21.1.2
5	G90 U-10. Z100. R-2.5 F350.	(F-)
6	G00 X90.	
7	G74 R0.5;	Lange
8	G74 X0. H-10. P3000 Q5000 R1.5 F300.	-È
9	G00 Z190.	
10	G71 U2.5 R0.5	124
11	G71 P10 050 U1. W1. F250.;	C.
12	NTO 600 0-50.	1 WARE
13	N20 G3 X60, Z180, 10, K-10, F150.;	(ac
14	N30 GZ U5. Z155. K200. F200.;	11
15	N40 G01 X70. W-20, F50.	
16	N50 020. 2130. F150.;	6
17	G70 F10 (200)	CALCU
18	600 X92.	X
19	-100.	v
	≣ 11:23:28	MORE
RET	URN REACH A FONT E	13.7
	FONT	

Open the font scaling function optional menu by soft button; refer to the following figure:

HN		S0000 T0000
PROCE	AM -> LOCAL PROGRAM [00000]	00000 N0000
1	0000000(0.001HM/DA98/DA98A/步进);	- ENLARG
2	G50 X300. Z500.	
3	G98 G00 X100. Z200.:	FON
4	690 U-10, W-200, F500.;	NARRO
5	G90 U-10, Z100, R-2.5 F350.	
6	G00 X90.	
7	G74 R0.5;	
8	G74 X0. H-10. P3000 Q5000 R1.5 F300.	
9	600 Z190.	
10	G71 U2.5 R0.5	
н	G71 P10 050 U1. W1. F250.;	
12	N10 G00 U-50.:	
13	N20 G3 X60. Z180. 10. K-10. F150.;	The second se
14	N30 G2 U5. Z155. R200. F200.;	
15	N40 G01 X70. #-20, F50.:	
16	N50 U20. 2130. F150.	
17	G70 P10 Q50;	
18	G00 X92.	
19	<b>m</b> -100.;	
		🗄 11:23:38 EXI
A RET		

The font size can be adjusted by **ENLARCE**, **NARROW**, this function is only enabled to the displayed machining program on the program content page.

# 6.10 Program Preview Function

In order to reduce the alarm error in the operation program and improve the safety of component program performance, GSK980TDi adds the [Path Preview] function, also displayed the direction of the programming path, so that it is convenient to confirm whether the program is correct.

## 6.10.1 Interface Display of Path Preview

Select the Edit mode, on the program -> local program interface; press the **TRACK** soft button after the program is compiled; refer to the following figure:



### 6.10.2 Operation of Path Preview

#### 1) The beginning or dwell of path preview

Enter to the path preview page; the programming path is then automatically displayed.

Alternatively, the program path can be shown by **START** soft button (or **S**) button) on the path preview page, refer to the following figure:

CHECK

EDIT	50000 T0000
PROGRAM       → LOCAL       PROGRAM       (10)         1       (550 X0 Z100)       (10)         2       H03 S1000       (10)         3       10101:       (10)         4       G00 X20 Z10.       (10)         5       G01 #-56 F200       (10)         6       G01 U10 #-5:       (20)         7       G01 #-80.       (20)         8       G01 U10 #-56.       (20)         9       G01 #-15.       (10)         10       G00 X180 Z15.       (11)         11       H05.       (12)         12       H30.       (10)	0000] INSER1     000000 H00000       ORAM(S)       OENTER (P)       ZOOM+       ZOOM+       ZOOM+       ZOOM+       ZOOM+       ZOOM+       NIRROR TRACK       SNOW C       COMP       WORE
The drawing can be temporarily stop diagram;	oped by $\frac{9}{\text{STOP}(T)}$ soft button (or $T =$ button) during the
In the process of the path preview,	when the path exceeds its range, the diagram can be
displayed at the middle of the screen by	soft button (or <u>Fa</u> ).
The current diagram path can be elimir 2) Drawing speed selection	nated by clear soft button (or).
Enter to the next soft function menu k RAPID, COMMON or SPEED (The corresponding speed can be overridden with real-time duri	by MORE; the drawing speed can be controlled by SPEED, shortcut buttons are D, 1, 2 or 3); the ng the drawing.
3) Scaling up/down of path	
In the path preview page, the scalin performed by $\overbrace{20044}^{4}$ soft button (or $\overbrace{1}^{4}$ ), zoomed in $\sqrt{2}$ times by the $\overbrace{20044}^{4}$ ; the dia well the current scaling shows at its corresp <b>4)</b> The displayed movement of diagram is	ig up/down of the diagram path with real-time can be soft button (or $M_L$ ). The diagram path can be gram path can be zoomed out $1/\sqrt{2}$ times by zoom, as onding prompt column.
The diagram path movement can be c	arried out by cursor movement button in the path display
page. The movement interval can be adjust interval is then displayed at its correspondir 5) Mirror image path	ed by soft button (or JB); the current movement ag prompt column.
In the path preview page, the program	nming path and symmetric line of the programming path

(cutting command) will display by **MIRROR**; refer to the following figure:

EDIT	S0000 T0000
PROGRAM         ->         LOCAL         PROGRAM         [00000]         INSER1           1         650         X0         Z100;         .	COBBO NOBBO START CENTER (P) START CENTER 2004 FROGRAM TRACK SHOIL C SHOIL C
	₩ 19:35:53 WORE:::-
will be cancelled by $\frac{PROGRAM}{TRACK}$ soft button,	only the programming path is then drawr

#### 6) Display the cutter compensation C

TR

The

If the program in the cutter compensation C, and press the soft button; the programming path and the cutter compensation C path will display, and the cutter compensation C shows with red, refer to the following figure:



## 6.10.3 Command Display of Path Preview



(Single dotted-line): G00

(Double full-line): G01/G02/G03/G05/G122/G124/G144/G146

(Thread line): G32

(Symmetric line): Mirror image path symmetric axis

\_\_\_\_\_ (Single full-line): The connection cable of the cutting path and symmetric cables in the mirror image path.

Explanations:

(1) G28, G30: This section will not show if there is no intermediate point to be specified; if the intermediate point is specified in command, the drawing will be performed to the intermediate point, and part of the figure where from intermediate point to the mechanical zero will not be drawn;

(2) G50, G52-59 are denoted with coordinate systems, color: Green;

(3) M, S and T commands are shown by Yellow dot; the M30, M99, M00, M01 and M02 are not displayed near the note M, S, T and M codes;

(4) G31/G36/G37 are treated as G01;

(5) The path at the G17, G19 plane can not be regarded as the path preview;

(6) The writ of the system variable in the macro program does not register to the cutter compensation file; the read for the system variable, is the state, before entering to the program preview;

(7) Enter to the polar coordinate, cylinder interpolation, the graph is shown be Red;

If the polar coordinate and cylinder command are programmed in the G17 and G19 planes, at last, the graph is shown in the X, Z planes.

The difference between the displayed graph and the actual one of the programmed path are 90 degrees (The coordinate system of drawing can be consistent with the one of the programming by adjusting the data parameter No. 175 and pressing the [SHIFT] soft button). The example program (G17 panel) of the polar coordinate interpolation in this Manual can be illustrated as follows:



If the polar coordinate and the cylinder command are programmed in the G18 plane, but the eventual graph displays in the X, Y plane $_{\circ}$ 

The displayed graph and the programmed one are symmetric (The coordinate system and programming system based upon drawing can be consistent by adjusting the data parameter 175) to Z axis to describe the example program (G18 plane) in the cylinder interpolation; refer to the following figure:



### 6.10.4 Precautions

(1) The figure in the path preview is a schematic of the programming path, which is not absolutely equal that of actual workpiece;

(2) Path preview is mainly inspected whether the programming path is correct, regardless of the correction of the miscellaneous commands M, S and T.

# 6.11 Teaching function

Teaching is a programming method by the artificial guiding machining operation, GSK980TDi adds a teaching function, so that the teaching programming is more simply and efficient.

Select the Manual or MPG operation method and press the *multiple to enter the program page set*,

and then enter to the program content page by pressing **CONTENT** if necessary; the display is shown below:



Open the next optional menu by pressing the **CONTENT** again, refer to the following figure:

HND	S0000 T0000
PROGRAM -> LOCAL PROGRAM [00000]	00000 N0000 73
A RETURN MALICUL AND TOTAL TOTAL	EN 15526530 MORE
function page by	refer to the following figu

Enter to the Teaching function page by \_\_\_\_\_, refer to the following figure:

after controlling this button.





: Insert the current absolute coordinate (original value input state) or the sum (offset input state) of the absolute coordinate and offset value input for the corresponding axis at the cursor position.



. Shift the system to the retyping offset value when the absolute coordinate value along



E: Shift the system to state that only the absolute coordinate along each axis can be inserted;

simultaneously, it becomes differ controlling this button.

each axis is inserted; simultaneously, it becomes

EXIT: Retreat from Teaching mode.

# 6.12 Other Operations Available in Edit Mode

The operations by this GSK980TDi machine panel allowed in Edit mode are defined by ladders, please refer to the materials by the machine builder.

Please note that the following functions are described based on the 980TDi standard PLC programs!

W1009

- Spindle override can be adjusted by pressing
- 2) Feedrate override can be adjusted by pressing
- CNC can be reset by pressing key;
- 4) The operation mode is switched by pressing any of the keys among





- 5) The data transmission
- 6) Refer to II OPERATION, Chapter 12
- 7) Cooling control Refer to II Operation, Section 3.2.3
   2) Independent of a sector.
- 8) Lubricating control

Refer to II Operation, Section 3.2.4

- 9) Chuck control Refer to II Operation, Section 3.2.5
- 10) Tailstock control
- 11) Refer to II Operation, Section 3.2.6
- 12) Hydraulic control Refer to II Operation, Section 3.2.7



# CHAPTER 7 TOOL OFFSET AND SETTING

The actual location of tool can be overlooked in programming for simplifying programming. Three methods including positioning tool-setting, trial tool-setting and machine zero tool-setting are available in this GSK980TDi system. The tool offset data are obtained from this tool-setting operation.

## 7.1 Tool Positioning Setting

Steps:



- 1. Firstly determine if the offset values are zero in X, Z, if not, clear all the tool number offset values;
- Set the offset No. for 00 (i.e. T0100,T0300), as for the offset value: (method: execute a move code or perform the machine zero return in T0100 state, then clear the offset value automatically as returning to the machine zero);
- 3. Select a tool by random (usually the 1<sup>st</sup> tool, this tool will be used as the reference tool);
- 4. Position the tool nose of the reference tool to a point (tool-setting point), as shown in Fig. A;
- In PRG STATE page of the MDI mode, set up the workpiece coordinate system by the command G50 X\_ Z\_;
- 6. Clear the relative coordinate (U, W), see details in APPENDIX;
- 7. After the tool is moved to a safety height, select another tool and move it to the setting point, as shown in Fig. B;
- 8. Press key and move the cursor by 4, 4 key to select the corresponding offset number of that tool;
- 9. Press address key, then press key to input the tool offset value of X axis into the corresponding offset number;
- 10. Press address key , then press key to input the tool offset value of Z axis into the corresponding offset number;
- 11. Repeat the steps from 7 to 10 to perform the tool-setting operation for other tools.

Note: For the fixed tool-setting, the original system tool offset should be cleared, input the new offset one

time instead of many times by pressing . Refer to II OPERATION, Section 7.5.4 about the tool compensation clearing method.

# 7.2 Trial Tool-setting

Whether the method of trial tool-setting is inactive is defined by the system parameter No.012 Bit5.

Steps (workpiece coordinate system by part end surface):



- 1) Select a tool by random and make it cut on Surface A;
- 2) Retract the tool along X axis without Z axis moving and stop the spindle; directly press

and Z POS., and the CNC records the absolute values of the position, at the moment, directly move the tool;

Press key to enter the Offset interface, select the TOOL OFFSET page, then move

- 3) the cursor by pressing 4, 4 key to select the corresponding offset number;
- 4) Key in by sequence the address key  $\mathbb{Z}$ , number key  $\mathbb{D}$  and  $\mathbb{B}$  key;
- 5) Make the tool cut along Surface B;
- 6) Retract the tool along Z axis without the movement of X axis, and stop the spindle; directly press record and record, and the CNC records the absolute values of the position at the

press <u>ves.</u> and <u>ves.</u>, and the CNC records the absolute values of the position, at the moment, directly move the tool;

- 7) Measure the diameter " $\alpha$ " (supposing  $\alpha$ =15) ;
- 8) Press key to enter the Offset interface, select the TOOL OFFSET window, then move the cursor by pressing 1, where the select the corresponding offset number;
- 9) Key in the address key by sequence, number key 1, 5 and key
- 10) Move the tool to a safety height to change for another tool;



Note: The offset value may be large by this tool-setting method, so the tool compensation should be done by the coordinate offset by the CNC system. (set the BIT4 of the CNC parameter No.003 to 1). Moreover, the tool lengths compensation should be performed by using the T code in the 1st block, or the 1st move block should contain the T code for the tool length compensation.

# 7.3 Tool-Setting by Machine Zero Return

There is no reference tool in this tool-setting methods, when the tool is worn or to be adjusted, it only needs to be set again, and a machine zero return should be done before the tool-setting. The machining could be continued by performing a machine zero return at power on after power-off, which is very convenient for the operation.

Steps (workpiece coordinate system by part end surface):



- 1) Press key to enter Machine Zero mode, move axes to machine zero;
- 2) Select a tool by random and set the offset number of the tool to 00 (e.g. T0100, T0300) ;
- 3) Make the tool to cut on Surface A;
- 4) Retract the tool along X axis without the movement of Z axis, and stop the spindle; directly press RECORD and RECORD and RECORD and RECORD and the CNC records the absolute values of the position, at the

press  $\times$  POS. and 2 POS., and the CNC records the absolute values of the position, at the moment, directly move the tool;

5) Press key to enter the Offset interface, select the TOOL OFFSET window, then move

the cursor by pressing , key to select the corresponding offset number;

- 6) Key in by sequence the address key Z, number key D and Key to set the offset value of Z axis;
- 7) Make the tool cut along Surface B;
- 8) Retract the tool along Z axis without the movement of X axis, and stop the spindle;
- 9) Measure the distance " $\alpha$ "(supposing  $\alpha$ =15);
- 10) Press key to enter the Offset interface, select the TOOL OFFSET window, then move

the cursor by pressing  $\square$ ,  $\square$  to select the corresponding offset number;

- 11) Key in by sequence the address key , number key 1, 5 and key to set the offset value of X axis;
- 12) Move the tool to a safety height for tool change;
- 13) Change for another tool, and set the tool offset number to 00 (i.e. T0100, T0300);



- 14) Make the tool to cut on Surface A1;
- 15) Retract the tool along X axis without Z axis moving and stop the spindle; measure the distance "β1" between the Surface A1 and the workpiece coordinate system origin (supposing β1=1);
- 16) Press key to enter the Offset interface, select the TOOL OFFSET window, then move

the cursor by pressing (T),  $\forall$  to select the corresponding offset number;

- 17) Key in by sequence the address key Z, sign key in hyber key 1, and key to set Z offset value;
- 18) Make the tool to cut on Surface B1;
- 19) Retract the tool along Z axis without the movement of X axis, and stop the spindle;
- 20) Measure the distance " $\alpha$ 1" (supposing  $\alpha$ 1=10);
- 21) Press key to enter the Offset interface, select the TOOL OFFSET window, then move

the cursor by pressing  $\square$ ,  $\checkmark$  key to select the corresponding offset number;

- 22) Key in by sequence the address key , number key , and key to set X offset value;
- 23) Move the tool to a safety position;
- 24) Repeat the execution from Step 12 to Step 23 to perform the tool-setting operation for other tools.
- Note 1: Machine zero switch must be fixed for the tool-setting operation by machine zero return.
- Note 2: The workpiece coordinate system setting can't be done by G50 code after tool-setting by machine zero return.
- Note 3: The tool compensation should be done by coordinate offset by the CNC system (the system parameter No.003 Bit4 is set to 1), further more, the tool lengths compensation should be performed by using the T code in the 1st block, or the 1st move block should contain the T code for the tool length compensation.
- Note 4: The corresponding parameters should be set as follows: Bit7=0 of the system parameter No.004; Bit5=1 of the system parameter No.012; Bit7=1 of the system parameter No.012.
- Note 5: The setting values of the system parameter No.047 should be close to the absolute coordinate values of machine zero in workpiece coordinate system XOZ, as is shown in the following figure:
- As shown below:



Example: After machine zero returning, when the absolute coordinate of the tool in workpiece coordinate system is (a,b), the setting value of system parameter No.047 should be close to a,b.

# 7.4 Coordinates Record

When the trail-cut tool-setting or machine zero return tool-setting is executed, the coordinates record function can be used to get the convenient tool-setting operation.

When the tool-setting is executed and after the tool cuts along X (or Z), the following steps are executed to directly move the tool to the safety position as follows:

1) Press to enter the tool offset interface, and then press to enter the tool offset page as follows:

101	-> OFFSE	T & WEAR		00000	N0000	COORDINATES	Bin.
10.		X	Z	R	T		1
00	OFT	0.0000	0.0000	0.0000		[RELATIVE]	
00		Sector ad rates	and the state from the state	-	0		- Inter
<b>61</b>	OFT	5.0000	0.0000	0.0000		U 0.0000	REC
01	WEAR	0.0000	0.0000	0.0000	0		XF
0.0	OFT	0.0000	0.0000	0.0000		W 0.0000	DEC
0Z	WEAR	0.0000	0.0000	0.0000	0		ZF
00	OFT	0.0000	0.0000	5.0000	2		
03	WEAR	0.0000	0.0000	0.0000	3	Transferred	123
	OFT	0.0000	0.0000	0.0000		[ABSOLUTE]	-
04	WEAR	0.0000	0.0000	0.0000	0		
00	OFT	0.0000	0.0000	0.0000	0	X 0.0000	-
00	WEAR	0.0000	0.0000	0.0000	0		OF
00	OFT	0.0000	0.0000	0.0000	0	Z 0.0000	
90	WEAR	0.0000	0.0000	0.0000	0 -		12
				-		# 16:01:03	FIN
OFF	SET MACO	WAR IL OFF	SET USER-DE	LT TOOL	IEE	PREV.	NEX

2) Press x POS. and x POS. absolute corrdinates of X and Z(without including current tool offset values) are recorded in the CNC. After the absolute values are recorded correctly, there is a flash "Record coordinates" in the upper of the screen, and there is a prompt "Current X, Z Absolute coordinates have been recorded" in the bottom of the screen as follows:

001	-> OFFSE	I & WEAR		00001	N0000	COORDINATES	Bitter
NO.		X	Z	R	TA		IN
00	OFT	0.0000	0.0000	0.0000	0	[RECORD POS]	+ INP
01	OFT	5.0000	0.0000	0.0000	0	X 250.0000	CLEAN
02	OFT	0.0000 0.0000	0.0000 0.0000	0.0000	0	Z 450.0000	CLEAN
03	OF I WEAR	0.0000	0.0000	5.0000	3		CLR /
04	OFT	0.0000 0.0000	0.000.0 0000.0	0.0000.0	0	[ABSOLUTE]	-
05	OFT	0.0000 0.0000	0.0000.0 0000.0	0.0000 0.0000	0	X 250.0000	
06	OFT	0.0000 0.0000	0.0000.0 0.0000.0	0.0000	0	Z 450.0000	-Li
						11:47:47	FIND

3) Retract the tool to the safety position, and stop the spindle. When the diameter is measured for the outer circle and the distance from the reference plane to it is done, the measured

value is input in the tool offset page; the system counts the new tool offset value and sets it to the selected tool offset number according to the input value and the previous recorded absolute coordinates.

Use the following methods to clear the recorded coordinates when the above methods are used to execute the tool-setting:

- In the tool offset page, after the absolute coordinates are input in some tool offset(for 1) example: Z0 is input in the No.01 tool offset number) and then the axis moves, the recorded coordinates are cleared:
  - CLEAR Z RECORD CLR ALL RECORD
- Press\_RECORD in the tool offset page and the recorded coordinates are 2) cleared.
- 3)

## 7.5 Setting & Altering an Offset Value

Refer to Section 1.3.3 about methods of entering the offset setting page.

#### 7.5.1 Offset Setting

- key to enter the offset setting page, select the desired window by pressing the 1) Press
- 2) Move the cursor to the location of the tool offset, wear number to be input.

Scanning: Press to move the cursor in sequent Searching: use the following press keys to directly move the cursor to the input position:

> 4 + offset number + or **FIND(P)** and input the offset number in the Press

and the cursor directly positions the target offset pop-up dialogue box, press number.

3) Numerical value input.

Method 1: Input number after pressing the address button (the corresponding axis name

, etc.);
_,

INPUT soft button; Method 2: Input number after pressing the

4 and the CNC calculates the offset value automatically and displays the result in 3) Press the window. Its range:-9999.999~9999.999 (IS\_B) /-9999.9999~9999.9999 (IS\_C) (unit: mm)

#### 7.5.2 Offset Alteration

1) Refer to OPERATION, Section 7.5.1, and move the cursor to the location of the offset number that is to be altered:

2) If the offset value of X axis is to be altered, key in U; as for that of Z axis, key in W;

alternatively, select the data position to be changed by \_\_\_\_\_ soft button;

- 3) Then key in the incremental value;
- 4) Press isolated the current offset value to the value keyed in, the operation result will be displayed as a new offset value.

Example: The set X axis offset value is 5.678 The increment keyed in is U 1.5

Then the new offset value is 7.178 (=5.678+1.5)

## 7.5.3 Offset Alteration in Communication Mode

For the alteration and setting of the offset value in the communication, please see Chapter 12 of this part for its operations.

Note 1: While changing the offset value, the new offset value takes effect after the T code is executed.

Note 2: If the actual workpiece dimensions doesn't conforms to that of the part drawing, subtract the error from the original offset value for the oversize workpiece, add the error to the original offset value for the undersize workpiece.

Example: The external diameter of the workpiece to be machined is Φ55.382, and the No.01 offset value is applied in the machining. Before machining, the values in No.01 are shown as follows table:

No.	Х	Z	Т	R
00	0	0	0	0
01	16.380	-24.562	0	0

In machining, the actual external diameter measured of workpiece is  $\Phi$ 55.561, so the offset value of No.01 can be altered as follows table:

No.	X	Z	Т	R
00	0	0	0	0
01	( 16.201 )	-24.562	0	0

<sup>→ 16.380- ( 55.561-55.382 )</sup> 

Note: To backup and restore the tool offset values, the relevant operations may be performed on PC via communication.

## 7.5.4 Offset Values Clearing

- 1) Move the cursor to the offset number to be cleared;
- 2) When the offset value of X axis is to be cleared, is pressed, then is done, the offset will be cleared. Other axis clearing is done like that;
- Note: The offset clearing in the tool offset page doesn't mean that the system in under the state with no offsetting, if the system is needed to be in this state, the offsetting is required to be executed, which is shown as follows:

Execute a positioning command in T0100 state or perform a machine zero return. After the offsetting is

finished, the " $\Box\Box$ "in "T $\circ\circ\Box\Box$ " shown at the right bottom of the screen will not be backlighted.

### 7.5.5 Setting & Altering a Tool Wear

To prevent the mistaken operation of the setting and alteration of the offset value (decimal point missed, mislocated etc.), which may cause the tool collision by oversize offset value, for the visual judgement for the tool wear by the operator, the TOOL WEAR window is set in this GSK980TDi system. When the offset value is needed to be altered due to the inaccurate dimensions by the tool wear, it may set or alter the wear input value. The wearing value resolution is -9999.999-9999.999 (IS\_B) /-9999.9999-9999.9999 (IS\_C) (unit: mm); The upmost incremental value of each input value can be restricted to prevent the incorrect numerical value from inputting. The wear input range is defined by the data parameter No.140, and they are saved even at power down.

The setting and alteration methods for the tool wear are approximately identical to that of the tool offset, and the wear value is input by U(X axis), W(Z axis), V(Y axis).

## 7.5.6 Locking & Unlocking an Offset Value

In order to protect the offset value to be operated by mistaken, the offset values can be put into lock, the operation steps are as follows:

- 1) Move the cursor to the location of the offset number to be locked;
- 2) Press the event offset value will be backlighted for locking, which

is forbidden to alter, press the or the locking may be cancelled. No.1 tool offset is locked as follows:

101	-> OFFSE	I & WEAR		00001	N0000	COORDINATES	8
10.		X	Z	R	T		
00	OFT	0.0000	0.0000	0.0000	0	[RELATIVE]	
00			an single for all	-	0		
<b>5</b> 1	DET	5.0000	0.0000	0.0000		U 250.0000	RE
	WEAR	0.0000	0.0000	0.0000	0		X
20	OFT	0.0000	0.0000	0.0000		# 450.0000	00
02	WEAR	0.0000	0.0000	0.0000	0		Z
10	OFT	0.0000	0.0000	5.0000	2		
93	WEAR	0.0000	0.0000	0.0000	•		
	OFT	0.0000	0.0000	0.0000		[ABSOLUTE]	-
24	WEAR	0.0000	0.0000	0.0000			
20	OFT	0.0000	0.0000	0.0000	0	X 250.0000	-
0	WEAR	0.0000	0.0000	0.0000	0		10
	OFT	0.0000	0.0000	0.0000	0	Z 450.0000	
0	WEAR	0.0000	0.0000	0.0000	0		1
	-	-	-			# 13:37:59	FI

Note: The tool wear values can't be locked.

# 7.5.7 No.0 Tool Offset Moving Workpiece Coordinate System

When No.012 Bit 6 is set to 1, No. 0 tool offset moving workpiece coordinate system is valid.

After the value is input in No. 0 tool offset, the workpiece coordinate system executes the offset based on the input value.

001	-> OFFS	ET & WEAR		00001	N0000	COORDINATES	Pres an
NO.		X	Z	R	TA		IN
00	OFT	0.0000	0.0000	0.0000	0	[RELATIVE]	+ 1NP
			and a sector of		-		
01	OFT	5.0000	0.0000	0.0000	0	U 250.0000	RECO
~	WEAR	0.0000	0.0000	0.0000	100		X PC
02	OFT	0.0000	0.0000	0.000	0	# 450.0000	RECO
10	WEAR	0.0000	0.0000	0.0000			Z PC
83	OFI	0.0000	0.0000	5.0000	3		In
	WEAR	0.0000	0.0000	0.0000		CARGON LITE?	
84	OFT	0.0000	0.0000	0.0000	0	LABSOLUTET	-
-	WEAR	0.0000	0.0000	0.000	•	0000 070 V	
85	OFT	0.0000	0.0000	0.0000	0	X 250.0000	-
00	WEAR	0.0000	0.0000	0.0000		-	UFF
06	OFT	0.0000	0.0000	0.0000	0	2 450.0000	L
00	WEAR	0.0000	0.0000	0.0000			1
OFF	SET MAC		e inputti	TOOL-	.0 to	ol offset	PAGE
OFF SWE	AR MAC	RO VAR.	FSET USER-DI MACRO e inputtin	ng No	.0 to		PAGE
	SET MAC	RO VAR.	FSET USER-DI MACRO	ng No	.0 to	ol offset	PAGE
	SET MAC	RO VAR.	FSET USER-DI MACRO	var tool- ng No 00001	.0 to	OI Offset S0000 TI	DODO
	SET MAC	RO VAR. E CO Before Et & WEAR	FSET USER-DI MACRO e inputtin z	TODE- NG NO 00001 R	.0 to	OI Offset S0000 TI	DODO
OFF SWE	SET MAC	RO VAR. ECO Before EL & HEAR X 100.0000	rset user-or MacRo e inputtin 7 100.0000	TODL- TO	LIFE .0 to N0000 T 2 0	COORDINATES	
OFF SWE	AR MAC	RO VAR. 15 00 Before 1 & HEAR X 100.0000 5.0000	Z 100.0000 0 0000	TODL- TO	LIFE .0 to N0000 T	COORDINATES	
OFF SWE DOI NO. 00	DI OFT WEAR	RO VAR. 1500 Before 1 & HEAR X 100.0000 5.0000 0.0000	F3ET USER-DI MACRO e inputtin 7 100.0000 0.0000	TODE- TO	LIFE .0 to N0000 T 0 0	COORDINATES	
OFF SWE	SET MAC	RO VAR. E CO Before Et & WEAR X 108.0000 9.0000 9.0000	FSET USER-DI MACRO P INPUTTI 7 100.0000 0.0000 0.0000 0.0000	ELT VAR TOOL	.0 to	CORDINATES	PAGE BBBBB PIN INF RECC X PC
0000 800 000 000 001 002	SET MAC	RO VAR. 1 C OF Before X 100.0000 0.0000 0.0000 0.0000 0.0000	FSET USER-DI MACRO P INPUTTION 7 100.0000 0.0000 0.0000 0.0000 0.0000	TODE - TODE - TO	LIFE .0 to N0000 T 0 0 0	COROTINATES	NEXT PAGE
00000000000000000000000000000000000000	SET MAC	RO VAR. 11 00 Before 10.0000 0.0000 0.0000 0.0000 0.0000 0.0000	Z         User-Di MACRO           2         inputtin           7         100.0000           0.0000         0.0000           0.0000         0.0000           0.0000         0.0000	TODE - TODE - TO	LIFE .0 to N00000 T 0 0	COORDINATES	NEXT PAGE
0000 800 000 001 002 003	SET MAC	R0 VAR. LE 00 Before I & HEAR X 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	Z         User-Di MACRO           0         inputtin           0         0000           0         0000           0         0000           0         0000           0         0000           0         0000           0         0000	LT         TOOL -           NO         00001           R         0.0000           0.0000         0.0000           0.0000         0.0000           0.0000         0.0000           0.0000         0.0000           0.0000         0.0000	LIFE .0 to N00000 T 0 0 0 3	COORDINATES	DDDD PAGE DDDD *1NF RECC X PC RECC
0011 002 003	SET MAC	RO VAR. LE 00 Before X 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	FSET USER-DI MACRO P INPUTTION 7 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	LT         TOOL -           NO         000001           R         0.00000           0.00000         0.00000           0.00000         0.00000           0.00000         0.00000           0.00000         0.00000           0.00000         0.00000	LIFE .0 to N00000 T 0 0 0 3	CORDINATES	DDDD PAGE DDDD PAGE DDDD PAGE IN IN IN RECC X PC RECC X PC
001 200 000 001 002 003 004	SET MAC	RO VAR. E CO Before X 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	FSET USER-DI MACRO P INPUTTION 7 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	CO0001 R 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	LIFE .0 to N00001 T 0 0 3 0	CORDINATES	BBBBB BBBBB *1NF RECC Z PC
001 800 001 002 003 004	SET MAC	RO VAR. E C Before X 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	FSET USER-DI MACRO E INPUTTIO 7 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	LT TOOL - TOOL - TOO	.0 to .0 to .0 to .0 .0 .0 .0 .0 .0 .0 .0 .0 .0	CORDINATES (RELATIVE) U 350.0000 W 550.0000 (ABSOLUTE) X 350.0000	NEXT PAGE BBBBB IN +INP RECO X PD RECO
001 001 002 003 004 005	SET MAC	RO VAR. E C Before X 100,0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	FSET USER-DI MACRO P INPUTTION 7 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	VAR TOOL - TO A COULT TO A COULT R 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000000	LIFE .0 to N0000 T 0 0 0 3 0 0 0	COROLINATES U 350.0000 (ABSOLUTE) X 350.0000	
001 NO. 00 01 02 03 04 05	SET MAC	RO VAR. 11.00 Before 1 & HEAR X 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	FSET USER-DI MACRO E INPUTTION 100.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000 0.0000	TOOL -           TOOL -           NO           Openal           R           0.0000	LIFE .0 to N09999 T 2 0 0 0 3 0 0 0 0 0 0 0	■ PACE       ■         OI Offset       SDDDD TI         CORDINATES       ■         U 350.0000       ■         W 550.0000       ■         (ABSOLUTE)       ×         X 350.0000       ≥         Z 550.0000       ≥	
001 002 03 04 05 06	SET MAC	RO VAR. 11 00 Before 1 4 HEAR X 100.0000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000 0.00000000	Z         User-Di MACRO           2         Inputtin           100.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0           0.0000         0	TOOL -           O00011           R           0.00001           0.00001           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000           0.0000	LIFE	COORDINATES COORDINATES (RELATIVE) U 350.0000 W 550.0000 (ABSOLUTE) X 350.0000 Z 550.0000	RECO X POLICE

After inputting No.0 tool offset

As the above figure, after X100, Z100 in No.0 tool offset is input, the workpiece coordinate system offsets X100, Z100.

Note: When No. 0 offset modification is valid real-time, No. 0 tool offset must be set before the system runs a program, otherwise, the run path will offset.

# 7.6 High Efficiency Tool-Change

### 7.6.1 Breif

When the tool operation is performed during the program machining; usually, the steps are shown below:

- 1) Return to the specified safety tool-change position by program from the current position;
- 2) Perform the tool-change operation and waiting for the completion of the tool-change;
- 3) Return to the cutting position from safety tool-change position;

The tool-change safety area is set by machine operator before the machining is performed (that is, the area, without any impact to the workpiece, when the tool-post rotates a circle); Tool returns to the safety tool-change position specified by program from the current position. Tool is immediately performed the tool-change operation as long as it enters to the tool-change safety area when the tool-change operation is performed; that is, the step 1 and 2 in the above-mentioned combines a completion motion, so that it can be reached to the high-efficiency tool-change. It is better to set the Bit 7 of the state parameter to "1".

# 7.6.2 Tool-Change Safety Area Setting

When the desired tools for program machining are totally installed, in the case that the spindle clamps the workpiece blank, the area, without any impact for one cycle of the tool-post rotation, is called as the tool-change safety area; refer to the following figure:



The coordinate of point A in the figure is (Px, Pz), the tool-change safety area is X > Px or Z > Pz; the tool will not collide with workpiece as long as the tool-change is performed in this safety area. To carry out the high-efficiency tool-change in the actual machining, the machine operator should be performed within the safety area setting based upon the following steps:

1) In the absolute coordinate page, press soft key, refer to the following figure:



2) Press the setting soft key, the tool-change safety point setting information window is shown and covered the integrated information window. It will show a unset state when X or Z axis does not set; it will show the coordinate value of setting when X or Z is set. The initial state is as follows:



3) Manually move the tool-post at the side of + X of the workpiece, and the optimized position of the impact will not occur when the tool-change executes at this side; record the X axis coordinate

at this position by pressing the SETTING; refer to the following figure:



4) Manually move the tool-post at the side of + Z on the surface of the workpiece, and the optimized position of the impact will not occur when the tool-change executes at this side; record

the Z axis coordinate at this position by pressing the Z axis; refer to the following figure:



In the above-mentioned interface, shift the interface or press the small window of "Tool-change safety point setting", this area recovers and displays the small

window of the "Integral information"

The high-efficiency tool-change function can be enabled after the X and Z are set; the setting value at the tool-change safety area is memorized after the power is turned off. After the high efficiency tool-change is enabled, the tool mark is then shown at the right corner of the page "—". Note: The record in the setting of the tool-change safety point is the machine coordinate.

# 7.6.3 Setting Clear in Tool-Change Safety Area

The setting value of the set tool-change safety area can be eliminated by the following methods:

1) The set data along with the X or Z can be eliminated by soft button or difference of the tool-change safety point setting window is shown;



2) The setting data set by X or Z axis on the tool-change safety area will be automatically eliminated after the G50 command sets the coordinate system;

3) The setting data set by X or Z axis on the tool-change safety area will be automatically eliminated after the machine zero return is operated;

4) On the tool offset page, if the tool-setting operation is performed by the measure input method or trial cutting tool-setting method; the current tool is regarded as to be changed; the setting data set by its corresponding data on the tool-change safety area will be automatically eliminated.

# 7.6.4 High-Efficiency Too-Change Programming Format

In order to realize the high-efficiency tool-change, user should use the shared programming format both the positioning G code and Tool-change T code when the machining procedure is programmed.

G00 X\_ Z\_ T\_ or

G01 X\_ Z\_ T\_

T code is performed sharing a same block with G00 or G01 code, simultaneously, the T code is performed while the positioning code executes; and then deliver the tool-change strobe signal TF to PLC. When the plate moves to the tool-change safety area, CNC delivers the tool-change allowable signal TCEN. PLC program triggers the tool-change operation by identifying the tool strobe signal TF and tool-change allowable signal TCEN. Refer to the following signal output time of high-efficiency tool-change:



When T code does not share a same block with the movement code, simultaneously output tool strobe signal TF and tool-change allowable signal TCEN when T code is performed.

# 7.6.5 High-Efficiency Tool-Change Procedure Explanation

Firstly, set the tool-change safety area before using this function. If the tool is installed again or the raw-material dimension is changed during using this function, the safety area should be set again. For example:

i ui example.

G00 X100 Z100 T0404;

#### ...

. . .

The tool-change motion and carriage plate positioning are performed as follows:



## 7.6.6 Precaution of High-Efficiency Tool-Change

- 1) When the tool-change code does not performed with a same block to the axis positioning code; the tool-change allowable signal will be output before performing the tool-change;
- 2) When the tool-change code and axis positioning code (G00 or G01) are performed based upon a same block; the tool-change allowable signal TCEN output after the carriage plate enters to the safety area. When the tool-change code and other movement codes are performed with a same block; the tool-change allowable signal TCEN outputs after the movement ends;

- 3) When the high-efficiency tool-change is performed, It is necessary to prevent the tool rotation from impacting to other machine components during that the plate moves to the tool-change point within the tool-change safety area;;
- 4) High-efficiency tool-change function is suitable for the tool-change safety detection within the XZ panel, if additional axes are placed at the machine tool, it is necessary to confirm that tool-change will not interfere to other additional axes when programming.
  - Note: The high-efficiency tool-change function will disable after performing G50 command or mechanical zero point return, as well the tool-setting operation in measure input method is performed; the high-efficiency tool-change function can be enabled after resetting the tool-change safety area operation.



# CHAPTER 8 COORDINATE SYSTEM

GSK980TDi owns workpiece coordinate system selection function, which can be contented several workpiece coordinate system during the machining; specifying one of the G54~G59 code in the block can be selected in the workpiece coordinate systems 1~6.

## 8.1 Coordinate System Setting



## 8.1.1 Directly Input

Enter to the workpiece coordinate system page, press  $\land$  Move the cursor to the inputted position, input the numerical value by the number buttons, and then directly input the

numerical value by the button.

EDIT			S0000 T	101
OFFSET -> WORKP	IECE COORDINATE :	SYSTEM		MEAS INPUT
EXT OFFSET	G54 COORD.	G55 COORD.	[RELATIVE]	+ INPUT
X 100.12	X 0.0000	X 0.0000	U 248.6352	CLEAR
Z 0.0000	Z 0.0000	Z 0,0000	# 448.6352	INPUT MACH, COORD
G56 COORD.	G57 COORD.	G58 COORD.	[DIST TO GO]	_
X 0.0000	0.0000 X	X 0.0000	X 0.0000	_
Z 0.0000	Z 0.0000	Z 0.0000	Z 0.0000	
		12	15:54:04	
AWEAR MACRO	VAR. CD.	SER-DFLT IACRO VAR TOOL-LIFE	PREV	PAGE

#### 8.1.2 Measure Input

CNC automatically calculates the data such as the cutter compensation or zero offset, etc. when using the measure input, so that the input data becomes the absolute coordinate of the new coordinate system at the machine's current position.

台 々 Move the cursor to the inputted position, input the coordinate Method 1: Press or value after pressing the INPUT soft button, the CNC will automatically calculate to input the data by

controlling the

button;

↑ or ↓, key Method 2: Move the cursor to the selected coordinate system by pressing Z CNC automatically calculates and then inputs the coordinate value by address button or

the data by

FSET -> WORKP	IECE COORDINATE :	SYSTEM	COORDINATES	Bie
	1	F	-	IN
EXT OFFSET	G54 COORD.	G55 COORD.	[RELATIVE]	+IN
X 0.0000	X 0.0000	X 0.0000	U 248.6352	CLE
Z 0.0000	Z 0.0000	Z 0.0000	# 448.6352	INP MACI COOI
G56 COORD.	657 COORD.	658 COORD.	[DIST TO GO]	-
x 0.0000	X 0.0000	X 0.0000	X 0.0000	-
Z 0.0000	Z 0.0000	Z 0.0000	Z 0.0000	
ASUREMENT INPL	JT: X100.0101_			

Note: The input data from measure will become the absolute coordinate of which the current point locates at the setting coordinate system, for example:

System executes G54 command, input X100; Z100 in G54 coordinate system by measure input method. CNC automatically calculates the G54 offset value, so that the absolute coordinate at the current position will become X100; Z100.

#### Machine Tool Coordinate Record 8.1.3

Enter to the workpiece coordinate system setting page, move the cursor to the inputted position

directly input the machine tool coordinate by soft button.

#### **Coordinate System Modification** 8.2

Enter to the workpiece coordinate system setting page, press move the cursor to the

+INPUT

+INPUT data position to be modified; input the incremental value by the soft button press add the current workpiece coordinate system offset value and the inputted incremental value, and its result will show as a new workpiece coordinate system offset value.

FFSET -> WORKP	IECE COORDINATE :	SYSTEM	COORDINATES	Big
				_1
EXT OFFSET	G54 COORD.	G55 COORD.	LRELATIVE	-11
X 0.0000	X 0.0000	X 0.0000	U 248.6352	CL
Z 0.0000	Z 0.0000	Z 0,0000	₩ 448.6352	IN MA CO
G56 COORD.	657 COORD.	658 COORD.	[DIST TO GO]	
X 0.0000	X 0.0000	X 0.0000	X 0.0000	-
Z 0.0000	Z 0.0000	Z 0.0000	Z 0.0000	
INPUT: 0.0101_			15-55-0	7

# 8.3 Coordinate System Clearing

Enter to the workpiece coordinate system setting page; the overall workpiece coordinate offset

values will clear after the confirmation by pressing the directly input method of the workpiece coordinate system in this chapter to set the axis offset value of any coordinate system as "0".



# CHAPTER 9 AUTO OPERATION

#### Note !

The key functions of GSK980TDi machine panel are defined by PLC program (ladders), please refer to the materials by the machine builder for their significance.

Please note that the following description for the keys function in this chapter is based on GSK980TDi standard PLC program!

### 9.1 Automatic Run

9.1.1 Selection of a Program Running

Refer to Section 6.3.

## 9.1.2 Start of Automatic Run

1. Press is to select the Auto mode;

2. Press to start the program, and the program automatically runs.

Note: Since the program execution begins from the block where the cursor locates, before pressing the

, make a check whether the cursor is located at the block to be executed.

### 9.1.3 Stop of Automatic Run

#### • Stop by code (M00)

1. M00

After the block containing M00 is executed, the auto run is stopped. So the modal function and

state are all reserved. Press the is or the external run key, the program execution continues.

2. M01

Press and the optional stop indicator is ON and the function is valid. After the block with M01 is executed, the system stops the automatic run, the modal function and the state are saved.

Press with or the external run key, and the program continuously runs.

#### • Stop by a relevant key

1. In Auto run, by pressing is or external pause key, the machine keeps the following state:

- (1) The machine feed slows down to stop;
- (2) The modal function and state are reserved;

- (3) The program execution continues after pressing the key.
- 2. Stop by Reset key
- (1) All axes movement is stopped.
- (2) M, S function output is inactive (the automatic cut-off of signals such as spindle CCW/CW,

Iubricating, cooling by pressing *key* can be set by the parameters)

(3) Modal function and state is held on after the auto run.

#### 3. Stop by Emergency stop button

If the external emergency button (external emergency signal active) is pressed under the dangerous or emergent situation during the machine running, the CNC system enters into emergency state, and the machine moving is stopped immediately, all the output (such as spindle rotation, cooling) are all cut off. If the Emergency button is released, the alarm is cancelled and CNC system enters into reset mode.

#### 4. Switching operation mode

When Auto mode is switched to the Machine zero, MPG/Step, Manual, Program zero mode, the current block "dwells" immediately; when the Auto mode is switched to the Edit, MDI mode in Auto mode, the "dwell" is not displayed till the current block is executed.

- Note 1: Ensure that the fault has been resolved before cancelling the emergency alarm.
- Note 2: The electric shock to the device may be decreased by pressing the Emergency button before power on and off.
- Note 3: The Machine zero return operation should be performed again after the emergency alarm is cancelled to ensure the correctness of the position coordinates (but this operation is forbidden if there is no machine zero in the machine).
- Note 4: Only the BIT3 (MESP) of the bit parameter No.172 is set to 0, could the external emergency stop be active.

# 9.1.4 Automatic Run From an Arbitrary Block

Press

key to enter the Edit mode, press key to enter the program content page;

1) Move the cursor to the block to be executed (for example, move the cursor to the 3<sup>rd</sup> row head if it executes from the 3<sup>rd</sup> row);



2) If the mode (G, M, T, F code) of the current block where the cursor locates is defaulted and inconsistent with the running mode of this block, the corresponding modal function should be

executed to continue next step.

3)



key to enter the Auto mode, then press key to start the execution. Press

#### Adjustment of Feedrate & Rapid Rate 9.1.5

In Auto mode, the running speed can be changed by adjusting the feedrate override, rapid override. It doesn't need to change the settings of the program and parameter.

#### Adjustment of the feedrate override



16-level real time feedrate can be obtained.

Note 1: The actual feedrate value is specified by F in feedrate override adjustment;

Note 2: Actual feedrate= value specified by Fx feedrate override

#### Adjustment of rapid override

It can realize the F0, 25%, 50%, 100% 4-level real time rapid override adjustment by

Л X100 Л 50% Л X1000 **几 X10** 10 25% pressing MFO

Note 1: The rapid traverse speeds of X, Z axis are set by the system parameter No.022, No.023 X axis actual rapid traverse rate = value set by parameter No.022X×rapid override Z axis actual rapid traverse rate = value set by parameter No.022Z×rapid override

Note 2: When the rapid override is F0, the min. rapid traverse rate is set by bit parameter No.032.

#### Spindle Speed Adjustment 9.1.6

While the spindle speed is controlled by the analog voltage output in Auto mode, it can be adjusted by spindle override.

to adjust the spindle override for the spindle speed, it can realize 8-level Press some real-time override adjustment between 50%~120%.

Note : The actual output analog voltage = analog voltage by parameter × spindle override.

## 9.2 Running State

#### 9.2.1 Single Block Execution

When a program is executed firstly, the system selects the single block run mode to avoid the program error to cause the unexpected.

to select the single block run function in Auto mode; in single block mode, after the Press

current block is executed, the CNC stops run; press it to execute the next block. Such repetition is executed till the program is done.

Note 1: The single block stops at the mid point of G28 code.

- Note 2: For the single block state in the execution of canned cycle codes G90, G92, G94, G70 ~ G76, refer to the 1st part PROGRAMMING.
- Note 3: While the subprogram calling (M98 ), or subprogram calling return (M99) is being executed, the single block is inactive. But it is active except for N, O, P addresses in the block that contains M98 or M99 code.
# 9.2.2 Dry Run

Before the program is to be executed automatically, in order to avoid the programming errors, it may select the Dry run mode to check the program.

In Auto mode, press it to enter the dry run state; in Dry run state, the machine feed and miscellaneous functions are both active (as machine lock, MST lock are both OFF), that means the dry run switch has nothing to do with the machine feeding, MST functions, so the feedrate by program is inactive and the CNC system runs at the speed described in the following table:

	Program comm	nand
	Rapid traverse	Cutting feed
Rapid traverse switch ON	Rapid traverse	Max. manual feedrate
Rapid traverse switch OFF	Manual feedrate or rapid traverse(see note)	Manual feedrate

Note 1: The rate by manual feedrate or rapid rate is set by the BIT6 of the CNC system parameter No.004.

- Note 2: The shift of rapid switch in Dry run mode doesn't affect the rate of the current block being executed, but that of the next block.
- Note 3: The switch operation of Dry run is inactive if the ladder of this GSK980TDi is defined to be in auto running state (Auto, MDI mode).

### 9.2.3 Machine Lock

In Auto mode, press is to enter the machine lock; the machine lock and MST lock are usually used together to check the program. While the machine is in the lock run state:

- 1. The machine carriage doesn't move, the "MACHINE" in the INTEGRATED POS window of the Position interface doesn't vary too. The RELATIVE POS and ABSOLUTE POS, DIST TO GO are refreshed continuously, which is the same as that the machine lock switch is OFF.
- 2. M, S, T commands can be executed normally.

3. Press the system operation panel to close the machine lock; the system is then automatically recovered the absolute coordinate value along each axis; that is, the coordinate system automatically restores.

### **Precautions:**

- 1) The machine lock open/close system automatically restores the absolute/relative coordinate along each axis;
- The tool state is regardless of the automatic recovery of the workpiece coordinate system before/after the machine lock. For example, the tool state before the machine lock is T0101; after is T0202;
- The state of the cutter compensation C is regardless of the automatic recovery of the workpiece coordinate system before/after the machine lock. For example, the state of the cutter compensation C before the machine lock is G40; after is G42;
- 4) The system ON-OFF state is regardless of the automatic recovery of the workpiece coordinate before/after the machine lock. For example, the machine is locked before the power-off; the system can be automatically restored the workpiece coordinate system after the power is turned on again.

5) To avoid the tool interval motion during the automatic operation, it is better not to change the state of the machine tool after starting the program;

### 9.2.4 MST Lock

In Auto mode, press to enter the miscellaneous function lock state; The machine carriage moves without the M, S, T code being executed. The machine lock and MST lock are usually used together to check the program.

Note: When the MST lock is active, it takes no effect to the execution of M00, M29, M30, M98, M99.

# 9.2.5 Block Skip

When a block in program is not needed to be executed and not to be deleted, this block skip function can be used. When the block is headed with "/" sign and Block skip indicator lights up (panel key active or external skip input active), this block is skipped without execution in Auto mode. In Auto

mode, press is valid.

Note: While the block skip switch is off, the blocks headed with "/" signs are executed normally in Auto mode.

# 9.3 MPG Trial-Cut

The user can use MPG trial-cut function after editing part programs, check the run path of program. In MPG trial-cut function, rotating MPG controls the execution speed of program, which can easily check the program error conveniently.

### 9.3.1 Switching MPG Trial-cut Mode

Press to enter the MPG trial-cut mode after a machinig program is selected as follows:



At the moment, press and the display is shown below:



At the moment, rotating MPG makes the program start running. When the execution speed of program is proportional to MPG speed, execution speed of program fastens as soon as the MPG rapidly rotates; the execution speed slows down as soon as the MPG slowly rotates. Movement amount of one pulse can be adjusted by rapid override.

When the system is in the MPG trial-cut mode, it returns to Auto mode after is pressed. All operations in MPG trial-cut mode are the same those of Auto mode.

# 9.3.2 Command Speed in MPG Trial-Cut Mode

#### 1) Cutting feedrate

Cutting command speed in MPG trial-cut mode is determined by No. 241 and rapid override. The command speed during actually rotating MPG is executed by the following:

[Command speed]×[MPG pulse amount per 1 second]× $\lambda$ ×([the parameter setting value] /100) × (8/1000) (mm/min or inch/min).

 $\lambda$  value is determined by the current rapid override, and their relationship is:

Rapid override	λ value	Rapid override	λ value
F0	1	25%	10
50%	100	100%	100

Rapid traverse speed is clamped at 100% speed when it exceeds 100%, i.e.:

[MPG pulse amount per 1 second]×λ×([No.241setting value]/100)×(8/1000)≤1

2) Rapid traverse speed

Rapid traverse speed is clamped at the speed set by No.240, i.e.:

[Rapid traverse speed]=[rapid traverse speed of each axis]×([No.240 setting value]/100)× [MPG pulse amount per 1 second]× $\lambda$ ×([No.241 setting value]/100)×(8/1000)

At the moment, when the speed by rapidly rotating MPG exceeds the clamped, the rapid traverse speed is clamped at the setting value by parameter, i.e.:

[MPG pulse amount per 1 second]× $\lambda$ ×([No.241 setting value]/100)×(8/1000) ≤1

### 9.3.3 Notes in MPG Trial-Cut Mode

Pay more attention to the followings when the system is in MPG trial-cut mode:

1) Press in Auto mode and the CNC does not switch to MPG trial-cut mode; when the CNC is in MPG trial-cut mode, it escapes the MPG trial-cut mode from the next block by

pressing the mode switch key;

- 2) When the system executes the MPG trial-cut control, the single block signal and the feed hold signal are valid. When the single block or feed hold stops, the program execution state is recovered to the MPG trial-cut control after the cycle start key is pressed.
- 3) Execution speed of blocks for movement and pause can be controlled by rotating MPG. Their speed of blocks with M, S, T, F, i.e. without movement or pause cannot be controlled(except for executing the tool offset in traverse mode) by rotating MPG which only controls whether they are executed.
- 4) The spindle speed is not related to the MPG pulse. The spindle rotates with the commanded speed even if the system is in the MPG trial-cut mode. For feed per rotation, reading the current spindle speed is switched to the execution after feed per minute.

# 9.3.4 Temporarily Invalid in MPG Trial-cut Mode

1) Executing screw cutting commands

In the course of executing screw cutting blocks (G32, G32.1, G33, G34, G76, G84, G88, G92, G92.1), the MPG trial-cut function is temporarily invalid with the speed under the override 100%, and is valid in the next block again. The MPG control is invalid when the screw cutting is executed actually, and it is valid in others.

2) Executing from the middle point to machine zero

In the course of executing the block (G28, G30) from the middle point to machine, the MPG trial cutting function is enabled from the start to intermediate point, and the MPG trial cutting is temporarily disabled from intermediate point to mechanical zero. The block is executed with the speed under the override 100%, and the next block is valid again.

3) Measuring related G commands execution with the override 100%

When the system measures the related G commands, the MPG trial-cut is invalid temporarily, is executed with the speed under the override 100%, at the moment, execution of the next block is valid again. The related G commands include:

G31, G36, G37

# 9.4 MPG Interrupted Function

In the Auto (Auto, MDI) and Edit mode, In the Auto (Auto, MDI) and Edit mode, the movement value from MPG can be overlapped to the Auto movement by rotating the MPG. The axis performed the MPG interruption can be selected by the MPG interruption axis selection signal. The movement distance of the MPG interruption is determined by the rotation value of the MPG and hand-wheel federate.

Note : It is necessary to set the Bit 1 of parameter No.0012 to "1" when using the MPG interruption function, it is necessary to support by dedicated PLC program.

### 9.4.1 MPG Interrupted Operation

In the Auto, MDI and Edit mode, enter to the MPG interruption state to perform the MPG based upon the MPG axle number on the selection panel after controlling the [MPG interruption switch] (External switch) once; retreat from the MPG interruption by pressing the [MPG interruption switch] again.



Perform the axle selection by <u>Market</u>, <u>Marke</u>

The velocity during the MPG interruption is the sum both in the Auto operation and MPG interruption movement, and its overlapping speed is controlled within the upper limit speed of the cutting feed. For example, cutting upper limit is 8000mm/min, if the current feedrate is 2000mm/min, the MPG interruption speed range is -10000~6000mm/min ("-" means that the MPG interruption movement direction is reverse to the feed one).

Related parameter

K0019.4	MPG interruption function 0: Disabled 1: Enabled
K0019.5	MPG interruption operation 0: Disabled 1: Enabled

# 9.4.2 Affection of Coordinate System from MPG Interruption

Axis moves by MPG interruption, and the actual position of the movement axis changes, the machine coordinate is renewed instead of the absolute coordinate. Therefore, machine moves after the MPG interrupts, and the machine coordinate system holds, but the workpiece coordinate system will offset.

- Absolute coordinate → Absolute coordinate value will not change due to the MPG interruption.
- Relative coordinate  $\rightarrow$  Due to the MPG interruption, Interrupted amount change.
- Mechanical coordinate  $\rightarrow$  Due to the MPG interruption, interrupted amount change.



When automatically returning the reference point (G28), although the end (reference point) does not affect by MPG interruption, the intermediate point may generate the offset of interruption value by the MPG interruption at the workpiece coordinate system

# 9.4.3 MPG Interruption Value Cancel

The cancellation of the MPG interruption value can be returned the workpiece coordinate system after offset to the one before offset.

When the cancellation operation of the interruption value is performed, the MPG interruption value reflects to the absolute coordinate value.

The workpiece coordinate system offset generated from MPG interruption is shown below:



The workpiece coordinate system recovers to the state before interruption after the MPG interruption is cancelled, however, the actual position is invariable, refer to the following figure:



The interruption value can be cancelled base upon the following situations:

- Reset, EMS (Set whether it is cancelled by parameter).
- Perform G28 or Manual return reference point operation. (When the absolute coordinate system is set after returning to the reference position, the interruption value will be directly eliminated regardless of the new-created absolute coordinate system. When the absolute coordinate system does not set after returning to the reference position, the workpiece system will recover to the previous state of the interruption, simultaneously, the interruption value is then eliminated).

- When the non-block reference point set is performed. (The treatment is consistent with the manual reference point return)
- When performing the G50 workpiece coordinate system setting. (In this case, the workpiece coordinate is one by G50, simultaneously, the interruption value is eliminated)
- System restarts. The MPG interruption value will be also cleared after the system is power off, but the workpiece coordinate system holds, and therefore, the system is turned off after the MPG interrupt, the workpiece coordinate offset generated in the MPG interruption will always enabled, and it can not recover to the previous state of interruption.)

# 9.4.4 MPG Interruption Display Page

The Bit 1 of state parameter No.0012 should be set to "1" before using the MPG interruption function, and then lead in the dedicated PLC program;

Press the soft function button to enter its corresponding page after controlling the

INTERRUPT button, refer to the following figure:

MDI		S0000 T01	01
HANDLE INTERRUPTION	00000 N0000	MODAL INFORMATION	INTERRU
[INPUT UNIT] X 0.0000 mm	[OUTPUT UNIT] X 0.0000 mm	600 697 698 621 640 623 667 654 664 618 615 613.1 N00 80000 L0	CLR TNTERRU AMOUNT CLR
Z 0.0000 mm	Z 0.0000 mm	F 0.0000 mm/min 200 mm/min	
		MAIN INFORMATION	-
[RELATIVE]	[0151 10 60]	JOG.F 1260	
U 248.6352	X 0.0000	FED OVR1     100%       RAP OVR1     100%	
448.6352	Z 0.0000	SPI OVRI 100% PART CNT 3	
		CUT TIME 00:22:00	
	The second	15:21:47	
ABS	HANDLE INTERRUPT		

The following 4 data can be simultaneously displayed at the MPG interruption display page: 1) Input unit:

The MPG interruption movement value in the input unit means the specified movement value of MPG interruption based upon its least input command unit.

2) Output unit:

The MPG interruption movement value in the output unit means the specified movement value of MPG interruption based upon its least output movement unit.

3) Relative coordinate:

The position at the relative coordinate system and the position of the current relative coordinate system may generate the change of the interruption value due to the interruption of the MPG.

4) Residual movement value:

The residual movement value at the current block is irrelevant to the MPG interruption.

The MPG interruption movement value is cleared when the manual reference point end return is performed along each axis.

Note 1: In the MPG interruption page, the letters of the coordinate axis name should be marked by @ in the MPG interruption axis.

Note 2 : Manually clear the MPG interruption value by the soft button of the MPG interruption page; the

workpiece coordinate system will not renew; that is, the coordinate system position before the MPG interruption will not recover, the workpiece coordinate offset generated in the MPG interruption will always enabled, and then can not be recover again.

#### 9.4.5 Precaution of MPG Interruption

1) MPG interruption is disabled when the MPG feed (Including the Manual, MPG, Single-step, Machine tool zero return or program zero return) is performed;

2) The axis is controlled by PLC axis; MPG interruption is disabled.

3) MPG interruption is disabled when MPG trial-cutting is performed.

4) The axis does not move when the machine is locked, and the MPG interruption is disabled.

5) MPG interruption is disabled when returning the reference position.

MPG interruption is disabled when the system alarm occurs.

Note: The MPG interruption disabling are on the states 1 > 3, as the above-mentioned, the system will not enter to the MPG interruption state. If it on the states 4) ~ 6), the system can be entered to the MPG interruption state, instead of generating the enabled MPG interruption value.

#### 9.5 **Other Operations**

- 1. In Auto mode, press key to switch on/off the cooling;
- keys to switch the operation 2 C E 2. Press any of the

modes;

key to reset this CNC system. 3. Press the

4. Automatic lubricating operation (Refer to OPERATION, Chapter 3).



# CHAPTER 10 ZERO RETURN OPERATION

### Note!

The key functions of this GSK980TDi machine panel are defined by PLC program (ladders), please refer to the manuals by the machine builder for their significance.

Please note that the following description for the panel key functions in this chapter is based on the GSK980TDi standard PLC program!

# 10.1 Program Zero Return

### 10.1.1 Program Zero

While the part is fixed on the machine, absolute coordinate of current tool position may be set by G50 code according to the relative position between the tool and the part, so a workpiece coordinate system is setup. The tool current position is called **program zero**, and this is the program zero return position.

# 10.1.2 Program Zero Return Steps

1. Press key, it enters the Program zero return mode, the bottom line of the window displays "P. ZERO":



2. Press the direction key of X, Z , Y,  $4^{th}$ , C axis, it returns to the program zero of X, Z , Y,  $4^{th}$  or C axis;

- 3. The machine axis moves toward the program zero return, and the axis stops with the program zero return completion indicator ON after the axis returns to the program zero.
- Note 1: The tool offset is not changed for the program zero return operation, if there is offset, the return position is the point set by G50.

Note 2: Whether the key is held on at program zero return is defined by the bit parameter No.011 BIT2 (zero return is locked automatically).

# 10.2 Machine Zero Return

### 10.2.1 Machine Zero

The **machine coordinate system** is a reference coordinate system for CNC coordinate operation. It is an inherent coordinate system of the machine. The origin of the machine coordinate system is called machine zero (or machine reference point). It is defined by the zero or zero return switch fixed on the machine. Usually this switch is fixed at the positive stroke point of each axis.

# 10.2.2 Machine Zero Return Steps

1. Press key, it enters the Machine zero mode, the bottom line of the window displays "REF":



2. Press, and the machine zero of X, Z, Y, 4th or C axis:

3. Carrier moves along with the machine tool zero; when it matches with the incremental encoder motor, return to the machine tool zero after passing the deceleration signal or zero signal detection. When it matches with the absolute encoder motor, directly position the set mechanical zero based upon the velocity of the mechanical zero turn; in this case, the axis stops, and the zero return indicator is ON.

- Note 1: If there is no machine zero on the machine, the machine zero operation is forbidden;
- Note 2: The machine zero finish indicator is gone out on condition that: 1)The axis is moved out from machine zero; 2) CNC is powered off.
- Note 3: After the machine zero operation, the tool length compensation is cancelled by CNC;
- Note 4: Parameters related to machine zero return are referred to INSTALLATION and CONNECTION.
- Note 5: After the machine zero return is executed, the original workpiece coordinate system is set again with G50.

# 10.3 Other Operations in Zero Return

- 1) The spindle rotates (CW, CCW), stops.
- 2) The cooling is ON or OFF.
- 3) The lubricating control.
- 4) Manual relative tool change.
- 5) The spindle override tuning.
- 6) Rapid override tuning.
- 7) Feedrate override tuning.
- 8) Hydraulic chuck control;
- 9) Hydraulic tailstock control.



# CHAPTER 11 DATA SETTING

### 11.1 Data Setting

Press and then **SETTING** to enter the CNC setting page which includes the switch setting, level setting and parameter operation function as follows:

MDI	S0000 T0	100
SWITCH SETTING	LEVEL SETTING	~
PARAMETER SWT. : 41 ON PROGRAM SWT. : 47 ON AUTO SEGNENT : 44 OFF	CURRENT LEVEL: 3 DEGRADE INPUT PASSWORD: ALTER PASSWORD:	PARM SWITCH
PARAMETER OPERATION		AUTO
⊂BACKUP PAR. (USER) ⊂RESUME PAR. (USER)		AUTH
RESUME DEFAULT PAR. I (SERVO 1 P	LEVEL)	INPUT PWD
CRESUME DEFAULT PAR.3(SERVO 0.)	1 P LEVEL)	CHANGE PWD
PRESS KEY [L] TO TURNON, PRESS KE	Y [W] TO TURNOFF.	PARM
and the second sec	₹ 13:28:57	UPERATE
SETTING CLOCK DC LIST	NC. BUG	

### 11.1.1 Switch Setting

When the cursor is in the switch set column, the system can set parameters, programs, automatic sequence number ON/OFF state.

#### 1) Switch explanation:

Parameter switch: parameters can be modified when the parameter switch is ON; they are forbidden to alter when it is OFF.

Program switch: programs can be edited when the program switch is ON; they are forbidden to edit when it is OFF.

Automatic block number: the block number is automatically generated when the automatic sequence number switch is ON and a program is edited; when the switch is OFF, the block number is input manually instead of being automatically generated.

#### 2) Switch setting method:

a) Move the cursor to the setting item;

b) Directly press the switch, white or block soft button to open the switch, if it is ON, press the corresponding switch, switch or block soft button to close it; simultaneously, the cursor

will automatically move to the switch item;

Note: When the parameter switch is shifted from "OFF" to "ON", an alarm will be issued by CNC system. The

alarm can be cancelled by pressing <u></u>If the PARM SWT is shifted again, no alarm is issued. For security it should set the PARM SWT for "OFF" after the parameter alteration is finished.

# 11.1.2 Level Setting

To prevent programs, CNC parameters from being modified at will, GSK980TDi provides the level setting function, and its password grade is divided into five, from high to low grade: 2<sup>nd</sup> grade (machine manufacturer), 3<sup>rd</sup> grade (device management), 4<sup>th</sup> grade (engineer), 5<sup>th</sup> grade (machining operation), 6<sup>th</sup> grade(operation limit). The current operation grade is displayed in "Current Level:\_" in the level setting page.

- 2<sup>nd</sup> grade: it is for the machine manufacturer, which permits the machine manufacturer to alter the state parameters, data parameters, pitch compensation data, tool compensation data, to edit programs, to transmit PLC and so on.
- 3<sup>rd</sup> grade: it permits to alter state parameters, data parameters, tool compensation data and to edit programs.
- 4<sup>th</sup> grade: it permits to alter tool compensation data (tool-setting operation), macro variables, to edit programs, but not to alter state parameters, data parameters and pitch compensation data.
- 5<sup>th</sup> grade: it permits to alter tool compensation data, not to select and edit programs, and not to alter state programs, data programs and pitch compensation data.
- 6<sup>th</sup> grade: it has no level to operate only the machine operation panel, not to alter tool compensation data, not select and edit programs, not to alter state parameters, data parameter and pitch compensation data.

#### 1) Operation grade entry

- a) Move the cursor to the line "INPUT PASSWORD" in the CNC setting page;
- b) Input the operation password(the system displays one "\*" as soon as a number is input;
- c) Press and the operator can enter the corresponding grade operation;

d) After the operator enters the corresponding operation grade page, the prompt column prompts the system's current grade, and the corresponding operations as follows:



Note 1: The defined password length corresponds to the operation grade, and the user cannot increase or reduce the length at will, which is shown below:

Operation grade	Length	Initial password
3 <sup>rd</sup> grade	5 digits	12345
4 <sup>th</sup> grade	4 digits	1234
5 <sup>th</sup> grade	3 digits	123
6 <sup>th</sup> grade	None	None

Note 2: When the operation level is less than or equal to the 3<sup>rd</sup> grade ( 3<sup>rd</sup>, 4<sup>th</sup>, 5<sup>th</sup> or 6<sup>th</sup> grade) and the system is turned on again, the operation level does not change. When the level is the 2<sup>nd</sup> grade and the system is turned on again, the operation level defaults to the 3<sup>rd</sup> grade.

2) Password modification

Steps:

a) The operator enters the grade to alter the password according to the method "Operation grade entry" after the system enters the setting page;

b) Press the soft button or manually move the cursor; Move the cursor to the line "ALATER PASSWORD";

- c) Input the new password, and then press
- d) The CNC prompts "Input the new password again";
- e) Input the new password again and then press . When the two input passwords are identical, the CNC prompts "Password has been altered, please save the new password." The password alteration is done successfully.

Note: The system prompts, "The new password is not identical with the confirmation" when the two input passwords are not identical. At the moment, input the new password again.

#### 3) Operation grade degradation

The degradation is to degrade from the high to the low, and its steps are shown below:

a) Input the password according the method of "Operation grade entry" after the system enters the setting page;

b) Press soft key, Move the cursor to the line "CURRENT LEVEL" and the system

pops u	р	DE	GKI
popo a	r –		

#### as follows:

MDI	50000 TE	0100
SWITCH SETTING	LEVEL SETTING	~
PARAMETER SWT.: Q OFF	CURRENT LEVEL: 3 DEGRADE	CONFIRM
PROGRAM SWT.: a ON	INPUT PASSWORD:	PARM
AUTO SEGMENT : 🚨 OFF	ALTER PASSWORD:	B PROC
		SWITCH
PARAMETER OPERATION		AUTO BLOCK
BACKUP PAR. (USER)		AUTH
CRESUME PAR. (USER)		DEGRADE
CRESUME DEFAULT PAR. I (SERVO 1 P	LEVEL)	INPUT PWD
"RESUME DEFAULT PAR.3(SERVO 0.1	P LEVEL)	CHANGE
HOLICK DEDINGTED HID COLT DECODER		PWD
MODIFY PARAMETER AND EDIT PROGRAM	× 19-90-17	PARM
SETTING CLOCK DC LIST & FU	NC.	
s confirm (or ), and the	e CNC prompts "Passw	vord degrades

follows:

	11 ממממב	101
WITCH SETTING	LEVEL SETTING	~
PARAMETER SWT.: △ OFF PROGRAM SWT.: △ ON AUTO SEGMENT : △ OFF	CURRENT LEVEL: 3 DEGRADE? INPUT PASSWORD: ALTER PASSWORD:	CON G
ARAMETER OPERATION		5
CBACKUP PAR. (USER) CRESUME PAR. (USER)		AUDEG
CRESUME DEFAULT PAR.1(SERVO	1 P LEVEL)	IN
*RESUME DEFAULT PAR.3(SERVO	0.10 LEVEL)	CH
SET THE PASSWORD LOWER ?		P
And in case of the local division of the loc	09:41:48	OPE

Note 1: The degradation operation cannot be executed when the current level is the 6<sup>th</sup> grade. Note 2: The current password can be altered after degradation. When the system is in the high level, the degradation can be executed to set to the low-level password.

# 11.1.3 Parameter Operation

The parameter data (state parameter, data parameter) can be backup (stored) and recovered (read). Programs can be stored in the CNC when the backup or recovery is executed. The display is shown below:

MDI	S0000 T0100
WITCH SETTING	LEVEL SETTING
PARAMETER SWT.: 네 OFF PROGRAM SWT.: 네 ON AUTO SEGMENT : & OFF	CURRENT LEVEL: 3 DEGRADE
ARAMETER OPERATION	
@BACKUP PAR, (USER)	
CRESUME PAR. (USER)	DÉ
RESUME DEFAULT PAR.1(SERVO	TP LEVEL)
CRESUME DEFAULT PAR.3(SERVO	8.1 p LEVEL)
PRESS [IN] + [P] TO CONFIRM (P	OWER ON AGAIN)
	≫ 13:30:51 <sup>011</sup>

#### 1) Option explanation:

Backup current parameters (user): the user to backup the CNC data (store)

Resume backup parameters(user): the user resumes the backup data (read)

Resume parameter (servo 1u level): the user reads the original parameter data matched with the servo drive with the precision 1um

Resume parameter (servo 0.1u level): the user reads the original parameter data matched with the servo drive with the precision 0.1um

Note: When the level is the 2<sup>nd</sup> grade, the backuping current parameters (user) and resuming backup parameters (user) become backuping current parameters (machine manufacturer) and resuming backup parameters (machine manufacturer), which is used to backup and resume the manufacturer's data.

#### 2) Operation methods:

a) Open the parameter switch;

b) Press to enter the MDI mode, move the cursor the required item;

c) Press <u>CONFIRM</u>, and the system prompts whether to confirm the current operation.

d) Press , and the system prompts the backup or resume is done successfully. When the recovery is done, the system prompts power-on again.

Note: Don't turn off the system and execute other operations when the backup or resuming is executed.

# 11.2 Clock Setting

Press and then to enter the system clock page. The operator can alter the current data and time as follows:

SUN	MON	TUE	WED	THU	FRI	SAT	
1	2	3	4	5	6	7	11 12
8	9	10	11	12	13	14	10 2
15	16	17	18	19	20	21	-9 3:
22	23	24	25	26	27	28	.8 4.
29	30	T	2	3	4	Ь	61.0
6	7	8	8	10	11	12	
			2015	i - 11 - 1	9,09	46 : 27	



required modification (Year/Month/Date/Minute/Second), input directly numbers, and press

then **SET** or **EXAMPLE** to escape from the alteration mode.

# 11.3 Graphic Display

Press key to enter the path page as follows:



### 1) The START, STOP and CLEAR of the graphic path

START (S) (Or S ]) and the system starts the drawing; press In the path display page, press the ), it clears the current graphic path. ), it stops drawing; press **CLEAR** (or STOP(T) (Or When the path exceeds the display range during automatic graph, the system regulate the FIXED (L) (or graphic center following the tool nose position in real time. Press and the display area is locked, the system does not regulate the graphic center on when the path FLOAT (L) (Or ÍD) and the system releases the lock. exceeds the display area. Press Scaling up and down 2)  $M_{t}$ ), the system scales up/down <u> 200</u>₩- (or In the path display page, press 2004+ (or ) each time, the graphic path is scaled up  $\sqrt{2}$  fold, press the path in real time. Press 2004 (or ) each time, the graphic path is scaled down  $\sqrt{2}$  fold. ZOOM-3) Path display moving **OVEDIS** In the graph display page, press the cursor movement key to move the graphic path. Press

(or intervals.) to adjust mobile intervals.

### 4) Graphic attribution display

In the path display page, press (or ) to display the graphic attribution window, including the current coordinate system, translation position, scaling and mobile interval. It is shown below:

328

EDIT	50000 T0000		
TRACK DISPLAY D0001(0.001WW/DA98/DA98A/步进) ~G98 G50 X250. Z450. T0101	00001 N0000  MACHINE] X 83.3809 Z 123.2053	CLEAR	
· · ·	GRAPH FEATURE	ZOOM- ZOOM- PLOAT (L)	
	H.OFFSET: 0 V.OFFSET: 0 SCALE: 0.50 MOVE DIS: 1	CHANGE NOVED1S GRAGH	
E TONY	B 10:03:20	FEATURE	
DISPLAY			

Press FEATURE G ) again to close the graph attribution window. (or

### 5) Graphic parameter meaning

Coordinate system setting: 8 types of graphic paths can be displayed in this GSK980TDi CNC system according to the front or rear tool post coordinate system, and there is 4 kinds of path as

C

К

follows: (switch X, Z axis by pressing CHANCE or

Bit par	ameter No.175	Graphic path coord	inata display
Bit1	Bit0	Graphic path coord	inate display
0	0	EDIT IRACK DISPLAY DO001(0.001W/DA98/0A98A/步进) * (58: 050 X250, Z450, T0101	CORDEL TOBUE   Longel Nonege   Lanchinei   X   Z   123.2053   CRAPH FEATURE   X <td< th=""></td<>
0	1	EDIT TRACK DISPLAY → 00001(0,0004//0000000000000000000000000000000	S00000     N00000       CARSOLUTE:     START       X     250.0000       Z     450.0000       Z     450.0000       CLEAR



Bit paran	neter No.175	Graphic path cool	rdinate disnlav
Bit1	Bit0		
		EDIT TRACK DISPLAY 	S0000 T0000 CO001 N0000 CARSOLUTET X 250.0000 Z 450.0000 CLEAR 43
1	0		ZOOM COMPETENTIAL COMPETENTI
		EDIT TRACK DISPLAY → COROLI (0.001 HW/DA98/DA98A/参佳) G88 G50 X250, Z450, T0101	S0000 T0000 C0001 N0000 (A9SOLUTE) × 250.0000 Z 450.0000 CLEAR 4
1	1		GRAPH FEATURE     200H       X     200H       X     200H       X     200H       X     200H       H.OFFSET:     0       V.OFFSET:     0       SCALE:     0.56
		DISPLAY	MOVE DIS: 1 Re 10:09:51

# 11.4 Parameter Setting

Parameter setting can adjust related characteristics of the drive unit and machine.



### 11.4.1 State Parameter

- 1) Byte alteration:
  - a) Turn on the parameter switch;
  - b) Enter the MDI mode;
  - c) Move the cursor to the parameter number to be set:

Method 1: Press or to enter the page containing the parameter to be set, press
$\uparrow$ or $\downarrow$ key to move the cursor to the parameter number to be set;
Method 2: Press (or ), and input the parameter number in the pop-up
dialogue box, at last, press
Key in a new parameter value;
<b></b>

- 5) Press key, the parameter value is entered and displayed.
- 6) For security, the PARM SWT needs to be set to OFF after all parameter settings are finished.

#### Example:

4)

Set the bit parameter No.001 Bit 3(STEP/MPG) to 1, and the other bits remain unchanged. Move the cursor to No.001, input 00011000 by sequence according to the above steps. The display is shown below:

NO.	DATA	NO.	DATA	NO.	DATA	
0001	00011000	0013	00000000	0184	00000001	
0002	00000011	0014	00011111	0185	00000000	
0003	00010000	0017	00001000	0186	00000000	
0004	01000000	0018	00000000	0187 X	00000000	
0005	00010010	0020	00000000	Z	00000000	
0006	00000000	0172	01101000	Y	00000010	
0007	10000000	0174	00011000	B	00000010	
8006	00011111	0175	00000000	C	01000010	
0009	00000000	0180	00000000	0188 X	00000101	
0010	00011111	0181	11100000	Z	00000101	0
0011	00000000	0182	00000000	Y	01000101	FI
0012	10101001	0183	00000000	B	01000101	

Press

to finish the parameter alteration. The page is shown below:

is pressed to escape from the

MDI	ALARM(1/1):e	again	when para	ameter is	modifie(	<b>S0000</b>	TØ1	<u>0</u> 1
PARAMETER	R -> BIT PARAM	AETER.				00001 NB	000	ADD TO
NO'.	DATA	NO.	Û	ATA	NO.	DATA	4	USED
0001	000110.0	0013	000	00000	0184	00000001		SET
0002	00000011	0014	000	11111	0185	00000000		PARM
0003	00010000	0017	000	01000	0186	00000000		THE MANUA
0004	01000000	0018	000	00000	0187 X	00000000		
0005	00010010	0020	000	00000	Z	00000000		_
0006	00000000	0172	011	01000	Y	00000010	1	
0007	10000000	0174	000	11000	B	00000010		
0008	00011111	0175	000	00000	C	01000010		811
0009	00000000	0180	000	00000	0188 X	00000101		MODIFY
0010	00011111	0181	111	00000	Z	00000101		(R)
0011	00000000	0182	000	00000	Y	01000101		FIND(P)
0012	10101001	0183	000	00000	B	01000101		
0001 xxx BITI Inc	xxx xxx ACS HW rement system 0	L XRC ISC I:u(IS-B:C	1NI 0.001) 1:0	. lu(IS-C:(	.0001)	₩ 10:44	:43	
BIT PARM	DATA PARM	CLASS PARM	PITCH COMP			PREV		NEXT PAGE

2) Alteration by bit:

- a) Turn on the parameter switch;
- b) Enter the MDI mode;

c) Move the cursor to the parameter number to be set (the method is referred to Section 10.4.1 Step c) ;

d) Press to enter the bit alteration mode, at the moment, some bit of the parameter

is backlighted. Press  $\longrightarrow$  or  $\checkmark$  to move the cursor to the bit to be altered, then key in 0 or 1;

e) After all parameters setting is finished, the PARM SWT needs to be set to OFF for security.

Note: After the system enters some bit of the parameter, alteration mode, and the cursor stops the parameter number .

Example:

Set the Bit3 of the bit parameter No.001 to 1, and the other bits remains unchanged.

Move the cursor to No.001 according to the above steps, press to skip to some bit of the parameter, and move the cursor to Bit3. The display is shown below:

	and the second se	E CONTRACTOR OF THE OWNER OWNER OF THE OWNER OWNE	_			00001 110	0.00	DETLA
NO.	DATA	NO.	D	ATA	NO.	DATA	-	USED
0001	00010010	0013	000	00000	0184	00000001	_	SET
0002	00000011	0014	000	11111	0185	00000000		PARM
0003	10010000	0017	000	01000	0186	00000000		
0004	01000000	0018	000	00000	0187 X	00000000		
0005	00010010	0020	000	00000	Z	00000000		-
0006	00000000	0172	011	01000	Y	00000010	100	
0007	10000000	0174	000	01000	B	00000010		_
0008	00011111	0175	000	000011	C	01000010		BYTE
0009	00000000	0180	000	00000	0188 X	00000101		MODIF
0010	00011111	0181	111	00000	Z	00000101		
0011	00000000	0182	000	00000	Y	01000101		FIND
0012	10101011	0183	000	00000	B	01000101		
9001 *** 31T3 0:St	ep 1:Handwheel	XRC 1SC 1	NI			≣ 1 <b>8-3</b> 2	-85	

Input 1, and the parameter alteration is done.

ARAMETE	K -2 BIT PARAM	ETER			UDDDT NDD	ADD ADD
NO.	DATA	NO.	DATA	NO.	DATA	USET
9001	00011010	0013	0000000	0184	0000001	SET
3002	00000011	0014	00011111	0185	00000000	PAR
0003	10010000	0017	00001000	0186	00000000	
0004	01000000	0018	00000000	0187 X	00000000	
0005	00010010	0020	00000000	Z	00000000	
0006	00000000	0172	01101000	Y	00000010	
0007	10000000	0174	00001000	B	00000010	
8000	00011111	0175	00000011	C	01000010	BYI
0009	00000000	0180	00000000	0188 X	00000101	MODI
0010	00011111	0181	11100000	Z	00000101	
0011	00000000	0182	00000000	Y	01000101	FIND
0012	10101011	0183	00000000	B	01000101	
001 ±±±	tep 1:Handwheel	XRC ISC 1	NI			10

### 11.4.2 Data Parameter, Pitch Compensation

- 1) Turn on the parameter switch;
- 2) Enter the MDI mode;
- 3) Move the cursor to the No. of the parameter to be set;
- 4) Key in the new parameter value;
- 5) Press key, the value is entered and displayed;

6) After all parameters setting is finished, the PARM SWT needs to be set to OFF for security. **Explanation:** The screw-pitch parameter can only be altered under the 2 level password authority.

Example 1: set the data parameter No.027 to 7600.

Move the cursor to No.027 by the steps above, key in 7600 by sequence as follows:

MDI					<b>S0000 TO</b>	101
PARAMETER -	-> DATA PARAM	ETER			00001 N0000	ADD TO
NO.	DATA	NO.	DATA	NO.	DATA	USED
0015 X	1	0021 S2	0	0024	100	SET
man Z	1	\$3	0	0025	0	PARM
Y	1	0022 X	4000	0026	100	THE MARKIN
8	1	Z	7600	0027	8000	1.000
C	1	Y	8000	0028	200	-
0016 X	1	B	8000	0029	100	1000
Z	1	C	180000	0030	200	-
Y	1	0023 X	100	0031	1260	1.000
B	1	Z	100	0032 X	200	in the second se
C	1	Y	100	Z	400	(N)
0019	5	B	100	Y	400	FIND(P)
0021 S1	0	C	100	B	400	
0022 Max.:	speed of rapid	traverse(	nn/nin)	-	# 10:41:00	
BIT PARM	DATA PARM 💦		PITCH SERV	0	PREV	NEXT

Press

to finish the alteration. The display is shown below:

MDI					50000 T	0101
PARAMETER -	DATA PARAM	ETER			00001 N000	ADD TO
NO.	DATA	NO.	DATA	NO.	DATA	OF TEN USED
0015 X	1	0021 S2	0	0024	100	SET
2	1	\$3	0	0025	0	PARM
Y	1	0022 X	4000	0026	100	THE MARK
8	1	Z	7600	0027	8008	
C	1	Y	8000	0028	200	
0016 X	1	B	8000	0029	100	
Z	1	C	180000	0030	200	<u> </u>
Y	1	0023 X	100	0031	1260	
B	1	Z	100	0032 X	200	1
C	1	Y	100	Z	400	
0019	5	B	100	Y	400	FIND(P
0021 S1	0	C	100	B	400	
0022 Max.sr	eed of rapid	traverse(mm	/min)		≣ 10:41:2	8
BIT PARM	TA PARM		ITCH SERVI	2	PREV	

# 11.4.3 Classification Parameter

Press soft button to enter its page after controlling the PARM button ,The display is shown below :

NO	DATA	NO	DATA	NO	DATA	A
NU.	UATA	NU.	UATA	NU.	UATA	OCII
0008	0011111	0188 B	01000101	0022 X	4000	SPIN
0009	00000000	C	01000101	Z	8000	SET
0013	00000000	0015 X	1	Y	8000	MACH
0175	00000011	Z	1	B	8000	ZE
0187 X	00000000	Y	1	Ĉ	180000	REI
Z	00000010	B	1	0023 X	100	GSKI
Y	00000010	C	1	Z	100	SET
B	00000010	0016 X	1	Y	100	THE
C	00000010	Z	1	B	100	CUT
188 X	00000101	Y	1	C	100	BKL
Z	00000101	B	1	0027	7600	CO
Y	01000101	Č	1	0029	100	U PI
008	*** *** DIR5 D	IRA DIRY DIR	Z DIRX			ER
IT7 Rese	rved					
						V

In the classification parameter, the parameter can be displayed based upon its function, it is convenient to check or modification. The current displayed classification parameter can be shifted by

its corresponding soft button; for example, press the soft button, the following figure is shown below:

ARAME	<b>IER</b>	-> CLASSFICAT	ION PARAMET	ER [SPINDLE	SETTING]	00001 N0000	AXIS
NO.		DATA	NO.	DATA	NO.	DATA	SETTI
0001		00011010	0036 S3	0	0040 S3	9999	COMP
0175		00000011	0037 S1	9999	0043	99	SETT
8186		00000000	S2	9999	0067 S1	100	MACUT
0195	\$1	01000000	\$3	9999	S2	100	ZER
	S2	00000000	0038 \$1	9999	\$3	100	RETU
	\$3	00000000	S2	9999	0068 S1	0	GSKL 1
0196		00000000	\$3	9999	S2	0	SETTI
0021	S1	0	0039 S1	9999	\$3	0	THRE
	S2	0	S2	9999	0069 S1	1	CUTTI
	\$3	0	\$3	9999	S2	0	BKI A
0036	S1	0	0040 S1	9999	\$3	0	COMP
3	\$2	0	S2	9999	0070 S1	1024	PHO
0001		TTT TTT ACS HWL	XRC ISC INI	-			ERRO
3117	Reser	ved					
_	-						- V
						14:23:41	MORE

# 11.4.4 Often Used Parameters

Press to enter parameter interface, and press to enter the often used parameter page. The page is shown below:

110	DIT		DITA	10	DATA
NU.	UATA	NU.	UATA	NU.	UATA
0001	0011010	0015 Y	1	0022 Z	8000
0004	01000000	B	(1)	Y	8000
0006	00000000	C	1	B	8000
0007	10000000	0016 X	1	C	180000
0008	00011111	Z	1	0023 X	100
0009	00000000	Y	1	Z	100
0010	00011111	B	1	Y	100
0011	00000000	C	1	B	100
0013	00000000	0021 S1	0	C	100
0014	00011111	S2	Ø	0026	100
0015 X	1	\$3	0	0027	7600
7	1	0022 X	4000	0028	200

The user can add the often used state parameter, data parameters to the often used parameters to get the convenient search and alteration.

#### 1) Adding often used parameters

In the state, data or classification parameter page, move the cursor to the parameter number

where is desired to add as the common parameter; press the used soft button, the current parameter is then add as the common one.

#### 2) Sorting often used parameters

In the common parameter page, enter to the next menu of the common parameter by pressing

the **PARM** soft button again; refer to the following figure:

NO	DATA	NO	DATA	10	DATA	~
NU.	UATA	NU.	UATA	NU.	UATA	RETUR
10001	00011010	0015 Y	1	0022 Z	8000	MOVE
0004	01000000	B	1	Y	8000	UP
0006	00000000	C	1	B	8000	-
0007	10000000	0016 X	1	C	180000	DOWN
0008	00011111	Z	1	0023 X	100	
0009	00000000	Y	1	Z	100	AUTO
0010	00011111	B	1	Y	100	UNDER
0011	00000000	C	1	B	100	REMOV
0013	00000000	0021 S1	0	C	100	USED
0014	00011111	S2	0	0026	100	REMOVE
0015 X	1	\$3	0	0027	7600	ALL
Z	1	0022 X	4000	0028	200 🗸	
0001 III BIT7 Rese	TTT TTT ACS HWL	XRC ISC INI				-

sorts all often

AUTO ORDER

Pressing \_\_\_\_\_, \_\_\_\_can move the parameter where the current cursor is. Pressing used parameter in sequence number.

MOVE Down

NOVE UP

#### 3) Removing often used parameters

Move the cursor to the required parameter in the often used parameter page. Press and

the current often used parameter is removed. Press and all often used parameters are removed.

#### 4) Altering often used parameter

Parameters can be altered directly in the often used parameter page. Its alteration method is the same that of state parameter and data parameter. Its value is also refreshed in the state parameter or data parameter page.

# 11.5 Macro Variable Note

Macro variable note display is mainly administrated for the macro note and macro note file. The administration of the macro note file includes the leading-in, leading-out, rename, overloading and remark, etc. of the macro note file.

# 11.5.1 Macro Variable Note Page

Press the soft button to enter its corresponding customization page ,after entering the

cutter compensation page by controlling the MACRO VAR button, The page is shown below:

00 注释1    01 注释2    02 注释3    03 注释4    04 注释5    05 注释6	69	)1 注释12 )9 注释13	
501 注释2   502 注释3   503 注释4   504 注释5   505 注释6	69	99 注释13	
502 注释3   503 注释4   504 注释5   505 注释6			
503 注释4   504 注释5   505 注释6			
504 注释5   505 注释6			
505 注释6			
506 注释7			
507 注释8			
508 注释9			
509 注释10			
700 注释11			

The overloaded file data can be set on the "Custom macro variable" page, only 4 and above operation authorities can be performed.

### 11.5.2 Note List

Press the button to enter the macro variable note list after entering the macro variable note page.

N		50000 T0100
NO		00001 N0000
	00009.EXT 注释文件例子	SELECI
		RENAME
		12 HALDY
		×
		DELETE
		DELETE
		LENU
		(Terrar)
F	ILE SIZE: 308 B	Contract Contract
H	COIFIED TIME: 2015-09-18,01:12:03	14-26-02 BACK
Bi	OFFSET MACRO VAR. CD. OFFSET WSER-DFLT TOOL-LIFE	14.20.05
Function soft bu	Itton explanations:	
SELECT soft button	n: Select the note file to enable the fi	le;
RENAME	m. The file can be renormed for the	a surrent file, the note file at surrent
		e current me, the note me at current
	loading can not bealtered;	
<b>REMARK</b> soft butto	<b>n:</b> Modify or add the remark informat	ion, the note file at current loading can
	not bealtered;	
×		
<b>DELETE</b> soft butto	n: Delete the file at the cursor's	position; (2 or above authorities are
	desired)	
DELETE		
soft buttor	n: Clear the overall annotated files ar	nd contents;
LEAD		
ALL soft butto	n: The "EXT files" under the MAR	DEXT list of the U-disk are led to the
	system note list.	
	System note list,	
ALL a oft butto	n. The overall files in the note list or	in lad out to the MACROEXT list of
	the U-disk; if there are files are si	hared with a same name, the same
	files will be replaced;	
	can be performed in any authority, the	or snould be operated with
∠ or above l	ievers authorities; other functions sh	ouiu de performed with 3 of more
Note 2: The	can be performed in any method, othe	r functions should be operated in the
Edit method.		

# 11.5.3 Macro Variable Note File

#### 1. File content format

- 1) Create a TXT file, the surfix is renamed as .EXT  $_{\circ}$
- 2) The file content format is as follows:
- 0, Remark the display content

Variable number, custom content \t Note content.

For example: Set up a O0009.EXT file, its content is as follows:

0, Note file example 500, Note 1\t Detailed note 1 501, Note 2\t Detailed note 2 ..... 701, Note 12\t Detailed note 12 699, Note 13\t Detailed note 13

The displayed result of the above-mentioned note file is as follows:

M	וכ				50000 T00	00
USER-	DEFINED MACRO VARI	ETY			00001 N0000	NOTE
NO.	VARIABLE NOTE	DATA	NO.	VARIABLE NOTE	DATA	LIST
500	注释1		701	注释12		
501	注释2		699	注释13		
502	注释3					
503	注释4					
504	注释5					
505	注释6					
506	注释7					
507	注释8					
508	注释9					1
509	注释10					
700	注释11					
500 1	詳細注釋1					
					章 10:57:44	
S OFF	AR MACRO VAR.	DEFSET USER	DFLT T	OOL-LIFE		

#### 2.File leading-in/out operation

Leading-in operation

- 1) Create a new file MACROEXT under the root list of the U-disk;;
- 2) The performed system custom file is delivered to the folder;
- 3) Set the system authority as 2-level or above, and then insert to U-disk;
- 4) The \*.EXT file under the U disk MACROEXT list can be entirely lead out to the system

note list by soft button.

Leading-out operation

- 1) Insert an U-disk;
- 2) The overall files in the system note list are lead out to the U disk MACROEXT folder by

ALL soft button; if the note file name is same as the system list under the U disk MACROEXT; the same name note file will be covered under the systme root list.

# CHAPTER 12 U OPERATION FUNCTION

# **12.1 File Management Function Introduction**

GSK980TDi has the file management function to execute the file copy, data backup, data resume, the system upgrading (2<sup>nd</sup> grade) and so on.

In any states, press to select the setting interface, press LIST to enter the file management page. Insert U disk and the system automatically identifies it. The system displays the icon s at the lower right bottom of the system after it successfully identifies the icon as follows:



# 12.2 Often Used File Operation Function Introduction

# 12.2.1 File Extension & Return

1)

Move the cursor to the required extension file, press to extend it as follows: 50000 T0000 MDI GSK980TDi /u SELECT CN15接GS进给伺服的焊线图.do SYSTEM FILES DARAW PILES CNCSW.BIN sk980tdi backup SWITCH 0000 COPY TO CNC BSPLOG →LADDER FILES ├ 980TDc系列标准梯形图1107F Cnc.cfg 41 Comparam.cfg - 980TDi系列瑞远机床梯形图1 - 980TDi系列瑞远机床梯形图1 - 10\_TEST\_PLC.1d2 CUSTON BACKU DIAGNOSE 19 - STDPLC.LD2 - STDPLC\_EN.1d2 MACROEXT UPDATE STOPLC\_TOUNIT\_1d2 MAINT MAINT.CFG PROGRAM - 00000.CNC DILC -D pagebg.gif Userpagel.uic 00002.CNC - 00003.CNC ≥ 11:20:46 SETTING CLOCK DOC LIST \* FUNC. DEBUG GSKLINK SET IP

2) Move the cursor to the target file, press file as follow:

to return the previous catalog of the current



ৢ

# 12.2.2 File Selection & Cancellation of File Selection

Take an example of U:\gsk980TDi\_backup\user\NCPROG\O0000.CNC to introduce the selection and cancellation.

1) After entering the file administration page, move the cursor above the O0000.CNC by



々

refer to the following figure:



2) Press (or ) to select O0000.CNC as follows:

MDI	<b>S0000 T0000</b>
SETTING → DOCUMENT MANAGEMENT GSK980TDi SYSTEM FILES F PARAW.PAR TOFF.CMP WOFF.WMP SERVO PARAMETER FIL F LADDER FILES F 980TDi系列瑞远机床梯形图1 F 10_TEST_PLC.Id2 F STDPLC.LD2 STDPLC.LD2 STDPLC.LOUIT.Id2 F STDPLC.LOUIT.Id2 F O00000_CNC F 000001_CNC F 000000_CNC F 00000_CNC F 000000_CNC F 00000_CNC F 0000	00001 N00000 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓
Press Press (or again ) to car	B ≤ 11:24:20

# 12.2.3 File Copy

1)

Refer to Section 11.2.2 to select the file. When the cursor is in the U disk catalog window, result is pressed and the the files in the U disk is copied to the CNC; when the cursor is in the CNC catalog

window, is pressed and the file in the CNC is copied to the U disk.

# 12.3 Data Copy & Resume

In the file managemetn page, backup, resume the CNC data (including the system parameters, part parameter, tool compensation, pitch compensation, ladder parameters, ladder, self-defined data, servo parameter and daily record, etc.) via the U disk. The CNC can be operated to the file in the MDI working mode and keeps at the stopping state.

# 12.3.1 Entering Backup/Resume Page

After the system identifies the U disk, it enters the file management page. Press **BACKUP** to enter the backup/resume page as follows:

MDI			S0000 TO	100
BACKUP OPTION			HELP	SELECT
PARAMETER	PROGRAM	OFFSET	1.SELECT ITEMS.PRESS	
PITCH COMP.	FPLC PARM	IT PLC	[PERFORM] SOFT KEY	SELECT
□ SELF-DEFINING	FSERVO PARM.	<b>□10</b> G	2.CORRESPONDING ITEM	CANCEL
RESUME OPTION			OF RESTORING COULD	i marca
TPARAMETER	TPROGRAM	FOFFSET	WHEN THE FILE DOES	1948
TPLICK COMP.	THE PARM	<b>m</b> pLC	NOT EXIST.	PERFOR
ESTIT HELINING	E GERVEL PARM.		3.BACKUP/RESTORE OPERATION WORKS	-
SOURCE PATH: 1	u/gsk980tdi_back	up/user	RESPECTIVELY.	
BACKUP SYSTEM P	ARAMETERS TO /u,	/gsk980tdi_bac	kup	-
-		-	₩ 13:20:55	BACK

# 12.3.2 Backup/Resume Operation



Note 1: Data which has been backup or has been done to store in the U disk can be resumed.

- Note 2: When the cursor is in the "BACKUP OPTION" column, all options in the the "RESUME OPTION" column cannot be selected; when the cursor is in the "RESUME OPTOIN", all options in the "BACKUP OPTION" column cannot be selected;
- Note 3: Pressing executes operations only in the column where the cursor is. When the cursor is in "BACKUP OPTION" column, the resume operation is executed. The backup, resume cannot be executed simultaneously.

### 12.3.3 Operation Path Selection

When the user uses the U disk to execute the CNC data backup, the CNC creates a backup file "gsk980TDi\_backup" in the root catalog of the U disk. The backup file includes two backup data "U:\gsk980TDi\_backup\user" and "U:\gsk980TDi\_backup\serial number" (it is created by the system's serial number). When the user uses one U disk to execute data backup of many CNC systems, the data in "U:\gsk980TDi\_backup\user" is replaced by the new but data in "U:\gsk980TDi\_backup\serial number" remains unchanged.

For the above reason, the user should execute the operation path selection during resuming data:

Default path : U:\gsk980TDi\_backup\user

Serial number path: U:\gsk980TDi\_backup\serial number

Example: backup/resume data of many CNC systems

When the user backups the system A (serial number CT0000001), the generated file by data backup is "U:\gsk980TDi\_backup\CT0000001" and "U:\gsk980TDi\_backup\user"; When the user backups the system B (serial number CT0000002), the generated file by data backup is "U:\gsk980TDi\_backup\CT0000002". The "U:\gsk980TDi\_backup\user" generated by A is replaced automatically by the same name of the system B. At the moment, the user can execute the operation path selection when it executes the data resume operation of the system A:

- 1) When the previous data of the system A is resumed, the operation path is : "U:\gsk980TDi\_backup\CT0000001";
- When the backup data of the system B is copied to the system A, the operation path is: "U:\gsk980TDi\_backup\CT0000002" or default path;

Press  $\stackrel{\text{SELECT}}{\longrightarrow}$  and appear the dialog box of operation path selection, and then select the peration path by  $\begin{array}{c} \uparrow & \downarrow \\ \hline \end{array}$  when the cursor is in the resume column. Taking an example of

operation path by [1, 4], [4, 5] when the cursor is in the resume column. Taking an example of selecting the default path, the display is shown below:

BACKUP OPTION			HELP
TPARAMETER	PROGRAM	CONSET	1.SELECT ITEMS.PRESS
FRITCH COMP	TTPLE PARM	TPIC	[PERFORM] SOFT KEY
COLF-DIFTNING	T SE RYG PARM	F ( 06	2.CORRESPONDING ITEM
RESUME OPTION			OF RESTORING COULD
PARAMETER	PROGRAM	POFFSET	WHEN THE FILE DOES
TPUCK COMP.	TPLE PARM	T PLC	NOT EXIST.
ESTORE PATH SELE	CT		OPERATION WORKS
u/gsk980tdi_bac	kup/L07SGCOA000	29	RESPECTIVELY.
			- the former
		1_0	ackup/user
			2 13-18-89

### 12.3.4 Format of Data Backup/Resume File

	File	Extension name	Content
Parameter file	PARAM	.PAR	State parameters, data parameters
Tool compensation data	TOFF	.CMP	Tool offset, tool wear
Pitch compensation	WOFF	.WMP	Pitch compensation
Alarm log	Alarm.his	.his	Alarm log
PLC program	No requirements	.ld2	PLC programs
PLC parameter	plcpar	.dat	K, D, DT, DC parameters
Part program	O0000~O9999	.CNC	Part programs

# 12.3.5 Level Explanation of Data Backup/Resume Operation

	System	More than the 5 <sup>th</sup> grade password
	parameters	
	Tool	More than 5 <sup>th</sup> grade(including the 5 <sup>th</sup> grade)
	compensation	password
	data	the second secon
	Pitch	More than 5" grade(including the 5" grade)
Backup	compensation	password
operation	Alarm log	More than 5 <sup>th</sup> grade(including the 5 <sup>th</sup> grade)
operation		password
	PLC programs	More than 5 <sup>th</sup> grade(including the 5 <sup>th</sup> grade)
		password
	PLC programs	More than 5 <sup>th</sup> grade(including the 5 <sup>th</sup> grade)
		password
	Part programs	More than 5 <sup>th</sup> grade(including the 5 <sup>th</sup> grade)
		password
	System	More than 3 <sup>rd</sup> grade(including the 3 <sup>rd</sup> grade)
	parameters	password
	Tool	More than $E^{th}$ are defined using the $E^{th}$ are defined as
	compensation	More than 5 grade(including the 5 grade)
Resume operation	data	password
	Pitch	More than 2 <sup>nd</sup> grade(including the 2 <sup>nd</sup> grade)
	compensation	password
	PLC programs	More than 5 <sup>th</sup> grade(including the 5 <sup>th</sup> grade)
		password
	PLC	More than 2 <sup>nd</sup> grade(including the 2 <sup>nd</sup> grade)
	parameters	password
	Part programs	More than 4 <sup>th</sup> grade(including the 4 <sup>th</sup> grade)
		password

# 12.4 System Update

In the system update page, the CNC update operation can be performed by the U-disk. The updated file is registered under the root-directory of the U-disk when the operation is performed; so that the CNC can be operated holding on the MDI working method and keeping on the stop state.

	S0000 T0100
YSTEM UPGRADE	HELP
RISYSTEM SOFTWARE UPGRADE	THIS PAGE IS ONLY ONE UPGRADE OPTION, SO CANCELLATION WI LL NOT BE ALLOWED.
PDATE SYSTEM SOFTWARE, UPGRADE THE SYSTEM	× 13-10-11



Select the update system by soft button, and confirm the update state by Note: Page update can be entered above the 2-level authorities.

# 12.5 Notes

The user should pay more attention to the followings during executing the data backup/resume operation:

- 1) Need more than the 2<sup>nd</sup> grade password(including the 2<sup>nd</sup> grade) to resume more than (including be equal to) 9000 part programs;
- It is necessary to connect the GSKLINK bus normally when the back up/recovery of the servo parameter is performed;
- 3) Backup/resume operation must be in MDI mode;
- 4) When the user executes the data backup operation, the system automatically replaces all files in "U:\gsk980TDi\_backup\user", the user should save them as when they cannot be replaced;
- 5) Stop part programs running before data backup/resume;
- 6) They must not stop unless the data backup/resume operation is completed;
- 7) The system is turned on again after the data resume is done.


## CHAPTER 13 COMMUNICATION

## 13.1 GSK980TDi Communication Software GSKComm

GSKComm is an allocated project administrator. It can execute the upload/download between PC and CNC, conveniently transmit batch with easy operation, high communication efficiency and reliability.

The followings introduce communication transmission and setting between GSK980TDi and GSKComm. Refer to GSKComm explanations about GSKComm communication software functions.

## 13.1.1 GSKComm's System (PC) Requirements

Hardware: general PC with RS232 serial port, serial communication cable (3-wire) Operation system: Microsoft Windows 98/2000/XP/2003

## 13.1.2 Software Interface

Interface after GSKComm's initial run:

GSKComm - No project	is selected	
Eile View Comunication He	elp	
	· · · · · · · · · · · · · · · · · · ·	
Workspace	File Size	Modified Date
😨 CNC Project		

Fig. 12-1 file download (  $\text{PC}{\rightarrow}\text{CNC}$  ) interface

GSKComm software takes an administrator as a unit to complete management. When it run firstly, it does not upload project files, at the moment, the user should create an project program or upload project to execute the communication operation. The display is shown below after the an project is created:



	001007	
Elle View Comunication	Help	
<b>G G G G</b>	🛛 🧈 📂 🖽 💈	
Workspace	File Size	Modified Dat
E 👰 CNC Project		
- NewPrj (980TDc)		
Dudder File		
Svetam Filas		
U Dyatem Titles		
\$		13

At the mode, the user can receive the files from the CNC to the current project or send files in the current project to the CNC.

## 13.1.3 Receiving Files (CNC→PC)

Click the option [Receive files from CNC] in [Communication] and GSKComm can receive files from the CNC after the current project is selected as follows:

🔚 GSKComm -	NewPrj(980TDc)		
File View Q	omunication Help	2	
Vorkspace	Sendi Files Receive Files DNC Comunication Manage Part Programs Comunication Setup	le Size	Modified Date
<			

After [Receive Files] is clicked, a dialog box about receiving files from the CNC, the required files from the CNC including part programs, tool compensation (TOFF. CMP), pitch compensation (WOFF.WMP), parameters (PARAM.PAR).



After the user selects the required file, [ Start Receiving ] is pressed and the system pops up a

20 00 00 C	Addeive filted from KNC	×	
Torkspace	Select the required files		_
<ul> <li>@ Def Freyet</li> <li>@ Jeff (90Th)</li> <li>Leder File</li> <li>Peter Freyes</li> <li>System Files</li> </ul>	Control C		

path selection dialog box to save the received files as follows:

Select the save path, start to receive the file from CNC to PC by pressing [i.e. Confirm] as follows:

orkspace	File Size	Modified Date	
GE Traject			
Ladder Fi			100
C Fart Prop			
	## /user/HCDATA/HOPF HMP ## /user/HCDATA/USEBBE PAE		2
	/maar/MCDATA/TABAM FAB		
	/user/MCFRDG/00101.CMC		100
	connutation	SUTATU SMITA	
	Status: Receiving file data	Last Error:	
	Retry Times: 0	Speed: 8541 byte/s	
	Current Fils: 28/248	1a 3/27	
	(		
	A11: 9%		
		and a	

After the receiving is done, the system displays below:

GSECom - Novier j (98010	a)		
Elle Yew Comunication Hel	p		
10 0 0 0 B	1 H 13 1		
forkspare	File Size	Modified Date	
CHC Project			
- ( Seefr j (900TDc)			
C Ladder File			
- O Part Programs			
00101 CHC	113% Byte (3.11.32)	2011-09-29 17 94 49	
<ul> <li>00100, CMC</li> </ul>	944 Byts	2011-04-29 17:04.50	
DO022 CHC	806 Byta	2011-04-29 17 04 50	
► 00021 CHC	524 Byte	2011-04-29 17:04:50	
(a) 00018 CMC	245 Tyte	2011-04-29 17 04 50	
00012 CHC	873 Byte	2011-04-29 17:04:50	
P 00011 CHC	612 Byte	2011-04-29 17:04:50	
(e) 00010 CMC	128 Byte	2011-04-29 17-04-50	
(P) 00009.CHC	92 Dyte	2011-04-29 17:04:50	
(a) 00007. CHC	39 Byte-	2031-04-29 17-94-50	
D0006, CHC	53 Eyts	2011-04-29 17:04:50	
00005 CHC	300 Eyts	2011-04-29 17 04 51	
(a) 00004 CMC	130 Epta	2011-04-29 17:04 51	
(a) 00003 CMC	40 Byte	2011-04-29 17:04 51	
(a) 00002 CMC	52 Eyte	2011-04-29 17:04 51	
(a) 00001.CNC	1103 Syta (1 08 KB)	2011-04-29 17 04 51	
P 00003 CHE	OD Byte	2011-04-29 17-04 51	
(P) 00000. CHC	744 Byts	2011-04-29 17:04.51	
00200 CMC	135 Byte	2011-04-29 17-04-51	
C NUFF. WW	4120 Eyts (4 02 MB)	2011-04-29 17:03:39	
CA WSEREE PAR	25048 Byte (24 46 33)	2931-09-29 17 93 42	
ALTE FAS	15360 Byte (15.00 12)	2011-04-29 17 04 27	

## 13.1.4 Sending Files (CNC→PC)

After the current project file is selected, the user clicks [Send projects to CNC] in the menu [Communication], and so the receiving file from CNC is done. A dialog box to send files to CNC is popped up as follows:

	Send to the		8
aca	Select the required files		
Berriging Start (1997)     Berriging Start	Image:	-> 00191.0% -> 00191.0% -> 00022.0% -> 00021.0% -> 00031.0% -> 00031.0% -> 00031.0% -> 00005.0% -> 0005.0% -> 0005.0%	
■ 00000 CMC	Cover the file in CNC		
¥077, ¥82		[Transmitten]	

Hereby, the user can select the required receiving files from CNC including part programs, tool compensation (TOFF.CMP), pitch compensation (WOFF.WMP), parameters (PARA.PAR). The part programs which can be altered are saved to the file name of the CNC. Move the cursor to the part program required to alter its program name, double-click the left key to pop up a dialog box as Fig. A, and the file which can be altered is saved the file name of the CNC (as Fig. B).

Save	00022.0	CNC		
As O	0022			CNC
As O	0022			. CNC
_	OK		Cance	1

Save	00022. CNC	
As D	1234	. CNC

Fig. B



Select the required file to the CNC and confirm the saved file name, then press [start sending], and the file is started to send to the CNC as follows:

CK: Project SevPrj (SBOTDc) Ludder Fi Fatt From	file Size	Redrived Date	
OUTOL     O	C. Uncreasers and Settings Making C. Macquest and Settings Making Compared Settings File Sets Ratery Tises. 0 Correct File. UK/IX All 708	stream A B VOOD C CE stream A B VOOD C CE TRANS A B VOOD C CE T	
00000	Tel Polo	2011-04-20 17	04.51
(a) 00200 CMC	135 Esta	2011-04-29 17	04 51
WOFF WH?	4120 Byta (4 0	2 131) 2011-04-29 17	03 30
A USERBE PAR	25048 Byte (24	45 133) 2011-04-29 17	03:42
A MACEN PAR	15360 Byta (15.	00 13) 2011-04-29 17	104 27

When a file name in the CNC is the same that of the transmitting, a dialog box is popped up to select the covering, skipping the file or cancelling transmission as follows:

pace	File Size	Hodified Date
CHC Project (a) NewFrj (980TDe) (c) Ladder Fil (c) Fart Prog	ennend (kanj	6
00101 C.V	Decuments and Dettange Administratory	
00022     C.     00021     C.     00018     C.     00018     C.	Borus Cover File Borus Borus 1 Cover is file "00101 Cl to cover it?	E" in DE, viether 😤
00011     00010     Statm     00009     Betry	s Se [ Yez ] Cover file I He ] Skip this fil Time [Cancel] Cancel comin	la Louison
00006. Dury     00005. Dury     00004. All	ent F Same option for all	Cancel
<ul> <li>₩ 00002;</li> <li>₩ 00001;</li> </ul>	Cancel	3
€ 00000.CHC	744 Syte	2011-04-29 17:04:51
TOTE THE	135 Byte 4120 Bets (\$ 02 ED)	2011-04-29 17:04:51
A ISTREE PAR	25050 Evt+ (24 40 ED)	2011-04-29 17:02:42
CA MACHE PAR	15360 Evt. (15.00 KB)	2011-04-29 17 04 27

When the part program name is the same that of the transmitted file, the covering cannot be done, otherwise, the system pops up the wrong prompt as follows:



## 13.1.5 Part Program Management

Select the current project file, then click [Manage Part Programs] in the menu [Communication], and the part programs in the CNC are managed. The system pops up a dialog box to manage part programs in the CNC as follows:

	Sunaging Part Programs	8
Forkspace	Select Files	-
A Mesefri (900TDc)	Tritterms	-
Ladder File	E 00000 CMC	744 Exts
MACHE PAB	S C 00001 CHE	1103 Byts
+ D Tart Tragras	Fi □ 00002 CHC	52 Byte
C USEREE FAR	00003 CHC	40 Byte
C NORP AND	E 00004.CHC	130 Byte
		200 Byte
	O 00006 CHC     O	63 Byte
	OCOUT. CMC     OCOUT. CMC	30 Byta
	O0008.CHC	69 Byts
	■ □ 00009.CHC	92 Byta
	■ 0 00010 CMC	128-Byte
	E 00011 CHC	612 Dyta
		073 byte
	▶ □ 00018.CHC	246 Dyte
		524 Byta
	00002.CHE	606 Byts
		994 Dyta
		1134 byte
	E G MED CH.	1.35 Dy14
	14	× 1

Press [Delete File] and the selected part programs are deleted in the CNC after the required programs are selected.

Note: The program being used in the CNC cannot be deleted.

## **13.2 Preparatory Before Communication**

## 13.2.1 Communication Cable Connection

DB9 male plug is inserted into CN51 communication interface of the CNC, DB9 female plug is inserted in to DB9-male serial port (COM0 or COM1) of PC. Connect the communication cable when PC and CNC are turned off.

## 13.2.2 Communication Setting Baud Rate

Setting the baud rate of communication ensures that the baud rate of PC is the same that of the CNC communication.

The communication baud of the serial port is set by No.044; click [Communication Setup] in the menu [Communication] and the system pops up a dialog box as follows:

Comunication Se	rtup 🔯
Communicatinon De	vice O NET
COM Setup	
Port: COM	1 💌
Baud Rate(bps):	115200
Net Setup CNC IP:	168 () (j00
OK	Cancel

Set the serial port and baud rate. The baud rate should be not less than 4800 when the data is transmitted between CNC and PC, the factory setting is :115200.

## 13.2.2.1 Network Cable Connection

Use the common network cable, one terminal connects with the internet access of GSK980TDi, the other one directly connects the Computer or Router access.

## 13.2.2.2 Communication IP Setting

Set the IP address of communication, so that the IP address between PC and CNC communication are consistant.

The IP setting of the GSK980TDi is as follows: \_\_\_\_\_\_ and then set the IP address and sub-net mask, etc. after entering the system IP setting page, refer to the following figure:

JOG	<b>S0000 T00</b>	00 年
SYSTEM IP	00000 N0000	
	,	
IP ADDRESS 192 . 168 . 7 . 135	,	
SUBNET MASK 255 . 255 . 0 . 0		
DFLT. GATEWAY 192 . 168 . 11 . 254		
MAC ADDRESS 882288855888		
	,	
	,	
	<u>@ 1/:19:41</u>	
SETTING CLOCK DUC & FUNC. SKINK SET	IP	

Wherein, the IP address can not be identical with the other PC computer in the network or CNC. The subnet mask should be same with the PC computer or the subnet mask of the router; it is not necessary to alter the default subnet.

In the GSKComm, click the [Communication Setting] in the [Communication] menu, its corresponding dialog frame is shown below, refer to the following figure:

Communicati	on Setup	×	
Communication O Seria	n Device 1 port 💿 Network		
Serial Port	Setting		
Port: COM	1		
Baudrate	115200		
-Network Sett	ing		
CNC IP:	.92 . 168 . 0  . 100		
OK Cancel			

Network selection of communication equipment, write the IP address set to CNC in the network setting.

Note 1: Stop machining when the machining is being done to get the stable communication.

Note 2: Must not turn off during the data transmission, otherwise, it causes the mistaken data transmission.



## CHAPTER 14 MACHINING EXAMPLES



Machine a part by a bar stock with dimension  $\Phi$ 136mm×180 mm, as follows:



Machine it with 4 tools as follows:

Tool number	Tool shape	Explanation
No. 1	<u>ې</u>	Outer circle rough turning tool
No. 2		Outer circle finish turning tool
No. 3		Grooving tool, tool width 3mm
No. 4		Threading tool, tool nose angle 60°

## 14.1 Programming

Set up the workpiece coordinate system as Fig.14-1 according to the machining process and the codes introduced in this manual. The programming steps are as follows:

O 0 0 0 1 ;		Name of the part program
N 0 0 0 0	G0 X150 Z50 ;	Position to the safety height for tool change
N 0 0 0 5	M12 ;	Clamp the chuck
N 0 0 1 0	M3 S800 ;	Start the spindle with speed 800
N 0 0 2 0	M8 ;	Turn on the cooling
N 0 0 3 0	T0101 ;	Change for the No. 1 tool
N 0 0 4 0	G0 X136 Z2 ;	Approach the part
N 0 0 5 0	G71 U0.5 R0.5 F200 ;	Cut depth 2mm and retract 1mm
N 0 0 5 5	G71 P0060 Q0150 U0.25 W0.5 ;	0.25mm pre-reserved in X axis, 0.5mm machining allowance in Z axis
N 0 0 6 0	G0 X16 ;	Approach to the end face of the part
N 0 0 7 0	G1 Z-23 ;	Cut the Φ16 outer circle
N 0 0 8 0	X39.98;	Cut the end face
N 0 0 9 0	W-33 ;	Cut the Ф39.98 outer circle
N 0 1 0 0	X40 ;	Cut the end face
N 0 1 0 5	W-30 ;	Cut the Φ40 outer circle
N 0 1 1 0	G3 X80 W-20 R20 ;	Cut the convex arc
N 0 1 2 0	G2 X120 W-20 R20 ;	Cut the concave arc
N 0 1 3 0	G1 W-20 ;	Cut the Φ120 outer circle
N 0 1 4 0	G1 X130 W-5;	Cut the cone
N 0 1 5 0	G1 W-25 ;	Cut the Ф130 outer circle
N 0 1 6 0	G0 X150 Z185;	Rough cut end and back to the tool change point
N 0 1 7 0	T0202 ;	Change for the No.2 tool and execute its offset
N 0 1 8 0	G70 P0060 Q0150 ;	Fine cut cycle
N 0 1 9 0	G0 X150 Z185;	Rough cut end and back to the tool change point
N 0 2 0 0	T0303 ;	Change for the No.3 tool and execute its offset
N 0 2 1 0	G0 Z-56 X42 ;	Approach to the part

N 0 2 2 0	G1 X30 F100 ;	Cut the Φ30 groove
N 0 2 3 0	G1 X37 F300 ;	Return
N 0 2 4 0	G1 X40 W1.5 ;	Chamfering
N 0 2 5 0	G0 X42 W30 ;	Keep the width of the grooving
N 0 2 6 0	G1 X40 ;	
N 0 2 6 2	G1 X37 W1.5 ;	Chamfering
N 0 2 6 4	G1 X10 ;	Cut the Φ10 groove
N 0 2 6 6	G0 X17 Z-1;	
N 0 2 6 8	G1 X16 ;	
N 0 2 7 0	G1 X14 Z0 F200 ;	Chamfering
N 0 2 8 0	G0 X150 Z50 ;	Return to the tool change point
N 0 2 9 0	T0404 S100 ;	Changing for the No. 4 tool and set the spindle speed for 100
N 0 3 0 0	G0 X42 Z-20 ;	Approach the part
N 0 3 1 0	G92 X39 W-34 F3 ;	Thread-cutting cycle
N 0 3 2 0	X38 ;	Feed 1mm for the 2 <sup>nd</sup> cutting
N 0 3 2 0	X37 ;	Feed 1mm for the 3rd cutting
N 0 3 3 0	X36.4 ;	Feed 0.6mm for the 4th cutting
N 0 3 3 2	X36 ;	Feed 0.4mm for the 5th cutting
N 0 3 4 0	G0 X150 Z50 ;	Return to the tool change point
N 0 3 5 0	T0100 U0 W0 ;	Change for the No.1 tool and execute its offset
N 0 3 6 0	M5 ;	Turn off the spindle
N 0 3 7 0	M9 ;	Turn off cooling
N 0 3 8 0	M13 ;	Unclamp the chuck
N 0 3 9 0	M30 ;	Program ends

## 14.2 Program Input

14.2.1 View a Saved Program

Press to enter program interface , and press to enter the local catalog page as follows:

L					20000 10	101
PRI	OGRAM -	> LOCAL	DIRECTORY		UUUUT NUUUU	2
	TOTAL:	36	SPACE: 64.0 M	USED: 1.8 M	IDLE: 62.2 M	OPE
	NAME	SIZE	DATE PRO	GRAM PREVIEW 00000		BINE
	00000	501 B	2015-11-18 13 1	\$1000;		OP
Ņ	00001	0.0	2015-11-18 G0 1	(0 Z5		3
	00002	52 B	2015-09-18 61	20;		D
	00003	40 B	2015-09-18 30			LDE
	00004	130 B	2015-09-18 671	111 R0 5 F200		-10 00
	00005	46 B	2015-09-18 - 671	P1 02 U0.5 W0.5.		U D1
	00006	63 B	2015-09-18 N1 (	G1 X18		12
	00007	39 B	2015-09-18 X20	W-1;		ETHIN
	80000	85 B	2015-09-18 Z-20	):		FINDE
	00009	92 B	2015-09-18 X26	<u>.</u>		DEMAN
	00010	128 B	2015-09-18	W-1:		IL ROU
	00011	612 B	2015-09-18 670	P1 02		
	00012	873 B	2015-09-18 61	(30 25		SA
	00018	246 B	2015-09-18 \$500	):		AS.
	00021	524 B	2015-09-18 🔽 60 :	K20 Z2		*
		-	Concession of the local division of the loca		₩ 08:54:58	MORE
2	Col.	MD1	CNC TA USE		PREV	NEXT

In above window the names of the programs saved can be viewed for renaming the new program.

## 14.2.2 Creating a New Program

Ο Enter the local catalog page in Edit mode, press address key , choose a name that is not 1 Ο Ο Ο same with the ones in this window (i.e. 0001), key in the number key and 

to create a new program as follows:

EDIT S0000 T	
PROGRAM -> LOCAL PROGRAM [00001] INSER	DOGOT NOODO PAPO SEARCI SEARCI LABO
	08:55:30 MORE:
PROG CONTENT	TRACK PREV PAGE

Input the characters of the above edit program one by one and the editing program is done.

## 14.3 Checkout a Program

#### **Graphic Setting** 14.3.1

to enter graph interface as follows: Press

EDIT	S0000 T0000		00
TRACK DISPLAY		00000 00000	STAR
- G50 X0 Z100 M03 S1000 T0101		IMACHINE] X 0.0000 7 0.0000	(S)
			ZOOM+
			ZOOM
			FIXED
			CHANGE
			MOVEDIS
		= 15-01-44	GRAGH

## 14.3.2 Program Check





When there is error in the program path, analysize the error and alter the part program, make another checkout for the program by the method above till the error is eliminated.

## 14.4 Tool-setting & Running

1) Move the tool to a safe position, execute T0100 U0 W0 command in PROGRAM->MDI page in MDI mode, and cancel the tool offset;

2) Move the tool to cut in the part end surface;



3) Release the tool along X when Z does not move, and stop the spindle, execute G50 Z0 in PROGRAM->MDI page in MDI mode to set the coordinate of Z axis;

4) Switch to tool offset page and input Z0 to No.001 offset;



5) Move the tool and make it to cut along the outer circle of the part;

6) Release the tool along Z when X does not move, and stop the spindle, measure the dimensions of the outer circle of the part (e.g. The measuring value is 135mm);

7) Execute G50 X135 command in PROGRAM>MDI page in MDI mode to set the coordinate of X axis;

- 8) Switch to tool offset page, and input X135 to No.001 offset;
- 9) Move the tool to a safe position, and change No. 002 tool;

10) Start the spindle and move the tool to the tool-setting point, as A point in the following figure;



11) Switch to TOOL OFFSET window, move the cursor to No.002 offset and input X135 Z0;

12) Move the tool to a safe position, and change the No. 003 tool ;

13) Start the spindle and move the tool to the tool-setting point, as A point in the following figure;



- 14) Switch to TOOL OFFSET window, move the cursor to No.003 offset and input X135 Z0;
- 15) Move the tool to a safe position, and to change the No. 004 tool;
- 16) Move the tool to the tool-setting point, as point A in the following figure;





- 17) Switch to tool offset, move the cursor to No.004 offset and input X135 Z0;
- 18) Move the tool to a safe position after the tool-setting is finished;
- 19) Start the machining in Auto mode;
- 20) If there is any error between the designed and the actual dimensions, the tool offset may be altered till the part dimensions are within the tolerance.

Note: Press key to make the auto running to pause if dwell is needed during the machining. Also if

emergency occurs, the user presses the key, Emergency stop button to cut off the power to terminate the program running.

# III Connection

## CHAPTER 1 INSTALLATION LAYOUT

## 1.1 GK980TDi System Connection

## 1.1.1 GK980TDi Rear Cover Interface Layout



Fig. 1-1 GSK980TDi rear cover interface layout

## 1.1.2 Interface Explanation

- CN1: power supply interface
- CN4, CN5:GSKLINK bus connection interface B,A are connected with the servo unit and IO unit
- CN15:Analogy spindle 1, male socket of 9-cord in type D, connect with analogy spindle 1
- CN16:Analogy spindle 2,male socket of 9-cord in type D, connect with analogy spindle 2
- CN21: encoder, pin15 D male, connect with spindle encoder 1
- CN22: encoder, pin15 D male, connect with spindle encoder 2
- CN31: MPG, pin26 D male, connect with MPG
- CN51: communication, pin9 D female, connect PC RS232 interface
- CN54:Ethernet interface, plug are connected with the PC to transmit data
- CN61: input, pin44 D male, connect with machine input
- CN62: output, pin44 D female, connect with machine output
- CN66:the spindle override input signal, 4 input interfaces are connected with the additional panel
- CN67:the feedrate override input signal, 5 input interfaces are connected with the additional panel
- CN78:4 input/2 output interfaces, 8 connection terminals, machine input,output

## 1.2 GSK980TDi Installation

## 1.2.1 GSK980TDi External Dimensions

See Appendix I, II.

## 1.2.2 Preconditions of Cabinet Installation

- The dust, cooling liquid and organic resolution should be effectively prevented from entering the cabinet;
- The designed distance between the CNC back cover and the cabinet should be not less than 20cm, the inside and outside temperature difference of the cabinet should be not more than 10°C when the cabinet inside temperature rises;
- Fans can be fixed in the cabinet to ventilate it;
- The panel should be installed in a place where the cooling can't splash;
- The external electrical interference should be taken into consideration in cabinet design to prevent it from interfering the CNC system.

## 1.2.3 Measures Against Interference

In order to insure the CNC stable working, the anti-interference technology such as space electromagnetic radiation shielding, impact current absorbing, power mixed wave filtering are employed in CNC design. And the following measures are necessary during CNC connection:

- 1. Make CNC far from the interference devices (inverter, AC contactor, static generator, high-voltage generator and powered sectional devices etc.);
- 2. To supply the CNC via an isolation transformer, the machine with the CNC system should be grounded, the CNC and drive unit should be connected with independent grounding wires at the grounding point;
- To inhibit interference: connect parallel RC circuit at both ends of AC winding (Fig. 1-2), RC circuit should approach to inductive loading as close as possible; reversely connect parallel freewheeling diode at both ends of DC winding (Fig. 1-3); connect parallel surge absorber at the ends of AC motor winding (Fig. 1-4);



- 4. The CNC leadout cables use the twisted shield cable or shield cable, the cable shield tier is grounded by an terminal at CNC side, signal cable should be as short as possible;
- 5. To reduce the mutual interference among the CNC signal cables, and among the strong current, the wiring should follow the following:

Table 1-1 The Wiring requirem	ent
-------------------------------	-----

Group	Cable type	Wiring requirement		
A	AC power cable	Tie up A group cables with a clearance at least 10c		
	AC coil	from that of B, C groups, or shield A group cables from		
	AC contactor	electromagnetism		
	DC coil(24VDC)			
В	DC relay(24VDC)	Tie up B and A group cables separately or shield B		
	Cables between CNC and	group cables: and the further B group cables are from		
	strong-power cabinet	that of C group, the better it is		
	Cables between CNC and			
	machine			
	Cables between CNC and			
	servo drive unit	Tie up C and A group cables separately, or shield C		
6	Position feedback cable	group cables; and the cable distance between C group		
C	Position encoder cable	and B group is at least 10cm and they are twisted pair		
	Handwheel (MPG) cable	cables.		
	Other cables for shield			

## CHAPTER 2 DEFINITION & CONNECTION OF INTERFACE SIGNALS

## 2.1 GSKLink Bus Interface

Bus interfaces of GSK980TDi are CN4 and CN5 (GSKLinkB and GSKLinkA), which is connected with the GSKLink bus communication function, the feedrate servo drive unit, spindle drive unit and extended I/O communication. GSKLink bus communication uses a loop control, and therefore, CN4 AND CN5 interfaces should be used together.

GSKLINK bus connection is shown below:

2	TX-		2	TX-
1	TX+	<u></u>	1	TX+
6	RX-		6	RX-
3	RX+	\	3	RX+
	Outmost layer shielding cable			Outmost layer shielding cable

Fig. 2-1 GSKLink communication connection

## 2.2 Being Connected with Spindle Encoder

## 2.2.1 Spindle Encoder Interface Definition



Name	Explanation
*PAS/PAS	Encoder A phase pulse
*PBS/PBS	Encoder B phase pulse
*PCS/PCS	Encoder C phase pulse

Fig.2-2 CN21 encoder interface (15-core D type male socket)

## 2.2.2 Signal Explanation

\*PCS/PCS,\*PBS/PBS,\*PAS/PAS are the encoder C, B, A phases differential input signals respectively, which are received by 26LS32; \*PAS/PAS,\*PBS/PBS are orthogonal square wave with phase shift 90° and their maximum signal frequency is less than 1MHz; the encoder pulses for GSK980TDi are set at will by parameter, the setting range is from 100 to 5000.

Its interior circuit is shown in Fig. 2-13: (n=A, B, C)



Fig. 2-3 Encoder signal circuit

## 2.2.3 Spindle Encoder Interface Connection

GSK980TDi is connected with spindle encoder shown in Fig. 2-4, and it uses twisted pair cables. (exemplified by CHANGCHUN YIGUANG ZLF-12-102.4BM-C05D encoder):



Fig. 2-4 GSK980TDi is connected with the encoder

## 2.3 MPG Connection

## 2.3.1 MPG Interface Definition



Fig.2-5ACN31 MPG interface(26-core DB type male socket)



Fig. 2-5B CN32MPG interface (4-point wiring terminal)

Signal	Explanation	
HA+,HA-	MPG A phase signal	
HB+,HB-	MPG B phase signal	
+24V		
+5V,0V		
Stand	ard PLC Definition	
Address	Function	
X6.0	X MPG axis selection	
X6.1	Y MPG axis selection	
X6.2	Z MPG axis selection	
X7.0	4TH_axis selection signal	
X7.1	5TH_axis selection signal	
X6.3	Increment0.001	
X6.4	Increment0.01	
X6.5	Increment0.1	

Signal	Explanation
HA	MPG A phase signal input
HB	MPG B phase signal input
GND	0V
VCC	5V

## 2.3.2 Signal Explanation

HA,HB are the MPG A, B phase input signals respectively. Their interior circuit is shown in Fig. 2-6:



Fig. 2-6 MPG signal circuit

GSK980TDi is connected with MPG shown in Fig. 2-7:



Fig. 2-7A CN31 connects with the single-port MPG input

	CN31		MPG
1	HA+	$\vdash w / \vdash$	A+
2	HA-	$\vdash \land \vdash$	A-
3	HB+	$\vdash$	B+
4	HB–	$\vdash \land \vdash$	B-
14	+5V	$\vdash \cdots \vdash \vdash$	+5V
11	OV	$\vdash \land \vdash /$	OV
Me	tal shell		null

Fig. 2-7B CN31 connects with the difference MPG input

C	N32	MPG
1	А	A
2	В	В
3	OV	OV
4	+5V	+5V

Fig. 2-8 CN32 connects with MPG

## 2.4 Analog Spindle Interface

## 2.4.1 Analog Spindle Interface Definition



Fig.2-9 CN15 analogy spindle interface (male socket of 9-cord in type D)



Fig.2-10 CN16 analogy
spindle interface (male
socket of 9-cord in type D)

## 2.4.2 Inverter Connection

The analog spindle interface SVC may output 0~10V voltage, its interior signal circuit is shown in Fig. 2-11:



GSK980TDi is connected with the inverter shown in Fig. 2-12:

Signal	Explanation	
SVC	0~10V Analog voltage	
GND	Signal grounding	

Standard PLC Definition		
Address	Function	
X5.0	Spindle 1 alarm signal	
X5.1		
V5.0	series spindle 1 rotation	
13.0	signal CW(positive)	
V5 1	series spindle 1 rotation	
13.1	signal CCW(negative)	
Y5.2		
X8.0	Spindle 2 alarm signal	
X8.1		
Vº O	series spindle 2 rotation	
10.0	signal CW(positive)	
V9 1	series spindle 2 rotation	
10.1	signal CCW(negative)	
Y8.2		

## **CNCmakers**



### Fig. 2-12 GSK980TDi is connected with the inverter

## 2.5 GSK980TDi / GSK980TDi-V being Connected with PC

## 2.5.1 Communication Interface Definition

 $\left[ \circ \right]$ 1: 6: 0 2: RXD 0 7: 8: 0 3: TXD 0 0 4: 0 9: 0 5: GND  $\bigcirc$ 

Signal	Explanation
RXD	Receiving data
TXD	Transmitting data
GND	Signal grounding

Fig. 2-13 CN51 communication interface (DB9-female)

## 2.5.2 Communication Interface Connection

GSK980TDi can perform the communication by CN51 and PC(optional communication software). GSK980TDi is connected with PC shown in Fig 2-14:



Fig. 2-14 GSK980TDi is connected with PC

374

## 2.6 Network Interface

PIN NO.	Signal	PIN NO.	Signal
1	TXDLAN+	9	LINK_LED
2	TXDLAN-	11	LAN_LED
3	RXDLAN+	10, 12	VDD33
6	RXDLAN-	13, 14	Shell grounding

Network interfaces of GSKTDi CN54 are standard and their definitions are shown below:

Note: TXD+ and TXD- are difference signal, as well the RXD+ and RXD-, which are required to connect with twisted-pair.

## 2.7 Power Interface Connection

The power box is applied in GSK980TDi system, which involves 2 groups of voltage: +24V. The connection of power box to GSK980TDi CN1 interface has been done for its delivery from factory, and the user only need to connect it to a 220V AC power in using.



Fig. 2-15 system power interface CN1

24VOM is connected with the output interface CN62 24V. When GSK980TDi's power supply box supplies power supply for an external electron device, the supply box's +V is connected with 24VCOM. When an external power supply is used, its 24V is connected with 24VCOM and its 0V must be connected with the system's supply box's-V.

## 2.8 I/O Interface Definition

## Note!

The I/O function significances of the unlabelled fixed addresses of this GSK980TDi/GSK980TDi-V turning machine CNC system are defined by PLC programs (ladders), and they are defined by the machine builder when matching with a machine, please refer to the manual by the machine builder.

The fixed address I/O function not be marked are described for GSK980TDi PLC. The described contents without other special explanation are also applied to GSK980TDi-V.



Fig.2-16 CN61 inputinterface (male socket of 44-cord in type D)

	Pin	Address	Function	Explanation	
	21~24	0V	Power supply		
ļ			interface		
	17~20	Floating	Floating	Floating	
	25~28				
	1	X0.0	SAGT	Guard door check signal	
	2	X0.1	Reserved	Reserved	
l	3	X0.2	DIQP	Chuck input signal	
l	4	X0.3	DECX(DEC1)	X deceleration signal(fixed address )	
l	5	X0.4	DITW	Tailstock control signal	
	6	X0.5	ESP	External emergency stop signal	
-				(fixed address )	
-	7	X0.6	PRES	Pressure check signal	
			<b>T</b> 05	Tool signal 5 /Sensor E	
	8	X0.7	105	(LIO_SHING Tool Post )/YA_XING locking	
-				signal	
	0	X1.0	TOC/ atraha	1 ool signa 1 6/ strobe signal	
	9	X1.0	106/ Strode	(YantaiAK31)/Sensor F(LIO_SHING Tool	
-				FUSE)	
	10	X1.1	T07/ pregraduation	switch/VantaiAK31)/VA_XING releasing	
-			T08/ tool post	Tool signal 8//tool post worktable overheat	
	11	X1.2	worktable overheat	check (YantaiAK31)	
ŀ	12	X1 3		Z deceleration signal(fixed address )	
ŀ	12	X1.0	Reserved	Reserved	
ŀ	14	X1.1	M41I	Shifting gear to 1st gear in-position	
ŀ	15	X1.6	M42I	Shifting gear to 2nd gear in-position	
ŀ		7110		Tool signal / Sensor A(LIO SHING Tool	
	16	X1.7	T01	Post )	
ŀ				Tool signal / Sensor B (LIO SHING Tool	
	29	X2.0	T02	Post )	
ŀ				Tool signal / Sensor C (LIO SHING Tool	
	30	X2.1	1 T03	Post )	
ŀ				Tool signal / Sansar D. (LO. SHING Tool	
	31	X2.2	T04	Post )	
-	30	¥2.3		Y deceleration signal/fixed address )	
-	52	72.5	DECT(DEC2)	Ath deceleration signal (fixed	
	33	X2.4	DEC4/LUBS	address )/lubricating oil detection	
ŀ	34	X2.5	DEC5	5th deceleration signal (fixed address )/	
ŀ	35	X2.6	TCP	Tool post clamping signal	
ŀ	36	X2.0	FXHP	external hydraulic control input	
f	37	X3.0		X overtravel	
ŀ	38	X3.1	LMIY	Y overtravel	
ŀ	39	X3.2	LMIZ	Z overtravel	
ł	40	X3.3	WQPJ/VPO2	Chuck releasing in-position signal	
ŀ	41	X3.4	NQPJ/SALM2	Chuck clamping in-position signal	
ŀ	42	X3.5	SKIP	G31 skip signal	
ŀ	43	X3.6 AEX X tool measure position arrival signal (		X tool measure position arrival signal (G36)	
ŀ	44	X3.7	AEZ	Z tool measure position arrival signal (G37)	
L			l · · <b>==</b>		

Note: Partial input interface is the fixed address for some functions, for example: the signal of ESP, DECX, DECZ or SKIP, etc. If this function does not use, it will be redefined in PLC.

# **CNCmakers**

$\bigcirc$
$\bigcirc$

Fig.2-17 CN62output interface(female socket of 44-cord in type D)

Pin	Address	Function	Explanation
17,18,19,	0.7	Power supply	Power supply 0V terminal
26,27,28	00	interface	
20~25	+24V	Power supply	Power supply $\pm 24V$ terminal
		interface	
1	Y0.0	M08	Cooling output
2	Y0.1	M32	Lubricating output
3	Y0.2	HOLD	HOLD release output
4	Y0.3	M03	Spindle rotation (CCW)
5	Y0.4	M04	Spindle rotation (CW)
6	Y0.5	M05	Spindle stop
7	Y0.6	SCLP	spindle clamped output
8	Y0.7	SPZD	Spindle brake
9	Y1.0	S1/M41	Spindle machine gear output 1
10	Y1.1	S2/M42	Spindle machine gear output 2
11	Y1.2	S3/M43	Spindle machine gear output 3
12	Y1.3	S4/M44	Spindle machine gear output 4
13	Y1.4	DOQPJ(M12)	Chuck clamping output
14	Y1.5	DOQPS(M13)	Chuck releasing output
15	Y1.6	TL+	Tool post CCW rotation
16	Y1.7	TL-	Tool post CW rotation
			Tool post worktable brake
29	Y2.0	TZD/TLS	(YantaiAK31) / tool pot releasing
			(LIO_SHING Tool Post)
			Tool post worktable pregraduation coil
30	Y2.1	INDXS/TCLP	(YantaiAK31) / tool pot lock
			(LIO_SHING Tool Post)
31	Y2.2	YLAMP	Three-color lamp-yellow
32	Y2.3	GLAMP	Three-color lamp -green
33	Y2.4	RLAMP	Three-color lamp -red
34	Y2.5	DOTWJ(M10)	Tailstock forward
35	Y2.6	DOTWS(M11)	Tailstock backward
36	Y2.7	SLK	Protective door lock
37	Y3.0		reserved
38	Y3.1	HPST	Hydraulic control output
39	Y3.2	UO0/WKLP	User macro output 0/ indicator
40	Y3.3	UO1/EMOT1	User macro output 1/ Extended M
	10.0		function output signal 1
41	Y3.4	UO2/EMOT2	User macro output 2/ Extended M
			function output signal 2
42	Y3.5	003	User macro output 3
43	Y3.6	UO4	User macro output 4/Chip-cleaner
		ļ	
44	Y3.7	UO5	backward

Pin.No	Address	Function	Explanation
1	Y9.1	SPLAMP	Extended pause lamp
2	Y9.0	STLAMP	Extended start lamp
3	0V	0V	Power supply 0 V
4	X9.3	EXESP	Extended emergency stop signal
5	X9.2	reserved	reserved
6	X9.1	SP	Extended pause
7	X9.0	ST	Extended cycle start
8	+24V	24V	Power supply + 24V



	Pin.No	Address	Function	Explanation
	1	X29.4	BAUD1_A	Spindle override wave-band switch
				signal 0
	2	X29.6	BAUD1_B	Spindle override wave-band switch
		729.0		signal 2
	3	Floating	Floating	Floating
	4	+24V	24V	Power supply +24V
	5	¥20.7	BAUD1_E	Spindle override wave-band switch
	0	A23.1		signal 3
	6	X29.5 BAUD1 F	Spindle override wave-band switch	
	0	A23.0		signal 1
	7	INH	BAUD1_INH	INH





7

Fig.2-19 CN66

Pin.No	Address	Function	Explanation
1	X29.0	BAUD2_A	Feedrate wave-band switch signal 0
2	X29.2	BAUD2_B	Feedrate wave-band switch signal 2
3	Floating	Floating	Floating
4	+24V	24V	Power supply 24V
5	X29.3	BAUD2_E	Feedrate wave-band switch signal 3
6	X29.1	BAUD2_F	Feedrate wave-band switch signal 1
7	INH	BAUD2_INH	INH



- Note 1: Various functions can be defined to some of the input and output interfaces, and they are indicated by "/"sign in the table above.
- Note 2: If output function is active, the output signal is through on to 0V. If output function is inactive, the output signal is cut off by high impedance.
- Note 3: If input function is active, the input signal is through on to +24V. If input function is inactive, the input signal is cut off with it.
- Note 4: The effectiveness of +24V, COM terminals are equivalent to those of the GSK980TDi/GSK980TDi power box terminals that have the same names.

#### 2.8.1 Input Signal

Input signal means the signal from machine to CNC, when this signal is through on with +24V, the input is active; when it is off with +24V, the input is inactive. The contact of input signal at machine side should meet the following conditions:

Capacity of the contact: DC30V, 16mA above

Leakage current between contacts in open circuit: 1mA below

Voltage drop between contacts in closed circuit: 2V below (current 8.5mA, including cable voltage drop)

There are two external input types for input signals: one type is input by contact switch whose signals are from keys, stroke switch and contacts of relay at machine side, as shown in Fig. 2-21A:





The other type is input by switch with no contacts (transistor) as shown in Fig. 2-21B, 2-21C:





Fig. 2-21B Connection of NPN type



Fig. 2-21C Connection of PNP type

The input interface signals defined by PLC of GSK980TDi / GSK980TDi-V system involve XDEC, ZDEC, ESP, ST, SP/SAGT, PRES, DITW, DIQP, T01 $\sim$ T08, TCP and so on.

## 2.8.2 Output Signal

The output signal is used for the machine relay and indicator. When the output is enabled, the output state of its corresponding Y address is 1, and its output signal potential is 0V. When the output is disabled, the output state of its corresponding Y address is 0, this output signal represents as high-impedance state. The digital value output of I/O interfaces are owned the same structure, refer to the following figure:



Fig. 2-22 Circuit for digital volume output module

Its typical application is as follows:

• To drive LED

A serial resistance is needed to limit the current (usually 10mA) that goes through the LED by using output to drive LED, which is shown in Fig. 2-23:



## • To drive filament indicator

An external preheat resistance is needed to decrease the current impact at power on by using output to drive filament indicator, and this resistance value should be within a range that the indicator cannot be lighted up as shown in Fig. 2-24:




• To drive inductive load (such as relay)

To use output to drive an inductive load, it requires connecting a freewheeling diode near the coil to protect output circuit and reduce interference as shown in Fig. 2-25:

The significances of the output signal of I/O interface are defined by PLC program, these signals include S1 $\sim$ S4 (M41 $\sim$ M44), M3, M4, M5, M8, M10, M11, M32, TL-, TL+, U00 $\sim$ U05, DOQPJ, DOQPS, SPZD signals etc.. And their common terminal is +24V.

## 2.9 I/O Function & Connection

## Note !

The I/O function significance of this GSK980TDi / GSK980TDi-V turning machine CNC system is defined by PLC programs (ladders), and they are defined by the machine builder when matching with a machine, please refer to the manual by the machine builder.

The fixed address I/O function not be marked are described for GSK980TDi PLC. The described contents without other special explanation are also applied to GSK980TDi-V.

## 2.9.1 Stroke Limit & ESP

#### Relevant signal

ESP: emergency stop signal, alarm issued if the system is not connected with +24V EXESP: External emergency stop signa, when not be connected with +24V emergency alarm LMIX: X overtravel limit check input LMIY: Y overtravel limit check input LMIZ: Z overtravel limit check input

#### • Diagnosis data

0	0	0	ESP				
Pin		CN61.6					

#### Signal diagnosis

Signal	ESP	EXESP	LMIX	LMIY	LMIZ
Diagnosis address	X0.5	X9.3	X3.0	X3.1	X3.2
Interface pin	CN61.6	CN78.4	CN61.37	CN61.38	CN61.39

## Control parameter

Bit	Bit parameter										
1	7	2						ESP			
	ES	Ρ	=0:	Check ES	SP signal						

=1: Do not check ESP signal

## • PLC bit parameter

K	1	0	]	LMIT	LMIS	EXESP			
	ł	4					 12.1		

LMIT =1: Travel limit check function of each axis is valid.

- =0: Travel limit check function of each axis is invalid
- LMIS =1: The system alarms for overtravel when the travel limit check signal is not connected with +24V.
  - =0: The system alarms for overtravel when the travel limit check signal is connected with +24V

EXESP =1:External emergency stop signa is valid.

=0:External emergency stop signa is invalid.

## Signal connection

The ESP signal circuit is shown in Fig.2-26:



Fig. 2-26 ESP signal circuit

## • Machine external connection

(1) The series connection between the emergency stop and travel switch is shown in Fig. 2-27:



Fig.2-27 Series connection between emergency stop and travel switch

(2) The separate connection between the emergency stop and travel switch is shown in Fig. 2-34B:



Fig. 2-28 Separate connection between the emergency stop and travel switch

#### Control logic

(1) Series connection between the emergency stop and travel switch

When the contact of the emergency stop switch is cut off, the ESP signal is off to +24V, and CNC makes an emergency alarm. Meanwhile the CNC turns off the enable (EN) signal to stop the pulse output. Except the functions processed by NC, other functions can also be defined by PLC program when the emergency alarm is issued. The function defined by standard PLC program is: when emergency alarm is issued, it turns off the signal output of M03, M04, M08, and outputs M05 signal at the same time.

(2) Separate connection between the emergency stop and travel switch

- 1. Each axis has only one overtravel contact, and the system judges the overtravel alarm based on the axis movement direction.
- 2. When the system alarms for the overtravel, the axis moves reversely, the reset key is pressed to clear the alarm after the axis exceeds the limit position.

Note: Before the overtravel limit function is enabled, the slider must be between the positive and the negative limit; otherwise, the prompted alarm will not be consistent with actual situation.

## 2.9.2 Tool Change Control

#### Relevant signals (by standard PLC program)

Ladder diagram supports 4 kinds of tool-post controllable logic; refer to the tool-change logic for the Signal Specification.

## Control parameter

#### Bit parameter

Κ	1	1		СНОТ		CHET	TCPS	CTCP	TSGN	CHTB	CHTA
H	HTA: tool change mode selection bit 0										

CHTB: tool change mode selection bit 1 (see following table)

CHTB	CHTA	Tool post type
0	0	Standard tool change mode B
0	1	Standard tool change mode A
1	0	Yantai AK31
1	1	Unused

TSGN =0 : tool signal HIGH(turn on +24V) is valid

=1 : tool signal LOW(turn off +24V) is valid

CTCP =0 : do not check tool post locking signal

=1 : check tool post locking signal

TCPS =0 : tool post locking signal LOW(turn off +24V) is valid

=1 : tool post locking signal HIGH(turn on +24V) is valid

CHET=0 : do not check tool signal after the tool change is completed

- =1 : check tool signal after the tool change is completed
- CHOT=0 : do not check tool post overheat
  - =1 : check tool post worktable overheat

The maximum time limit for tool change

D	Τ	0	7	T1TIME

Tool change time T1: Tool post delay time from CCW stop to CW output (ms)

D	Т	0	8	ТСРСКТ
-				

Tool post lock signal detection time (ms)

D	Т	0	9

TCPTIME

Tool change time T2: tool post CW rotation locking time

0	0	8	4		ТМАХ					
Tat	Fotol tools colorism									

Total tools selection

#### Signal connection

1. The T01~T08, TCP signals input are employed with photocoupler, its interior circuit is shown in Fig. 2-29:





2. TL+, TL- are tool post CCW/CW output signal, its interior circuit is shown in Fig.2-30:



3. The external circuit of the tool number signal is shown in Fig. 2-31, when the tool number signal is low level active, it requires an external pull-up resistor.



Fig. 2-31

## • Function description (defined by standard PLC program)

The control sequence and control logic of the tool change are defined by PLC program. There are 4 tool change modes defined as follows by standard PLC program:

## 1. CHTB (K11.1)=0, CHTA (K11.0)=0: tool change mode B

Signal type	Code	Interface	Address	Function	Remark
	CN61.16	X1.7	T01	tool signal	
	CN61.29	X2.0	T02	tool signal	
	CN61.30	X2.1	T03	tool signal	
Intruit	CN61.31	X2.2	T04	tool signal	
signal	CN61.8	X0.7	T05	tool signal	
eignei	CN61.9	X1.0	T06	tool signal	
	CN61.10	X1.1	T07	tool signal	
	CN61.11	X1.2	T08	tool signal	
	CN61.35	X2.6	TCP	tool post locked signal	
Output	CN62.15	Y1.6	TL+	tool post CW rotation	
signal	CN62.16	Y1.7	TL-	tool post CCW rotation	

1.1 Signal specification

## 1.2 Tool-Change schedule

①During the tool change process, CNC outputs TL+ signal until the tool in-position signal is detected, then CNC turns off TL+ signal output and outputs TL- signal after a delay time specified by data parameter No.082. Then CNC detects TCP signal till it is detected, the CNC turns off TL- signal after a delay time specified by the data parameter No.085. So the tool change is over.

②When CHET(K0011.5) is set to 1(check tool signal after the tool change ends) and the tool post (CCW) rotation time ends to confirm whether the current tool input signal is consistent with the current tool No., if not, the system alarms.

③ The tool change process ends.

④ After the system outputs the tool post rotation (CCW) signal, if the CNC doesn't receive the TCP signal within the time set by DT08, an alarm will be issued and the TL- signal will be turned off.

<sup>(5)</sup> When the tool post has no tool post locking signal, CTCP(K0011.3) is set to 0, at the time, the system does not check the tool post locking signal.



## Sequence of tool change mode B

## 2. CHTB (K11.1)=0, CHTA (K11.0)=1: YA\_XING hydraulic tool post HLT series:

Signal type	Code	Interface	Add.	Function	Remark
	CN61.16	X1.7	T01	tool signal	
	CN61.29	X2.0	T02	tool signal	Cutter position 8421
	CN61.30	X2.1	T03	tool signal	code
	CN61.31	X2.2	T04	tool signal	
Input signal	CN61.8	X0.7	TCP	tool post locked signal	Normally-closed contactor (Low LEVEL enabled)
	CN61.9	X1.0	SELE	tool post strobe signal	
	CN61.10	X1.1	TUCP	tool post released signal	Normally-closed contactor (Low LEVEL enabled)
	CN62.15	Y1.6	TL+	tool post CW rotation	
Output	CN62.16	Y1.7	TL-	tool post CCW rotation	
signal	CN62.29	Y2.0	TRLS	tool post released outout	
	CN62.30	Y2.1	TCLP	tool post locked outout	

## 2.1 Signal explanation

Notice: The cutter-head clamping signal and releasing signal are normally-closed contactor, which are enabled in low LEVEL.

## 2.2 Tool-change schedule

- (1) Cutter-head relases and waits for that the cutter-head releasing signal is low LEVEL.
- ② The system judges the shortest path based upon the destination tool number and current tool number; select the output rotation direction in terms of the principle of the approximated tool-selection regardless of the positive signal (TL+) or negative one (TL-), the tool starts to rotate and perform the tool-selection.
- ③ In the rotation process, the system performs the coding based upon the cutter position encoder signals T1~T4 to identify the current tool number. When rotating to the previous

station of the destination tool number, detect the skip of the cutter-head strobe signal. System closes the cutter-head releasing signal and outputs the cutter-head clamping signal at the falling-edge of the previous state strobe signal of the destination tool number.

- ④ When the cutter-head clamping input signal in detecting is low LEVEL, close the cutter-head rotation output signal (TL+ or TL-), the motor is then stopped.
- (5) Confirm whether the current tool position code signal is consistent with the detstination tool number, confirm whether the cutter-head clamping signal is Low LEVEL again.
- (6) The tool-change is absolutely performed if the above-mentioned steps are correct.

## 2.3 Tool-Change Schedule



- 2. CHTB (K11.1) =1, CHTA (K11.0) =0 Yantai AK31 series (6, 8, 10, 12 tools) Chanzhou SBWD-80
  - 3.1. Signal specification

Signal type	Code	Interface	Address	Function	Remark
	CN61.16	X1.7	T01	tool signal	
	CN61.29	X2.0	T02	tool signal	Tool position is
	CN61.30	X2.1	T03	tool signal	8421 encoder
la mut	CN61.31	X2.2	T04	tool signal	
Input	CN61 25	VDE	тер	Tool post locked	
signai	CIN01.55	A2.0	ICP	signal	
	CN61.9	X1.0	SELE	strobe signal	
	CN61 10	X1 1		Tool post worktable	
		Х1.1	INDA	pregraduation coil	
	CN61 11	X1.2	снот	tool post overheat	
	CINOT.TT	X1.2	CHOT	check	
	CN62 15	V1.6	ΤΙ.	Tool post CW	
	CIN02.15	11.0	I LŦ	rotation	
	CNE2 16	V4 7	ті	ool post CCW	
Output	CIN02.10	11.7	16-	rotation	
signal	CN62 20	V2 0	TZD	Tool post worktable	
	CN62.29 Y2.0 12D		brake		
	CN62 30	Y2 1	INDXS	Tool post worktable	
	01102.00	12.1		pregraduation coil	

## 3.2. Tool change process

(1). Ensure the tool post brake TZD signal is turned on.

<sup>(2)</sup>.The system executes the shortest path judge based on the target tool no. and the current tool no., and selects the rotation direction of the output according to the nearby tool selection, outputs the positive signal(TL+) or negative signal (TL-), and the tool post rotates to select the tool.

(3).During the rotation, the system decodes to identify the current tool no. based on the tool encoding signal T1~T4 input. When it rotates to the previous tool before the target tool no., it checks the skip of the tool post strobe signal. The strobe signal of the previous signal before the target tool no. executes the falling edge, the system outputs pregraduation electromagnetic signal of the tool post, and the electromagnet is turned on.

<sup>(4)</sup>.When the input signal of the pregraduation proximity input signal of the tool post is HIGH, the system closes the tool post rotation output signal (TL+ or TL-), and the motor stops.

(5).After the system delays 50ms, it outputs the signal(TL- or TL+) which is reverse to the previous rotation direction and the tool post rotates reversely.

<sup>(6)</sup>.When the proximity input signal of the tool post locked is HIGH, the system closes the rotation signal (TL-, TL+), and the motor stops. Then the system outputs the tool post brake signal TZD, and the motor brake is turned on.

(7).When the system delays 200ms, it closes the pregraduation electromagnetic output signal, and then the electromagnet is turned off.

(8). The system checks the current tool no. again and confirms whether the encoding signal of the current tool is consistent with the target tool no..

(9). The system confirms again whether the locked proximity switch signal is HIGH.

(10).When the above steps are correct, the system closes the tool post brake signal TZD, and so the tool change is completed.

(1).In the course of the tool change, when the system has found the motor overheat signal, it

alarms and closes output of all signals.

## 3.3. Tool change flow



## 4. CHTB (K11.1)=1, CHTA(K11.0)=1: LIO\_SHING hydraulic tool post

Signal type	Code	Interface	Address	Function	Remark
	CN61.16	X1.7	T01	tool signal	Sensor A
	CN61.29	X2.0	T02	tool signal	Sensor B
	CN61.30	X2.1	T03	tool signal	Sensor C
Input	CN61.31	X2.2	T04	tool signal	Sensor D
signal	CN61.8	X0.7	SSE	the tool pot stop and the start signal be locked	Sensor E
	CN61.9	X1.0	SSF	tool post releasing/lock signal	Sensor F
	CN62.15	Y1.6	TL+	Tool post CCW rotation	Sol B
Output	CN62.16	Y1.7	TL-	Tool post CW rotation	
signal	CN62.29	Y2.0	TRLS	tool post released outout	Sol A
	CN62.30 Y2.1 TCLP tool outour		tool post locked outout		

## 4.1. Signal specification

Sensor A, B, C, D: only check the tool, and are not any start signals

Sensor E: it executes the inductive once when one tool change is executed, which makes the tool pot stop and the start signal be locked. When the tool pot rotates to the required position, Sensor is inductive, i.e. the electromagnet to control the tool pot rotation is turned off, which makes the tool stop rotation and start the electromagnet to lock the tool pot to ensure that the tool pot is locked.

- Sensor F: releasing/lock confirmation signal. When it is not inductive, the tool pot is released, at the time, the tool pot is started to rotate. When it is not inductive, the tool pot is locked,
  - i.e. the tool change is completed.
- Sol A: control the tool pot releasing/locking

Sol B: control the tool pot rotation(CW/CCW)

#### 4.2 . Corresponding table between position and signal

8-tool:

	1	2	3	4	5	6	7	8	]
Α			•		•	•	•		
В	٠				•		•	•	
С				•	•	•		•	
D		•				•	•	•	
E	٠	•	•	•	•	•	•	•	
10-tool	:								-
	1	2	3	4	5	6	7	8	9
Α			•		•	•	•		•
В	•				•		•	•	•
С				•	•	•		•	
D		•				•	•	•	

10

•

E	•	•	•	•	•	•	•	•	•	•		
12-tool											•	
	1	2	3	4	5	6	7	8	9	10	11	12
Α	•			•	•		•	•	•			
В			•			•	•		•	•	•	
С		•			•	•		•	•	•		
D				•			•	•		•	•	•
Е	•	•	•	•	•	•	•	•	•	•	•	•

#### 4.3 Tool change process description

Example: No. 1 tool is changed into No. 4 tool

Step 1: Sol A is turned on(tool pot is released)

Step 2: Ensure Sensor F is not inductive, Sol B is turned and the oil hydraulic motor rotates Step 3: check the tool signal(Note: Sensor E is inductive for No. 1, 2, 3 tool, does not execute the locking operation when the tool pot does not reach No. 4 tool). When No. 3 tool signal is confirmed, Sensor E preparatory operation should be set to make the tool pot rotate to No.4 tool, at the time, Sensor E is inductive, i.e. Sol B is turned on, the tool pot stops rotation and Sol A makes the tool pot be locked.

## 2.9.3 Machine Zero Return

#### Notice

When the feed axis matches with the absolute encoder, set the arbitrary point as the machine reference point by the [n axis reference point setting] on the page of the "Position - > Integral Coordinate". It will directly position to the reference point when zero return after the reference position is set.

Mainly, the following relevant description is about the adaptive incremental encoder and the zero return procedure of the rotation axis.

Relative signal

DECX: X deceleration signal; DECY: Y deceleration signal; DECZ: Z deceleration signal; DEC4: 4th deceleration signal; DEC5: 5th deceleration signal; PCX: X zero signal; PCY: Y zero signal; PCZ: Z zero signal; PC4: 4th zero signal; PC5: 5th zero signal;

DECX	X deceleration signal	PCX	X zero signal
DECZ	Z deceleration signal	PCZ	Z zero signal
DECY	Y deceleration signal	PCY	Y zero signal
DEC4	4th deceleration signal	PC4	4th zero signal
DEC5	5th deceleration signal	PC5	5th zero signal

## Diagnosis data

0	0	0			DEC5	DEC4	DECZ	DECY	DECX
Inte	erfac	e pin			CN61.34	CN61.33	CN61.12	CN61.32	CN61.4
0	0	8			PC5	PC4	PCY	PCZ	PCX
Inte	erfac	e pin			CN15.10	CN14.3	CN13.3	CN12.3	CN11.3

• Controlling parameter

Status parameters

0	0	4	1		DECI			
	г <u>4</u> .	Duri		مملك مسيلم		با مايه أما 4 م	a vali	

Bit 5 1: During machine zero return, the deceleration signal is at high level;

0: During machine zero return, the deceleration signal is at low level;

0	0	5							PPD	
Bit	1: 1: (	G50 s	ets rel	ative coo	ordinate s	system va	alue;			

0: G50 does not set relative coordinate system value;

0 0 6	ZM5	ZM4	ZMY	ZMZ	ZMX
Bit4 1: 5 <sup>th</sup> axis zero point return method C					
0: 5 <sup>th</sup> axis zero point return method B					
Bit3 1: 4 <sup>th</sup> axis zero point return method C					
0: 4 <sup>th</sup> axis zero point return method B					
Bit2 1:Y axis zero point return method C					
0:Y axis zero point return method B					
Bit1 1:Y axis zero point return method C					
0:Y axis zero point return method B					
Bit0 1:X axis zero point return method C					
0:X axis zero point return method B					

0	0	7					ZC5	ZC4	ZCY	ZCZ	ZCX
Bit 4	· 1: D	uring	machin	e zero re	turn, the	deceleratio	on signal	of the 5 <sup>th</sup>	axis (DEC	C5) and or	ne-rotation

signal (PC5) are connected in parallel (use a proximity switch as a deceleration signal and zero-point signal at the same time).

- 0: During machine zero return, the deceleration signal of the 5<sup>th</sup> axis (DEC5) and one-rotation signal (PC5) are connected separately (use a proximity switch as a deceleration signal and zero-point signal at the same time).
- Bit 3 1: During machine zero return, the deceleration signal of the 4<sup>th</sup> axis (DEC4) and one-rotation signal (PC4) are connected in parallel (use a proximity switch as a deceleration signal and zero-point signal at the same time).
  - 0: During machine zero return, the deceleration signal of the 4<sup>th</sup> axis (DEC4) and one-rotation signal (PC4) are connected separately (use a proximity switch as a

deceleration signal and zero-point signal at the same time).

- Bit 2 1: During machine zero return, the deceleration signal of the Y axis (DECY) and one-rotation signal (PCY) are connected in parallel (use a proximity switch as a deceleration signal and zero-point signal at the same time).
  - 0: During machine zero return, the deceleration signal of the Y axis (DECY) and one-rotation signal (PCY) are connected separately (use a proximity switch as a deceleration signal and zero-point signal at the same time).
- Bit 1 1: During machine zero return, the deceleration signal of the Z axis (DECZ) and one-rotation signal (PCZ) are connected in parallel (use a proximity switch as a deceleration signal and zero-point signal at the same time).
  - 0: During machine zero return, the deceleration signal of the Z axis (DECZ) and one-rotation signal (PCZ) are connected separately (use a proximity switch as a deceleration signal and zero-point signal at the same time).
- Bit 0 1: During machine zero return, the deceleration signal of the X axis (DECX) and one-rotation signal (PCX) are connected in parallel (use a proximity switch as a deceleration signal and zero-point signal at the same time).
  - 0: During machine zero return, the deceleration signal of the X axis (DECX) and one-rotation signal (PCX) are connected separately (use a proximity switch as a deceleration signal and zero-point signal at the same time).

Note: In the zero return method B, it is set to 0; the zero return can be detected the PC signal after releasing from the block when it independently connects. If it is set to 1, PC detection signal begins after pressing the block to decelerate to zero when it is connected in parallel, and the block then can be reserved.

0: Manual machine zero return is valid;

Bit 2: 1: The direction key is self-locked during machine zero return; press the direction key once till the machine zero return is finished;

0: The direction key is not self-locked during machine zero return; press down the direction key;

Bit1 1:Ref.C mode, the feeding slowdown when machine press down switch, it is reversed after decelerating to zero.

0:Ref.C mode, the feeding slowdown when machine release switch, it is reversed after decelerating to zero.

0 1	2		APRS					ISOT
D:4 7	4. CN	0 + -	بم منا با ممام ما	بلا م ما ام م		منامعاليه	ft an mafa	 int nations

Bit 7 1: CNC sets the absolute coordinate system automatically after reference point return;
 0: CNC does not set absolute coordinate system automatically after reference point return;

Bit 0 1: Manual rapid traverse is valid after system power-on and before machine zero return;0: Manual rapid traverse is invalid after system power-on and before machine zero return;

0 1 4			ZRS5	ZRS4	ZRSY	ZRSZ	ZRSX
Bit4. Bit3. Bit2. E	3it1. Bit0						

1: Machine zero point is set on the 5<sup>th</sup>, 4<sup>th</sup>, Y, Z, X axes; deceleration signal and zero point signal are needed to be detected during machine zero return;

0: Machine zero point is not set on the 5<sup>th</sup>, 4<sup>th</sup>, Y, Z, X axes; deceleration signal and zero point signal are not detected during machine zero return;

1	8	3	Г		MZR5	MZR4	MZRY	MZRZ	MZRX
Bit4/I	Bit3/	Bit2/E	Bit1/Bit0	1: The	direction of	f machine zero	return is ne	gative;	
				0: The	direction of	of machine zero	o return is po	sitive;	
1	8	8	F	RFCK	RRT				
Bit7	1:C	528 ru	unning ev	ery time	e to check	the PC signal			
	0:0	G28 r	unning o	nly first	to check th	e PC signal			
Bit6	1:Z	ero re	eturn D r	node is	used when	the additional	axis is a rota	ary axis;	
	0:Z	Zero i	return A	, B, C n	node is us	ed when the	additional ax	kis is a rotar	y axis (powe
		agai	n).						
		Ū	,						
Da	ita pa	arame	eters						
0	3	3				ZRNFLn			
The I	low s	speed	of mach	nine zero	o return;				
1	1	3	1			REF_SPDn			
The I	hiah	spee	d of mac	hine zer	o return:				

PRSn

Setting value of absolute coordinate after machine zero return;

#### Signal connection

7

4

0

The interior circuit of deceleration signal is shown in Fig. 2-32:



Fig. 2-32

• Machine zero return by regarding servo motor one-turn signal as the zero signal ①Its sketch map is shown below:



Fig. 2-33

2 The circuit of deceleration signal



Fig. 2-34

#### ③ Sequence of machine zero return

When the BIT0 (ZMX) of the bit parameter No.006 is set to 0, and the BIT5(DECI) of the bit parameter No.004 is set to 0, the system chooses the machine zero return mode B, and the deceleration signal low level is active.

So the sequence of machine zero return mode B is shown as follows:





Return process of machine zero mode B

- A: Select Machine zero mode, press the manual positive or negative feed key (machine zero return direction set by bit parameter No.183), the corresponding axis moves to the machine zero by a rapid traverse speed (No.113). As the axis press down the deceleration switch to cut off deceleration signal, the feeding slows down immediately, and it continues to run in a fixed low speed (No.33).
- B: When the deceleration switch is released, the deceleration signal contact is closed again. And CNC begins to detect the encoder one-turn signal (PC), if this signal level skips, the motion will be halted. And the corresponding zero return indicator on the operator panel lights up for machine zero return completion.

When the BIT0 (ZMX) of the bit parameter and No.006 are both set to 1, and the BIT5 (DECI) of the bit parameter No.004 is set to 0, it chooses the machine zero return mode C, and the deceleration signal low level is active. The Bit 1 of status parameter No.011 can be set the deceleration time.

So the sequence of machine zero return mode C is shown as follows:



Fig. 2-36 (Out-of-block deceleration)

(Push the block deceleration) Fig. 2-37

Return process of machine zero mode C

- A: Select Machine zero mode, press the manual positive or negative feed key (return direction set by bit parameter No.183), the corresponding axis moves to the machine zero by a rapid traverse speed (No.113). As the axis press down the deceleration switch to cut off deceleration signal, if the pushing block begins deceleration (Bit 1 of status parameter No.011), the operation speed is then decelerated to zero. The feeding keeps rapid rate and depart from the deceleration switch, when the DEC signal contact is closed, the feeding slows down to zero, then run reversely to return to machine zero in a low speed.
- B: In the reverse running, it presses down the deceleration switch to cut off the DEC signal contact and continues returning; as it departs from the deceleration switch, the deceleration signal contact is closed again. And CNC begins to detect the encoder one-turn signal (PC), if this signal level skips, the motion will be halted. And the corresponding axis zero return indicator on the operation panel lights up for zero return completion.
- Machine zero return by a proximity switch taken as both deceleration and zero signals 1) Its sketch map is as follows:

Sketch map of zero tongue for machine zero return mode B:



Fig. 2-38

Sketch map of zero tongue for machine zero return mode C:





② Circuit of the deceleration signal





③Sequence of machine zero return (taking example of X)

When the BIT0 (ZMX) of the bit parameter No.006 are all set to 0, and the BIT5 (DECI) of the bit parameter No.004 is 0, it chooses the machine zero return mode B.

The sequence of machine zero return is as follows:





B type machine zero return process

- A: Select the Machine Zero mode, press manual positive or negative (zero return direction set by bit parameter No.183) feed key, the corresponding axis will move to the zero at a high speed(set by parameter No.113).
- B: As the proximity switch touches the tongue for the first time, the deceleration signal is active and speed immediately slows down and it runs in a fixed low speed (set by parameter No.33).
- C: As the proximity switch detaches the tongue, the deceleration signal is inactive; it moves at a fixed low speed after deceleration and starts to detect zero signal (PC).

D: As the proximity switch touches the tongue for the second time, the zero signal is active and the movement stops. The zero return indicator on the panel lights up for machine zero return completion.

When the BIT0 (ZMX) of the bit parameter No.006 are all set to 1, and the BIT5(DECI) of the bit parameter No.004 is 0, it chooses the machine zero return mode C.

The sequence of machine zero return mode C is shown as follows:



- Fig.2-42 (the feeding slowdown release switch)Fig.2-43 (the feeding slowdown press down switch)Ref.C mode,the feeding slowdown when 0:release switch 1:press down switch
  - C type machine zero return process
  - A: Select the Machine Zero mode, press manual positive or negative (zero return direction set by bit parameter No.183) feed key, the corresponding axis will move to the zero at a high speed(set by parameter No.113).
  - B: As the proximity switch touches the tongue for the first time, the deceleration signal is active. If the pushing block deceleration begins (The Bit 1of the status parameter equals to 1), the feed speed decelerates to zero, then it runs reversely by low return speed.
  - C: If the setting block begins to decelerate (The Bit 1 of the status parameter No.011 sets to 0), it is still operated with same speed when its speed descends. When the deceleration signal contactor is closed, the operation speed decelerates to zero till leaving the deceleration switch, and then it reversely operates with low speed based upon the machine tool zero.
  - D: As the proximity switch touches the deceleration switch for the second time in reverse running, deceleration signal contact is cut off, it still runs by low return speed; as it detaches the deceleration switch, deceleration signal contact is closed again, so the movement stops. The zero return indicator for the corresponding axis on the panel lights up for zero return completion.
- The machine zero return (zero-return method D) of deceleration signal or zero signal by using the servo motor one-turn signal

There are four zero return methods for rotation axis, which are separately divided into: A, B, C and D. Wherein, zero return method A, B and C are identical with the one of the linear axis. Only the D is a special zero return method of the rotation axis.

When the controllable axis is rotation one, and the Bit 6 of status parameter No.188 sets to 1, select the machine zero return method D.

The time-sequency figure of the machine zero operation in method D is as follows:



The process of machine zero return in method D:

- A: Select the mechanical zero return method, positively feed manually, the corresponding axis moves to the zero direction at the rapid traverse rate.
- B: When met the one-turn signal (PC) of the servo axis at the first time, the system decelerates to the zero return.
- C: When the system decelerates to the zero return, the system is then detected the one-turn signal again (PC).
- D: The system operation stops when mets the one-turn signal (PC) of the servo axis; simultaneously, the zero return indicator of if its corresponding axis on the operation panel is turned on, the mechanical zero return is then ended.

# 2.9.4 Spindle Control

## Relevant signal (by standard PLC program)

Туре	Sign	Interface	Address	Function	Remark
Input signal	SALM	CN15.8	X5.0	Spindle abnormity alarm input	
	M03	CN62.4	Y0.3	Spindle rotation(CCW)	
	M04	CN62.5	Y0.4	Spindle rotation(CW)	
	M05	CN62.6	Y0.5	Spindle stop	
-	SPZD	CN62.8	Y0.7	Spindle brake	
Output signal	SFR	CN15.6	Y5.0	Spindle rotation(CW)	Its function is consistent with that of M03
	SRV	CN15.7	Y5.1	Spindle rotation(CCW)	Its function is consistent with that of M04
Command	M03			Spindle rotation(CCW)	
format	M04			Spindle rotation(CW)	
ionnat	M05			Spindle stop	

Note: When the spindle is serial-connected, system delivers the rotation signal to servo by

## bus regardless of the above-mentioned IO signals.

K 1 0							RSJG	
				•				
RSJG =1: (	CNC not tur	n off M03, I	M04, M0	8, M32 ou	utput sigr	als wher	pressing	g 📶 ke
								11
=0: 0	CNC turns o	off M03, M0	4, M08, I	M32 outp	ut signals	s when pr	essing	🖌 key.
				SALM	SSTP	- 1 1:		
5ALIVI =1: 11	ne system	alarms whe	en the sp	bindle ab	normai d	etection	input sig	nal is LOV
=0: Tł	ne system a	alarms whe	en the sr	oindle abr	normal de	etection i	nput siai	nal is HIG
•••••	turned on v	vith 0V) .						
SSTP =1: Th	e analog vo	oltage is clo	osed whe	n the spir	ndle stop	s;		
=0: Th	ne analog v	oltage is no	ot closed	when the	spindle	stops.		
			1	1				
1 7 5		SAR						
Bit6 1: The	spindle SA	R signal is	checked	before c	utting;			
0: The	e spindle SA	AR signal is	s not cheo	cked befo	re cutting	<b>]</b> .		
Data parame	ter							
Data parame	ter			SAR_I	DELEY			
Data parame 0 7 2 Delay check	ter time (ms) c	of the spind	le speed	SAR_I arrival.	DELEY			
Data parame       0    7    2      Delay check      D    T    0    5	ter time (ms) c	of the spind	le speed	SAR_I arrival. MT	DELEY			
Data parame    0  7  2    Delay check    D  T  0  5    Execution tin	ter time (ms) c	of the spindl	le speed	SAR_I arrival. MT	DELEY			
Data parame       0    7    2      Delay check      D    T    0    5      Execution tin	ter time (ms) c	of the spind	le speed	SAR_I arrival. MT	DELEY			
Data parame   0 7 2   Delay check   D T 0 5   Execution tin   D T 1 0	ter time (ms) c	of the spind le (ms)	le speed	SAR_I arrival. MT SPE	DELEY			
Data parame072Delay checkDT05Execution tinDT10Spindle brake	ter time (ms) c he of M cod	of the spindl le (ms) utput time a	le speed	SAR_I arrival. MT SPC dle stop (	DELEY IME DDLT M05) is c	output		
Data parame 0 7 2 Delay check D T 0 5 Execution tin D T 1 0 Spindle brak	ter time (ms) c ne of M cod	of the spind le (ms) utput time a	le speed	SAR_I arrival. MT SPE dle stop (	DELEY IME DDLT M05) is c	putput		
Data parame      0    7    2      Delay check      D    T    0    5      Execution tin      D    T    1    0      Spindle brake	ter time (ms) c	of the spind le (ms) utput time a	le speed	SAR_I arrival. MT SPE dle stop (	DELEY IME DDLT M05) is c	putput		
Data parame      0    7    2      Delay check      D    T    0    5      Execution tin      D    T    1    0      Spindle brak      D    T    1    1      Spindle brak	ter time (ms) c he of M cod ing delay or	of the spindl le (ms) utput time a	le speed	SAR_I arrival. MT SPC dle stop ( SPZC	DELEY IME DDLT M05) is c	output		
Data parame 0 7 2 Delay check D T 0 5 Execution tin D T 1 0 Spindle brak D T 1 1 Spindle brak	ter time (ms) c ne of M cod ing delay or ing output t	of the spind le (ms) utput time a	le speed	SAR_I arrival. MT SPE dle stop ( SPZE	DELEY IME DDLT M05) is c DTIME	output		
Data parame 0 7 2 Delay check D T 0 5 Execution tin D T 1 0 Spindle brak D T 1 1 Spindle brak D T 2 3 D T 2 3	ter time (ms) c ne of M cod ing delay of ing output t	of the spindle (ms)	le speed	SAR_I arrival. MT SPE dle stop ( SPZE	DELEY IME DDLT M05) is c DTIME DELEY	output		
Data parame      0    7    2      Delay check      D    T    0    5      Execution tin      D    T    1    0      Spindle brak      D    T    1    1      Spindle brak      D    T    2    3      Delay time brak	ter time (ms) c be of M cod ing delay of ing output t efore spind	of the spind le (ms) utput time a ime (ms) le motor tor	le speed	SAR_I arrival. MT SPE dle stop ( SPZE SVF_I rease to (	DELEY IME DDLT M05) is c DTIME DELEY ) when sp	output	rts clamp	
Data parame 0 7 2 Delay check D T 0 5 Execution tin D T 1 0 Spindle brak D T 1 1 Spindle brak D T 2 3 Delay time brak	ter time (ms) c me of M cod ing delay or ing output t	of the spind le (ms) utput time a ime (ms) le motor tor	le speed	SAR_I arrival. MT SPE dle stop ( SPZE SVF_I rease to ( SCI F	DELEY IME DDLT M05) is c DTIME DELEY ) when sp	output pindle sta	rts clamp	
Data parame      0    7    2      Delay check      D    T    0    5      Execution tin      D    T    1    0      Spindle brak      D    T    1    1      Spindle brak      D    T    2    3      Delay time brak    D    T    2    0      Spindle clam    Spindle clam    0    Spindle clam	ter time (ms) c he of M cod ing delay of ing output t efore spind	if the spindle (ms) utput time a ime (ms) le motor tor	le speed	SAR_I arrival. MT SPE dle stop ( SPZE SVF_I rease to ( SCLF	DELEY IME DDLT M05) is c DTIME DELEY When sp PTIME	output bindle sta	rts clamp	
Data parame072Delay checkDT05Execution tinDT10T111Spindle brakeDT23Delay time brakeDT20T20Spindle clame	ter time (ms) c ne of M cod ing delay of ing output t efore spind ping/releas	of the spindle (ms) utput time a ime (ms) le motor tor ing comma	le speed	SAR_I arrival. MT SPI dle stop ( SPZI SVF_I rease to ( SCLF rmance ti	DELEY IME DDLT M05) is c DTIME DELEY ) when sp PTIME me (ms).	output	rts clamp	
Data parame      0    7    2      Delay check      D    T    0    5      Execution tin      D    T    1    0      Spindle brak      D    T    1    1      Spindle brak      D    T    2    3      Delay time brak      D    T    2    0	ter time (ms) c he of M cod ing delay of ing output t efore spind	of the spindle (ms) utput time a ime (ms) le motor tor	le speed	SAR_I arrival. MT SPC dle stop ( SPZC SVF_I rease to ( SCLF	DELEY IME DDLT M05) is c DTIME DELEY ) when sp PTIME	output	rts clamp	Ding;

## • Signal connection

M03, M04, M05, SPZD signal output circuit is shown in Fig. 2-45A:



## SAR, SALM signal input circuit is shown in Fig.2-45B:





## • Operation sequence (defined by standard PLC program)



Note: T2 is the delay time from sending the spindle stop signal to sending the spindle brake signal; T3 is the spindle brake hold time.

## • Function description (defined by standard PLC program)

① After the CNC is turned on, when M05 output is valid, M03 or M04 is executed, M03 or M04 output is valid and remains, at the time, M05 output is closed; when M03 or M04 output is valid, M05 is executed, M03 or M04 is closed, M05 output is valid and remains; the spindle brake SPZD signal output delay is set by No.087 (delay time from the spindle stop signal output to the spindle brake SPZD signal output), the hold time of the brake signal is set by No.089 (the spindle brake output time).

2 When M03 (M04) output is valid, M04 (M03) is executed, the alarm occurs.

③ When №175.6 is set to 1, the system checks whether the speed arrival signal SAR is valid, if it is valid, the system normally runs, if not, "Check speed arrival....." is displayed.

④ When the spindle speed command and the cutting feed command are in the same block, the system executes the delay check for SAR signal to avoid that the CNC starts the cutting based on the last spindle speed arrival signal SAR, the delay time is set by No.072.

⑤ DC00 is the spindle zero-speed output range. When the actual spindle speed is not more

than DC00 setting value, the system defaults the spindle speed to be zero, and can release the chuck, close the hydraulic and other operations.

- 6 SALM (X5.0) is spindle abnormity alarm input.
- Note 1: In the emergency stop, it turns off M03, M04, M08 signals, and outputs M05 signal;
- Note 2: Whether M03, M04 is cancelled is set by BIT3 of the bit parameter No.009 when CNC is reset. If Bit 1=0, CNC turns off M03, M04 at reset; If Bit 1=1, M03, M04 is kept at reset.

# 2.9.5 Spindle Wwitching Volume Control

## Relevant signal(defined by standard PLC program)

S01 $\sim$ S04: Control signal for spindle speed switching volume, they are compound interfaces defined by standard PLC program, and they share common interfaces with M41 $\sim$ M44, U00 $\sim$ U03.

## • Signal diagnosis

Signal	S4	S3	S2	S1
Diagnosis address	Y1.3	Y1.2	Y1.1	Y1.0
Interface pin	CN62.12	CN62.11	CN62.10	CN62.09

ACS

# Control parameters

Bit parameter

0	0	1
Bit	4	=

=1: Analog voltage control of spindle speed

=0: Switching volume control of spindle speed

## • Control logic (defined by standard PLC program)

S1 $\sim$ S4 output are inactive at power on. If any code of them is executed, the corresponding S signal output is active and held on, and the other S signal outputs are cancelled. S1 $\sim$ S4 outputs are cancelled when executing S00 code, and only one of them is active at a time.

# 2.9.6 Spindle Automatic Gearing Control

## • Relevant signal (defined by standard PLC program)

- M41~M44: Spindle automatic gear shifting output signals. It supports 4-gear spindle automatic gear shifting control when the system selects the spindle analog value control(0~ 10V analog voltage output)
- M41I, M42I: spindle automatic gear shifting No.1, 2 gear in-position signals to support gear shifting in-position check function

## • Signal diagnosis

Signal	M42I	M41I	M44	M43	M42	M41
Diagnosis address	X1.6	X1.5	Y1.3	Y1.2	Y1.1	Y1.0
Interface pin	CN61.15	CN61.14	CN62.12	CN62.11	CN62.10	CN62.09

## Signal connection

The circuit for M41~M44 is shown in Fig.2-47:

# **CNCmakers**



Fig. 2-47

## Control parameter

Bit paramet	ər									
0 0 1	Γ				ACS					
Bit4 =1:	Spindle	analog	y volume	control,	set to 1 if	using sp	indle aut	omatic g	earing	
=0:	=0: Spindle switching volume control									
1 9 5	Г		PLCS							
Bit6 =1:	PLC s	pindle r	otation s	speed fu	nction of e	each axis	enabled	;		
=0.	PI C sr	' bindle ro	otation s	' need fui	nction of e	ach axis	disabled	,		
	1 20 0			pood idi			aloabloa	0		
K 1 5						SHT	AGIM	AGIN	AGER	
AGER =1:	Spindle	autom	atic geai	ring activ	ve				•	
=0:	Spindle	autom	atic geai	ring inac	ctive					
AGIN =1:	Detect	M41I, N	/I42I sigr	nal wher	n shifting t	o gear 1,	2			
=0:	Not det	ect M4 <sup>2</sup>	1I, M42I	signal w	hen shiftir	ng to gea	r 1, 2			
AGIM =1	Active	when N	141I, M4	2l signa	ls disconn	ecting to	+24V			
=0:	Active v	when M	I41I, M42	2I signal	s connect	ing to +2	4V			
SHT =1: s	SHT =1: spindle gear power-down executes the memory									
	•	-				-				

=0: spindle gear power-down does not execute the memory

Data parameter

	•		
0	S	7	GRMAX1
0	3	8	GRMAX2
0	3	9	GRMAX3
0	4	0	GRMAX4

GRMAX1, GRMAX2, GRMAX3, GRMAX4: The respective max. speeds of spindle gear 1, 2, 3, 4 when analog voltage output is 10V. Spindle speeds for M41, M42, M43, M44 when spindle automatic gearing is active.

	0	6	7		SFTREV
-	-1 .				

The output voltage during spindle gear shift  $(0 \sim 10000, Unit: mV)$ 

	T	^	^	
U		U	U	
		-	-	

#### SFT1TME

Time for original gear disable during spindle gear shift (ms), refer to function description for details.

П	т	0	1	
		v	•	

SFT2TME

Delay time after spindle gear shift (ms), refer to function description for details.

## • Function description (defined by standard PLC program)

The spindle automatic gearing is active only under the spindle analog voltage control (BIT4 of the bit parameter No.001 set to 1) and the BIT 7 of the bit parameter No.164 is set to 1; if the spindle auto

gearing is inactive, alarm will be issued when M41 $\sim$ M44 is being executed and only one of them is active at a time.

When spindle auto gearing is used to control automatic spindle mechanical gear switching, as CNC executes  $S_{\square\square\square}$  code, it calculates the analog voltage output to spindle servo or frequency inverter based on the parameter of the current gear by M4n (M41 $\sim$ M44 to data parameters No.037~No.040 respectively) to make the actual speed to be consistent with the S code.

When CNC is powered on, the spindle gear memorizing is set by the BIT1 of bit parameter No.168.

If the BIT4 of bit parameter No.001 is 0, the spindle gear is not memorized at repowering after power down, and the gear 1 will be defaulted, M41~M44 are not output. If BIT4 of bit parameter No.001 is 1, the spindle gear is memorized at repowering after power down.

No gearing is done if the specified gear is consistent with the current gear. If not, gearing will be performed, and the process defined by standard ladders is shown in the following:

①Execute any of M41, M42, M43, M44 codes, output analog voltage to spindle servo or frequency inverter according to a value set by data parameter No.067 (Unit: mV);

②After a delay (gearing time 1) by the DT00, turn off the original gear output signal and output the new gearing signal;

(3) If the gear is 1 or 2, and the BIT6 of the bit parameter No.164 is 1, it jumps to (4), or else it jumps to (5);

(4) Check the gear in-position input signal M41I, M42I, it jumps to (5) if the gear in-position is done; if not, the CNC waits the gear in-position signal;

5After a delay (gearing time 2) by DT01, output spindle analog voltage by the current gear according to a value set by data parameter No.037~No.040 (gear 1~4) and finish the gearing.

# Note: The output of M41 ~ M44 is held on when CNC is reset or i emergency stop, which is defined by standard PLC ladder.

# 2.9.7 Spindle 8-point Orientation Function

## • Command format

M51: spindle orientation command

M50: cancel spindle orientation command

Note: When the system is matched with GS-L Spindle Servo Unit, it can realize one-point orientation.

#### • Control parameter

Κ	1	5				SPOR				
SPC	)R	=1:	The sp	oindle eig	ht-orienta	ation fund	tion is va	alid.		

=0: The spindle eight-orientation function is invalid.

## • Functional description(standard PLC program definition)

1. After the positioning function commands M51 are executed,  $PLC \rightarrow CNC$  executes the orientation signal.

2. CNC issues an orientation command after reciving the orientation signal; (after the system delays 100ms, the spindle rotation(CW/CCW) is disabled, at the same time, the system starts to check the orientation completion signal (COIN).

3. Drive unit starts the orientation.

4. After the drive unit orientation is completed, Drive  $\rightarrow$  CNC $\rightarrow$ PLC outputs the spindle completion signal COIN;

5. After PLC receives the spindle orientation completion signal COIN, the spindle orientation is completed, but the spindle orientation signal STAO keeps the output.

6. When M51 is input again, the spindle oriented to another position.

7. After the orientation is completed and when M50 is executed or the spindle orientation is operated, PLC closes the spindle orientation signal STAO output and cancels the positioning function.

8. When the system has not received the orientation completion signal after the PLC sends the orientation completion signal for 10000ms, it alarms "the spindle orientation time being long".

9. Before the orientation, the spindle can rotate or stop; the spindle stops after the orientation.

## Note 1: The drive is for the spindle servo drive unit.

Note 2: The spindle should be the serial-connected when selecting this function; simultaneously, adapt the GS-L series spindle servo drive unit.

## Connected diagram

When GSK980TDi matches with the GS-L series servo drive, it is connected with bus regardless of the special wiring.

# 2.9.8 Spindle Cs Axis Control Function

## Command format

M14: The spindle is switched from the speed control mode into the position

M15: The spindle is switched from the position control mode into the speed

Note: When the spindle is rotary, Cs function is valid and the corresponding spindle servo drive unit is speed/position switch working mode, the spindle speed/position control switch is valid.

## • Control parameters

State parameters

0	0	1			Analog		
					spindle		

- Bit4 =1: Spindle speed analog control. When the spindle automatic gear change function is used, it must be set to 1;
  - =0: Spindle speed switch control.

1	8	7	]						ROS	ROT	
D:44		ι <u>ν</u> .	00	+ + +	بالمعرب فلنامام		day 04. a	ملم مماخخم		مطلحة مأبر	

Bit1, Bit0 : 00: set the additional axis to the linear axis; 01: set the additional axis to the rotary axis (A-type); 11: set the additional axis to the rotary axis (B-type); 10: set the additional to be invalid.

4	•	E	CCDD			CODEE	DCC
	3	Э	3350			COREL	кьз
D'4		4 0	 . , .	 			

Bit0 =1:Cs function of spindle valid ,power on;

=0:Cs function of spindle is:invalid,power on.

- Bit1 1:Change to position mode, the axis do return REF; 0:Change to position mode, the axis don't return REF.
- Bit7 1:series spindle controllable function enabled (series spindle The slave ID number of the spindle 1~3 is 11~13), it is necessary to restart;

0:series spindle controllable function disabled (analogy spindle), it is necessary to restart.

	_			-
0		•		
<b>Z</b>		_	1	
_		_		

Feed axis of the corresponding spindle

The feed axis number related with the spindle should be set when matches with the CS axis function.

1	6	4

Spindle shifting M code

Spindle CS shifts the M code [Setting value +1 is the M code of the function releasing].

Note 1: When the spindle positioning function is enabled, it is regarded as the M code shifted by spindle positioning.

Note 2: The setting value should be shifted the M code by the compiled CS in the ladder diagram.

Note 3: The setting is enabled when its setting is less than the 6. The coordinate system will not be cleared as zero by shifting the CS axis when its value is disabled.

Κ	1	5		RCS	RSCS						
	DOO A. On franchism of the embedde in vehicle										

RCS =1: Cs function of the spindle is valid.

=0: Cs function of the spindle is invalid.

RSCS =1: The spindle contour control is disabled in emergency stop, reset.

=0: The spindle contour control is enabled in emergency stop, reset.

Note: K15.7 sets whether all Cs functions are valid, №0187.5, №0189.5, №0191.5 set whether Cs functions of the special axis is valid. When the multiple spindle function is valid, Cs function of only one axis is valid.

#### • Function description (defined by standard PLC program)

1. Control logic

1.1. The PLC sets the spindle contour controllable shifting signal CON (G27.7) to 1 after the M14 is executed;

1.2. CNC controls the drive to shift the controllable method, after the switch is completed,  $CNC \rightarrow PLC$  outputs the spindle contour controllable shifting end signal FSCSL (F44.1);

1.3. Aafter the PLC detects the spindle contour controllable shifting end signal FSCSL (F44.1), end the performance of the M14. The spindle controllable shifting method is ended.

2. M15 execute processes are the same those of M14.

3. Only, the M15 cancels the speed/position shifting performed by M14; if the spindle shifts into the Cs contour control by executing the M29, the performance of the M15 will not be converted into the speed controllable method.

4. on the panel is equal to the spindle speed/position control mode switch in Manual mode.

In Manual/MPG mode, press and the CNC starts the spindle speed/position control mode switch. After the CNC is switched into the spindle position control mode, the spindle orientation

indicator is ON, at the time, Cs position movement is performed. Press again and the CNC is switched into the spindle speed control mode and the spindle orientation indicator is OFF.

5. Before switch, the spindle can rotate or stop. After switch, the spindle stops.

6. When the spindle is in Cs contour control mode, the spindle rotation(CW/CCW) output is invalid.

7. When the spindle is in the external speed control mode, the manual operation of Cs axis is invalid.

8. When the alarm occurs in the servo or because of the too long switch time or the reset or emergency stop appears in switch, PLC switches the spindle into the speed control state.

9. When PLC K15.6 is set to 1, the spindle contour control is disabled in emergency stop, reset.

PLC switches the spindle into the speed control state.

10. There is the CS shifting M code (Standard ladder diagram defines as M14) in the setting of the No.164; the coordinate system can be cleared after the feed CS shifts.

## Wiring diagram

When the GSK980TDi matches with the GS-L series servo drive; the bus then can be connected regardless of the special wiring.

# 2.9.8 Multiple Spindle Function

When the multiple spindle function is valid, related signals, parameters and commands are consistent with related explanations of the spindle control, the 1<sup>st</sup>, the 2<sup>nd</sup> spindle explanations are shown below.

## • Related signals (defined by PLC program)

Туре	Sign	Interface	Address	Function	Remark
Input	SALM2	CN16.8	X8 0	The 2nd spindle abnormality alarm signal	
signal	O/ LIVIZ	01110.0	70.0	The zha spinale abhormanty alarm signal	
Output	SFR2	CN16.6	Y8.0	The 2nd spindle rotation(CW)	
signal	SRV2	CN16.7	Y8.1	The 2nd spindle rotation(CCW)	

Note: It is unnecessary to to connect the above-mentioned signals after the spindle is serial-connected.

## Command format

M63 the 2<sup>nd</sup> spindle rotates (CW)

M64 the 2<sup>nd</sup> spindle rotates (CCW)

- M65 the 2<sup>nd</sup> spindle stops
- M24 the 2<sup>nd</sup> spindle is switched from the speed control mode into the position control mode
- M25 the 2<sup>nd</sup> spindle is switched from the position control mode into the speed control mode. The speed control mode is defaulted after the system is turned on.

## Control parameters

1	8	7				RCS				ROS	ROT
Bit	5 =	=1: (	Cs func	tion of th	ne additio	onal axis	; is valid (po	ower-on a	again);		

=0: Cs function of the additional axis is invalid(power-on again).

- Bit 1, Bit0: 00 sets Y to be the linear axis; 01 sets Y to be the rotary axis (A type); 11 sets Y to be the rotary axis(B type); 10 sets Y to be invalid.
- Bit1, Bit0 : 00: set the additional axis to the linear axis; 01: set the additional axis to the rotary axis (A-type); 11: set the additional axis to the rotary axis (B-type); 10: set the additional to be invalid.

1	9	5	SSPD				RCS
D:4	<u> </u>		 · · · · · · · · · · ·	 1. 1		-	

Bit0 =1:Cs function of spindle valid ,power on;

=0:Cs function of spindle is:invalid,power on.

Bit7 =1:series spindle controllable function enabled (series spindle The slave ID number of the spindle 1~3 is 11~13), it is necessary to restart;

=0:series spindle controllable function disabled (analogy spindle), it is necessary to restart.

III Connection

) 2 2	1		The	e feed ax	is relate	d with th	e spindl	е	
The feed	axis nu	umber rela	ated with	the spin	dle shou	ld be set	when m	atches v	with the C
tion.									
Setting va	alue me	aning: 0: V	Vithout	1~5: tł	ne 1 <sup>st</sup> axis	$s \sim the 5^{t}$	<sup>h</sup> axis		
1 9 6	;				MSEN				
Bit4 1:	The m	ultiple spir	ndle cont	rol functio	on is valio	ł;		_	_ <b>I</b>
0:	The m	nultiple spi	ndle cont	trol functi	on is inva	alid;			
		1 -1							
K 1 5		RCS	RSCS						
RCS =1:	The sp	indle Cs fu	unction is	s valid:					
=0.	The sp	indle Cs fi	inction is	invalid					
RSCS =1	l: The s	spindle cor	ntour con	trol is dis	abled in e	emergen	cv stop, r	eset:	
	). The c			trol ic on	ablad in a	morgon	v ctop r	ocot	
=(	J. The s	spinule coi				mergend	y stop, n	561.	
V 4 7	· ]	MOEN		CAL MO				[	T
<b>N</b> 1 1		MISEN		SALIVIZ					
MSEN =	1: The r	multiple sp	indle cor	ntrol funct	tion is val	id;			
=	0: The r	multiple sp	indle cor	ntrol funct	tion is inv	alid.			
SALM2	=1: The	e system a	alarms w	hen the	check inp	out signa	l of the 2	2 <sup>nd</sup> spindl	le abnorn
	10	w.							

=0: The system alarms when the check input signal of the 2<sup>nd</sup> spindle abnormality is HIGH;

## Function description(defined by the standard PLC program)

- 1.1. After the multiple spindle control function setting is valid, the system defaults to the 1<sup>st</sup> spindle control after power-on;
- 1.2. When M03, M04, M05 is executed, the corresponding signal of the 1<sup>st</sup> spindle outputs, at that time, the system sets the 1<sup>st</sup> spindle control, hereafter, the S command being executed will change the 1<sup>st</sup> spindle speed. In a similar way, M63, M64, M65 is executed, the corresponding signal of the 2<sup>nd</sup> spindle outputs, at the time, the corresponding signal of the 2<sup>nd</sup> spindle outputs, and is switched into the 2<sup>nd</sup> spindle control, after that, the executed S command will change the 2<sup>nd</sup> spindle speed.
- 1.3. The spindle switch is invalid in rigid tapping.
- 1.4. The manual CW, CCW, STOP, SPINDLE OVRRRIDE keys on the panel are valid only to the 1<sup>st</sup> spindle. When the current system is controlled by the 2<sup>nd</sup> spindle, the manual control key of the spindle on the panel still controls the 1<sup>st</sup> spindle.
- 1.5. The spindle override of the  $2^{nd}$  spindle is fixed to 100%.
- 1.6. Cs axis control of two spindles can be separately switched and the current used spindle has no requirements, that is, when the current is the 1<sup>st</sup>(2<sup>nd</sup>) spindle, the 2<sup>nd</sup> (1<sup>st</sup>) spindle executes the Cs switch.

## • Cs control logic of the 2<sup>nd</sup> spindle

- 1.1. After M24 is executed, PLC sets the spindle contour controllable signal CON (G127.7) to 1;
- 1.2. CNC controls the drive to shift the controllable method, after the shifting is performed, CNC→PLC outputs the spindle contour controllable shifting end signal FSCSL (F144.1);
- 1.3. After the PLC detects the spindle contour controllable shifting end signal FSCSL (F144.1), end the performance of the M24. The spindle controllable method is then completed.
- 2. M25 execute processes are the same those of M24.
- 3. M25 only cancels M24 executing the speed/position switch. Executing M25 cannot switch the

system into the speed control mode when executing M29 switches the spindle into Cs contour control.

- 4. C/S on the panel is only used to Cs switch of the 1<sup>st</sup> spindle.
- 5. Before switch, the spindle can rotate or stop. After switch, the spindle stops.
- 6. When the spindle is in Cs contour control mode, the spindle rotation(CW/CCW) output is invalid.
- 7. When the spindle is in the external speed control mode, the manual operation of Cs axis is invalid.
- 8. When the alarm occurs in the servo or because of the too long switch time or the reset or emergency stop appears in switch, PLC switches the spindle into the speed control state.
- 9. When PLC K15.6 is set to 1, the spindle contour control is disabled in emergency stop, reset. PLC switches the spindle into the speed control state.

## • Wiring

When the GSK980TDi matches with the GS-L series servo drive; the bus then can be connected regardless of the special cable.

# 2.9.9 Rigid Tapping Function

## Related commands

M20 spindle clamped output

- M21 spindle clamped/released output
- M29 entering rigid tapping state
- Note: When only the selected spindle used to the rigid tapping interpolation is the rotary axis, the rigid tapping function can be executed.

## • Function description (defined by the standard PLC program)

- ① When the Cs function of the tapping spindle is invalid, the system is switched into the rigid tapping state instead of switching the spindle servo speed/position in executing M29, defaults the spindle servo to be the position control state.
- ② When Cs function of the tapping spindle is enabled, the spindle servo for the tapping is switched into the position control state and the system is switched into Cs contour control state.
- ③ Before M29 switch, the tapping spindle is permitted to the spindle mode or Cs contour control mode. After the rigid tapping return, the tapping spindle returns to the previous control mode.
- ④ When the system is in the rigid tapping state, the manual movement tapping spindle cannot be performed.
- (5) The rigid tapping state is cancelled in reset or emergency stop.
- In M29, when the 1<sup>st</sup> or the 2<sup>nd</sup> spindle is currently used, it is switched into the rigid tapping state. In rigid tapping, a spindle should be selected firstly to execute the rigid tapping interpolation. After the spindle is switched into the rigid tapping state, the spindle switch is invalid.
- ⑦ After M29 is execute, M20 and the tapping command in the same block are executed to clamp the spindle before drilling or tapping.

# 2.9.10 Spindle Clamped Function

## • Relative signals (Standard PLC program definition)

Signal	Code	Interface	Address	Function	Remark
type	0000	internatio	/ 1441 000	i unotion	Komark

Output signal	SCLP	CN62.07	Y0.6	Spindle clamped output	
------------------	------	---------	------	------------------------	--

#### • Relative commands

- M20 Spindle clamping output
- M21 Spindle clamping output cancel

Note: The spindle clamping equipment should be matched with the machine tool.

#### • Control parameters

Status parameters

Κ	1	7			SCLP						
SCI	SCLP =1:Spindle clamped function is valid.										

# =0:Spindle clamped function is invalid

D	Т	2	0		SCLPTIME						
Spii	Spindle clamping/releasing command execution time (ms).										
D	Т	2	3		SVF_DELEY						

spindle is started to clamp, delay to reduce the spindle servo exciting time (ms).

## • Function description (Standard PLC program definition)

- M20 and M21 are a pair of M commands for controlling the spindle clamp and release, and they are for clamping the spindle after positioning, so that the spindle won't rotate due to the force during drilling or tapping.
- ② During executing M20, to avoid the clamped spindle servo motor current too big, CNC will control the spindle and cut off the servo after the delay time set by DT23, and then, the spindle servo reduces the motor excitation, while the position control can't be executed. However the position detection can still functions and the position won't get lost.
- ③ The spindle can't be clamped by M20 during the spindle moving or rotating. After the spindle is clamped, the spindle can neither be rotated nor moved; otherwise, PLC issues the alarm.

# 2.9.11 Spindle Positioning Function

## Relevant command

- M14 Spindle shifts to the positioning control mode
- M15 Spindle shifts back to speed control mode

**Note:** It is necessary to set the CS function of the spindle, and the spindle clamping equipment is matched with the machine tool

## • Control parameters

Status parameters

1	9	5	SSPD			RPOS		CSREF	RCS
			 		/				6

Bit7 1:series spindle controllable function enabled (series spindle The slave ID number of the spindle 1~3 is 11~13), it is necessary to restart;

0: Series spindle controllable function disabled (analogy spindle), it is necessary to restart.

Bit3 1: Spindle position function is valid (When it is enabled, the mechinial releasing/clamping interlocking operaton is performed before/after the spindle is positioned);

- 0: Spindle position function is invalid.
- Bit1 1: Change to position mode, the axis do return REF.
  - 0: Change to position mode, the axis does not return REF.
- Bit0 1: Cs function of spindle valid, power on
  - 0: Cs function of spindle is: invalid, power on



Spindle shifting M code

Spindle CS shifts the M code [Setting value +1 is the M code of the function releasing].

Note 1: When the spindle positioning function is enabled that is regarded as the M code of the spindle positioning method shifting.

Note 2: The setting value should be performed based upon compiled CS shifting M code in the ladder diagram.

Note 3: The setting value is disabled when it is less than 6, in this case, the CS axis shifting will not perform the coordinate system clearing.

## • Function description (Standard PLC program definition)

- ① The system stops the detection spindle when executing the M14, simultaneously, output the spindle releasing signal; the spindle is then converted into positioning mode after confirming the spindle is released; the spindle is clamped after shifted.
- <sup>(2)</sup> When the spindle is at the positioning mode, the arbitrary angle positioning based upon the axis address command can be performed by G00 command. Firstly output the spindle releasing signal when the position is performed, confirm that the spindle positions after releasing; output the spindle clamping signal after moves to the specified position, the positioning procedure is completed after confirming the spindle clamping.
- ③ The system will output the spindle releasing signal when executing M15; shift the spindle to the controllable mode after confirming that the spindle is released, the shifting is then performed.
- ④ Firstly set the Cs axis function before setting the spindle positioning function. When the positioning function setting is enabled, only the positioning operation can be performed instead of using the relevant function to the Cs contour control.
- (5) When the spindle positioning function is enabled, there are relevant operations between the spindle clamping and releasing before/after positioning. Therefore, the spindle clamping equipment should be matched with the machine tool.

# 2.9.12 External Cycle Start & Feed Hold

## • Relevant signal (defined by standard PLC program)

ST: External cycle start signal, whose function is the same with the CYCLE START key on the machine panel;

SP: External feed hold signal, whose function is the same with the FEED HOLD key on the machine panel, and it shares an interface with SAGT(safety door detect) signal.

## • Signal diagnosis

Signal	SP	ST
Diagnosis address	X9.1	X9.0
Interface pin	CN78.6	CN78.7

## Signal connection

The interior circuit of SP/ST signal is shown in Fig. 2-48:





## Control parameter

Bit parameter

1	7	2			MST	MSP					
Bit 6 =1: External cycle start signal (ST) is invalid;											

=0: External cycle start signal (ST) is valid;

Bit 5 =1: External stop signal (SP) is invalid;

=0: External stop signal (ST) is valid; the external feed hold switch is needed, otherwise, "Feed hold" is displayed.

## • External connection circuit

The external connection circuit of SP, ST signals is shown in Fig. 2-49:



# 2.9.13 Cooling Control

• Relevant signal (defined by standard PLC program)

Туре	Sign	Interface	Address	Function	Remark
Output signal	M08	CN62.1	Y0.0	Cooling control output	
Command format	M08			Cooing ON	
Command format	M09			Cooling OFF	

## Signal connection

Its internal circuit is shown in Fig. 2-50:



Fig. 2-50 M08 internal circuit

#### • Function description (defined by standard PLC program)

M09 is active, i.e. M08 is inactive, after CNC power on. To execute M08, M08 output is active and cooling is turned on; to execute M09, M08 output is cancelled and cooling is turned off.

- Note 1: M08 output is cancelled at CNC emergency stop.
- Note 2: Whether M08 is cancelled is set by BIT3 of the bit parameter No.009 when CNC is reset. When Bit1=0, M08 output is cancelled as CNC is reset; When Bit1=1, M08 output is not cancelled as CNC is reset;
- Note 3: There is no corresponding output signal for M09, and M08 output is cancelled if M09 is executed.

Note 4: The cooling can be controlled by the cooling can be controlled by the

# 2.9.14 Lubricating Control

Туре	Sign	Interface	Address	Function	Remark
Output signal	M32	CN62.2	Y0.1	Lubricating control output	
Input signal	LUBS	CN61.33	X2.4	Lubricating position detection signal	
Command	M32			Lubricating ON	
format	M33			Lubricating OFF	

## • Relevant signal (defined by standard PLC program)

#### Signal connection

The internal circuit is shown in Fig. 2-51:



Fig. 2-51 M32 circuit

## • Control parameter



K 1 6		LUBS	LUBCK	M32A						
M32A =1: output lubr	icating in start	ing the system wh	nen the au	Itomatic	lubricatin	g is valid				
=0: do not output lubricating in starting the system when the automatic lubricating is val										
PLC value	PLC value									
LUBCK =1: Detection with low lubricating position										
=0: Without detection with low lubricating position										
LUBS =1: Alarm with low lubricating position and low level										
=0: Alarm with low lubricating position and high signal										
D T 1 3		MAN	LUBT							
Time for manual lubri	icating ON (m	s) (0: lubricating ti	me is not	limited);						
D T 1 6	D T 1 6 AUTOLUBMT									
Automatic lubricating time (0 $\sim$ 2147483647ms)										
D T 1 7		AUTO	OLUBT							

Automatic lubricating interval time (0 $\sim$ 2147483647ms)

## • Function description

The lubricating defined by standard PLC program for this GSK980TDi system has two types: Non-automatic and automatic lubricating, which are set by parameter:

DT17 =0: Non-automatic lubricating (same as version before)

DT17>0: Automatic lubricating, lubricating time DT17 and lubricating interval time DT16 available

#### 1. Manual lubricating function

Press on the machine operator panel and the system executes the lubricating output, pressing it again and the system cancels the output. Execute M32 and the system executes the output; execute M33 and the system stops it.

DT13>1: the system executes the timed lubricating output, and the output is executed by

pressing , and is cancelled when the output exceeds the one set by DT13. After the system executes M32, the lubricating output is executed within the time set by DT13 and it is cancelled. Execute M33 in the time set by No. 112 and the output is cancelled.

#### 2. Automatic lubricating

When K16.2 is set to 1, the system executes the lubricating in the time set by DT17, and then stops the output. After it keeps the stop in the time set by DT16, it executes the lubricating again

repetitively, and executes the cycle in turn. In automatic lubricating, M32, M33, which was not the machine panel are valid, and the lubricating time is the one set by DT17.

Note 1: The lubricating output is disabled in emergency stop;

#### Note 2: K No.0.10 Bit1 sets whether the lubricating output is cancelled in reset:

Bit1 = 0: the lubricating output is disabled in reset;

Bit1 = 1: the lubricating output remains unchanged in reset.

Note 3: The lubricating position detectiong signal is duplicatedly usable with DEC4, therefore, when the system uses the DEC4 signal, it is better to set the disabled lubricating position detection.

## 2.9.15 Chuck Control

## • Relevant signal (defined by standard PLC program)

DIQP: Chuck control input signal

DOQPJ: Inner chuck clamping output/outer chuck releasing output signal

DOQPS: Inner chuck releasing output/outer chuck clamping output signal

NQPJ: Inner chuck clamping in-position/outer chuck releasing in-position signal, sharing a common interface with T08, M42I

WQPJ: Inner chuck releasing in-position/outer chuck clamping in-position signal, sharing a common interface with T07, M41I

Note 1: The key on the operation panel of GSK980TDi can replace DIQP input signal, and the diagnosis address is X0026.6.

## • Signal diagnosis

Signal	DIQP	NQPJ	WQPJ	DOQPJ	DOQPS
Diagnosis address	X0.2	X3.4	X3.3	Y1.4	Y1.5
Interface pin	CN61.3	CN61.40	CN61.41	CN62.13	CN62.14

## • Control parameter

Κ	1	2	Ī				RCKC	CCHU	NYQP	SLSP	SLQP
21 OP 4. Obviele control from the mile continue											

- SLQP =1: Chuck control function is active;
  - = 0: Chuck control function is inactive;
- SLSP =1: Check chuck clamping when the chuck function is active;
  - 0: Does not check chuck clamping when the chuck function is active; if chuck is not clamping, the spindle is disabled and an alarm is issued.
- NYQP =1: Outer chuck mode; NQPJ is outer chuck releasing signal, WQPJ is outer chuck clamping signal
  - =0: Inner chuck mode; NQPJ is inner chuck clamping signal, WQPJ is inner chuck releasing signal
- CCHU =1: Check chuck in-position signal.
  - =0: Does not check chuck in-position signal.
- RCKC =1: External chuck control is active during program running;

<sup>=0:</sup> External chuck control is inactive during program running;

D T 1 4	
Chuck clamping command (M12) execution til	me (ms)
D T 1 5	
Chuck released command (M13) execution tir	ne (ms)
DT0018	
DT18 >0: Chuck clamping and releasing s	signals are pulse output, the pulse width is set by
DT18	

=0: Chuck clamping and releasing signals are level output

## Signal connection

The circuit of DOQPJ/DOQPS is shown in Fig. 2-52:



#### Sequence

①When SLQP=1, SLSP=0, NYQP=0, CCHU=1, CNC chooses inner chuck mode, and chuck in-position signal detecting is active:

DOQPS: chuck releasing output; WQPJ: releasing in-position signal;

DOQPJ: chuck clamping output; NQPJ: clamping in-position signal.

DOQPJ and DOQPS output high resistance at power on, when CNC detects that the chuck input signal DIQP is active for the 1<sup>st</sup> time, DOQPJ is connected to 0V and chuck is clamped.

After M12 is executed, DOQPS (pin 14 of CN62) outputs high resistance, DOQPJ(pin 13 of CN62) outputs 0V, chuck is clamped and CNC waits for NQPJ signal to be in-position.

After M13 is executed, DOQPJ (pin 13 of CN62) outputs high resistance, DOQPS(pin 14 of CN62) outputs 0V, chuck is released and CNC waits for WQPJ signal to be in-position.



Fig. 2-53 (Chuck clamping, releasing signals are level output)

②When SLQP=1, SLSP=0, NYQP=1, CCHU=1, CNC chooses outer chuck mode, and chuck in-position signal detecting is active:

DOQPS: chuck clamping output;

WQPJ: clamping in-position signal;

DOQPJ: chuck releasing output; NQPJ: releasing in-position signal.

DOQPJ and DOQPS output high resistance at power on, when CNC detects that the chuck input signal DIQP is active for the 1<sup>st</sup> time, DOQPS is connected to 0V and chuck is clamped.

After M12 is executed, DOQPS (CN62.14) outputs 0V, DOQPJ(CN62.13) outputs high resistance, chuck is clamped and CNC waits for WQPJ signal to be in-position.

After M13 is executed, DOQPJ (CN62.13) outputs 0V, DOQPS(CN62.14) outputs high resistance, chuck is released and CNC waits for NQPJ signal to be in-position.


Fig. 2-54 Chuck clamping, releasing signals are level output

As the 2<sup>nd</sup> chuck input is active, DOQPS outputs 0V, chuck is released. The chuck clamping/releasing signal is output alternatively, i.e. the output is changed each chuck input signal is active.

③The interlock between the chuck and the spindle

When SLQP=1, SLSP=0, M3 or M4 is active, the alarm is issued if M13 is executed and the output is unchanged.

When SLQP=1, SLSP=0, CCHU=1, if M12 is executed in MDI or Auto mode, CNC does not execute next code till it detects the chuck clamping in-position signal is active. When the chuck input signal DIQP is active in Manual mode, the panel spindle CW, CCW key are inactive till it detects the chuck clamping in-position signal is active. In spindle running or auto cycle processing, DIQP input signal is inactive. And DOQPS, DOQPJ is held on at CNC reset and emergency stop.

### 2.9.16 Tailstock Control

#### Relevant signal (defined by standard PLC program)

DOTWJ: Tailstock forward output signal

DOTWS: Tailstock backward output signal

DITW: Tailstock input signal, DITW and BDT share a common interface.

Note: For GSK980TDi, can replace DITW input signal, and the diagnosis address is X0026.5.

#### Signal diagnosis

Signal	DITW	DOTWJ	DOTWS
Diagnosis address	X0.4	Y2.5	Y2.6
Interface pin	CN61.5	CN61.34	CN61.35

#### Control parameter

State parameter

K	1	3					RTSC	SPTW	SLTW
SLT	W =	=1: '	Tailsto	ck functic	on active.				

- =0: Tailstock function inactive.
- SPTW =1: No interlock between spindle rotation and tailstock advancing and retracting, tailstock may be moved regardless of the spindle, or spindle may run regardless of tailstock;
  - =0: Interlock between spindle rotation and tailstock advancing and retracting, tailstock retraction disabled as spindle is running, spindle disabled if tailstock does not advance.

RTSC =1: External tailstock control is active when a program runs.

=0: External tailstock control is inactive when a program runs

#### Signal connection

The tailstock circuit is shown in Fig. 2-55:





Sequence (defined by standard PLC program) The sequence of tailstock is shown in Fig. 2-56:



Tailstock advancing (DOTWJ) and retracting(DOTWS) are both inactive when power on; when the tailstock input (DITW) is active for the 1<sup>st</sup> time, tailstock advancing is active; when it is active for the 2nd time, tailstock retracting is active, so the DOTWJ/ DOTWS signal interlock is output alternatively, i.e. The output changes each time the DITW signal is active. If M10 is executed, DOTWJ (CN62.34) outputs 0V and tailstock advances; if M11 is executed, DOTWS (CN62.35) outputs 0V and tailstock retracts.

DITW signal is inactive as spindle is running. If M11 is executed, alarm will be issued, and its

output are held on. And DOTWS, DOTWJ outputs are held on at CNC reset or emergency stop.

#### 2.9.17 Low Pressure Detection

Relevant signal (defined by standard PLC program)
 PRES: Low pressure alarm detection signal, sharing a common interface with TCP.

#### • Signal diagnosis

Signal	PRES
Diagnosis address	X0.6
Interface pin	CN61.7

#### • Control parameters

#### State parameter

Κ	1	4						SPB3	PB3
PB3	3 :	=0:	Low p	pressure	detection	inactive			

- =1: Low pressure detection active.
- SPB3 =0: Low pressure alarm issued when PRES is connected with +24V.
  - =1: Low pressure alarm issued when PRES is connected with 0V.
- PLC data parameter

D	т	0	2	ΡΕΔΙΜΤΙΜ
2	•	U	-	
	A I A	1	4. 1/	 ing time hotors low processes clarm (0, 0000 mg)

PEALMTIM: Waiting time before low pressure alarm(0~60000ms)

#### Function description

①When PB3=1 and SPB3=0, PRES is connected to +24V, which is confirmed to be low pressure alarm by CNC;

②When PB3=1 and SPB3=1, PRES is connected to 0V, which is confirmed to be low pressure alarm by CNC;

③When low pressure alarm detection function is selected, once CNC detects the low pressure alarm signal PRES to be active, and the signal holding time is over the setting by the data parameter No.069 alarm is issued by CNC. And the axis feed is held, spindle is stopped, cycle start is disabled,

the alarm may be cancelled by pressing

key or cutting off power;

### 2.9.18 Hydraulic Control

Related signal (defined by the standard PLC program)
 HPST: hydraulic control output signal

#### Signal diagnosis

Signal	HPST
Diagnosis address	Y3.1
Interface pin	CN62.38

#### • Control parameter

#### PLC state parameter

Κ	1	4		HPST					
PB:	3 =	=0: 1	the hyd	draulic co	ntrol fund	tion is di	sabled.		

=1: the hydraulic control function is enabled.

#### • Function description

- (1) When the hydraulic control function is enabled, pressing can control HPST output to start the hydraulic motor.
- ② In non-run, the spindle stop with the speed 0, pressing can disable HPST output.
- ③ When the hydraulic control function enables and the hydraulic motor is started, the system alarm, at the time, the spindle cannot rotate.

#### 2.9.19 Safety Door Detection

#### • Relevant signal

SAGT: For safety door detection, sharing a common interface with SP signal SLK: Defense door lock control output. Only GSK980TDi-H is enabled.

Note: SLK defense door controllable function. Only GSK980TDi-H is enabled.

#### • Signal diagnosis

Signal	SAGT	SLK
Diagnosis address	X0.0	Y2.7
Interface pin	CN61.1	CN62.36

#### • Control parameter

<ul> <li>PLC status parameters</li> </ul>	
---	--

	Κ	1	4				SLK	SGSP	SPB4	PB4	
PB4		=0:	Pro	tection	n door de	tection fu	inction is	invalid;			

=1: Protection door detection function is valid;

SPB4 =0: When SAGT is at low level (disconnect with +24V), the protection door is closed;
 =1: When SAGT is at high level (connected with +24V), the protection door is closed;

SGSP =0: Spindle is disabled when the protection door is open;

=1: Spindle is not disabled when the protection door is open;

SLK =0: (980TDi-H) defense door disabled.

=1: (980TDi-H) defense door enabled.

PLC data parameter

D T 2 8

Delay the controllable time (ms) of the defense door close

#### • Function description (defined by standard PLC program)

- When PB4=1, SPB4=0, CNC confirms that the safety door is closed as SAGT is connected to 0V;
- ② When PB4=1, SPB4=1, CNC confirms that the safety door is closed as SAGT is connected to +24V;
- ③ In Auto mode, if CNC detects the safety door is open, alarm is issued as cycle starts;

- ④ In Auto running, if CNC detects the safety door is open, the axis feed is held, and alarm is issued by CNC;
- (5) The safety door detection function is only active in Auto mode;
- (6) When the defense door lock function is enabled, in the Auto/MDI mode, the program should be at the dwell state by opening the door lock pressing the "safety door" button on the panel. Firstly close the spindle and cooling pressing the defense door lock button on the panel; the defense door lock output when detecting that the spindle rotation speed is zero; in this case, the defense door can be opened. The feed dwells when opening the lock by M18, the others are consistent with the buttons on the button.
- ⑦ The spindle or cooling will not be closed in Manual/MPG mode.
- ⑧ Defense door lock controllable output, close the door lock controllable output after delaying the DT28 setting time. When the defense door becomes close state from the open state, the door lock controllable outputs are entirely closed regardless of the DT28 timing is performed or not.

#### 2.9.20 CNC Macro Variables

#### Relevant signal

Macro output signal: standard PLC defines 5 macro output interfaces  $#1100 \sim #1105$ ; Macro input signal: standard PLC defines 16 macro output interfaces  $#1000 \sim #1015$ 

#### Signal diagnosis

Macro	variable	#1105	#1104	#1103	#1102	#1101	#1100	I
number								
Diagnosis add	ress	Y3.7	Y3.6	Y3.5	Y3.4	Y3.3	Y3.2	
								-
Macro	variable	#1007	#1006	#1005	#1004	#1003	#1002	#1001
number								
Diagnosis add	ress	X0.7	X0.6	X0.5	X0.4	X0.3	X0.2	X0.1
Macro	variable	#1015	#1014	#1013	#1012	#1011	#1010	#1009
number								
Diagnosis add	X1.7	X1.6	X1.5	X1.4	X1.3	X1.2	X1.1	

#### • Function description (defined by standard PLC program)

 $U00 \sim U05$  signal output may be changed if macro variable  $\#1100 \sim \#1105$  are assigned. If they are assigned for "1", it outputs 0V, if they are assigned for "0", it turns off their output signals.

Detect the macro variable  $\#1000 \sim \#1015$  values (input signal state), they may be used for various processing if combined with other transfer judgment macro code.

#### 2.9.21 External Override

#### • Related signals

Туре	Sign	Interface	Address	Function	Remark
	CN67.1	FOV0	X29.0	Feed override wave-band switch 0	
	CN67.6	CN67.6FOV1X29.1Feed override wave-band switch 1		Feed override wave-band switch 1	
Input	CN67.2	CN67.2 FOV2		Feed override wave-band switch 2	
	CN67.5	FOV3	X29.3	9.3 Feed override wave-band switch 3	
signal					
orginal	CN66.1	SOV0	X29.4	Spindle override wave-band switch 0	
	CN66.6	SOV1	X29.5	Spindle override wave-band switch 1	
F	CN66.2	SOV2	X29.6	Spindle override wave-band switch 2	
	CN66.5	SOV3	X29.7	Spindle override wave-band switch 3	

#### • Related parameters

PLC state parameter

Κ	1	6							ROVI	SOVI
RO	ROVI =0: External feedrate override does not inverse.							se.		

=1: External feedrate override inverses.

SOVI =0: External feedrate override switch is disabled.

=1: External feedrate override switch is enabled.

#### • Function description

- 1. When the external feedrate override switch is selected, the button on the panel is disabled.
- 2. When the external feedrate override inverses, the system changes the direction of the override regulation.

### 2.9.22 External MPG

#### • Related signals

CN31(MPG)	PLC	Address	Function	Remark		
	address	character				
5	X6.0	EHDX	X MPG			
6	X6.1	EHDY	Y MPG			
8	X6.2	EHDZ	Z MPG	Annelised		
19	X7.0	EHD4	4 <sup>th</sup> MPG	Applied		
7	X7.1	EHD5	5 <sup>th</sup> MPG	ZSSY2080 MPG		
9	X6.3	EMP0	Increment ×1			
22	X6.4	EMP1	Increment ×10			
23	X6.5	EMP2	Increment ×100			
11, 12, 13	GND					
14,15	+5V					
17,18	+24V					

Related parameters

State parameter

0 0 Bit3 =	1 0: Step wo	orking mo	ode.			MPG				
=	=1: MPG v	vorking n	node.							
PLC sta	atus paran	neters								
K 1	6	SINC								
SINC	=0: Whe	n the sys	tem incre	ement is (	0.1µ, gea	r ×1000	in MPG a	and STEP	<sup>o</sup> mode is	valid;
	=1: Whe	n the sys	stem incre	ement is	0.1µ, gea	ar ×1000	in MPG	and STEI	P mode is	invalid;
K 2	0						DB	MPG1 C	DBMPG0	
DBMPC	GO Dual	-MPG fu	nction se	lection bi	t 0; 00	: Disable	ed 01:	Enabled,	as well th	ne MPG
1 fixes the X	(axis and	the MPG	3 2 fixes t	he Z axis	, the sha	red step	-length c	an be sel	ected:	

DBMPG 1 Dual-MPG function selection bit 1; 10: It is enabled and its panel button is only enabled by MPG 1; external MPG input is only enabled by MPG 2.

#### • Function description

- MPG/STEP mode ×1000-gear selection is disabled. When x1000-gearis selected before modifying the parameter, the system automatically changes into ×100-gear;
- <sup>(2)</sup> When the external MPG, its axis selection does not lock, that is, the axis selection of MPG is disabled, the system changes to the non-axis selection state.
- ③ When the external MPG axis selection and gear selection input are enabled, the axis selection on the panel and the gear selection keys are disabled; when the external MPG axis selection and gear selection input are disabled, the axis selection on the panel and the gear selection keys are enabled and self-locked.
- ④ When the dual-MPG is enabled, which can be selected the dual-MPG controllable mode by parameters K20.1 and K20.0.
- (5) When K20.1=0 K20.0=1, MPG 1 fixes the controllable X axis, MPG 2 fixes the controllable Z axis; the step-length values of two MPGs are identical, which can be adjusted by step-length on the panel or external step-length input signal.
- <sup>(6)</sup> When K20.1=1 K20.0=0, the panel MPG axis selection or step-length button only can be controlled the MPG 1, and the external MPG input signal can be controlled the MPG 2.

#### 2.9.23 Tri-color Lamp

#### • Relevant signals and function definition (standard PLC program)

Signal type	Sign	Signal interface	Address	Function
Output	CLPY	CN62.31	Y2.2	Yellow— normal state (non-running, non-alarm state)
signal	CLPG	CN62.32	Y2.3	Green—running state
	CLPR	CN62.33	Y2.4	Red—alarm state

#### 2.9.24 Extended M Function

# Signal interfaceAddressAddress charactersFunctionCN62.40Y3.3EMOT1Extended M function signal 1CN62.41Y3.4EMOT2Extended M function signal 2

#### • Relevant signals (standard PLC program)

	•	Relevant commands
--	---	-------------------

M34 Extended M function signal 1 (EMOT1) outputs

M35 Extended M function signal 1 (EMOT1) closes output

M36 Extended M function signal 2 (EMOT2) outputs

M37 Extended M function signal 2 (EMOT2) closes output

- Control parameters
  - PLC parameters

Κ	1	8		EXTM	RSTM						
EXTM =0:extended M function is invalid.											

=1:extended M function is valid.

RSTM =0:extended M function closes output when emergency stop, reset.

=1:extended M function remains output when emergency stop, reset.

- Function explanation
- 1. When M34 is executed, extended M function 1 (EMOT1) outputs; when M35 is done, its output is closed.
- 2. When M36 is executed, extended M function 2 (EMOT2) outputs; when M37 is done, its output is closed.
- 3. Whether extended M function output is closed is set by K18.6 when emergency stop, reset.

#### 2.9.25 HOLD Control

#### • Relevant signals (standard PLC program)

Signal	Address	Address	Function
interface		characters	
CN62.03	Y0.2	HOLD	HOLD release output

• Control parameter

PLC state parameter

Κ	1	8				HOLD					

HOLD =0:HOLD release control is invalid.

=1:HOLD release control is valid.

Function

1. After power-on, there is no emergency stop alarm or servo spindle alarm and the system delays 4S, HOLD signal is output to release HOLD.

2. HOLD signal is closed when an emergency stop alarm or servo spindle alarm occurs.

#### 2.9.26 Handle Interrupt

#### • Control parameters

PLC	PLC Status parameters											
Κ	1	9				HDFD						

HDFD =0: MPG interruption function is disabled in the process of the operation.

=1: MPG interruption function is enabled in the process of the operation.

•	4	2				MPG	
U	I	2				interruption	

Bit1 1:Handle interrupt is valid;

0:Handle interrupt is invalid.

- Function description
- 1. When the MPG interruption function is enabled, in the Edit/Auto/MDI mode, enter the MPG

interruption state by the MPG axis number on the selection panel after pressing the end once, the MPG interruption operation is then can be performed. The MPG interruption can be retracted by pressing this button again.

- 2. In the Non-Edit/Auto/MDI mode, the MPG interruption state will be retreated.
- 3. Whether the MPG interruption is enabled that can be set by K19.5 during the operation of the program.
- 4. The panel rapid traverse override can not be adjusted at the state of MPG interruption; the indicator displays the MPG override state when the MPG override adjustment is enabled.

### 2.9.27 Chip-Removal Control

Relative signals

Signal type	Symbol	Signal interface	Address	Function description	Remark
Signal	CHRO+	CN62.43	Y3.6	Chip-removal CW (positive)	
output	CHRO-	CN62.44	Y3.7	Chip-removal CCW (negative)	
Command	M38			Chip-removal CW (positive)	
format	M39			Chip-removal stop	

#### Relevant parameters

PLCStatus parameters

κ	1	3		CHIPR							

**CHIPR** =1: Chip-removal control enabled.

=0: Chip-removal control disabled.

- Function description
- 1. The reverse rotation of the chip-removal only can be performed the JOG by hand. If the chip-removal is being rotated, firstly stop the positive rotation when the JOG reverse is performed.
- 2. When the chip-removal is positively rotated, press the chip-removal positive rotation by hand again, and then it is closed.
- 3. Close the chip-removal rotation in the ESP resetting.

#### 2.9.28 Working Indicator

Relative signals

Signal type	Symbol	Signal interface	Address	Function description	Remark
Output signal	WKLP	CN62.39	Y3.2	Working indicator output	

Relevant parameters

PLCStatus parameters

			_					
κ	1	3			WKLP			

**WKLP** =1: Working indicator control enabled.

=0: Working indicator control disabled.

Function description

The working indicator outputs pressing \_\_\_\_\_ once; it closes by pressing it again.

#### 2.9.29 Gear/tool Number Display

#### • Signal diagnosis

Y0025	BIT	7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
Corresponding	LED	01	LED1	LED1	LED1	LED0	LED0	LED0	LED0
BCD code	2 <sup>3</sup>		2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>	2 <sup>3</sup>	2 <sup>2</sup>	2 <sup>1</sup>	2 <sup>0</sup>

LED 0 displays the current tool number, BIT0~BIT3 of PLC diagnosis number Y25 are BCD code of the current tool number; LED 1 displays the gear of the current spindle, BIT4~BIT7 of PLC diagnosis number Y25 are BCD code of the current spindle gear and is shown below:



#### • Function description

① When the tool count is less than 10, the gear and the tool number separately use one LED to display.

2 When the tool count is more than 10, LED 1 displays 10-digit numbers and the LED 0 displays the single digits.

③ When the gear and the tool number are displayed in time-division, that is, the gear instead of the tool number is firstly display, the tool number instead of the gear is displayed after 1.5S, and the system executes them like the above cycle.

### 2.10 Commonly Use Sign of Electricity Drawing

GSK980TDi DC24V power supply and the electromagnetic valve with power working current separately use DC24V, and the electronic component explanations are as follows:

## **CNCmakers**

Name	Sign	Graph	Name	Sign	Graph
Air breaker	QF	大大中	Contactor coil	KM	1
		333	contact and auxiliary		
			contact		
transformer	TC	hum	Heat relay and	FR	
		(*****)	contact		
Rectifier	VC		Capacity	С	
Motor	М	(M 3~)	Resistant	R	
D' I		$\sim$			
Diode	VD	—— <del>N</del> ——	Hall switch		
Electromagnetic	YV		Travel switch	SQ	
coil					
Relay coil and	KA		Veneer socket		)—
contact			Pedal switch	SA	
					$\sim$
			Fuse	FU	-

### CHAPTER 3 PARAMETERS

The CNC bit and data parameters are described in this chapter, various functions can be set by these parameters. The major parameter data type are listed as follows:

	Data type	Range
(1) Bit	0001 00011000	
(2) Bit axis	0187 X 00000010 Z 00000010	8 bit, 0 or 1
(3) Bit spindle		
(4) Word	0030 200	
(5) Word axis	0015 X 1 Z 1	See relevant parameters for
(6) Word spindle	0021 S1 0 S2 0	details

Note: if the data type is not specified, the type is bit or word.

### 3.1 Parameter Description (by Sequence)

#### 3.1.1 Bit Parameter

The state parameter is expressed as follows:



0 0 2 CLK *** *** LIFJ MDITL LIFC TNRC TLIF				-								
	0	0	2		CLK	***	***	LIFJ	MDITL	LIFC	TNRC	TLIF

## **CNCmakers**

- Bit7 1: Show clock
  - 0: Conceal clock
- Bit4 1: Tool life management group skip active
  - 0: Tool life management group skip inactive
- Bit3 1: Tool life management active in MDI mode
  - 0: Tool life management inactive in MDI mode
- Bit2 1: Tool life counting type 2, by times
  - 0: Tool life counting type 1, by times
- Bit1 1: Tool nose radius offset active
  - 0: Tool nose radius offset inactive
- Bit0 1: Tool life management active
  - 0: Tool life management inactive

	0 3	HTC	IG ***	PCOMP	TCOMP	CDCOMP	***	***	OIM
--	-----	-----	--------	-------	-------	--------	-----	-----	-----

- Bit7 1: High efficiency tool-change function enabled
  - 0: High efficiency tool-change function disabled
- Bit5 1: Pitch error offset active

0

- 0: Pitch error offset inactive
- Bit4 1: Tool offset by coordinate offset
  - 0: Tool offset by move
- Bit3 1: Tool compensated by the shift of coordinate system do not memorize the unexecuted tool compensation
  - 0: Tool compensated by the shift of coordinate system memorize the unexecuted tool compensation
- Bit0 1: Offset automatically change in metric and inch conversion
  - 0: Offset not change in metric and inch conversion

0	0	4	1 Г	ABOT	RDRN	DECI	ORC	**	* ***	* PROD	SCW
Bit7	1: c	do not i	memoriz	ze absol	ute coord	linate in	power-de	own			
	0:	memoi	rize the a	absolute	e coordina	ate in po	wer-dow	n			
Bit6	1:	G00 i	s rapid t	raverse	speed in	dry run	mode				
	0:	G00	is manu	al feedra	ate in dry	run mo	de				
Bit5	1:	DEC	signal is	high le	vel for ma	achine z	ero returr	า			
	0:	DEC	signal is	s low lev	el for ma	ichine ze	ero return	l			
Bit4	1:	Tool c	offset by	radius							
	0:	Tool	offset by	diamet	er						
Bit1	1:	Relati	ve posit	ion for p	orogramm	ning in P	OSITION	l page			
	0:	Relat	tive posi	tion invo	olving offs	set in PC	OSITION	page			
Bit0	1:	Inch s	system for	or min. (	code unit	, active a	after repo	wering	)		
	0:	Metri	c systen	n for mii	n. code u	nit, activ	ve after re	power	ing		
0	0	5	1 Г	***	*** SI	MAL	M30	***	POSRE	PPD	PCME
Bit	5	1: Man	ual spin	dle geai	r change	during t	he execut	tion of	S code;		I

- 0: Automatic spindle gear change during the execution of S code;
- Bit 4 1: Cursor returns to the head of the program after the execution of M30;
  - 0: Cursor does not return to the head of the program after the execution of M30;

- Bit 2: 1: Position recording signal PRC is used during tool setting;
  - 0: Position recording signal PRC is not used during tool setting;
- Bit 1: 1: G50 sets relative coordinate value:
  - 0: G50 does not set relative coordinate value;
- Bit 0: 1: Axial output wave is pulse; 0: Axial output wave is square;

0 0 6	**:	* ***	***	ZM5	ZM4	ZMY	ZMZ	ZMX
Bit4~Bit0 1:	5 <sup>th</sup> , 4 <sup>th</sup> , <u>Y, Z, 1</u>	X zero retu	ırn type C					

0: 5<sup>th</sup>, 4<sup>th</sup>, Y, Z, X zero return type B

0	0	7	]	DISP	SMZ	***	ZC5	ZC4	ZCY	ZCZ	ZCX
Bit7	1:	Enter	ABSO	LUTE PO	S page a	after powe	er on				

- 0: Enter RELATIVE POS page after power on
- Bit6 1: Execute the next block after all motion block exactly are executed to the in-position 0: Smooth transition between two blocks
- Bit4~Bit0 1: In machine zero return, 5<sup>th</sup>, 4<sup>th</sup>, Y, Z, X deceleration signal (DEC5~DEC1) and one-revolution signal (PC5~PC1) are parallel(use one proximity switch as the deceleration signal and zero signal)
  - 0: In machine zero return, 5<sup>th</sup>, 4<sup>th</sup>, Y, Z, X deceleration (DEC5~DEC1) and one-revolution signal (PC5~PC1) is separately connected (need the separate deceleration signal and zero signal)

Note: In the zero-return B method; when it is set to 0 and connected independently, it is necessary to detect the PC signal after releasing the block during the zero-return; when it is set to 1 and connected in parallel, the PC signal detects with block after the pressing block decelerates to zero during the zero-return method.

0 0 8	***	***	***	DIR5	DIR4	DIRY	DIRZ	DIRX
Bit4~Bit0 1:	The motor's rota	ation dire	tion of the	e 5 <sup>m</sup> , 4 <sup>m</sup> , Y	/, Z and X	K axes ar	e positiv	e;

0: The motor's rotation diretion of the 5<sup>th</sup>, 4<sup>th</sup>, Y, Z and X axes are negative;

Note: The movement direction of the machine tool is inconsistent with the actual direction, which can be modified by adjusting this parameter.

0	0	9		***	***	***	5ALM	4ALM	YALM	ZALM	XALM
Bit4~Bit0 1: Servo not ready alarm without detection of the 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X axis.											

0: Servo not ready alarm detection of the 5<sup>th</sup>, 4<sup>th</sup>, Y, Z or X axis.

0	1	0		***	***	***	CPF5	CPF4	CPF3	CPF2	CPF1
	Di+4.	Dul	oo froa		tting volu	an of hon	klach offe	at (by DC			

Bit0~ Bit4: Pulse frequency setting values of backlash offset (by BCD code)

CPF5	CPF4	CPF3	CPF2	CPF1	Set frequency (Kpps)
0	0	0	0	0	1
0	0	0	0	1	2
0	0	0	1	0	3
0	0	0	1	1	4
0	0	1	0	0	5

The set frequency =(setting value+1) Kpps

0	0	1	0	1	6
0	0	1	1	0	7
0	0	1	1	1	8
0	1	0	0	0	9
0	1	0	0	1	10
0	1	0	1	0	11
0	1	0	1	1	12
0	1	1	0	0	13
0	1	1	0	1	14
0	1	1	1	0	15
0	1	1	1	1	16
1	0	0	0	0	17
1	0	0	0	1	18
1	0	0	1	0	19
1	0	0	1	1	20
1	0	1	0	0	21
1	0	1	0	1	22
1	0	1	1	0	23
1	0	1	1	1	24
1	1	0	0	0	25
1	1	0	0	1	26
1	1	0	1	0	27
1	1	0	1	1	28
1	1	1	0	0	29
1	1	1	0	1	30
1	1	1	1	0	31
1	1	1	1	1	32

5	)
Ο	
ወ	
Q	
-	è
0	

0 1 1 BDEC BD8 \*\*\* \*\*\* NORF ZNIK REFC2 \*\*\*

Bit7 1: Backlash offset type B, the offset data are output by ascending or descending type and the set frequency is inactive;

- 0: Backlash offset type A, the offset data are output by the set frequency (by bit parameter No.010) or 1/8 of it.
- Bit6 1: Backlash offset is done by the 1/8 of the set frequency
  - 0: Backlash offset is done by the set frequency
- Bit3 1: Manual machine zero return inactive
  - 0: Manual machine zero return active
- Bit2 1: Direction key locked during zero return, homing continues to end by pressing direction key once;
  - 0: Direction key unlocked, which is held on during zero return
- Bit1 1: Ref.C mode, the feeding slowdown when pressing down switch, reverse after decelerating to zero.
  - 0: Ref.C mode, the feeding slowdown when releasing the switch, reverse after decelerating to zero.

		_		-						· · · · · · · · · · · ·		
0	1 2		APF	RS	WSFT	DOF	SI ***	EAL	***	HDINT	ISOT	
Bit7	1: Au	itomatic	ABSOLI	JTE set a	after refe	rence re	turn,;					
	0: A	BSOLU	TE not au	utomatica	ally set a	fter refer	ence ret	urn				
Bit6	1: W	orkpiece	e coordin	ate offse	t active,	defined l	by offset	No.000				
	0: V	orkpiec	e coordir	hate offse	et inactiv	е						
Bit5	1: Tr	al tool s	etting ac	tive								
	0: Trial tool setting inactive											
Bit3	t3 1: Program editing allowed during CNC alarming											
	0: P	rogram	editing u	nallowed	during C	CNC alar	ming					
Bit1	1:Han	dle inter	rupt is va	alid (powe	er on)							
	0:Har	dle intei	rrupt is in	ivalid (po	ower on)							
Bit0	1: Pi	ior to ma	achine ze	ero returi	n after po	ower on,	manual	rapid trav	verse ac	tive		
	0: P	rior to m	achine z	ero retur	n after p	ower on,	manual	rapid tra	verse in	active		
		-										
0	1 3		RTH	RPH	***	HW5	HW4	HWY	HWZ	HWX		
Bit7	1: Wh	en syste	m reset,	the hand	dle interro	upt move	e amount	is cance	elled			
	0: Wh	en syste	m reset,	the hand	dle interr	upt move	e amount	is not ca	ancelled			
Bit6	1: Whe	en MPG	feedrate	exceeds	s the rapi	d moven	nent spe	ed,the ex	ceeding	g part is no	ot ignored	
	ar	d saved	in CNC									
	0: Wh	en MPG	6 feedrat	e exceed	ds the ra	ipid mov	ement s	peed,the	exceed	ling part i	s ignored	
	an	d saved	in CNC		U: When MPG feedrate exceeds the rapid movement speed, the exceeding part is ignored							
	and saved in CNC Bit 1. Discretion in $E^{th}$ $4^{th}$ V. 7 or V. MDC (CC)(4) rotation											
Bit4-	~Bit0 1:	Coordina	ates incre	ease in 5	<sup>th</sup> , 4 <sup>th</sup> , Y,	Z or X N	IPG (CC	W) rotat	ion			
Bit4-	-Bit0 1: 0	Coordina : Coordi	ates incre nates inc	ease in 5 crease in	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , `	Z or X N Y, Z or X	IPG (CC MPG (C	W) rotat W) rotat	ion ion			
Bit4-	-Bit0 1: 0	Coordina : Coordi	ates incre nates inc	ease in 5 crease in	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , `	Z or X N Y, Z or X	IPG (CC MPG (C	W) rotat W) rotat	ion ion			
Bit4-	-Bit0 1: 0 1 4	Coordina : Coordi	ates incre nates incre	ease in 5 crease in	<sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , `	Z or X N Y, Z or X <b>ZRS5</b>	IPG (CC MPG (C ZRS4	W) rotat W) rotati ZRSY	ion ion <b>ZRSZ</b>	ZRSX		
Bit4-	-Bit0 1: 0 1 4 Bit3, Bit2	Coordina : Coordi ] 2, Bit1, E	ates incre nates incre nates inc sit0	ease in 5 crease in	<sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , `	Z or X N Y, Z or X <b>ZRS5</b>	IPG (CC MPG (C <b>ZRS4</b>	W) rotat W) rotati ZRSY	ion ion ZRSZ	ZRSX		
Bit4- <b>0</b> Bit 4, E 1: 5tl	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y	Coordina : Coordi ] , Bit1, E , Z, X h	ates incre nates incre sito ave the p	ease in 5 crease in *** machine	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , ` *** zeroes.	Z or X N Y, Z or X <b>ZRS5</b> The sys	IPG (CC MPG (C <b>ZRS4</b> tem nee	W) rotat W) rotati ZRSY ds to ch	ion ion <b>ZRSZ</b> eck the	ZRSX	on signal	
Bit4- Dit4, E 1: 5tl and ze	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa	Coordina : Coordi , Bit1, E ; Z, X h I in exee	ates incre nates incre ates incre	ease in 5 crease in *** machine e machine	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , ` *** zeroes.	Z or X N Y, Z or X ZRS5 The sys eturn	IPG (CC MPG (C <b>ZRS4</b> tem nee	W) rotat W) rotati ZRSY ds to ch	ion on <b>ZRSZ</b> eck the	<b>ZRSX</b> decelerati	on signal	
Bit 4- Bit 4, F 1: 5tl and ze 0: 5th	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y	Coordina : Coordi 2, Bit1, E 7, Z, X h Il in exec Z, X I	ates increased in a tes increased in a tes increased in a test in	ease in 5 crease in *** machine e machine machine	<sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , ` *** zeroes. e zero re zeroes.	Z or X M Y, Z or X <b>ZRS5</b> The sys eturn The sys	IPG (CC MPG (C <b>ZRS4</b> tem nee tem doe	W) rotat W) rotati ZRSY ds to cho s not ch	ion on ZRSZ eck the eck the	<b>ZRSX</b> decelerati decelerati	on signal on signal	
Bit 4- Bit 4, E 1: 5tl and ze 0: 5th and ze	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y	Coordina : Coordi , Bit1, E ; Z, X h I in exec Z, X I I till it ret	ates increased in a tes increased in a tes increased in a test in	ease in 5 crease in *** machine e machine machine he zero o	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , ` zeroes. e zero re zeroes. of machin	Z or X M Y, Z or X ZRS5 The sys eturn The sys ne coord	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to cho s not cho executing	ion <b>ZRSZ</b> eck the eck the g the ma	ZRSX decelerati decelerati	on signal on signal o return	
Bit 4, F Bit 4, F 1: 5tl and ze 0: 5th and ze	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y tro signa	Coordina : Coordi , Bit1, E , Z, X h I in exec Z, X I I till it ref	ates incre nates incre nates incre sit0 ave the n cuting the have no turns to t	ease in 5 crease in *** machine e machine machine he zero o	2 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , Y 2eroes. 2eroes. 5 zeroes. 5 machin	Z or X N Y, Z or X <b>ZRS5</b> The sys eturn The sys ne coord	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to ch s not ch executing	ion on ZRSZ eck the eck the g the ma	ZRSX decelerati decelerati achine zero	on signal on signal o return	
Bit 4, E Bit 4, E 1: 5tl and ze 0: 5th and ze	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y ro signa	Coordina : Coordi , Bit1, E ; Z, X h I in exec Z, X l I till it ref	ates incre nates incre nates incre sit0 ave the no cuting the have no turns to t	ease in 5 crease in *** machine e machine machine he zero o <b>D</b> (**	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , ` zeroes. ae zero re zeroes. of machin	Z or X M Y, Z or X ZRS5 The sys eturn The sys ne coord	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to cho s not ch executing	ion ZRSZ eck the eck the g the ma	ZRSX decelerati decelerati chine zero TSL	on signal on signal o return <b>TS1</b>	
Bit 4, F Bit 4, F 1: 5th and ze 0: 5th and ze Bit7	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y ero signa 1 7 1:Coo	Coordina : Coordi 2, Bit1, E 7, Z, X h I in exec Z, X I I till it ref	ates increases i	ease in 5 crease in *** machine e machine he zero o D (*** stored b	2eroes. 2eroes. 2eroes. 2eroes. 2eroes. 5f machin * RS 2efore po	Z or X M Y, Z or X ZRS5 The sys eturn The sys ne coord SCD	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to cho s not cho executing	ion ZRSZ eck the eck the g the ma	ZRSX decelerati decelerati achine zero TSL	on signal on signal o return <b>TS1</b>	
Bit 4, E Bit 4, E 1: 5tl and ze 0: 5th and ze Bit7	-Bit0 1: 0 <b>1 4</b> Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y ro signa <b>1 7</b> 1:Coo 0: Co	Coordina : Coordi :, Bit1, E ; Z, X h I in exec Z, X l I till it ref	ates incre nates incre nates incre ates incr	ease in 5 crease in *** machine e machine he zero o D *** stored b is not st	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , Y zeroes. a zeroes. of machin * RS pefore po cored bef	Z or X M Y, Z or X ZRS5 The sys eturn The sys ne coord SCD	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to cho s not cho executing TSD	ion ZRSZ eck the eck the g the ma QNI system	ZRSX decelerati decelerati chine zero TSL is set by	on signal on signal o return <b>TS1</b> G54 after	
Bit 4, F Bit 4, F 1: 5th and ze 0: 5th and ze Bit7	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y ero signa 1 7 1:Coo 0: Co 0: Co	Coordina Coordi B, Bit1, E C, Z, X h I in exec Z, X l I till it ref dinate s oordinate	ates incre nates incre nates incre sit0 ave the re cuting the have no turns to t <b>SCRI</b> system is e system ;	ease in 5 crease in *** machine e machine he zero o D *** stored b is not st	2eroes. 2eroes.	Z or X M Y, Z or X ZRS5 The sys eturn The sys ne coord SCD wer-off; ore powe	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to cho s not ch executing TSD	ion ZRSZ eck the eck the g the ma QNI system	ZRSX decelerati decelerati ichine zero TSL is set by	on signal on signal o return <b>TS1</b> G54 after	
Bit4- Bit 4, F 1: 5th and ze 0: 5th and ze 0: 5th and ze Bit7	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y ro signa 1:Coo 0: Co p 1: Coo	Coordina Coordi Coordi C, Bit1, E C, Z, X h I in exec Z, X h I till it ref Z, X h I till it ref dinate s ordinate cover-on rdinate	ates incre nates incre nates incre nates incre sito ave the no cuting the have no turns to t SCRI system is e system is e system is	ease in 5 crease in *** machine e machine he zero o D *** stored b is not st	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , Y 5 <sup>th</sup> , 4 <sup>th</sup> , Y zeroes. be zeroes. of machin * <b>RS</b> before po cored bef G54 after	Z or X M Y, Z or X ZRS5 The sys eturn The sys ne coord SCD wer-off; ore powe	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to cho s not cho executing TSD	ion ZRSZ eck the eck the g the ma QNI system	ZRSX decelerati decelerati chine zero TSL is set by	on signal on signal o return <b>TS1</b> G54 after	
Bit 4, F Bit 4, F 1: 5th and ze 0: 5th and ze Bit7 Bit5	-Bit0 1: 0 1 4 Bit3, Bit2 h, 4th, Y ero signa n, 4th, Y ero signa 1:Coo 0: Co 0: Coo 0: Coo	Coordina Coordina Coordi C, Bit1, E C, Z, X h I in exec Z, X h I till it ref dinate s ordinate ordinate ordinate	ates incre nates incre nates incre ave the no cuting the have no turns to t System is e system is system is	ease in 5 crease in *** machine e machine he zero o 5 stored b is not st s set by 0 s not cha	5 <sup>th</sup> , 4 <sup>th</sup> , Y, 5 <sup>th</sup> , 4 <sup>th</sup> , Y zeroes. e zeroes. of machin * RS pefore po cored bef G54 after anged after	Z or X M Y, Z or X ZRS5 The sys eturn The sys ne coord SCD wer-off; ore powe r reset; er reset;	IPG (CC MPG (C ZRS4 tem nee tem doe inate in e	W) rotat W) rotati ZRSY ds to cho s not ch executing TSD	ion ZRSZ eck the eck the g the ma QNI system	ZRSX decelerati decelerati chine zero TSL is set by	on signal on signal o return <b>TS1</b> G54 after	

- 0: Movement direction discrimination is invalid during offset measurement 4 point input;
- Bit2 1: Tool offset number is set through G signal;
  - 0: Tool offset number is set through the current cursor;
- Bit1 1 Tool offset measurement detection signal is valid at low level;
  - 0: Tool offset measurement detection signal is valid at high level;
- Bit0 1:Tool offset automatic measurement detection signal 1 point input;0: Tool offset automatic measurement detection signal 4-point input;



- 1: External cycle start signal (ST) inactive)
  - 0: External cycle start signal (ST) active
- Bit5 1: External SP signal inactive 0: External SP signal active with external dwell switch needed, otherwise CNC shows "Pause".
- Bit4 1: Not detect software stroke limit 0: Detect software stroke limit
- Bit3 1: Emergency stop inactive
  - 0: Emergency stop active
- Bit1 1: Software limit is inactive after power-on and before machine zero return;
  - 0: Software limit is active after power-on and before machine zero return;
- Bit0 1: When Arriving stored travel position, CNC is stopped slowly
  - 0: When Arriving stored travel position, CNC is stopped immediately

1	7	4	PARTSET	***	TRPMO	TRP	KEY1	THDTLM	THDA	CKSPD
					D			OD		

- 1:Continue to run part program while current machining workpiece counts reach to max. Bit7 counts.and machining workpiece counts accumulate
  - 0:Continue to run part program while current machining workpiece counts reach to max. counts.and machining workpiece counts restart
- Bit5 1:Screw repair mode use follow the spindle with encoder 0:Screw repair mode use interpolation with servo spindle
- Bit4 1:Thread repair function is valid 0:Thread repair function is invalid
- Bit3 1: Program switch ON at power on 0: Program switch OFF at power on
- Bit2 1:Thread tailing mode tailling according angle; 0:Thread tailing mode rapid tailing.
- Bit1 1:Thread cut is exp. acc&dec 0:Thread cut is lin. acc&dec
- Bit0 1:Whether detect the spindle speed is too slow in thread cutting don't detect 0:Whether detect the spindle speed is too slow in thread cutting do detect

1	7 5	SPFD	SAR	THDA	VAL5	VAL4	VALY	VALZ	VALX	
Bit7	1: In cutting fe	ed, do not	permit t	he spind	le stoppi	ng rotatio	on; the s	spindle s	tops, the	feed also

- stops when the system appears No.404 alarm cutting
  - 0: In cutting feed, permit the spindle stops rotation; the spindle stops rotation, but the feed does not stop
- Bit6 1: Detect spindle SAR signal prior to cutting
  - 0: Not detect spindle SAR signal prior to cutting
- Bit5 1: Thread machining is the exponential acceleration/deceleration
  - 0: Thread machining is the linear acceleration/deceleration
- is positive, 1: 5<sup>th</sup> movement key Bit4 is negative
  - 0: 5<sup>th</sup> movement key is positive, is negative

Bit3	1: 4 <sup>th</sup> movement key is positive, is negative
	0: 4 <sup>th</sup> movement key 🗾 is positive, 🔯 is negative
Bit2	1: Y movement key is positive, is negative
	0: Y movement key is positive, is negative
Bit1	1: Z movement key is positive, is negative
	0: Z movement key is positive, is negative
Bit0	1: X movement key is positive, is negative
	0: X movement key is positive, is negative
1	8 0 NAT *** *** DISPC CUSTOM MLKEY SPOS
Bit7	1: Function ATAN, ASIN range is 90.0 $\sim$ 270.0;
	0: Function ATAN, ASIN range is -90.0 $\sim$ 90.0
Bita	3 1:Boot dispaly if custom page setted to display custom page
	0:Boot dispaly if custom page setted to display fault page
Bit2	2 1:Display custom page display
	0:Display custom page hide
Bit1	1:Multi-letter key input mode shift mode only\
	0:Multi-letter key input mode repeat keystroke or shift mode
Bit(	1: DIS TO GO displayed in POS&PRG page
	0: RELATIVE POS displayed in POS&PRG page
1	8 1 RLC MRC ZCL CLMDI MCL M30&MDI DDP LCNMD
Bit	7 1: G52 local coordinate system is cancelled after reset:
	0: G52 local coordinate system is not cancelled after reset:
Bite	5 1: G52 local coordinate system is cancelled after the execution of M30 M02.
Ditt	0: G52 local coordinate system is not cancelled after the execution of M30_M02.
Bit <sup>g</sup>	5 1: G52 local coordinate system is cancelled after reference point return:
Ditt	0: G52 local coordinate system is not cancelled after reference point return:
Rit <sub>2</sub>	1 1:When system reset the program block of MDI are deleted
DR	0:When system reset the program block of MDI are not deleted
Bit?	3 1: Blocks edited in MDI mode are deleted after reset:
Dire	0: Block edited in MDI mode are not deleted after reset:
Bit2	2 1:After the execution of M02, M30 the program block of MDI are not deleted
	0:After the execution of M02, M30 the program block of MDI are deleted
Bit1	<ul> <li>1:The angle in CHF/CNR measurement-programe-inputing function was specified by Supplementary one</li> </ul>
	0:The angle in CHF/CNR measurement-programe-inputing function was specified by Nornal
D:14	IVIIIal
BII	$J_{1}$ in linear chamiering, $\Box$ means the length between chamtering point and cross point;
	v. in inear chamiening, Lineans the length of chamiening,

## **C**makers

Y

1	8 3	***	***	***	MZR5	MZR4	MZRY	MZRZ	MARX
Bit4	1: for 5 <sup>th,</sup> press	e key	/ to exec	ute the n	nachine	zero retu	m		
	0:for 5 <sup>th</sup> , press_	ອ key	to execu	te the m	achine z	ero retur	n		
Bit3	1: for 4 <sup>th</sup> , press	to	execute 1	the mach	nine zero	return			
	0: for 4 <sup>th</sup> , press	to	execute	the mac	hine zero	o return			
Bit2	1: for Y, press	to ex	xecute th	e machi	ne zero i	eturn			
	0: for Y, press	🖄 to e	execute th	ne mach	ine zero	return			
Bit1	1:for Z, press	to ex	ecute the	e machir	ne zero r	eturn			
	0: for Z, press	ば to e	execute t	he mach	ine zero	return			
Bit0	1: for X, press	to e	xecute th	ne machi	ine zero	return			
	0: for X, press	₽ to e	execute t	he mach	ine zero	return			

1 8 4	***	***	***	***	***	L2	L1	L0
Bit0 Bit1 Bit2		laction.						

Bit0, Bit1, Bit2: Language selection:

Language	Bit2	Bit1	Bit0
Chinese	0	0	0
English	0	0	1
Portuguese	0	1	0
Spanish	0	1	1
Russian	1	1	0

1	8	5	SK0	SKF	AEO	***	***	***	PRPD	PLA
Bit7	1:	Skip inp	out active as	G31 sigr	al is 0					
	0:	Skip inp	out active as	G31 sigr	nal is 1					
Bit6	1:	Feedrat	te override pe	er minute	or dry ru	un active	e for G31			
	0:	Feedra	te override pe	er minute	e or dry r	un inacti	ve for G3	31		
Bit5	1:	Input a	ctive if G36, 0	G37 (XA	E, ZAE) s	signal is	0			
	0:	Input a	ctive if G36,	G37 (XA	E, ZAE)	signal is	1			
Bit1	1:	Axis rap	oid traverse ra	ate of PL	C by inp	ut value				
	0:	Axis ra	pid traverse	rate of F	LC by p	aramete	r value (	X axis: N	lo.022;	Z axis:No
		axis:No	o.134)							
Bit0	1:	PLC axi	is control acti	ve, activ	e after re	powerin	g			
	0:	PLC ax	is control inad	ctive, act	ive after	repower	ing			
1	8	6	RTORI	SRS	***	***	***	RTCRG	***	***
Bit7	1: lr	n executi	ng M29, the	spindle e	xecutes	the mac	hine zero	o return	1	<u> </u>

0: In executing M29, the spindle does not execute the machine zero return

- Bit6 1: The spindle selection signal is RGTSPn in the multiple spindle rigid tapping
  - 0: The spindle selection signal is SWSn in the multiple spindle rigid tapping

Bit2 1: In rigid tapping cancel, do not wait for G61.0 to be 0 in executing the next block 0: In rigid tapping cancel, wait for G61.0 to be 0 in executing the next block



Connection

## **CNCmakers**

1	9 5	SSPD	PLC	S **	**	* RPO	S	SRV		CSREF	RCS
Bit7	1:series s	pindle controlla	able fun	ction e	nabled	(series s	spindle	e The s	slave I	D numbe	er of the
	spindle '	1~3 is 11~13) ,	it is nec	essary	to rest	art;					
	0: Series	spindle control	llable fur	nction d	lisablec	l (analogy	spino	dle), it i	s nece	ssary to r	estart.
Bit6	1:PLC spir	ndle rotation sp	beed fun	ction o	f each a	axis enab	led;				
	0:PLC spindle rotation speed function of each axis disabled.										
Bit3	1:Spindle	position function	on is val	id (Wh	en it is	enabled,	the s	pindle	will per	form me	chanical
	releasing	g/clamping inte	erlocking	operat	ion bef	ore/after	oositic	oning);			
	0:Spindle	position function	on is inv	alid.							
Bit2	1:Servo m	otor spindle fu	nction is	valid ,	power	on;					
	0:Servo m	notor spindle fu	unction is	s invalio	d ,powe	er on 。					
Bit1	1: Change	to position mo	ode,the a	axis do	return	REF.					
	0: Change	e to position m	ode, the	axis do	besn't r	eturn REI	F.				
Bit0	1: Cs func	tion of spindle	valid ,po	ower or	1						
	0: Cs fund	ction of spindle	is: inval	id, pow	er on						
1	96	***	***	***	MSEN	N ***	**	* :	***	***	
Bit4	1: The mu	Itiple spindle c	ontrol is	enable	d						
	0: The mu	ultiple spindle c	control is	disable	ed						-
2	0 1	SNTP	*** *	**	ECN	HBR	ER\	/ *	**	***	
Bit7	1:Synchro	nization mode	follow								
<b>D</b> '4	0:Synchro	nization mode	interpol	ation							
BI4	1:wnether	the G81 syr	nchroniza	ation c	ommar	nd can b	e spe	ecified	in the	synchro	nization
	process	allow	nobroniz	otion (		nd oon h		opified	in the	overebre	nization
	D.WIIEIIIE	nrohibition		alion	Jonna	nu can i	ie shi	ecineu		Synchic	mzation
Bit3	1. The syst	tem resets in th	ne synch	ronizat	ion pro	cess rese	erve th	ne svno	hronize	ed contro	J
Bito	0. The system resets in the synchronization process cancel the synchronization control										
Bit2	Bit2 1:In the synchronization procedure in the G99 feed per revolution use the theoretical										
	revolving speed of workpiece										
	0:In the synchronization procedure, in the G99 feed per revolution use the encoder feedback										
revolving speed											
2	0 2	CTHDN	AAC	***	***	ΔΟΤ		***	***	EXTRA	
	• -	OENC	/							IO	
Bit7	1:Circular	screw interpola	ation add	opts C	axis int	erpolatior	n mod	e.			
	0:Circular screw interpolation adopts follow spindle mode										
Bit6	Bit6 1:Slope axis control enabled										
	0:Slope axis control disabled										
DHO	4.Th			al		1- 1- 0/4		:4-		al la si	
Bit3	1:The soft	-limit paramete	er of the	slope	axis se	ts to 0/1	when	its axi	s contr	ol is ena	bled the
Bit3	1:The soft coordina	-limit paramete	er of the r the rec	slope tangula	axis se Ir coord	ets to 0/1 linate sys	when tem\	its axi	s contr	ol is ena	bled the

Bit0 1:Extended I/O unit linked is valid 0:Extended I/O unit linked is invalid\

2 5 0	***	*** ***	***	***	***	VERI	GSKLINK
Bit1 1:Syster	m GSKLINK k	ous communic	cation CRC	verificati	on enabl	ed	
0:Syste	m GSKLINK I	ous communio	cation CRC	verificati	on disab	led	
Bit0 1: Whet	her the syste		ous connect	on is en	abled		
U: Whet	ner the syste	m GSKLINK D	ous connect	ion is als	abled		
3.1.2 Data	Paramete	er					
0 1 5			CMRn				
[Data type]	Word axis						
[Data meaning	] Pulse frequ	ency multiplic	cation coeffi	cient			
	1~9999999	99					
			CMDn			Т	
[Data type]	Word axis						
[Data meaning	Pulse frequ	iency division	coefficient.				
[Data mouning		anney anneien aa	ooomoroni,				
	1 000000	55	CMP	1*C	*8 7		
Explanation	: Formula of	electric gear r	atio: $\frac{CMR}{CMD}$	$r = \frac{4 C}{L}$	$\frac{z_{M}}{Z_{T}}$	<u>1</u>	
	δ· Least co	mmand increr	nent <sup>.</sup>		L	, ,	
	Zw: Teeth n	umber of nulle	ev on leadin	a screw	side <sup>.</sup>		
	C: Motor e	ncoder line ni	umber:	g screw	3100,		
	Z <sub>D</sub> Teeth nu	mber of pulle	y on motor :	side;			
	L: Screw lea	ad		,			
0 1 9			THDCH				
[Data meaning	] Run-ou	it length in thr	eading				
[Data range]	0~225	<b>j</b>					
	Thread	run-out width	= THDCH×	0.1×scre	ew lead		
	Word opind						
			n onindle m		donolog	waltaga	$a_{\rm sutput} = 10 V$
	111V	0000/11/2:10					
LData range	-2000~	~2000(Unit: m	1V)				
0 2 2			RPDFn				
	Word axis					J	
[Data type]		anid traverse	rate of all a	VAC			
		apia liaveise		703			
	<b>S</b> <sub>0</sub> ##	na unit	Data un	it			
	Mot	ic machine	mm/mir				
	Inch	machine		/min			
[Data range]		200	0.11101/				
	10 - 22222	555					



0 2 3		L	.INTn	1	
[Data type]	Word axis				
[Data meaning]	Acceleration/dec	eleration t	time o	constant of e	ach axis during rapid traverse
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	ms				5 1
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	0~4000				
2g- J					
0 2 6		T	HRD	Г	
[Data meaning]	ACC&DEC time c	onstant of	shor	t axis in threa	ad run-out
[Data unit]	ms				
[Data range]	0~4000				
-					
0 2 7		F	EDM	X	
Data meaning]	Upper limits of axis	s cutting fe	eed		
[Data unit]					
	Setting unit		Data	a unit	
	Metric mac	hine	mm	/min	
	Inch machi	ne	0.1i	nch/min	
[Data range]					
		IS-B		IS-C	
	Metric machine	10~300	000	10~30000	)
	Inch machine	5~116	00	10~11600	
				I	
0 2 8		Т	HDFL	-	
[Data meaning]	X, Z initial spe	ed in thre	ading	g (mm/min)	
[Data unit]					
	Setting unit	C	)ata ι	ınit	
	Metric machine	n	nm/m	in	
	Inch machine	0	.1inc	h/min	
[Data range]					
		IS-B		IS-C	
	Metric	6~800	00	6~8000	
	machine	0 00		0 0000	
	menmachine	3~300	00	3~3000	
0 2 9		F	FFD	r	
[Data meaning]	Exponential A		time	constant of (	sutting and manual feed
[Data meaning]	me	OOUDLO	unic		
	0~4000				
	0 4000				
0 3 0		F	EDFI	_	
[Data meaning]	Exponential a	cceleratio	n sta	art speed an	d deceleration and speed in cutting
feed			010		a according on a opera in outling

III Connection

Setting unit	Data unit
Metric machine	mm/min
Inch machine	0.1inch/min

[Data range]

	IS-B	IS-C
Metric machine	0~8000	0~8000
Inch machine	0~3000	0~3000

0	3	1	
[Da	ta me	anin	g]
[Da	ta uni	t]	

J	0	GS	P	ΞE	D

the set speed when the manual feedrate override is 100%

S	Setting unit	Data unit
ſ	Metric machine	mm/min
I	nch machine	0.1inch/min
10	~30000	•

[Data range]

0 3 2			
	0	3	2

#### RPDFLn

[Data type] Word axis

[Data meaning] Rapid traverse rate as axis rapid override is F0

[Data unit]

Setting unit	Data unit
Metric machine	mm/min
Inch machine	0.1inch/min

[Data range]

	IS-B	IS-C
Metric machine	0~4000	0~4000
Inch machine	0~1500	0~1500

#### 0 3 3

#### ZRNFLn

[Data type]

Word axis

[Data meaning] Low rate as axes return to machine zero

[Data unit]

Setting unit	Data unit
Metric machine	mm/min
Inch machine	0.1inch/min

[Data range]

	IS-B	IS-C
Metric machine	6~4000	6~4000
Inch machine	3~1500	3~1500

0 3 4

BKLn

[Data type]

### make

[Data meaning] backlash compensation of each axis

[Data unit]

Setting unit	IS-B	IS-C
Metric machine	0.001 mm	0.0001 mm
Inch machine	0.0001 inch	0.00001 inch

[Data range]

Setting unit	IS-B	IS-C
Metric machine	0~2000	0~20000
Inch machine	0~2000	0~20000

Note : X is the diameter value.

0	3	6		SPDLC
[Da	[Data type] Word		Word sp	bindle

[Data meaning] Voltage offset for 0V analog voltage output of spindle min. speed code

[Data unit] [Data range]

 $-1000 \sim 1000$ 

mV

0	3	7
0	3	8
0	3	9
0	4	0

000	1000		
		GRMAX1	
		GRMAX2	
		GRMAX3	
		GRMAX4	

JOGFL

[Data meaning]

GRMAX1, GRMAX2, GRMAX3, GRMAX4: Max. speeds of gear 1, 2, 3, 4 respectively when spindle analog voltage output is 10V (the function defined by GSK980TDi PLC is: if the spindle automatic gearing is active, it uses the speeds of M41, M42, M43, M44; if the automatic gearing is inactive or CNC is powered on, the gear is memorized by parameter or the gear 1 is defaulted.) r/min

Exponential ac-deceleration start speed and deceleration final speed in

10~9999

manual feed

0~8000

1~100

Setting unit

Inch machine

Metric machine

0	4	· ·	1	
[ Da	ita m	nean	ina 7	

[Data unit]

[Data unit]

[Data range]

-	-	
L Data	range	

2

[Data meaning] [Data range]

4

0	4	3	
[ Da	ta me	aning	٦

LOWSP

SEQINC

Block No. increment for auto block No. insertion

(G96) Spindle min. speed under the constant surface speed control

Data unit

mm/min

0.1inch/min

0

[Data unit] [Data range]

r/min 0~9999

~		
	 4	 4
v	 _	_
-	 -	 -

**BRATE0** 

Data meaning] [Data unit]

Serial communication baud rate,

bit/s

[Data range]

1200,2400,4800,9600,19200,38400 57600 115200

0	4	5	
0	4	6	

[Data type]

LT1X1
LT1Z1

Word axis

[Data meaning] LT1X1 (X), LT1Z1 (Z) positive max. travel, LT1X2 (X), LT1Z2 (Z) negative max. travel

[Data unit]

Setting unit	IS-B	IS-C		
Metric machine	0.001 mm	0.0001 mm		
Inch machine 0.0001 inch 0.00001 inch				

[Data range]

Λ . 7

Δ

-99999999*~*99999999

Note: If the BIT2 of the parameter No.001 is set for diameter, the X axis value is specified by diameter; if for radius, the X axis value is specified by radius.

PRSn

IS-B

IS-C

0.0001 mm

0.00001 inch

Setting unit	IS-B	IS-C
Metric input	0.001 mm	0.0001 mm
Inch input	0.0001 inch	0.00001 inch

MRCCD

[Data range]

	IS-B	IS-C
Metric input	1~99999	1~999999
Inch input	1~99999	1~999999

0	5	2

MRCD	Т

III Connection	
II Connection	
Connection	
Connection	
Connection	
Connection	
Connection	
Connection	
Connection	
onnection	
onnection	
nnection	0
nnection	
nection	
nection	
ection	
ection	
ection	
ction	-
tion	•
tion	~
ion	-
on	_
'n	
n	~

[Data meaning] Each retraction for G71, G72 rough turning cycle, which may also be changed by program code in auto running. [Data unit] Setting unit IS-B IS-C Metric input 0.001 mm 0.0001 mm Inch input 0.0001 inch 0.00001 inch [Data range] 0~99999 PECSCX 0 5 3 [Data meaning] X retraction amount in G73, which may be also changed by program code in auto running. [Data unit] Setting unit IS-B IS-C Metric input 0.001 mm 0.0001 mm Inch input 0.0001 inch 0.00001 inch [Data range] -9999999~9999999 PECSCZ 0 5 4 [Data meaning] Z axis rough turning retraction in G73, which may also be changed by program code in auto running [Data unit] Setting unit IS-B IS-C Metric input 0.001 mm 0.0001 mm 0.0001 inch 0.00001 inch Inch input

-9999999~99999<mark>99</mark>

running

1~9999

times

[Data range]

0	5		5	
[Da	ta m	ea	aning	]

[Data unit] [Data range]

0	5	6	
<b>F</b> -			_

[Data meaning]

GROVE

PATIM

Retraction value of Z axis in G74; retraction value of X axis in G75; a specified value in program during automatic running can also change the setting of this parameter;

Cycle times of G73, which may also be changed by program code in auto

[Data unit]

	Setting unit	IS-B	IS-C
	Metric input	0.001 mm	0.0001 mm
	Inch input	0.0001 inch	0.00001 inch
0	~99999		

THRPT

		-	
0	5	7	
U	5	1	
	+		٦
LDa	ia me	eaning	J

[Data range]

Repetitions of G76 finish machining, which may also be changed by program

II Connection	II Connection	
I Connection	l Connection	
Connection	Connection	
Connection	Connection	
Connection	Connection	
Connection	Connection	
Connection	Connection	_
onnection	Connection	O
onnection	onnection	~
nnection	nnection	Ο
nnection	nnection	
nection	nection	_
nection	nection	
ection	ection	_
ection	ection	
ction	ction	P
tion	tion	
tion	tion	<b>.</b>
ion	ion	
on	on	
ň	ň	$\mathbf{O}$
n	D	0

	code in auto ru	unning	a			
[Data unit]	times		,			
[Data range]	1~99					
0 5 8			THANG			
[Data meaning]	Tool nose and	e of C	G76 cvcle, w	hich r	nav also be o	I changed by program code in
2	auto running		· · · <b>)</b> · · · )	-	- <b>,</b>	
[Data unit]	deg					
[Data range]	0∼99					
- 0-						
0 5 9			THCLM			
[Data meaning]	Min. cut depth	of G	76 cvcle, wh	nich m	av also be c	hanged by program code in
2	auto running		<b>)</b> ,		,	
[Data unit]	C C					
	Setting unit		IS-B		IS-C	
	Metric input		0.001 mm		0.0001 mm	1
	Inch input		0.0001 inc	h	0.00001 ind	ch
[Data range]			1			
		IS-E	3	IS-C	;	]
	Metric input	0~9	99999	0~9	999999	•
	Inch input	0~9	99999	0~9	999999	
						]
0 6 0			THDFN			
[Data meaning]	Finish allowan	ce of	G76, which	may a	also be chang	ged by program code in auto
	running					
[Data unit]						
	Setting unit		IS-B		IS-C	
	Metric input		0.001 mm		0.0001 mm	
	Inch input		0.0001 inch	1	0.00001 incl	n
[Data range]						
			IS-B		IS-C	
	Metric input	0	$\sim$ 99999	0	$\sim$ 999999	
	Inch input	0	$\sim$ 99999	0	~999999	
						1
0 6 1			THDCUT			
[Data type] W	Vord					
[Data meaning] The default cut-in selection in G78 cycle, when the program does not specify, the						
parameter value is used for the cut-in selection.						
0: Equidistant in-feed; 1: Degressive in-feed.						
[Data range] 0~1						
0 6 2			THDMOD			
[Data type] W	Vord					-

- 0: Cutting edge is cut in along with the neutral cable of the thread teeth;
- 1: Cutting edge is cut in along the left of the thread teeth;
- 2: Cutting edge is cut in along the right of the thread teeth;
- 3: Cutting edge is cut in alternatively with left and right of the thread teeth.

[Data range] 0~3

0 6 7	SFTREV
[Data type]	Word spindle
[Data meaning]	Output voltage of spindle gearing
[Data unit]	mV
[Data range]	0~10000
·	
0 6 8	SJOGREV
[Data type]	Word spindle
[Data meaning]	spindle speed in manual (MPG) mode
[Data unit]	r/min
[Data range]	0~3000
0 6 9	ENCODER CSE
Data type] Wo	and spindle
[Data meaning] Th	be corresponding spindle encoder number of each spindle
[]Data meaning] 11 0: v	without installing the encoder:
1:3	Spindle revolving signal comes from the encoder interface 1;
2: 3	Spindle revolving signal comes from the encoder interface 2;
3: 5	Spindle revolving signal comes from the GSKLINK bus
3: 5 [Data range] 0∼	Spindle revolving signal comes from the GSKLINK bus
3: 3 [Data range] 0~	Spindle revolving signal comes from the GSKLINK bus
3: 5 [Data range] 0~	Spindle revolving signal comes from the GSKLINK bus
3: 5 [Data range] 0~ 0 7 0 [Data type]	Spindle revolving signal comes from the GSKLINK bus -3 ENCODER_CNT Word spindle
3: 5 [Data range] 0~ 0 7 0 [Data type] [Data meaning]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses
3: 5 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution
3: 3 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit] [Data range]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000
3: 3 [Data range] 0~ Data type] [Data meaning] [Data unit] [Data range]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000
3: 3 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit] [Data range] 0 7 1	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 RESET_TIME
3: 3 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit] [Data range] 0 7 1 [Data meaning]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 RESET_TIME Output time of reset signal
3: 3 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit] [Data range] 0 7 1 [Data meaning] [Data unit]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 RESET_TIME Output time of reset signal ms
3: 3 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit] [Data range] 0 7 1 [Data unit] [Data unit] [Data unit] [Data range]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 RESET_TIME Output time of reset signal ms 16~4080
3: 3 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit] [Data range] 0 7 1 [Data meaning] [Data unit] [Data unit] [Data range]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 RESET_TIME Output time of reset signal ms 16~4080
3: 3 [Data range] 0~ 0 7 0 [Data type] [Data meaning] [Data unit] [Data range] 0 7 1 [Data meaning] [Data unit] [Data unit] [Data range]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 RESET_TIME Output time of reset signal ms 16~4080 SAR_DELEY
3: 3 [Data range] 0~ Data type] [Data type] [Data meaning] [Data unit] [Data meaning] [Data unit] [Data unit] [Data range]	Spindle revolving signal comes from the GSKLINK bus 3 ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 <u>RESET_TIME</u> Output time of reset signal ms 16~4080 <u>SAR_DELEY</u> Delay detecting time of SAR signal
3: 3 [Data range] 0~ Data type] [Data type] [Data meaning] [Data unit] [Data range]	Spindle revolving signal comes from the GSKLINK bus Spindle revolving signal comes from the GSKLINK bus ENCODER_CNT Word spindle Spindle encoder pulses line/revolution 100~10000 <u>RESET_TIME</u> Output time of reset signal ms 16~4080 <u>SAR_DELEY</u> Delay detecting time of SAR signal ms

[Data range] 0~4080

0 7 3	SPMOTORMAX
[Data type]	Word spindle
[Data meaning]	Max. spindle motor clamping speed, setting value=(max. spindle motor
	clamping speed/max. spindle motor speed) ×4095
	r/min
Setting value	Imax. clamp speed of spindle/max. speed of spindle motor > x4095.
0 7 4	SPMOTORMIN
[Data meaning]	Min. spindle motor clamping speed, setting value=(min. spindle motor
2	clamping speed/max. spindle motor speed) ×4095
[Data unit]	r/min
[Data range]	0~4095
Setting valu	e = (min. clamping speed of spindle motor/max. speed of spindle motor) ×4095
0 7 5	SPSPEEDLIMIT
[Data type]	Word spindle
[Data meaning]	Maximum spindle rev speed(0~6000r/min)[0:unlimited]
[Data unit]	r/min
[Data range]	0~6000
	Spindle motor speed     No.075
	Max. <u>speed(</u> 4095, 10V)
No.07	3
No.07	4
	No.037 No.038 No.039 No.040
0 7 6	SPDLIMITEXT
[Data type] Wo	rd spindle
[Data meaning] The	e spindle speed limit when speed limit signal is active [Without restriction when it
is set to 0]	
[Data unit] r/m	in
[Data range] 0 $\sim$	9999

#### 0 7 7

FEEDLIMITEXT

[Data meaning] The feedrate limit when speed limit signal is active [Without restriction when it is set to 0].

## **CNCmakers**

[Data unit]

Setting unit	Data unit
Machine in metric system	mm/min
Machine in inch system	0.1inch/min
0~15000	

[Data range]

	IS-B	IS-C
Machine in metric system	0~15000	0~15000
Machine in inch system	0~5800	0~5800

0	8		4	
[Da	ta m	ear	ning]	

#### TMAX

Total tools number selection

piece

 $1 \sim 32$ 

[Data unit]

[Data range]

0	8	6	
0	8	7	
0	8	8	
0	8	9	
0	9	0	
0	9	1	
0	9	2	
0	9	3	
0	9	4	
0	9	5	

6	MACALL_GVAL1
7	MACALL_GVAL2
8	MACALL_GVAL3
9	MACALL_GVAL4
0	MACALL_GVAL5
1	MACALL_GVAL6
2	MACALL_GVAL7
3	MACALL_GVAL8
4	MACALL_GVAL9
5	MACALL_GVAL10

[Data meaning] User macro program G code of calling program No. 9010 $\sim$ 9019 [Data range] 0 $\sim$ 9999

0 9 6 PECMINn
[Data type] Word axis
[Data meaning] Minimum pitch error compensation position number
[Data range] $0\sim$ 1199
0 9 7 PECMAXn
[Data type] Word axis
[Data meaning] Maximum pitch error compensation position number
[Data range] $0\sim$ 1199
0 9 8 PECORGn
[Data type] Word axis
[Data meaning] Pitch error compensation position numbers corre
points

[Data range] 0~1199

099		PECINTn		
[Data type]	Word axis			
[Data meaning	] Pitch error compen	sation intervals		
[Data unit]				
	Setting unit	IS-B	IS-C	
	Metric machine	0.001 mm	0.0001 mm	
	Inch machine	0.0001 inch	0.00001 inch	
[Data range]		·		
		IS-B	IS-C	
	Metric machine	1000~999999	10000~9999999	)
	Inch machine	400~999999	4000~9999999	
·				
1 0 0		LTMAX_2		
1 0 1		LTMIN_2		
[Data type]	Word axis			
[Data meaning	] Stored stroke limit	2 of each axis,	LTMAX_2 positive	maximum stroke position,
	LTMIN_2 negative	maximum stroke	position.	
[Data unit]				
	Setting unit	IS-B	IS-C	
	Metric machine	0.001 mm	0.0001 mm	
	Inch machine	0.0001 inch	0.00001 inch	
[Data range]	-999999999~99999	999		
	ı <b>г</b>	ITMAY 2		
1 0 2				
		LIWIN_3		
		O of each avia		
	Stored Stroke Infil	osition	LIMAX_3 positive	maximum stroke position,
	e maximum suoke p			
	Setting unit	IS-B	18-0	
	Metric machine	0.001 mm	0.0001 mm	_
	Inch machine	0.0001 inch	0.00001 inch	_
[Data ranœ]	-999999999~99999	999		
2				
1 0 6		THD_SPD_VA	AR	
∫Data meaning	Spindle fluctua	tion alarm limit in	threading (not dete	ect spindle fluctuation alarm
- 0	if set to 0)		3 (	,
[Data unit]	%			
[Data range]	0~100			
Formula= currer	nt speed — previous	period speed ×20	0/(current speed+	previous period speed)
	· ·		· ·	/
1 0 7			-	
		THD_TAIL_SP	D	

### makers

[Data unit]

	Setting unit	Data unit
	Metric machine	mm/min
	Inch machine	0.1inch/min
0	$\sim$ 8000	

[Data range]

		-	-	
		~	~	
	-		 	
			<u> </u>	
		•••		
-		-	-	
	-			

#### [Data meaning] [Data unit] [Data range]

|--|

[Data type] [Data meaning] [Data range]

#### 1 1 1

[Data type] [Data meaning] [Data range]

[Data unit]

1		1		3		
D	ata	a ty	pε	<b>;</b> ]		
D	ata	a m	iea	anin	g]	
-				-		

	_
Data	range

1	1	4

[Data type] [Data meaning] [Data unit]

SP	L_	RE	V_	SP	D

Spindle jog speed (r/min)

r/min 1~8000

Word spindle

Gear ratio of encoder to spindle: spindle gear teeth number 1~255

#### SGR

Word axis

Gear ratio of encoder to spindle: encoder gear teeth number 1~255

REF_SPDn	

#### Word axis

Axes rapid traverse rates in machine zero return

Setting unit	Data unit
Metric machine	mm/min
Inch machine	0.1inch/min

10~99999999

Word axis

Offset of each axis machine zero

Setting unit	IS-B	IS-C
Metric input	0.001 mm	0.0001 mm
Inch input	0.0001 inch	0.00001 inch

REF\_OFFSETn

[Data range]

	IS-B	IS-C
Metric input	-99999~99999	-9999999 $\sim$
		999999
Inch input	-99999~99999	-9999999 $\sim$
		999999

1 1 9	KEY_	P_NUM	
[Data meaning]	lumber of active keys at	a time	
[Data unit] p	piece		
[Data range] 2	2~5		
1 2 0	REF1_	COORDn	
1 2 1	REF1_	COORDn	
1 2 2	REF2_	COORDn	
1 2 3	REF2_	COORDn	
[Data type] Wor	d axis		
Data meaning REF	1 COORDn 1st referend	ce point machine	coordinates:
REF	2 COORDn 2 <sup>nd</sup> referend	e point machine	coordinates:
RFF	3 COORDn 3 <sup>rd</sup> reference	e point machine	coordinates:
REF	4 COORDn 4 <sup>th</sup> reference	e point machine	coordinates
[Data unit]		• F •	
	Setting unit	IS-B	IS-C
	Metric input	0.001 mm	0.0001 mm
	Inch input	0.0001 inch	0.00001 inch
[Data range] -	999999999~999999999		
1 3 6	FPGA J	MP XPL	
[Data type] Word		—	
[Data meaning] Tool	offset testing input in me	thod B. X plus dir	rection test signal add
	alid:20~27.30~37.add X	2 0~X3 7)	confirmed signal and
[Data range] 0.20	~27 30~37	2.0 , (0.1 )	
	-21, 00-01		
1 3 7	FPGA J		
[Data type] Word			
[Data mooning] Tool	offect testing input in mo	thod R. X minus	diraction tast signal add
	alid:20~27 30~37.add X	2 0~X3 7)	ullection test signal add
[Data range] 0.20		2.0 -7(0.1)	
	~27, 50~57		
1 3 8	FPGA .		
LData meaning 1001	offset testing input in me	thoa B, Z plus air	ection test signal add
(U:INV	aliu,20~27,30~37:add X7	2.0~73.7)	
LUata range $\downarrow$ 0, 20	~27,30~37		
1 3 9	FPGA_J	MP_ZML	
[Data type] Word			
[Data meaning] Tool	offset testing input in me	thod B, Z minus o	direction test signal add
(0:inv	alid;20~27,30~37:add X	2.0~X3.7)	

### **CNCmakers**

[Data range] 0, 20~27, 30~37

1 4 0		TW	EAR_MAX			
[Data meaning]	+ or – limit of e	ach inp	ut wear in	TOOL	OFFSET&WEAR i	nterface
[Data unit]						
	Setting unit		IS-B		IS-C	7
	Metric input		0.001 mr	n	0.0001 mm	-
	Inch input		0.0001 ir	ch	0.00001 inch	7
[Data range]						—
			S-B		IS-C	
	Metric input	1~	99999	1~	~999999	
	Inch input	1~	99999	1~	~999999	
1 4 1	A	UTO_C	DFFSET_F	EED		
[Data meaning]	Feedrate in aut	omatic	tool offset	measu	re	
[Data unit]						
	Setting unit		Data un	it		
	Metric mad	hine	mm/mir			
	Inch machine	е	0.1inch/	min		
[Data range]						
			S-B		IS-C	
	Metric machine	15~	~1000	15	5~1000	
	Inch machine	7~	~375		7~375	
			OFESET	v v		
				·_^ V 7		
		NOTO_				on in outomotic tool
	A(AUTO_OFF3	SEI_I_	_X) ,Z(AU	0_0FI	-SET_T_Z)y valu	es in automatic tool
[Data unit]	onset					
	Setting unit		IS-B			7
	Metric mac	hine	0.001 mr	n	0.0001 mm	_
	Inch machine	e	0.0001 ir	ch	0.00001 inch	_
[Data range]	1~9999999	-		-		
Note: X setting va	alue is the radius in di	ameter o	or radius pr	ogramn	ning	
1 4 4		AUTO_	OFFSET_	E_X		
1 4 5		AUTO_	OFFSET_	E_Z		
[Data meaning]	AUTO_OFFSE	T_E_X	(X),AUTC	_OFFS	SET_E_Z(Ζ)ε val	ues in automatic tool
	offset					
[Data unit]						
	Setting unit		IS-B		IS-C	]
	Metric mac	hine	0 001 mm		0 0001 mm	1

0.0001 inch

Inch machine

0.00001 inch



MULTISTAGE_SKIP1
MULTISTAGE_SKIP2
MULTISTAGE_SKIP3
MULTISTAGE_SKIP4

[Data type] Word

[Data meaning] Multilevel skip G31 P1~P4 or G04 Q1~Q4 signal detect address setting(0:no effect; 20~27,30~37: address X2.0~X3.7)

[Data range] 0, 20~27, 30~37

1 5 4

	RADIUS_ERR_RANGE	
Max.	arc radius error	

[Data meaning] [Data unit]

Setting unit	IS-B	IS-C
Metric machine	0.001 mm	0.0001 mm
Inch machine	0.0001 inch	0.00001 inch

[Data range]

	IS-B	IS-C
Metric machine	0~1000	0~10000
Inch machine	0~50	0~500

#### 1 6 2

#### CSACCFL

[Data type] [Data meaning] [Data unit] [Data range]

initial speed of CS acceleration/deceleration deg/min

Word spindle

0~4000

1		6		3	
ΓD	ata	a tv	pe	۶]	

[Data meaning]

[Data unit]

[Data range]

#### CSACCTIME

Word spindle

acceleration/deceleration time constant of CS ms

1		6		4
[D	ata	a ty	pe	;]

#### CSMCODE

Word spindle

[Data meaning] Spindle CS shifts the M code [Setting value +1 is the M code of the function releasing].

- Note 1: When the spindle positioning function is enabled, the M code is regarded as the spindle positioning method shifint.
- Note 2: The setting value should be set by the M code shifted based upon the CS compiled in the ladder diagram.
## **CNCmakers**

Note 3: The setting value is disabled when it is less than 6, the coordinate system will not be cleared when the CS axis is shifted in the disabled state.

[Data range]	0~96	3							
1 6 6		(	CAACCFL						
[Data type]	Wo	rd spindle							
[Data meaning]	] initial	speed of linear accele	eration/decelerat	tion in rigid tapping					
[Data unit]	unit]								
		Setting unit	Data unit	7					
		Metric machine	mm/min	-					
		Inch machine	0.1inch/min						
[Data range]	0	~4000							
1 6 7		C	AACCTIME						
Data meaning	] lineai	acceleration/decelera	tion time consta	ant in rigid tapping tool in-feed					
[Data unit]	ms								
[Data range]	0~40	000							
1 6 9		RTA	PBACKRATE						
[Data meaning	] overr	ide value in rigid tappi	ng tool retraction	n (override is 100% when it is set to 0)					
[Data unit]	%								
[Data range]	0~20	0							
1 7 0		CN	ICODE						
[Data meaning]	] N	I code used for spindle	e clamping durin	g rigid tapping					
[Data unit]									
[Data range]	3~97	,							
1 7 3		CA	LCODE						
[Data meaning]	] T	ake count of machinin	g piece M code	(0:defined M99 & M30)					
[Data unit]									
[Data range]	0~97	,							
1 9 1		POSE	RR_SERVO						
[Data type]	Word	axis							
[Data meaning]	] Servo	o axes position error va	alue when runni	ng speed 1m/min					
[Data unit]									
[Data range]	0~99	999999							
1 9 7		EGB_N	<b>MASTERAX</b>						
[Data meaning	] In the	e synchronized control	, the correspond	ding system axis number of the master					
axis									
[Data unit]									
[Data range]	0~5								

	Setting va	lue	r	neaning								
	0		C	disabled								
	1~5	the ?	the 1st feed axis ~ the 5th axis									
					<b>_</b>							
EGB_SLAVEAX												
[Data meaning	] In the sychron	ized control	, the co	rresponding ax	is number of the	e slave axis						
[Data unit]												
[Data range] 0~5												
Setting value meaning												
		0		disabled								
	1	~5	the 1st	feed axis ~ the	5th							
				axis								
	·			<b>.</b>								
2 1 9		P		Dn								
LData type 」	Word axis											
Data meaning	Select DI/	DO accordir	ng to Pl	_C controlled a	xes (0 means F	<sup>2</sup> LC axis control is						
<b>F - - - -</b>	not applied)											
LData unit 」												
LData range	0~4											
				_								
2 2 0		SP	SERV_	On								
LData type 」 -	Word spindle											
Data meaning	The correspor	iding interfa	ice num	ber of each spi	ndle output							
[Data unit]												
[Data range]	0~14											
	Setting value		mea	aning								
	2	anal	og spine	dle interface 2								
	1	anal	og spine	dle interface 1								
	0	Disable	ed analo	og spindle outpu	ut							
	11~14	extensi	ion IO u	nit analog outp	ut							
			interfa	ice; 1~4								
	·	<u> </u>										
		3P_3	3P_03/	4712								
[Data type]	Word spindle											
LData meaning	J The functions	such as the	e feed a	axis number ar	id CS axis, etc.	related with each						
	spinale should	de set.										
	0 5											
[Data range]	0~5					· · · · · · · · · · · · · · · · · · ·						
Setting v	alue meaning	Setting	value	meaning	Setting value	meaning						
0	Nothing	2		Z axis	1 4							
A	V ovia	1 X axis 3 3 <sup>rd</sup> axis										

```
2 2 5
```

NAME\_n

# **CNCmakers**

[Data type] Word axis

[Data meaning] Axis name definition of each axis

[Data range] 65, 66, 67, 88, 89, 90

Axis name	Setting value	Axis name	Setting value	Axis name	Setting value 66	
Х	88	Y	89	В		
Z	90	A	65	С	67	

Note: The axis name of X or Z axis is fixed, which can not be modified.

	_			
<b>^</b>		^	-	<b>^</b>
-,		·.		
			-	
_		~		· ·
			-	

0~7

0~4

ATTRIB\_n

[Data meaning] ATTRIB\_n is the additional attribution setting

[Data range]

Setting value	Meaning
0	It is neither the three basic axes and an axis parallel to them
1	X axis of the three basic axes
2	Y axis of the three basic axes
3	Z axis of the three basic axes
5	An axis parallel to X
6	An axis parallel to Y
7	An axis parallel to Z

2 3 5

## POLARLINEAXIS

Linear axis setting of the polar coordinate interpolation

[Data meaning] [Data range]

Setting value	Meaning
0	X axis
1	Z axis
2	Y axis
3	4 <sup>th</sup> axis
4	5 <sup>th</sup> axis



[Data range]

## POLARTOSAXIS

Rotary axis setting of the polar coordinate interpolation 2~4

Setting value	Meaning
2	Y axis
3	4 <sup>th</sup> axis
4	5 <sup>th</sup> axis

2	~~	3	7	
[Da	ata I	mea	aning	

#### ACCEPTANGLEERR

Maximum fluctuating value when the angle is 0°or 180°for C tool offset C

[Data range]

IS-B	IS-C
0~1000	0~10000

2 4 0		HWRPDFRATE
[Data meaning]	Rapid traverse	override of MPG trial cut function
[Data range]	0~100	
2 4 1		HWPULSEINC
[Data meaning]	Movement amo	unt per pulse during trial cut function
[Data range]	0~100	
2 4 3		CNC_MPG_NUM
[Data meaning]	Quantity of MPC	3
[Data range]	1~2	
2 4 4		MPG1_INTERFACE
2 4 5		MPG2_INTERFACE
[Data meaning]	MPG interface of	of MPG 1,2
[Data range]	0~1	
	Setting value	Meaning
	0	Rear cover MPG interface 1 (CN31)
	1	Rear cover MPG interface 2(CN32)
2 4 9		ABSPOSERR

Word axis [Data type]

## [Data meaning] When an absolute encoder is equipped with each axis, the Max. position error value allows when the coordinate system is set up with power-on.

[Data unit]

Setting unit	IS-B	IS-C
Metric input	0.001 mm	0.0001 mm
Inch input	0.0001 inch	0.00001 inch

[Data range]  $0 \sim 999999$ 

## 3.1.3 PLC Parameters (Standard PLC Definition)

## 3.1.3.1 K Parameters

Κ	1	0		LMIT	LMIS	EXESP	JSPD	OVRI	***	RSJG	RRW		
Bit7	1:	ove	overtravel of each axis is enabled;										
	0:	ove	overtravel of each axis is disabled.										
Bit6	1:	alar	rm for o	overtravel	signal L	OW of ea	ach axis;						
	0:	ala	rm for o	overtrave	l signal L	OW of e	ach axis						
Bit5	1:	Exte	External ESP signal is enabled;										
	0:	External ESP signal is disabled.											
Bit4	1:	spir	spindle JOG is enabled in any modes;										
	0:	spir	spindle JOG is enabled in Manual, MPG, Zero Return mode.										
Bit3	1:	feed	drate o	verride is	fixed to	100%;							

## **CNCmakers**

- 0: feedrate override can be adjusted.
- Bit1 1: spindle lubricating, cooling output remain in reset;
  - 0: spindle lubricating, cooling output are disabled in reset.
- Bit0 1: the cursor returning to the beginning of the program is enabled in any working mode in reset;
  - 0: the cursor returning to the beginning of the program is enabled in Edit working mode.

Κ	1	1	1	СНОТ		CHET	TCPS	CTCP	TSGN	СНТВ	CHTA
Bi	t7	1: (	checks	the tool	post worl	table over	erheating	;	•	•	•
		0: does not check the tool post worktable overheating.									
Bi	t5	1: checks the tool signal when the tool change is completed;									
		0: does not check the tool signal when the tool change is completed.									
Bi	t4	1 · t	tool po	st locking	a signal H	IGH (be	connecte	d with +2	24V) is er	habled.	

- 0: tool post locking signal LOW (not be connected with +24V) is enabled
- Bit3 1: checks the tool post locking signal;
  - 0: does not check the tool post locking signal.
- Bit2 1: tool signal LOW(not be connected with +24V) is enabled;0: tool signal HIGH(be connected with +24V)is enabled.
- Bit1 Bit0 : tool change mode selects Bit1 tool change mode selects Bit 0

CHTB	CHTA	Tool post type
0	0	Standard tool change mode B
0	1	Standard tool change mode A
1	0	Yantai AK31 series(6, 8, 10, 12 tools)
1	1	LIO_SHING hydraulic tool post (8, 10, 12 tools)

Κ	1	2				RCKC	CCHU	NYQP	SLSP	SLQP	
Bi	t4	1: Externa	al chuck o	control is	enabled	during pr	ogram ru	inning;		1	
		0: Extern	al chuck	control is	disabled	d during p	orogram r	unning			
Bi	t3	1: the sys	stem cheo	cks the ch	nuck in-p	osition sig	gnal;				
		0: the sys	stem doe	s not che	ck the ch	nuck in-po	osition sig	gnal.			
Bi	t2	1: in oute	er mode,	NQPJ is	the oute	r chuck	released	signal, a	nd WQP	J is the o	outer chuck
		clampe	ed signal;								
		0: in inner mode, NQPJ is the inner chuck clamped signal, and WQPJ is the inner chuck									
		release	ed signal.								
Bi	t1	1: the sy	stem doe	es not ch	eck whe	ther the	chuck is	clamped	l when th	ne chuck	function is
		enable	ed;								
		0: the sy	stem che	ecks whe	ther the	chuck is	clamped	l when th	ne chuck	function	is enabled;
		when	the chuc	k is not c	lamped,	the syste	m canno	t start the	spindle	and alarn	ns.
Bi	t0	1: the chu	uck contro	ol functio	n is enab	led;					
		0: the chu	uck contro	ol functio	n is disat	oled.					
Κ	1	3	CHIPR	***	WKLP	***	***	RTSC	SPTW	SLTW	

- Bit7 1: The chip-removal controller is enabled;
  - 0: The chip-removal controller is disabled
- Bit5 1: Indicator control is enabled;
  - 0: Indicator control is disabled.
- Bit2 1: External tailstock control is enabled during program running;

Connection

- 0: External tailstock control is disabled during program running;
- Bit1 1: the spindle rotation and the tailstock forward/backward does not interlock, the tailstock executes the forward no matter what the spindle is in any states; the spindle rotates no matter what the tailstock is in any states;
  - 0: the spindle rotation and the tailstock forward/backward interlock, the tailstock cannot execute the forward when the spindle rotates; the spindle cannot be started when the tailstock does not execute the forward.
- Bit0 1: the tailstock control function is enabled; 0: the tailstock control function is disabled.

K 1	4 HPST	SGSP	SPB4	PB4	SPB3	PB3				
Bit7	1: the hydraulic control function is e	nabled;			•	·]				
	0: the hydraulic control function is a	disabled.								
Bit4	1: Spindle is enabled when the prot	ection doo	or is open	Ì						
	0: Spindle is disabled when the pro	tection do	or is ope	n;						
Bit3	1: when SAGT is connected with +2	24V, the s	afety doo	r is disab	led;					
	0: when SAGT is not connected wit	th +24V, th	ne safety	door is d	isabled.					
Bit2	1: the safety door check function is	enabled;								
	0: the safety door check function is	0: the safety door check function is disabled.								
Bit1	1: when PRES is not connected wit	h +24V,	the syste	m alarms	for press	sure LOW				
	0: when PRES is connected with +2	24V, the	system a	larms for	pressure	LOW.				
Bit0	1: the pressure LOW check function	n is enable	ed;							
	0: the pressure LOW check functio	n is disab	led.							
K 1	5 RCS RSCS SPOR		SHT	AGIM	AGIN	AGER				
Bit7	1: Cs function is enabled;		L	1	1	1]				
	0: Cs function is disabled.									
Bit6	1: the spindle contour control is disa	abled in e	mergency	/ stop, re	set;					
	0: the spindle contour control is ena	abled in er	mergency	v stop, re	set.					
Bit5	1: the spindle eight-point orientation	n function	is enable	d;						
	0: the spindle eight-point orientation	n function	is disable	ed.						
Bit3	1: the spindle gear power-down me	mory;								
	0: the spindle gear power-down do	es not exe	ecute the	memory.						
Bit2	1: the gear in-position signal M41I,	M42I whic	ch are not	t connect	ed with +	24V is en				
	0: the gear in-position signal M41I,	M42I whic	ch are co	nnected	with +24∖	/ is enable				
Bit1	1: when the spindle automatic gea	ar change	e is to Ge	ear 1, 2,	the syste	em check				
	change in-position signal M41I, N	M42I;								
	0: when the spindle automatic gea	r change	is to Gea	r 1, 2, th	e system	does no				
	gear change in-position signal N	/I41I, M42	I.							

Bit0 1: the spindle automatic gear change function is enabled; 0: the spindle automatic gear change function is disabled

Κ	1	6		SINC	***	SCWM	LUBS	LUBC	K M3	32A	ROVI	SOVI		
Bi	7	1: G	Gear ">	<b>&lt;</b> 1000" in	STEP (N	/IPG) mo	de is dis	abled;						
		0: G	Gear ">	×1000" in	STEP (N	MPG) mo	de is en	abled;						
Bit	5	1: V	Nhen	spindle	stop con	nmand is	s in the	same	block	with	moveme	nt comm	and,	the
		со	ommar	nds are e	executed	at the sar	me time;							

**CNCmakers** 

0: When spindle stop command is in the same block with movement command, movement command comes first to spindle stop command;

Bit4 1: When cooling OFF command and movement command are in the same block, they are executed at the same time;

0: When cooling OFF command and movement command are in the same block, movement command comes first to the cooling OFF command;

- Bit2 1: the lubricating outputs in power-on when the automatic lubricating is enabled;0: the lubricating does not output in power-on when the automatic lubricating is enabled.
- Bit1 1: the external feedrate override inverses;
  - 0: the external feedrate override does not inverse.
- Bit0 1: the external feedrate override switch is enabled 0: the external feedrate override switch is disabled.

K 1	7 MSEN	SCLP	SALM2	SALM	SSTP	***	***	SPDIR				
Bit7	1: the multiple spir	ndle contr	ol functio	on is enat	oled;							
	0: the multiple spir	ndle conti	rol functic	on is disa	bled.							
Bit6	1: the spindle cla enabled;	amped co	ommand	clamps	the 2 <sup>nd</sup>	spindle \	when the	multiple	spir			
	0: the spindle clan	): the spindle clamped command clamps the 1 <sup>st</sup> spindle when the multiple spindle is enabled										
Bit5	1: the system alar	: the system alarms when the 2 <sup>nd</sup> spindle is LOW;										
	): the system alarms when the 2 <sup>nd</sup> spindle is HIGH.											
Bit4	1: the system alar	1: the system alarms when the spindle is LOW;										
	0: the system alarms when the spindle is HIGH.											
Bit3	1: the analog volta	1: the analog voltage is disabled when the spindle stops;										
	0: the analog volta	0: the analog voltage is enabled when the spindle stops.										
Bit0	1: The spindle but	ton rotatio	on directio	on on the	panel is	reversed	l;					
	0: The spindle but	ton rotatio	on directi	on on the	panel is	positive.						
K 1	8 EXTM	RSTM	HOLD	***	MDOK	MD4	MD2	MD1				
Bit7	1: extended M function is valid;											
	0: extended M function is invalid											
Bit6	1: extended M function remains output when emergency stop, reset;											
	0: extended M function output closes when emergency stop, reset.											
Bit5	1: HOLD release of	control is	valid;									

0: HOLD release control is invalid.

Bit3 1: the operation mode is specified by MD4, MD2, MD1 state when the system is turned on;0: the operation mode is the state which is that of power-off when the system is turned on.

MD4	MD2	MD1	Operation mode in power-on
0	0	0	MDI mode
0	0	1	Auto mode
0	1	0	Program zero return
0	1	1	Edit mode
1	0	0	MPG mode
1	0	1	Manual mode
1	1	0	Machine zero return

K	1	9		***	MACH	HDFD	***	***	***	***	***
			-								

Bit6 1: The machine tool panel is the vertical one;

0: The machine tool panel is the horizontal one

Bit5 1: MPG interruption is enabled in operation;

0: MPG interruption is disabled in operation.

k	2	0	***	***	***	***	***	***	DBMPG	DBMPG
n	2	U							1	0

Bit 1 Dual-MPG function selection bit 1: 10: It is enabled and only the MPG 1 on the panel button is enabled, as well only the MPG 2 is enabled of the external MPG input.

Bit 0 Dual-MPG function selection bit 0: 00 Disabled 01: It is enabled and the MPG 1 fixes the X axis, and the MPG2 fixes the Z axis, and the step-length can be selectecd;

## 3.1.3.2 DT Parameter

Address	Meaning
	Time for original gear disabling during spindle automatic
D1000	gear changing (ms)
DT001	Delay time after the changed spindle gear is in position (ms)
DT002	Detection time for low pressure alarm (ms)
DT004	Permit time for tool changing (ms)
DT005	M command execution time (ms)
DT006	S command execution time (ms)
DT007	Delay time for tool post from CW to CCW output (ms)
DT008	Tool post lock signal detection time (ms)
DT009	Tool post CCW rotation lock time (ms)
DT010	Spindle braking delay output time (ms)
DT011	Spindle braking output time (ms)
DT012	Spindle JOG time (ms)
DT013	Time for manual lubricating ON (0: time is not limited) (ms)
DT014	Chuck clamping command execution time (ms)
DT015	Chuck unclamping command execution time (ms)
DT016	Interval of automatic lubricating (ms) (can be modified
Diolo	directly)
DT017	Time for automatic lubrication output (ms) (can be modified directly)
DT018	Chuck pulse output width (ms) (can be modified directly)
DT020	Spindle clamping/unclamping time (ms)
DT021	Spindle stop, chuck enable delay time (ms)
DT023	Delay time before spindle motor torque decreases to 0 after
01023	spindle starts clamping
DT024	Spindle CS shifting or positioning shifting allowable time (ms)

## 3.1.3.3 DC Parameters

Address	Meaning
DC000	Spindle zero speed output range (r/min)
DC001	Spindle revolving-speed arrival output range (r/min)

## 3.2 Parameter Description (by Function Sequence)

## 3.2.1 X, Z, Y, 4<sup>th</sup>,5<sup>th</sup> Axis Control Logic

			-				
0	0 1	***	***	***		ISC	

Bit1 1: IS-C incremental system;

0: IS-B incremental system.

ISC	Least input increment, least command increment	Abbreviation
0	0.001mm,0.0001inch	IS-B
1	0.0001mm,0.00001inch	IS-C

0	0	8			DIR5	DIR4	DIRY	DIRZ	DIRX
D:+ 4	D:+0 4	. Direction	aignal /	CLLukhan	Eth Ath V		n a a i ti va l		

Bit4~Bit0 1: Direction signal (DIR) is HIGH when 5<sup>th</sup>, 4<sup>th</sup>, Ym Z or X positively moves;

0: Direction signal (DIR) is HIGH when  $5^{th}$ ,  $4^{th}$ , Ym Z or X negatively moves.

If machine moving direction is inconsistent with the actually required direction, it may be adjusted by this parameter.



## 3.2.2 Acceleration & Deceleration Control



[Data meaning] max. speed of X rapid traverse (radius value)

L Data unit j	
Setting unit Data unit	
Metric machine mm/min	
Inch machine 0.1inch/min	
[Data range] 10~99999999	
0 2 3 LINTn	
[Data type] Word axis	
[Data meaning] Acceleration/deceleration time constant value	
[Data unit] ms	
[Data range] $10\sim4000$	
0 2 7 FEDM	
[Data meaning] Upper limit of cutting feedrate	
[Data unit]	
Setting unit Data unit	
Metric machine mm/min	
Inch machine 0.1inch/min	
[Data range]	
IS-B IS-C	
Metric machine 10~30000 10~30000	
Inch machine 5~11600 10~11600	
0 2 9 FEEDT	
[Data meaning] Acceleration/deceleration time constant during cutting feed and manual fee	ed
[Data unit] ms	
[Data range] 0~4000	
0 3 0 FEDFL	
[Data meaning] The starting speed of cutting feed	
[Data unit]	
Setting unit Data unit	
Metric machine mm/min	
Inch machine 0.1inch/min	
[Data range]	
IS-B IS-C	
Metric machine $0 \sim 8000$ $0 \sim 8000$	
Inch machine 0~3000 0~3000	
0 3 1 JOGSPEED	
[Data meaning] Set speed when manual feedrate override is 100%	
[Data unit]	
Setting unit Data unit	

# **NCmakers**

	Metric machine	mm/min	
	Inch machine	0.1inch/mi	n
[Data range]	10~30000	1	1
0 3 2	,	RPDFI	n
			•11
[Data type]	vvolu axis	a rata whan th	o override ie
			e overnue is
	Cotting unit	Data unit	
	Setting unit	Data unit	
			n
[Data rango]	menmachine	0.11101/111	11
[Data range]			
	Metric machine	IЗ-В	0. 4000
		0~4000	0~4000
	Inch machine	0~1500	0~1500
0 4 1	<u> </u>	JOGF	L
Data meaning	d ]Exponential ac-dec	eleration start	speed and de
[Data unit]	33		
	Setting unit	Data unit	]
	Metric machine	mm/min	-
-	Inch machine	0.1inch/min	-
[Data range]	0~8000		1
-			
0 7 7		FEEDLIMI	TEXT
[Data meanin	g] The feedrate limit	when speed li	mit signal is a
to 0.]			
[Data unit]			
	Setting unit	Data unit	]
F	Metric machine	mm/min	-
	Inch machine	0.1inch/min	-
[Data range]	0~15000	I	1
- _		IS-B	IS-C
	Metric machine	0~15000	0~15000
	Inch machine	0~5800	0~5800
[Data range]	Inch machine 0~15000 Metric machine Inch machine	0.1inch/min IS-B 0~15000 0~5800 ation	IS-C 0∼15000 0∼5800

0	0	3				PEC			
Bit5	1:	Pitch	error	offset acti	ve				

1: Pitch error offset active

0: Pitch error offset inactive

	0	1	0		***	***	***	CPF5	CPF4	CPF3	CPF2	CPF1
--	---	---	---	--	-----	-----	-----	------	------	------	------	------

CPF5	CPF4	CPF3	CPF2	CPF1	Set frequency(Kpps)
0	0	0	0	0	1
0	0	0	0	1	2
0	0	0	1	0	3
0	0	0	1	1	4
0	0	1	0	0	5
0	0	1	0	1	6
0	0	1	1	0	7
0	0	1	1	1	8
0	1	0	0	0	9
0	1	0	0	1	10
0	1	0	1	0	11
0	1	0	1	1	12
0	1	1	0	0	13
0	1	1	0	1	14
0	1	1	1	0	15
0	1	1	1	1	16
1	0	0	0	0	17
1	0	0	0	1	18
1	0	0	1	0	19
1	0	0	1	1	20
1	0	1	0	0	21
1	0	1	0	1	22
1	0	1	1	0	23
1	0	1	1	1	24
1	1	0	0	0	25
1	1	0	0	1	26
1	1	0	1	0	27
1	1	0	1	1	28
1	1	1	0	0	29
1	1	1	0	1	30
1	1	1	1	0	31
1	1	1	1	1	32

CPF6~CPF1: Setting values of backlash offset pulse frequency (by BCD code
The set frequency =(setting value+1) Kpps

0	1	1		BDEC	BD8						
BDE	C 1	: Ba	cklash	offset typ	be B, the	offset dat	a are out	put by as	scending	or	
		des	scendii	ng type ai	nd the se	t frequen	cy is inact	tive;			

0: Backlash offset type A, the offset data are output by the set frequency (by bit parameter No.010) or 1/8 of it;

- 1: Backlash offset is done by the 1/8 of the set frequency;
  - 0: Backlash offset is done by the set frequency;

BD8

## **CNCmakers**

0 3 4		BKLn		1
☐ Data type]	Word axis			1
Data meaning	BKLX (X axis	s),BKLZ(Z axis	) backlash compe	nsation.
[Data unit]	-	,		
	Set unit	IS-B	IS-C	
	Metric mac	hine 0.001 m	nm 0.0001 m	m
	Inch machi	ne 0.0001	inch 0.00001 i	nch
	Data range	2000	20000	
[Data range] Note: X is diamete	$0{\sim}2000$ er value.			
096		PECMINn		]
[Data type]	Word axis			-
[Data meaning]	] Minimum pitcl	h error compensat	tion number	
[Data range]	0~1023			
				•
0 9 7		PECMAXn		
LData type	Word axis			
[Data meaning]	Maximum pito	ch error compensa	ition number	
LData range	0~1023			
0 9 8		PECORGn		1
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	Word axis			1
[Data meaning]	] Pitch error co	mpensation numb	er corresponding t	o machine zero
[Data range]	0~1023	•	1 5	
C				
099		PECINTn		]
[Data type]	Word axis			_
[Data meaning]	] Pitch error co	mpensation interv	als	
[Data unit]				
	Setting unit	IS-B	IS-C	]
	Metric machine	0.001 mm	0.0001 mm	
_	Inch machine	0.0001 inch	0.00001 inch	
LData range ]				
	Mateia and Li	IS-B	IS-C	
	Nietric machine	1000~999999	10000~999999	99
	Inch machine	400~999999	4000~9999999	9
3.2.4 Mach	ine Protection			

- Bit6 1: External cycle start signal (ST) inactive)
  - 0: External cycle start signal (ST) active
- Bit5 1: External SP signal inactive

0: External SP signal active with external dwell switch needed, otherwise CNC shows "Pause".

- Bit4 1: Not detect software stroke limit
  - 0: Detect software stroke limit
- Bit3 1: Emergency stop inactive
  - 0: Emergency stop active
- Bit1 1: Software limit is inactive after power-on and before machine zero return; 0: Software limit is active after power-on and before machine zero return;
- Bit0 1: When Arriving stored travel position, CNC is stopped slowly 0: When Arriving stored travel position, CNC is stopped immediately

0 4 5		LT1n1		1
0 4 6		LT1n2		
[Data type]	Word axis			
[Data meaning]	LT1n1: Maxim	um stroke on po	ositive direction; l	T1n2: Maximum stroke or
	negative direction			
[Data Unit]				
	Setting unit	IS-B	IS-C	]
	Metric machine	0.001 mm	0.0001 mm	•
	Inch machine	0.0001 inch	0.00001 inch	
[Data range]	-999999999~99	9999999	1	1

Note: When bit 2 of parameter No. 001 set diameter programming, X axis is set by diameter system; when bit 2 set radius programming, X axis is set by radius system.

1	0	0
1	0	 1

LTMAX_2	
LTMIN_2	

[Data type] Word axis

[Data meaning] Stored stroke limit 2 of each axis, LTMAX 2 top stroke position along with the positive direction, LTMIN\_2 top stroke position along with the negative direction.

[Data unit]

Setting unit	IS-B	IS-C						
Metric machine	0.001 mm	0.0001 mm						
Inch machine 0.0001 inch 0.00001 inch								
99999999~9999999								

[Data range]

1	0	2					
1	0	3					

LTMAX_3	
LTMIN_3	

Word axis LData type J

[Data meaning] Stored stroke limit 3 of each axis, LTMAX\_3 top stroke position along with the positive direction, LTMIN\_3 top stroke position along with the negative direction.

[Data unit]



Setting unit	IS-B	IS-C
Metric machine	0.001 mm	0.0001 mm
Inch machine	0.0001 inch	0.00001 inch

[Data range] 

PLC parameter

D Т 0 2 [Data meaning]

## PEALMTIM

Under-pressure alarm detection time

[Data unit]

ms [Data range] 0~2147483647



**PSANGNT** 

Chuck operation delay time after spindle stop;

[Data unit] ms

[Data range] 0~2147483647

#### Machine Zero Return 3.2.5

0	0	4	***		DECI		***			
Bit5	1:	Deceleratio	on begins	as DEC	signal is	connected	d to +24∖	/ in mach	ine zero	return

0: Deceleration begins as DEC signal is disconnected to +24V in machine zero return

			-									_
0	0	5								PPD		
Rit1	1.	Rela	tive an	d absolut	e coordir	ate set to	naether fo	r absolute	e settina	and refe	rence ret	urn h

ve and absolute coordinate set together for absolute setting and reference return by G50

0: Only absolute coordinate set for absolute setting and reference point by G50

0 0 8		ZIVIS	2114				
ZMX, ZMZ, ZMY, ZM4, ZM5:	Return and initial	backlash	direction	of X, Y,	Z axes	machine	zeroes
at power on							

0: Zero return type C, machine zero return and backlash direction is positive;

1: Zero return type B, machine zero return and backlash direction is negative.

0 0 7						ZC5	,	ZC4	ZCY	ZCZ	ZCX	
ZCX, ZCZ, ZCY, ZC	4, ZC5	=0:	Sep	arate	DEC	and	zerc	o signa	ls neede	d during	machine	e zero
			retur	n								

=1: DEC and zero signals together by a proximity switch during machine zero return

Note: This parameter should be set to 1 if a proximity switch is taken as both deceleration and zero signal.

0	1	1				***	***	NORF	ZNIK	REFC2	***
Bit3	1:	Mani	ial ma	chine zer	o return i	nactivity					

0: Manual machine zero return active

1: Stop at zero by pressing direction key once in zero return with direction key locked; Bit2

0: Direction key should be held on in zero return with direction key unlocked.

Bit1 1:Ref.C mode, the feeding slowdown when press down switch, it moves negatively after decelerating.

0:Ref.C mode,the feeding slowdown when release switch, it moves negatively after decelerating.

0	1	2		APRS			***		***		ISOT	
Bit7	1:	ABSC	DLUTE	automat	ically se	t after i	reference	return,	the coord	inate set	by para	ameter
		No.0	49 and	No.050;								
	0:	ABS	OLUTE	not auto	matically	set afte	r referenc	e returr	า			
Bit 0	1:	Prior	to mad	chine zerc	o return a	fter pow	er-on or l	E-stop,	manual rap	id traverse	e active	
	0:	Prior	to mad	chine zero	o return a	fter pow	er-on or l	E-stop,	manual rap	id traverse	e inactiv	e
0	1	4		***	***	***	ZRS5	ZRS	4 ZRSY	ZRSZ	ZRSX	1
Bit4~	0 1	l∶5 <sup>th</sup> , ∠	I <sup>th</sup> , Y, Z	, X has m	achine z	ero, the	system d	etects I	DEC signal	and zero	signal in	)
		execu	iting m	achine ze	ro return							
	(	D: 5 <sup>th</sup> ,	4 <sup>th</sup> , Y,	Z, X has	no mach	ine zer	o, the sys	tem do	es not dete	ct DEC s	ignal an	d zero
		sigr	nal and	directly e	executes	machine	e zero ret	urn				
			_									
1	8	3		***	*** **:	* MZ	.R5 N	IZR4	MZRY	MZRZ	MZ	RX
			th		°_∧°)							
Bit4	1: F	or the	5"'axi	s, press	ec to	execute	machine	zero re	turn;			
	0.1	For the	5 <sup>th</sup> ovi	a nraaa	<i>√</i> 9   to	ovoouto	machina	zoro ro	turn (haa r	at dafina	d the pre	
	0.1			s, piess (	10	execute	machine	Zeioie	luin (nas i		i ine pre	:55 KEY
		in the	standa	ard PLC)	0							
Bit3	1 · F	or the	4 <sup>th</sup> axi	s press	to e	execute	the mach	ine zero	o return.			
Ditto				c, p. coc :		one care						
	0:	For the	e 4 <sup>th</sup> ax	is, press	ど to e	execute	the mach	ine zero	o return.			
				Q.								
Bit2	1: F	For Ya	xis, pre	ess 🗳 🛉	to execu	ute the r	nachine z	ero retu	ırn;			
	0.1	For V a	avie nr		to ever	uto tho	machina <sup>.</sup>	zara rat	urn			
	0.1	10116	аліз, рі	ess				2010 101	um.			
Bit1	1: F	For Z a	xis, pre	ess z	to execu	te the m	achine ze	ero retu	rn;			
					]							
	0:	For Z a	axis, pr	ess 🗳	to exec	ute the	machine	zero ret	urn.			
<b>D</b> '10				۳¥٦.								
Bit0	1: F	or x a	ixis, pre		o execute	e the ma	achine zer	o returr	1;			
	0.	For X a	axis pr	ess 🗸	to exect	ite the n	nachine z	ero retu	Irn			
	5.		, PI									
1	8	8	1	***	RRTn	***	***	***				
[De	ta tvi		J	Bit avis								
LDa	u iy											

RRTn 1: when Y, 4<sup>th</sup>, 5<sup>th</sup> are rotary axis, the zero return use D mode;

0: when Y, 4<sup>th</sup>, 5<sup>th</sup> are rotary axis, the zero return use A, B,C mode( need to power-on again).

# **CNCmakers**

0 3 3		ZRNFLn			1	
[Data type]	Word axis				4	
[Data meaning]	Lowest speed rate of	of X,Z machii	ne zero re	turn.		
[Data unit]						
	Set unit	Data unit				
	Metric machine	mm/min				
	Inch machine	0.1inch/mii	n			
[Data range]						
		IS-B	IS-C			
	Metric machine	6~4000	6~4000	)		
	Inch machine	3~1500	3~1500	)		
			•			
0 4 7		PRSn				
[Data type]	Word axis					
[Data meaning]	Setting value of ab	solute coord	inate afte	r machin	e zero retur	n is performed
[Data unit]						
	Setting unit	IS-B	IS-	С		
	Metric input 0	.001 mm	0.000	l mm		
	Inch input 0.0	0001 inch	0.0000	1 inch		
[Data range]	-999999999~999999	999				
					•	
1 1 3		REF_SPD	n			
[Data meaning]	high-speed of each	axis machine	e zero reti	urn.		
[Data unit]						
	Set unit	Data uni	t			
	Metric machine	mm/min	-			
<b>- -</b>	Inch machine	0.1inch/r	min			
[Data range]	10~99999999					
	R	EF OFFSE	Tn		1	
[Data type]	Word axis				1	
[Data meaning]	Offset value of each	axis machir	ne zero po	oint		
[Data unit]						
	Set unit	IS-B	IS-	С		
	Metric input	0.001 mm	0.0	001 mm		
	Inch input	0.0001 inc	h 0.0	0001 inc	h	
[Data range]						
		IS-I	В	I	S-C	1
	Metric input	-99999	99999	-999999	9~999999	1
	Inch input	-99999	99999	-999999	9~999999	-
······		<u>.</u>				-
1 2 0	R	EF1_COOR	Dn			
1 2 1	R	EF2_COOR	Dn			

470

1	2	2		REF3_COORDn
1	2	3		REF4_COORDn
[Data	a type	] W	ord axis	3

[Data meaning] REF1\_COORDn machine coordinates of 1<sup>st</sup> reference point of each axis; REF2\_COORDn machine coordinates of 2<sup>nd</sup> reference point of each axis;

REF3\_COORDn machine coordinates of 3<sup>rd</sup> reference point of each axis; REF4\_COORDn machine coordinates of 4<sup>th</sup> reference point of each axis.

[Data unit]

Set unit	IS-B	IS-C		
Metric input	0.001 mm	0.0001 mm		
Inch input	0.0001 inch	0.00001 inch		

[Data range] -99999999-99999999

## 3.2.6 Thread Function

1	7 4						THDTLMOD	THDA	CKSPD
Bit2	1.Three	d tailin	a mode t	ailling ac	cordir	a anala.			

- 312 1: I hread tailing mode tailing according angle; Orthread tailing mode rapid tailing
- 0:Thread tailing mode rapid tailing. Bit1 1:Thread cut is exp. acc&dec
- 0:Thread cut is lin. acc&dec

Bit0 1:Whether detect the spindle speed is too slow in thread cutting don't detect\ 0:Whether detect the spindle speed is too slow in thread cutting do detect

				_
•			•	
0	 1	- 8 -	- Q	
•				
		- 8 -		
		-		
-				_

[Data meaning] [Data range]

## THDCH

thread run-out length in thread cutting.

0~225

ms

 $0{\sim}4000$ 

6~8000

Thread run-out width=THDCH×0.1×thread lead

0		2		6
Dat	a	me	ear	nina]

## THRDT

short acceleration/deceleration time constant in thread run-out.

[Data unit]

[Data range]

	_				
-		-		-	
~		_		~	
				~	
		_		-	
	_		_		

|--|

X, Z initial speed in thread cutting.

Data	meaning]
[Data	unit]

Set unit	Data unit
Metric machine	mm/min
Inch machine	0.1inch/min

[Data range]

	_			
		~		~
- 1				6
			-	• • •
		~	-	<u> </u>
	-			

### THD\_SPD\_VAR

[Data meaning] Spindle fluctuation alarm limit in threading (not detect spindle fluctuation alarm if set to 0)

[Data unit] %

[Data range] 0~100

Formula=|current speed - previous period speed|×200/(current speed+previous period speed)

0 1 7 THD\_TAIL\_SPD

[Data meaning] Short axis speed in threading run-out (run-out by threading feedrate if set to 0) [Data unit]

Set unit	Data unit
Metric machine	mm/min
Inch machine	0.1inch/min

[Data range]

## 0~8000

#### **Spindle Control** 3.2.7

0	0	1	1				SPIN			
Bit4 1: Analog voltage control of spindle speed										

1: Analog voltage control of spindle speed

-2000~2000

-1000~1000

mV

0: Switching volume control of spindle speed

Κ	1		0	]							RSJG	
RSJ	3	1:	wh	en the	reset is p	pressed,	CNC does	not close	M03,M0	)4,M08,N	132 outpi	ut signal:

when the reset is pressed, CNC does not close M03,M04,M08,M32 output signal; 1:

0: when the reset is pressed, CNC closes M03, M04, M08, M32 output signal

SPDLC

0	2	1	
[Da	ta me	aning]	
[Da	ta uni	t]	
[Da	ta ran	ige]	

## **PSANGNT**

voltage offset offset value when the analog voltage outputs 10V. m٧

voltage offset offset value when the analog voltage outputs 10V.

0	3	8	6	
[Da	ata r	nea	aning	]
<b>- -</b>			-	

[Data unit] [Data range]

0	3	7
0	3	8
0	3	9
0	4	0
-		

GRMAX1	
GRMAX2	
GRMAX3	
GRMAX4	

[Data meaning]

GRMAX1, GRMAX2, GRMAX3, GRMAX4: Max. speeds of spindle gear 1, 2, 3, 4 respectively when analog voltage output is 10V (function defined by GSK980TDi PLC: if the spindle automatic gearing is active, they are the speeds of M41, M42, M43, M44; if the automatic gearing is inactive or CNC is powered on, the gears are memorized by parameter setting or the gear 1 is defaulted.) r/min

[Data unit]

472

[Data range]	10~9999
0 6 7	SFTREV
[Data meaning]	output voltage in spindle gear shifting.
[Data unit]	mV
[Data range]	0~10000
0 6 8	SJOGREV
[Data meaning]	spindle rotary axis speed in Manual (MPG) mode.
[Data unit]	r/min
[Data range]	0~3000
0 6 9	ENCODER_CSE
[Data type] Wo	ord spindle
[Data meaning] Th	ne corresponding spindle encoder number of each spindle.
0:	without installing the encoder;
1:	Spindle revolving signal comes from the encoder interface 1;
2:	Spindle revolving signal comes from the encoder interface 2;
3:	Spindle revolving signal comes from the GSKLINK bus
LData range J 0~	~3
0 7 0	ENCODER_CN1
[Data meaning]	spindle encoder lines.
[Data meaning] [Data unit]	spindle encoder lines. line/r
[Data meaning] [Data unit] [Data range]	spindle encoder lines. line/r 100~10000
[Data meaning] [Data unit] [Data range]	spindle encoder lines. line/r 100~10000
[Data meaning] [Data unit] [Data range] 0 7 2	spindle encoder lines. line/r 100~10000 SAR_DELEY
[Data meaning] [Data unit] [Data range] <b>0 7 2</b> [Data meaning]	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time.
[Data meaning] [Data unit] [Data range] <b>0 7 2</b> [Data meaning] [Data unit]	spindle encoder lines. line/r $100 \sim 10000$ SAR_DELEY spindle speed arrival signal delay check time. ms $0 \simeq 4090$
[Data meaning] [Data unit] [Data range] <b>0 7 2</b> [Data meaning] [Data unit] [Data range]	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080
[Data meaning] [Data unit] [Data range] <b>0 7 2</b> [Data meaning] [Data unit] [Data range]	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data meaning] [Data unit] [Data range] <b>0</b> 73	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max_clamp speed of spindle motor speed
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data meaning] [Data unit] [Data range] <b>073</b> [Data meaning] [Data meaning]	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data range] [Data unit] [Data range] <b>073</b> [Data meaning] [Data unit] [Data unit] [Data unit]	spindle encoder lines. line/r $100 \sim 10000$ SAR_DELEY spindle speed arrival signal delay check time. ms $0 \sim 4080$ SPMOTORMAX max. clamp speed of spindle motor speed. r/min $0 \sim 4095$
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data meaning] [Data unit] [Data range] <b>073</b> [Data meaning] [Data unit] [Data unit] [Data range]	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min 0~4095 sting value= (max_clamp speed of spindle motor/its max_speed) x4095
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data range] [Data unit] [Data range] <b>073</b> [Data meaning] [Data unit] [Data unit] [Data range]	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min 0~4095 etting value= (max. clamp speed of spindle motor/its max. speed) ×4095.
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data range] [Data unit] [Data range] <b>073</b> [Data meaning] [Data unit] [Data unit] [Data range] Se	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min 0~4095 etting value= (max. clamp speed of spindle motor/its max. speed) ×4095.
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data range] [Data unit] [Data range] <b>073</b> [Data range] [Data unit] [Data range] Se	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min 0~4095 sting value= (max. clamp speed of spindle motor/its max. speed) ×4095.
[Data meaning] [Data unit] [Data range] <b>0</b> 72 [Data meaning] [Data unit] [Data range] <b>073</b> [Data meaning] [Data unit] [Data range] Se <b>074</b>	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min 0~4095 etting value= (max. clamp speed of spindle motor/its max. speed) ×4095. SPMOTORMIN min. clamp speed of spindle motor speed.
[Data meaning] [Data unit] [Data unit] [Data range] <b>0</b> 72 [Data meaning] [Data unit] [Data range] <b>073</b> [Data meaning] [Data range] Se <b>074</b> [Data meaning]	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min 0~4095 etting value= (max. clamp speed of spindle motor/its max. speed) ×4095. SPMOTORMIN min. clamp speed of spindle motor speed. r/min
[Data meaning] [Data unit] [Data unit] [Data range] <b>0</b> 72 [Data meaning] [Data unit] [Data range] <b>073</b> [Data meaning] [Data unit] [Data meaning] Se <b>074</b>	spindle encoder lines. line/r 100~10000 SAR_DELEY spindle speed arrival signal delay check time. ms 0~4080 SPMOTORMAX max. clamp speed of spindle motor speed. r/min 0~4095 witing value= (max. clamp speed of spindle motor/its max. speed) ×4095. SPMOTORMIN min. clamp speed of spindle motor speed. r/min 0~4095





0:series spindle controllable function disabled (analogy spindle), it is necessary to restart.

Bit6 1:PLC spindle rotation speed function of each axis enabled;

 $0:\!PLC$  spindle rotation speed function of each axis disabled.

Bit3 1:Spindle position function is valid (The spindle will perform the mechanical releasing/clamping interlocking operation before/after positioning when it is enabled);

0:Spindle position function is invalid.

- Bit2 1:Servo motor spindle function is valid ,power on; 0:Servo motor spindle function is invalid ,power on.
- Bit1 1:Change to position mode, the axis do return REF. 0:Change to position mode, the axis don't return REF.
- Bit0 1:Cs function of spindle valid ,power on 0:Cs function of spindle is:invalid,power on

1	96	***	***	***	MSEN	***	***	***	***	
Bit4	1: The n	nultiple spindle	control i	s enabl	ed					
	0: The r	multiple spindle	e control	is disab	oled					
2	0 1	SNTP	***	***	ECN	HBR	ERV	***	***	
Bit7	1:Synch	ronization mod	de follow							
	0:Synch	nronization mo	de interp	olation						
Bi4	1:Wheth	er the G81 s	synchroni	zation	comman	d can	be specif	ied in tl	he synch	ronization
proces	s allow									
	0:Wheth	her the G81	synchron	ization	commar	nd can	be specif	fied in tl	he synch	ronization
	proc	ess prohibitior	n							
Bit3	1:The sy	/stem resets ir	n the synd	chroniza	ation pro	cess res	serve the s	synchron	ized contr	ol
	0:The s	ystem resets i	n the syn	chroniz	ation pro	cess ca	ncel the s	ynchroni	zation cor	ntrol
Bit2	1:In the	e synchronizat	tion proc	edure,i	n the G	99 feed	d per rev	olution u	use the t	heoretical
	revol	ving speed of v	workpiece	e/						
	0:In the	synchronizatio	on proced	dure,in	the G99	feed pe	r revolutio	n use the	e encoder	feedback
	revo	lving speed								
2	2 0			SP_S	SERVOn					
[Data	₁ type]	Word spindle	;							
[Data	a meaning	] The corresp	onding in	terface	number	of each	spindle o	utput		
[Data	a unit]									
[Data	a range]	0~14								
		Setting value	Э		meanir	ıg				
		2		analog	spindle	interface	e 2			
		1		analog	spindle	interface	e 1			
		0	Di	sabled	analog s	pindle o	output			
		11~14	ex	tension	IO unit a	analog c	output			
				i	nterface;	1~4				

SP\_SP\_CSAXIS

[Data type] Word spindle

[Data meaning] The functions, such as the feed axis number, CS axis related to each axis must be set.

[Data unit]

[Data range]  $0 \sim 5$ 

Set	ting value	meaning	Setting value	meaning	Setting value	meaning
	0	Nothing	2	Z axis	4	4 <sup>th</sup> axis
	1	X axis	3	3 <sup>ra</sup> axis	5	5 <sup>™</sup> axis

## 3.2.8 Tool Compensation

0	0	2							NRC		
Bit	1 1	: Tool nos	e radius of	ffset activ	ve						
	0	: Tool nose	e radius of	fset inac	tive						
0	0	3				ТСОМ	P CDC	OMP		OIM	
Bit4	1:	Tool offset	by coordir	ate offse	et						
	0:	Tool offset	by move								
Bit3	1:	Tool compe	ensated by	/ the shil	ft of coor	dinate sy	stem do	not men	norize the	e unexec	uted too
		compensat	ion								
	0:	Tool comp	pensated	by the	shift of	coordina	te syste	m memo	orize the	unexecu	uted too
		compensa	tion								
Bit0	1:	Offset auto	matically	change i	n metric	and inch	convers	ion			
	0:	Offset not	change in	metric a	nd inch c	onversio	n				
			5								
0	0	4				ORC			PROD		

- ORC 1: Tool offset by radius
  - 0: Tool offset by diameter
- PROD 1: Programming position for RELATIVE display
  - 0: Position involving offset for RELATIVE display

0	1	2				DOFSI			
DOF	SI	1: T	rial too	setting a	active				

0: Trial tool setting inactive

## 3.2.9 Tool Life Management Function

0	0	2			***	***	LIFJ	MDITL	LIFC	TLIF
Bit4	1:	Tool	life ma	inagemei	nt group s	skip activ	/e			
	0:	Tool	l life m	anageme	ent group	skip inad	ctive			
Bit3	1:	Tool	life ma	inageme	nt active i	n MDI m	ode			
	0:	Tool I	ife ma	nagemer	nt inactive	in MDI r	node			
Bit2	1:	Tool	life cou	unting typ	be 2, by ti	mes				
	0:	Tool I	ife cou	inting typ	e 1, by tir	nes				
Bit0	1:	Tool	life ma	inademe	nt active					

0: Tool life management inactive

## 3.2.10 Tool Wear Parameter

English

0

1 4	0			TWEAR	_MAX					
Data me	eaning] po	sitive/neg	gative li	mit of to	ol wear	value	e in too	loffset	& wear	windov
[Data un	it]									
		Set unit		IS-B		IS-C				
		Metric inp	out	0.001 m	m	0.000	01 mm			
		Inch inpu	t	0.0001 i	nch	0.000	001 inc	h		
Data ran	ge]									
				IS-B			IS-C		]	
	N	letric inp	ut	1~9999	99	1	~99999	99	1	
	Ir	nch input		1~9999	99	1	~99999	99		
									_	
2 1 1	Edit & Disr	olav								
<u> </u>		olay								
00	5				M3	0				
80 1:	Cursor to beg	ginning af	ter M30	C						
0:	Cursor to beg	ginning by	y press	ing CYC	LE ST/	ART k	ey afte	r M30		
01	2					Α	LM&			
							PRG			
31:	Program editi	ng allowe	ed durir	ng CNC a	alarmin	g				
0:	Program edit	ing unallo	owed d	uring CN	IC alarr	ning				
1 8	0				DIS	PC	CUST	MO		SPOS
3it3 1:E	Boot dispaly if	custom p	age se	tted to d	isplay o	custon	n page			
0:E	Boot dispaly if	custom p	age se	tted to d	isplay f	ault pa	age			
Bit2 1:E	Display custom	n page dis	splay							
0:0	Display custom	n page hid	de							
Bit0 1:	DIS TO GO	displayed	l in PO	S&PRG	page					
0:	RELATIVE P	POS displ	ayed ir	POS&F	PRG pa	ge				
1 8	1				CL	.MDI	MCL	M30	)&MDI	
3it4 1:V	When system r	reset,the	prograi	m block	of MDI	are de	eleted			
0:'	When system	reset,the	progra	m block	of MDI	are n	ot dele	ted		
Bit3 1:		in MDI m	ode are	e deleteo	d after r	eset;				
	BIOCKS edited									
0:	Blocks edited Block edited ir	n MDI mo	de are	not dele	ted afte	er rese	et;			
0: Bit2 1: <i>F</i>	Blocks edited Block edited ir After the execu	n MDI mo ution of M	de are 02, M3	not dele 0,the pro	ted afte ogram I	er rese block (	ət; of MDI	are no	ot deletec	k
0: Bit2 1: <i>F</i> 0: <i>F</i>	Blocks edited Block edited ir After the execu After the execu	MDI mo ution of M ution of M	de are 02, M3 02, M3	not dele 0,the pro 0,the pro	ted afte ogram I ogram I	er rese block ( block (	et; of MDI of MDI	are no are de	ot deletec eleted	ł
0: Bit2 1: <i>F</i> 0: <i>F</i>	Blocks edited in Block edited ir After the execu After the execu	MDI mo ution of M ution of M	de are 02, M3 02, M3	not dele 0,the pro 0,the pro	ted afte ogram I ogram I	er rese block ( block (	et; of MDI of MDI	are no are de	ot deletec	ł
0: Bit2 1: <i>F</i> 0: <i>F</i>	Blocks edited in Block edited in After the execu	MDI mo ution of M ution of M	de are 02, M3 02, M3 <b>TEST</b>	not dele 0,the pro 0,the pro	ted afte ogram I ogram I	er rese block ( block (	et; of MDI of MDI *	are no are de	ot deletec eleted	ני געני געני
0: 3it2 1: <i>A</i> 0: <i>A</i> 1 8 0 0, Bit1, E	Blocks edited in Block edited in After the execu After the execu <b>4</b> Bit2: Interface	MDI mo ution of M ution of M *** <b>P</b>	de are 02, M3 02, M3 TEST	not dele 0,the pro 0,the pro *** ***	ted afte ogram I ogram I ***	er rese block ( block ( ***	et; of MDI of MDI	are no are de L <b>2</b>	ot deletec eleted	LO
0: Bit2 1: <i>A</i> 0: <i>A</i> 1 8 0 0, Bit1, E	Blocks edited in Block edited in After the execu After the execu <b>4</b> Bit2: Interface <b>Language</b>	MDI mo ution of M ution of M *** <b>P</b> e languag	de are 02, M3 02, M3 TEST ge selee Bit2	not dele 0,the pro 0,the pro ***	ted afte ogram I ogram I ***	er rese block ( block ( *** Bit1	et; of MDI of MDI	are no are de	bt deleted eleted L1 Bit0	LO

1

0



Portugal	0	1	0
Spanish	0	1	1
Russian	1	1	0

## 3.2.12 Communication Setting

bit/s

0		4		4	
[D	ata	a m	iea	anir	ng]

## BRATE0

baud rate of serial communication.

[Data unit] [Data range]

1200,2400,4800,9600,19200,38400,57600 ,115200

## 3.2.13 MPG Parameters

Bit3       1:       MPG mode         0:       Step mode         0:       1       3       RTH       RPH       ****       HW5       HW4       HWY       HWX         Bit7       1:       When system reset, the handle interrupt move amount is cancelled       0:       When system reset, the handle interrupt move amount is not cancelled         Bit6       1:       When MPG feedrate exceeds the rapid movement speed, the exceeding part is not igr and saved in CNC         0:       When MPG feedrate exceeds the rapid movement speed, the exceeding part is igr and saved in CNC         Bit4-Bit0       1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW.         K       1       6         SiNC       ****       ***       ***         Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid         0: In STEP(MPG), x1000 gear is valid       0: In STEP(MPG), x1000 gear is valid         1       Quantity of MPG         [Data meaning]       Quantity of MPG         [Data range]       1 ~2         2       4       4         MPG interface of MPG 1,2       MPG interface         [Data meaning]       MPG interface of MPG 1,2         [Data range]	0 0 1	**	** ***		MPG	i			
<ul> <li>0: Step mode</li> <li>0 1 3 RTH RPH *** HWS HW4 HWY HWZ HWX</li> <li>Bit7 1: When system reset,the handle interrupt move amount is cancelled</li> <li>0: When system reset,the handle interrupt move amount is not cancelled</li> <li>Bit6 1: When MPG feedrate exceeds the rapid movement speed,the exceeding part is not igr and saved in CNC</li> <li>0: When MPG feedrate exceeds the rapid movement speed,the exceeding part is igr and saved in CNC</li> <li>Bit4~Bit0 1: coordinates increase when 5<sup>th</sup>, 4<sup>th</sup>, Y, Z or X MPG rotates CCW;</li> <li>0: coordinates increase when 5<sup>th</sup>, 4<sup>th</sup>, Y, Z or X MPG rotates CW.</li> </ul> K 1 6 SINC **** *** *** *** *** *** *** Bit7 1: In STEP(MPG) mode, ×1000 gear is invalid <ul> <li>0: In STEP(MPG), ×1000 gear is valid</li> </ul> Quantity of MPG [Data meaning] Quantity of MPG [Data meaning] MPG interface of MPG 1.2 [Data meaning] 0~1 Werd meaning Werd interface of MPG 1.2 [Data range] 0~1 Setting value Meaning	Bit3 1: MPG mode	9							
0       1       3       RTH       RPH       ***       HW5       HW4       HWY       HWZ       HWX         Bit7       1: When system reset,the handle interrupt move amount is cancelled       0: When system reset,the handle interrupt move amount is not cancelled         Bit6       1: When MPG feedrate exceeds the rapid movement speed,the exceeding part is not igr and saved in CNC       0: When MPG feedrate exceeds the rapid movement speed,the exceeding part is igr and saved in CNC         Bit4~Bit0       1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;       0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW.         K       1       6       SINC       ****       ****       ****       ****         Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid       0: In STEP(MPG), ×1000 gear is valid       0: In STEP(MPG), ×1000 gear is valid         Quantity of MPG       Data meaning       Quantity of MPG       Quantity of MPG         [Data range]       1~2       1~2       1       1~2         Z       4       4       MPG1_INTERFACE       MPG2_INTERFACE       Image: Down         [Data meaning]       MPG interface of MPG 1,2       Down       1~2       1       1	0: Step mode								
Bit7       1: When system reset, the handle interrupt move amount is cancelled         0: When system reset, the handle interrupt move amount is not cancelled         Bit6       1: When MPG feedrate exceeds the rapid movement speed, the exceeding part is not igr and saved in CNC         0: When MPG feedrate exceeds the rapid movement speed, the exceeding part is igr and saved in CNC         Bit4-Bit0       1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW.         It 1       6         SINC       ****         ****       ****         Bit7       1: In STEP(MPG) mode, x1000 gear is invalid         0: In STEP(MPG), x1000 gear is valid         It 1       1         It 2       4         It 4       It 6         It 4       It 6         It 5       It 6         It 7       1: In STEP(MPG) mode, x1000 gear is invalid         0: In STEP(MPG), x1000 gear is valid       It 7         It 4       It 6         It 4       It 6         It 4       It 6         It 5       It 7         It 6       It 6         It 7       It 1         It 7       It 6         It 7       It 7			H ***	HW5	HW4	HWY	HW7	HWX	
Diff       1. When system reset, the handle interrupt move amount is not cancelled         0: When MPG feedrate exceeds the rapid movement speed, the exceeding part is not igr and saved in CNC         0:When MPG feedrate exceeds the rapid movement speed, the exceeding part is igr and saved in CNC         Bit4~Bit0 1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW.         Image:	Bit7 1: When svs	tem reset the ha	ndle interru	nt move	amounti			Ших	
Bit6       1:When MPG feedrate exceeds the rapid movement speed,the exceeding part is not igr and saved in CNC         0:When MPG feedrate exceeds the rapid movement speed,the exceeding part is igr and saved in CNC         Bit4~Bit0 1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW.         K       1       6         SINC       ****       ****         Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid         0: In STEP(MPG), ×1000 gear is valid         Image:       CNC_MPG_NUM         Image:       1~2         Image:       1~2         Image:       0~1         Image:       0~1         Image:       0~1	0: When sys	tem reset the ha	andle interru	nt move	amount i	s not ca	ncelled		
and saved in CNC         0:When MPG feedrate exceeds the rapid movement speed, the exceeding part is igr and saved in CNC         Bit4~Bit0 1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW; 0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW.         K       1       6       SINC       ****       ****       ****       ****         Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid 0: In STEP(MPG), ×1000 gear is valid       0: In STEP(MPG), ×1000 gear is valid         IData meaning       Quantity of MPG         IData meaning       Quantity of MPG         IData meaning       MPG1_INTERFACE         IData meaning       MPG interface of MPG 1,2         IData range       0~1	Bit6 1.When MPC	Geodrate exce	eds the rapid	d moven	nent spee	d the ex	ceeding	n part is no	t ian
0:When MPG feedrate exceeds the rapid movement speed,the exceeding part is igr and saved in CNC         Bit4~Bit0 1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW;         0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW.         Image: the state of the state	and save	ed in CNC			ioni op oo			g part le rie	. igin
and saved in CNC Bit4~Bit0 1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW; 0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW. K       1       6       SINC       ****       ****       ****       ****         Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid 0: In STEP(MPG), ×1000 gear is valid         Quantity of MPG [Data meaning]       Quantity of MPG Quantity of MPG         Quantity of MPG       MPG1_INTERFACE         Data range]       1~2         Quantity of MPG interface of MPG 1,2       MPG interface of MPG 1,2         Data range]       0~1	0:When MP	G feedrate exce	eeds the ra	oid move	ement sp	eed,the	exceed	ling part is	s ign
Bit4~Bit0 1: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CCW; 0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW. K       1       6       SINC       ****       ****       ****       ****       ****         Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid 0: In STEP(MPG), ×1000 gear is valid         Quantity of MPG       Quantity of MPG         Data meaning       Quantity of MPG         Data range       1~2         Quantity of MPG interface of MPG 1,2       MPG interface of MPG 1,2         Data range       0~1         Setting value       Meaning         Quantity of MPG 1,2       O~1	and save	d in CNC							-
0: coordinates increase when 5 <sup>th</sup> , 4 <sup>th</sup> , Y, Z or X MPG rotates CW. K       1       6       SINC       ***	Bit4~Bit0 1: coordina	tes increase wh	en 5 <sup>th</sup> , 4 <sup>th</sup> , Y	, Z or X	MPG rota	tes CC	N;		
K       1       6       SINC       ***       ***       ***       ***       ***       ***         Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid 0: In STEP(MPG), ×1000 gear is valid       0: In STEP(MPG), ×1000 gear is valid         2       4       3       CNC_MPG_NUM         Data meaning       Quantity of MPG         [Data range]       1~2         2       4       5         [Data meaning]       MPG1_INTERFACE         Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning         0       0	0: coordina	ites increase wh	en 5 <sup>th</sup> , 4 <sup>th</sup> , ۱	γ, Z or X	MPG rota	ates CW			
K       1       6       SINC       *** <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>									
Bit7       1: In STEP(MPG) mode, ×1000 gear is invalid         0: In STEP(MPG), ×1000 gear is valid         2       4       3         [Data meaning]       Quantity of MPG         [Data range]       1~2         2       4       4         2       4       5         [Data meaning]       MPG1_INTERFACE         [Data meaning]       MPG1_INTERFACE         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	K 1 6	SINC	***	***	***	***	***	***	
0: In STEP(MPG), ×1000 gear is valid         2       4       3         [Data meaning]       Quantity of MPG         [Data range]       1~2         2       4       4         2       4       5         [Data meaning]       MPG1_INTERFACE         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	Bit7 1: In STEP(N	/IPG) mode, ×10	000 gear is i	nvalid					
2       4       3       CNC_MPG_NUM         [Data meaning]       Quantity of MPG         [Data range]       1~2         2       4       4         2       4       5         [Data meaning]       MPG1_INTERFACE         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	0: In STEP(M	1PG), ×1000 gea	ar is valid						
2       4       3       CNC_MPG_NUM         [Data meaning]       Quantity of MPG         [Data range]       1~2         2       4       4         2       4       5         [Data meaning]       MPG1_INTERFACE         [Data meaning]       MPG2_INTERFACE         [Data range]       0~1         Setting value       Meaning					-				
[Data meaning]       Quantity of MPG         [Data range]       1~2         2       4       4         2       4       5         [Data meaning]       MPG1_INTERFACE         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	2 4 3		CNC_MF	'G_NU№					
[Data range]       1~2         2       4       4         2       4       5         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	[Data meaning]	Quantity of MF	PG						
2       4       4         2       4       5         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	[Data range]	1~2							
2       4       4         2       4       5         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	·								
2       4       5       MPG2_INTERFACE         [Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	2 4 4		MPG1_IN	TERFAC	E				
[Data meaning]       MPG interface of MPG 1,2         [Data range]       0~1         Setting value       Meaning	2 4 5		MPG2_IN	TERFAC	E				
[Data range]     0~1       Setting value     Meaning	[Data meaning]	MPG interface	e of MPG 1,2	2					
Setting value Meaning	[Data range]	0∼1							
	2								
0 Rear cover MPG interface 1 (CN31)		Setting value		Μ	leaning				
1 Rear cover MPG interface 2(CN32)	2	Setting value	Rear c	M over MP	leaning G interfac	ce 1 (CN	131)		

## 3.2.14 PLC Axis Control Function



0: Rapid traverse rate of PLC axis by parameter value (X axis: No.022; Z axis:No.023; Y axis:No.155;)

PLA 1: PLC axis control active, and active after repowering

0: PLC axis control inactive, and active after repowering

Note: The PLC axis control function is only provided by machine builder.



## 3.2.15 Skip Function

			-						
1	8	5		SK0	SKF	***	***	***	
01/0	4	011							,,,,,,,

- SK0 1: Skip input active as G31 signal is 0
  - 0: Skip input active as G31 signal is 1

SKF 1: Feedrate override per minute or dry run active for G31

0: Feedrate override per minute or dry run inactive for G31

Note: The skip function is only provided by machine builder.

1	4	8	MULTISTAGE_SKIP1
1	4	9	MULTISTAGE_SKIP2
1	5	0	MULTISTAGE_SKIP3
1	5	1	MULTISTAGE_SKIP4

[Data type] Word

[Data meaning] Multilevel skip G31 P1~P4 or G04 Q1~Q4 signal detect address setting(0:no effect; 20~27,30~37: address X2.0~X3.7)

[Data range] 0、20~27, 30~37

## 3.2.16 Automatic Tool Setting Function



Set unit	Data unit
Metric machine	mm/min

# maker

				menmaenin		0.11101/11	111.1
Dat	a rar	ge]					
					IS-B		IS-C
			Metric r	nachine	15~10	000	15~1000
			Inch ma	achine	7~375	5	7~375
1	4	2		AUTO_OFFSET_Y_X			
1	4	3		AUTO_OFFSET_Y_Z			

Inch machina

[Data meaning]

X (AUTO\_OFFSET\_Y\_X), Z (AUTO\_OFFSET\_Y\_Z) y value in automatic tool offset.

[Data unit]

[

Set unit	IS-B	IS-C
Metric machine	0.001 mm	0.0001 mm
Inch machine	0.0001 inch	0.00001 inch

0 1inch/min

[Data range] 1~9999999

Note: X setting value is the radius in diameter programming and radius programming.



AUTO_OFFSET_E_X	
AUTO_OFFSET_E_Z	

AUTO\_OFFSET\_E\_X (X) ,AUTO\_OFFSET\_E\_Z (Z) & value in automatic tool offset.

Note: The function needs the automatic tool setting device.

#### Input & Output Function in Metric/Inch System 3.2.17



Metric system for min. code unit, active after repowering 0:

#### Parameters Related to Arc Turning 3.2.18

1	5		4	
[Da	ta m	ea	aning	]

RADIUS\_ERR\_RANGE

max. value of arc radius error
--------------------------------

[Data unit]

Setting unit	IS-B	IS-C
Metric machine	0.001 mm	0.0001 mm
Inch machine	0.0001 inch	0.00001 inch

[Data range]

	IS-B	IS-C
Metric machine	0~1000	0~10000
Inch machine	0~50	0~500

## 3.2.19 Parameters Related to Addition

1 8 7	IS1	IS0	RCS	***	***	***	ROS	ROT
[Data type]: Bit axis								

BIT7,BIT6: set incremental system of each axis, 00: consistent with the incremental system of the system, 01: IS-A, 10: IS-B; 11: IS-C.

Bit5 1: Cs function of additional axis is valid/invalid (power-on again);

0: Cs function of additional axis is valid/invalid (power-on again).

Bit1,Bit0: 00 sets the additional axis to be the linear, 01 sets the additional axis to be the rotary(A

\*\*\*

type), 11 sets the additional axis to be the rotary (B type), 10 sets the additional axis to be invalid.

\*\*\*

RRL

RAB

ROA

## Note: This parameter is invalid to axes X and Z.

	1	8	8		***	RRT
ĺ	Data	type]	: Bit a	ixis		

Bit6 1: When the additional axis is rotary, the zero return uses D mode;

0: When the additional axis is rotary, the zero return uses A, B, C (power-on again).

Bit2 1: When the additional axis is rotary, cycle function of the relative coordinate is valid;

\*\*\*

- 0: When the additional axis is rotary, cycle function of the relative coordinate is invalid (power-on again).
- Bit1 1: When the additional axis is rotary, its rotation direction is based on the sign direction;0: When the additional axis is rotary, its rotation direction is contiguous.
- Bit0 1: When the additional axis is rotary, cycle function of the absolute coordinate is valid;
  - 0: When the additional axis is rotary, cycle function of the absolute coordinate is invalid (power-on again).

### Note: This parameter is invalid to axes X and Z.

2	25			NAME_	_n		
[Da	ata type]	Word	axis				
[Da	ata meaning	] axis	name definitio	ons			
[Da	ata range]	65, 6	6, 67, 88, 89,	90			
	Axis nam	e S	etting value	Axis name	Setting value	Axis name	Setting value
	Х		88	A	65	С	67
	Z		90	В	66	Y	89
		_					
2	3 0			ATTRIE	3_n		
[Da	ata type]	Word	axis				

[Data meaning] The properties of each axis in coordinate system

0~7

[Data range]

Setting value	Meaning
0	Neither the basic three axes nor the parallel axis



1	X axis of the basic three axes
2	Y axis of the basic three axes
3	Z axis of the basic three axes
5	Parallel axis of X axis
6	Parallel axis of Y axis
7	Parallel axis of Z axis

## 3.2.20 GSKLink Bus Related to Absolute Encoder

	_								
1 8 9		CTS	***	APC	APZ	***	***	***	***

[Data type]:Bit axis Bit7 1:Each servo axis didn't connect servo drive , it is necessary to restart;

0:Each servo axis connected servo drive, it is necessary to restart.

- Bit5 1:The used encoder type of each axis is absolute encoder;
  - 0:The used encoder type of each axis is incremental encoder.
- Bit4 1:When each axis matches with an absolute encoder, the mechanical position and absolute one are shown consistent;
  - 0:When each axis matches with an absolute encoder, the mechanical position and absolute one are shown inconsistent.

1 9	9	5	SSPD			

Bit7 1:series spindle controllable function enabled (series spindle The slave ID number of the spindle 1~3 is 11~13), it is necessary to restart;

0:series spindle controllable function disabled (analogy spindle), it is necessary to restart.

0.00001 inch

2 4 9	] [	ABSPOSER	R	
[Data type]	Word axis			
[Data meaning	When an absolute e allows when the c	encoder is equippe oordinate system i	d with each axis, the s set up with power	e Max. position error value -on.
[Data unit]				
	Setting unit	IS-B	IS-C	]
	Metric input	0.001 mm	0.0001 mm	7

	-
[Data range]	0~999999

Inch input

2	5		0	]	***	***	***	***	***	***	VERI	GSKLINK
		-		-							-	

0.0001 inch

Bit1 1:System GSKLINK bus communication CRC verification enabled 0:System GSKLINK bus communication CRC verification disabled

Bit0 1: Whether the system GSKLINK bus connection is enabled 0: Whether the system GSKLINK bus connection is disabled

## CHAPTER 4 MACHINE DEBUGGING METHODS AND MODES

The trial run methods and steps at initial power on for this GSK980TDi/GSK980TDi-V are described in this chapter. The corresponding operation can be performed after the debugging by the following steps.

## 4.1 ESP & Limit

This GSK980TDi/GSK980TDi-V system has software limit function, it is suggested that hardware limit is employed by fixing the stroke limit switches in the positive or negative axes.

## 4.1.1 ESP & Limit Series-Connection

The connection is as follows (2 axes):





So the BIT3 (ESP) of bit parameter No.172 should be set to 0.

The diagnostic message DGN000.7 monitors the emergency stop input signal.

In Manual or MPG mode, slowly move the axes to testify the validity of stroke limit switch, correctness of alarm display, validity of overtravel release button. When the overtravel occurs or Emergency Stop button is pressed, "ESP" alarm will be issued by CNC system. The alarm can be cancelled by pressing down the OVERTRAVEL key for reverse moving.

## 4.1.2 Separately Connect of ESP & Limit

The connection is shown below; refer to the Fig. 4-2 (3-axis is regarded as an example):



Fig. 4-2

The Bit 3 of status parameters №172 equals to 0: ESP function is enabled;

The Bit 7 of PLC parameter K10 equals to 1: The overtravel function along each axis is enabled; The Bit6 of PLC parameter K10: High/Low LEVEL selection of overtravel signal

In the Manual or MPG mode, slowly move the effectiveness of the overtravel limit swith of each axis verification or the correction of alarm display; the CNC ESP alarm may occur when pressing the ESP button is controlled; when the overtravel alarm occurs, it will moves towards to the negative direction; after moving out the limit position, the resetting clear alarm then can be pressed.

## 4.2 Drive Unit Configuration

The corresponding axis of each servo drive unit should be set based upon the valid configuration of the system, which can be directly set on the page of "Setting->GSKLink setting" based upon the 2-level authorities.

Under the 2-level or more authorities, enter to the setting page by \_\_\_\_\_, and then to the

GSKLink setting page by

OG	i l			<b>S0000</b>	10000
KL INK NO. 1 2	CONNECTION SETT DRIVER TYPE GS2025L GS2025L	ING ADAPTIVE NOTOR 110SJT-M040D(A41) 110SJT-M040D(A41)	AXIS X Z	00000 NOO PROMPT Feed axis Feed axis	
					-

Select the servo drive by for button, set the selected corresponding axis of the servo

drive by Serring: When the connection sequence of the servo drive is: X axis, Z axis, Y axis, the 4<sup>th</sup> axis, the 5<sup>th</sup> axis, spindle 1, spindle 2 or spindle 3 (regardless of the unavailable axis), the overall servo

drives can be set by

If the connection sequence of the servo axis does not correct, we would not definitely know the corresponding servo drive of each axis on the page of the "Setting->GSKLink setting", it can be directly set at the side of the servo side. The corresponding setting parameter of the servo is PA156; the comparison table of the parameter setting is shown below:

System	Servo	System	Servo	System	Servo
axis	parameter	axis	parameter	axis	parameter
Х	1	Y	3	5TH	5
Z	2	4TH	4		
Spindle 1	11	Spindle 2	12	Spindle 3	13

The Bit 4, Bit 3, Bit 2, Bit 1 and Bit 0 (DIR4, DIR5, DIRY, DIRZ or DIRX separately corresponds to the 5<sup>th</sup>, the 4<sup>th</sup>, Y, Z or X axis) of the state parameter No.008 can be modified if the machine tool

movement direction is inconsistent with the one of command required.

The manual movement direction can be changed by the Bit 4, Bit 3, Bit 2, Bit 1 and Bit 0 (5VAL, 4VAL, YVAL, ZVAL or XVAL separately corresponds to the 5<sup>th</sup>, 4<sup>th</sup>, Y, Z or X axis movement button) of parameter No.175.

## 4.3 Gear Ratio Adjustment

N $^{0}$ 015  $\sim$  N $^{0}$ 016 can be modified for electronic gear ratio adjustment to meet the various mechanical transmission ratios when the machine travel distance is not consistent with the displacement distance displayed by the CNC.

Formula:

$$\frac{CMR}{CMD} = \frac{4 * C * \delta}{L} * \frac{Z_M}{Z_D}$$

CMR: Code multiplier coefficient (data parameter No.015)

CMD: Code frequency division coefficient (data parameter No.016)

C: Motor's encoder lines

lpha : Pulse volume, motor rotation angle for a pulse

L: Screw lead

 $\delta$ : Current min. input code unit of CNC

ZM : gear teeth number of lead screw

ZD: gear teeth number of motor

For example, the screw lead and motor are directly connected by linkage axis, the motor's encoder is 17-bit absolute one, screw lead is 4mm, the current increment of CNC is 0.1µ;

X electronic gear ratio:

$$\frac{CMR}{CMD} = \frac{C^*\delta}{L} * \frac{Z_M}{Z_D} = \frac{131072*0.00005}{4} * \frac{1}{1} = \frac{1024}{625}$$

Z electronic gear ratio:

$$\frac{CMR}{CMD} = \frac{C*\delta}{L} * \frac{Z_M}{Z_D} = \frac{131072*0.0001}{4} * \frac{1}{1} = \frac{2048}{625}$$

Then, the parameter data №015X (CMRX) =1024, №016X (CMDX) =625; №015Z (CMRZ) =2048, №016Z (CMDZ) =625。

If the electronic gear ratio numerator is more than the denominator, the allowed CNC max. speed will decrease. For example: the data parameter No.015Z (CMRZ) =2, No.016Z (CMDZ) =1, so the allowed Z axis max. speed is 30000 mm/min.

If the electronic gear ratio numerator is not equal to the denominator, the allowed CNC positioning precision may decrease. For example: the data parameter No.015Z(CMRZ) =1, No.016Z(CMDZ) =5, so the pulse is not output as the input increment is 0.0004, but a pulse is output when the input increment is 0.0005.

In order to ensure the CNC positioning precision and speed index, it is suggested that the CNC electronic gear ratio is set to 1:1 and the electronic gear ratio calculated is set to the digital servo when matching with digital servo.

When matching with the step drive, choose the drive unit with step division function as possible as it can, and properly select mechanical transmission ratio. The 1:1 electronic gear ratio should be ensured to avoid the excessive difference between the numerator and the denominator of this CNC electronic gear ratio.

## 4.4 ACC&DEC Characteristic Adjustment

Adjust the relative CNC parameters according to the factors such as the drive unit, motor characteristics and machine load:

Data parameter No.022: rapid traverse rate of each axis;

Data parameter No.023: linear ACC&DEC time constant of each axis rapid traverse rate;

Data parameter No.026: X axis exponential ACC&DEC time constant in threading;

Data parameter No.028: exponential ACC&DEC start/termination speed in threading;

Data parameter No.029: exponential ACC&DEC time constant in cutting and manual feeding;

Data parameter No.030: exponential ACC&DEC start/end speed in cutting feeding;

Data parameter No.041: ACC&DEC start/termination speed in manual feeding;

BIT5 (SMZ) of bit parameter No.007: for smooth transition between cutting feedrates of adjacent blocks

The larger the ACC&DEC time constant is, the slower the ACC&DEC is, the smaller the machine movement impact and the lower the machining efficiency is, and vice versa.

If ACC&DEC time constants are equal, the higher the ACC&DEC start/end speed is, the faster the ACC&DEC is, the bigger the machine movement impact and the higher the machining efficiency is, and vice versa.

The principle for ACC&DEC characteristic adjustment is to properly reduce the ACC&DEC time constant and increase the ACC&DEC start/end speed to improve the machining efficiency on the condition that there is no alarm, motor out-of-step and obvious machine impact. If the ACC&DEC time constant is set too small, and the start/end speed is set too large, it is easily to cause faults such as drive unit alarm, motor out-of-step or machine vibration.

When the bit parameter No.007 BIT5(SMZ) =1, the feedrate drops to the start speed of the ACC&DEC at the cutting path intersection, then it accelerates to the specified speed of the next block to obtain an accurate positioning at the path intersection, but this will reduce the machining efficiency. When BIT5=0, the adjacent cutting path transits smoothly by the ACC&DEC. The feedrate does not always drop to the start speed when the previous path is finished and a circular transition (non-accurate positioning) will be formed at the path intersection. The machining surface by this path transition has a good finish and a higher machining efficiency. When the stepper motor drive unit is applied, the BIT5 of the bit parameter No.007 should be set to 1 to avoid the out-of-step.

If AC servo drive unit is applied to this system, the machining efficiency can be improved by a larger start speed and a smaller ACC&DEC time constant setting. If optimum acc/dec characteristics are required, the ACC&DEC time constant may be set to 0 which can be gotten by adjusting the AC servo acc/dec parameters. The suggested settings for these parameters are as follows(electronic gear ratio is 1:1):

Data parameter No.022 X=5000 Data parameter No.023 X≤60 Data parameter No.029≤50 Data parameter No.026≤50 Data parameter No.022 Z=10000 Data parameter No.023 Z≤60 Data parameter No.028≤500 Data parameter No.030≤400

The parameter settings above are recommended for use, please refer to the actual conditions of the drive unit, motor characteristic and motor load for their proper setting.

## 4.5 Mechanical (Machine) Zero Adjustment

The debugging methods of the machine zero point are different based upon the encoder type of the adapted motor.

1. When the adapated absolute encoder and the servo axis is linear one.

When the bus connection is normal, as well the debugging of the electric gear ratio of servo axis or the movement direction is normal, the position from movement axis to preset value on machine tool is regarded as the machine zero, directly set the current position on the machine as the machine reference point by the [n axis reference point setting] soft button on the page of the "Position—> Integrated coordinate". The machine will directly position to the reference point when it returns to zero after the reference point is set.

2. When the adapted incremental encoder or servo axis is rotation axis.

Adjust the relevant parameters based on the active level of the connection signal, zero return type and direction applied:

BIT5 (DECI) of the bit parameter No.004: active level of deceleration signal in machine zero return.

BIT0, BIT1, BIT2, BIT3, BIT4 (ZMX, ZMZ, ZMY, ZM4, ZM5) of the bit parameter No.006: X, Z, Y, 4<sup>th</sup>, 5<sup>th</sup> axis machine zero return mode B or C selection.

BIT0, BIT1, BIT2, BIT3, BIT4 (ZCX, ZCZ, ZCY, ZC4, ZC5) of the bit parameter No.007: whether a proximity switch is taken as both deceleration and zero signals.

BIT2(ZNLK) of the bit parameter No.011: whether the direction key in zero return is self-locked.

BIT0, BIT1, BIT2, BIT3, BIT4 (ZRSCX, ZRSCZ, ZRSCY, ZRSC4, ZRSC5) of the bit parameter No.014: have/not the machine zero(zero turn mode BC/A)setting bit.

Data parameter No.033: low deceleration speeds of each axis in machine zero return.

Data parameter No.113: high speed of each axis in machine zero return.

BIT0, BIT1, BIT2, BIT3, BIT4 (MZRX, MZRZ, MZRY, MZR4, MZR5) of the bit parameter No.183: each axis zero return direction: negative or positive.

Only the stroke limit switch validity is confirmed, can the machine zero return be performed.

The machine zero is usually fixed at the max. travel point, and the effective stroke of the zero return touch block should be more than 25mm to ensure a sufficient deceleration distance for accurate zero return. The more rapid the machine zero return is, the longer the zero return touch block should be. Or the moving carriage will rush over the block and it may affect the zero return precision because of the insufficient deceleration distance.

The connection to AC servo motor: using a travel switch and servo motor one-turn signal separately



By this connection, when the deceleration switch is released in machine zero return, the one-turn signal of encoder should be avoided to be at a critical point after the travel switch is released. In order to improve the zero return precision, and it should ensure the motor reaches the one-turn signal of encoder after it rotates half circle.

The parameter setting is as follows:

Bit parameter No.004 BIT5(DECI) =0

Bit parameter No.006 BIT0(ZMX) , BIT1(ZMZ) , BIT2(ZMY), BIT3(ZM4), BIT4(ZM5) =0 Bit parameter No.007 BIT0(ZCX) , BIT1(ZCZ) , BIT2(ZCY) , BIT3(ZC4), BIT4(ZC5)=0

```
Bit parameter No.011 BIT2(ZNLK) =1
Bit parameter No.014 BIT0(ZRSCX) , BIT1(ZRSCZ) , BIT2(ZRSCY), BIT3(ZRSC4),
BIT4(ZRSC5) =1
Data parameter No.033=200
Data parameter No.183 BIT0(MZRX) , BIT1(MZRZ) , BIT2(MZRY), BIT3(MZR4) , BIT4(MZR5)
=0
```

## 4.6 Spindle Adjustment

## 4.6.1 Spindle Encoder

Encoder with the pulses  $100 \sim 10000$  p/r is needed to be installed on the machine for threading. The pulses are set by data parameter No.70. The transmission ratio(spindle gear teeth/encoder gear teeth) between encoder and spindle is  $1/255 \sim 255$ . The spindle gear teeth are set by CNC data parameter No.110, and the encoder gear teeth are set by data parameter No.111. The encoder number used by spindle is set in the data parameter No.069.

Synchronous belt transmission should be applied for it (no sliding transmission).

The DGN.011 diagnosis message is used to check the validity of thread signal of the spindle encoder.

## 4.6.2 Spindle Brake

After M05 code is executed, proper spindle brake time should be set to stop the spindle promptly in order to enhance the machining efficiency. If the brake is employed with energy consumption type, too long braking time may burn out the motor.

Data parameter No.087: delay from spindle stop(M05) to spindle brake output Data parameter No.089: spindle braking time

## 4.6.3 Switch Volume Control of Spindle Speed

When the machine is controlled by a multi-speed motor, the motor speed codes are S01 $\sim$ S04. The relevant parameters are as follows:

State parameter No.001 Bit4=0: select spindle speed switch control;

## 4.6.4 Analog Voltage Control of Spindle Speed

This function can be obtained by the parameter setting of CNC. By interface outputting  $0V \sim 10V$  analog voltage to control frequency inverter, the stepless shift can be obtained. And the related parameters needed to be adjusted are:

Bit parameter No.001 Bit4=1: for spindle speed analog voltage control;

The Bit 7 of the status parameters №195 equals to 0: Select the spindle revolving speed is analog voltage control;

Data parameter No.021: offset value as spindle speed code voltage is 10V;

Data parameter No.036: offset value as spindle speed code voltage is 0V;

Data parameter No.037 $\sim$  No.040: for max. speed clamping of spindle gear 1 $\sim$ 4; it defaults the spindle gear 1 when CNC power on.

Basic parameters are needed to adjust the inverter:

CW or CCW code mode selection: it is determined by terminal VF;

Frequency setting mode selection: it is determined by terminal FR;

If the speed by programming is not consistent with that detected by the encoder, it can be adjusted to be consistent with the actual one by adjusting the data parameter No.037 $\sim$ No.040.

Speed adjustment method: select the corresponding spindle gear, determine the data parameter is 9999 as for this system gear, set the spindle override for 100%. Input spindle run command in MDI mode to run the spindle: M03/M04 S9999, view the spindle speed shown on the right bottom of the screen, then input the speed value displayed into the corresponding system parameter.

When entering S9999 code, the voltage should be 10V, S0 for 0V. If there is a voltage error, adjust bit parameter No.021 and No.036 to correct the voltage offset value (corrected by manufacturer, usually not needed).

For the current max. speed gear, if the analog voltage output by CNC is not 10V, set it for 10V by adjusting the data parameter No.021; when the input speed is 0, if the spindle still slowly rotates, it means the analog voltage output by CNC is higher than 0V, so set a smaller value for data parameter No.036.

If the machine is not fixed with an encoder, the spindle speed can be detected by a speed sensing instrument, input S9999 in MDI mode to set the speed value displayed by the instrument into the data parameter No.037 $\sim$  No.040.

## 4.6.5 Spindle Speed Series Control

The spindle speed series control can be carried out by CNC parameter, directly control the spindle servo drive unit to achieve the stepless speed by delivering the seires data from bus; the relevant parameters to be adjusted are shown below:

The Bit 4 of the status parameter №001 equals to =1: Select the spindle speed analog voltage or series control;

The Bit 7 of the status parameter №195 equals to 1: Select the spindle speed as the series control;

Data parameters №037~№040: The top speed of each step;

When the revolving speed specified by programming is inconsistent with the one of the encoder detection, the specified speed becomes consistent with the actual one by adjusting the data parameters N037 $\sim$ N040.

Revolving speed adjustment method: Firstly, shift the spindle to the corresponding gears and ensure that the corresponding gear data parameter for the system is 9999, adjust the spindle override as 100%; Input the spindle operation command on the MDI interface and operate the M03/M04 S9999; secondly, observe the spindle speed on the right corner of the screen; lastly, input the displayed revolving speed value to the corresponding data parameter of the gear.

When the machine tool does not install the encoder, it can be detected the spindle speed by revolving speed sensor; MDI code inputs the S9999; Set the displayed revolving speed on its sensor to the corresponding gear data parameters №037~№040.

## 4.7 Backlash Offset

The X axis backlash offset value is input by diameter, Z axis backlash offset value is input by the actual backlash which can be measured by a dial-indicator, a micrometer or a laser detector. Because
the backlash offset can improve the machining precision only by accurate compensation, it is not recommended to measure it in MPG or Step mode, but the following method is suggested:

• Program editing (taking example of Z):

O0001; N10 G01 W10 F800 ; N20 W15; N30 W1; N40 W-1; N50 M30.

- Set the backlash error offset to 0 before measuring:
- Run the program by single blocks, search the measuring benchmark after 2 positioning operations, record the current data, move 1mm in the same direction, then move 1mm to point B reversely, read the current data.



Fig. 4-4 Schematic map of backlash measuring method

Backlash error offset value= | data of point A – data of point B |; then input its outcome to the data parameter No.034 (BKLn) (for X axis, multiply 2 and then input the outcome to data parameter No.034).

Data A: dial-indicator data at point A

Data B: dial-indicator data at point B

- Note 1: The backlash offset mode can be set by Bit7 of CNC parameter No.011; the backlash frequency can be set by Bit6 of parameter No.011 and Bit4, Bit3, Bit2, Bit1, Bit0 of bit parameter No.010.
- Note 2: Check the machine backlash every 3 months.

### 4.8 Tool Post Debugging

GSK980TDi supports various kinds of tool post, and the parameter settings are based on the machine manual. The parameter settings for the tool post running are as follows:

BIT2(TSGN) of K parameter No.011: high/low level selection of tool post in-position signal, when the signal is low level active, a parallel pull-up resistor is needed.

- Bit3 (CTCP) of K parameter No.011: check/do not check tool post lock signal in tool change;
- Bit4 (TCPS)of K parameter No.011: tool post lock signal HIGH/LOW selection;
- Bit5 (CHET) of K parameter No.11: check/do not check tool signal;

Combinations and functions of tool change mode selection Bit1(CHTB), Bit0(CHTA) of K parameter No.11 are referred to **Tool Change Control**.

Data parameter No.076: Duration for moving a tool in tool changing

Data parameter No.078: Upper limit time for changing one tool

Data parameter No.082: Delay time from tool post CCW stop to CW clamping start

Data parameter No.084: Total tools number

Data parameter No.085: Delay of tool post CW clamping

If the tool post doesn't rotate at first power on for tool change, the phase connection of the 3-phase power of the tool post motor may be incorrect, it needs to press the RESET key immediately and cutoff the power, then check the wiring; if the fault is caused by this, exchange two phases of the 3-phase power.

The CW clamping duration setting should be proper, it should be neither longer nor shorter, longer delay may damage the motor, shorter delay may cause the tool post not to be completely clamped. The method to check the tool post clamping is: approach the dial-indicator to the tool post, turn the tool post manually, and the pointer floating of the dial-indicator should not be over 0.01mm.

The BIT7(TL-) and BIT6(TL+) of diagnosis message DGN.005 are used to check the validity of tool post CCW/CW output signal.

The BIT0 $\sim$ BIT3 (T01 $\sim$ T04) of diagnosis message DGN.000 are used to check the validity of tool number T01 $\sim$ T04 signal.

During debugging, every tool, max. tools change should be performed to check the correctness of the tool change, time parameter setting.

#### 4.9 Step/MPG Adjustment

The key on the panel can be used to select the Step mode or MPG mode, which is set by the BIT3 of bit parameter No.001.

Bit3 =1: MPG mode active, Step mode inactive;

=0: Step mode active, MPG mode inactive;

### CHAPTER 5 DIAGNOSIS MESSAGE

Diagnosis messages for GSK980TDi system are described in this chapter.

### 5.1 CNC Diagnosis

The part is used to check the CNC interface signals and internal running and it can't be modified.

#### 5.1.1 I/O Status & Data Diagnosis Message

		_								
0	0		ESP	***	***	DEC5	DEC4	DECZ	DECY	DECX
Pi	n	1	CN61.6			CN61.34	CN61.33	CN61.12	CN61.32	CN61.4
PLC f	ixed	1	X0.5			X2.5	X2.4	X1.3	X2.3	X0.3
addr	ess									

DECX, DECY, DECZ, DEC4, DEC5: machine zero return signal of X, Y, Z, 4th, 5th ESP: emergency stop signal

0	0		1
	Pir	١	
PL	_C f	ixe	d
а	ddre	ess	6

0

	***	***	***	***	***	***	***	SKIP
1								CN61.42
1								X3.5

SKIP: skip signal

### 5.1.2 CNC Motion State & Data Diagnosis Message

EN5~ENX: X, Z, Y, 4 <sup>th</sup> , 5 <sup>th</sup> enabling signal         0       0       6         1       1         0       0       9         ****       ***       DRO5       DRO4       DRO2       DROY       DROX         DRO5~DROX: X, Y, Z, 4th, 5 <sup>th</sup> motion direction output         0       0       9       ****       ****       ALM5       ALM4       ALMZ       ALMY       ALMX         ALM5~ALMX: X, Y, Z, 4th, 5 <sup>th</sup> alarm signal       ****       ALM5       ALM4       ALMZ       ALMY       ALMX         0       1       1       Spindle speed 1 feedback data       0       0       Spindle 1 analog output value       0       0       Spindle 2 analog output value       0       0       Spindle 3 analog output value       0       X axis output pulse number       X axis motor feedback position       X axis motor feedback position	0	0	4	1	***	***	***	EN5	EN4	ENZ	ENY	ENX
0       0       6       ***       ***       DRO5       DRO4       DROZ       DROY       DROX         DRO5~DROX: X, Y, Z, 4th, 5 <sup>th</sup> motion direction output         0       0       9       ***       ***       ALM5       ALM4       ALMZ       ALMY       ALMX         ALM5~ALMX: X, Y, Z, 4th, 5 <sup>th</sup> alarm signal       ***       ***       ALM5       ALM4       ALMZ       ALMY       ALMX         0       1       0       1       1       Spindle speed 1 feedback data       0       0       1       1       Spindle speed 2 feedback data       0       0       1       3       Spindle 1 analog output value       0       0       1       5       Spindle 3 analog output value       0       0       1       5       Spindle 3 analog output value       0       0       4       8       X axis output pulse number       X axis motor feedback position       X       X axis motor feedback position       X	EN5	$\sim$ EN	X: X,	Z, Y, 4 <sup>tr</sup>	, 5 <sup>th</sup> ena	bling sigr	nal					
0       0       6       ***       ***       DRO5       DRO4       DROZ       DROY       DROX         DRO5~DROX: X, Y, Z, 4th, 5 <sup>th</sup> motion direction output         0       0       9       ***       ***       ALM5       ALM4       ALMZ       ALMY       ALMX         ALM5~ALMX: X, Y, Z, 4th, 5 <sup>th</sup> alarm signal       ***       ***       ALM5       ALM4       ALMZ       ALMY       ALMX         0       1       0       1       1       Spindle speed 1 feedback data       0       0       1       3       Spindle 1 analog output value       0       0       1       4       Spindle 2 analog output value       0       0       1       5       Spindle 3 analog output value       0       X axis output pulse number       X axis motor feedback position         0       4       9       X axis motor feedback position       X axis motor feedback position       X       <												
DRO5~DROX: X, Y, Z, 4th, 5 <sup>th</sup> motion direction output         0       0       9       ****       ***       ALM5       ALM4       ALMZ       ALMY       ALMX         ALM5~ALMX: X, Y, Z, 4th, 5 <sup>th</sup> alarm signal       MPG rotation data       0       1       1       0         0       1       1       0       Spindle speed 1 feedback data       0         0       1       2       Spindle speed 2 feedback data       0         0       1       3       Spindle 1 analog output value         0       1       4       Spindle 3 analog output value       0         0       1       5       Spindle 3 analog output value       X axis output pulse number         0       4       9       X axis motor feedback position	0	0	6		***	***	***	DRO5	DRO4	DROZ	DROY	DROX
009******ALM5ALM4ALMZALMYALMXALM5~ALMX: X, Y, Z, 4th, 5 <sup>th</sup> alarm signal0100110110120130130140104940<	DRC	)5∼D	ROX	X, Y, Z	, 4th, 5 <sup>th</sup>	motion di	rection o	output				
009******ALM5ALM4ALMZALMYALMXALM5~ALMX: X, Y, Z, 4th, 5 <sup>th</sup> alarm signal010011011012013013014015048049049												
ALM5~ALMX: X, Y, Z, 4th, 5 <sup>th</sup> alarm signal         0       1       0         0       1       1         0       1       1         0       1       2         0       1       2         0       1       3         0       1       3         0       1       4         0       1       5         0       1       5         0       1       5         0       4       8         0       4       9	0	0	9		***	***	***	ALM5	ALM4	ALMZ	ALMY	ALMX
010011011012013013014015048049049	ALM	5~A	LMX:	X, Y, Z,	4th, 5 <sup>th</sup> a	ılarm sigr	nal					
010011011012013014015048049XX axis motor feedback position												
011012012013014015048049Xaxis motor feedback position	0	1	0					MPG	rotation d	ata		
012013013014015048049Xaxis motor feedback position	0	1	1				Spi	indle spee	ed 1 feed	back data	a	
013Spindle 1 analog output value014Spindle 2 analog output value015Spindle 3 analog output value048X axis output pulse number049X axis motor feedback position	0	1	2				Spi	indle spee	ed 2 feed	back data	a	
014Spindle 2 analog output value015Spindle 3 analog output value048X axis output pulse number049X axis motor feedback position	0	1	3				Sp	oindle 1 ar	nalog out	put value	1	
015Spindle 3 analog output value048X axis output pulse number049X axis motor feedback position	0	1	4				Sp	oindle 2 ar	nalog out	put value	1	
048X axis output pulse number049X axis motor feedback position	0	1	5				Sp	oindle 3 ar	nalog out	put value	1	
0 4 9 X axis motor feedback position	0	4	8				Х	axis outp	out pulse	number		
	0	4	9				X a	axis motor	<sup>·</sup> feedbac	k positior	า	



0       5       1         0       5       2         0       5       3         0       5       4         0       5       5         0       5       6         0       5       7         0       6       1         0       6       2         0       6       5         0       6       9         0       6       9         0       7       0         0       7       1         0       7       3         0       7       5         0       7       5         0       7       6         0       7       7         0       7       5         0       7       7         0       9       0         1       0       4         1       0       4         1       0       7         1       0       7         1       0       7         1       0       7      1       0       7      1	0	5	0
0         5         2           0         5         3           0         5         4           0         5         5           0         5         7           0         6         1           0         6         2           0         6         2           0         6         5           0         6         9           0         6         9           0         7         0           0         7         1           0         7         3           0         7         5           0         7         5           0         7         5           0         7         6           0         7         5           0         7         7           0         9         0           1         0         4           1         0         4           1         0         7           1         0         8           1         1         1           1         1         3	0	5	1
0       5       3         0       5       4         0       5       5         0       5       7         0       6       1         0       6       2         0       6       5         0       6       9         0       6       9         0       7       0         0       7       1         0       7       2         0       7       3         0       7       5         0       7       5         0       7       6         0       7       7         0       9       0         1       0       4         1       0       4         1       0       4         1       0       7         1       0       8         1       1       1         1       1       3         1       1       3         1       1       3         1       1       3	0	5	2
0       5       4         0       5       5         0       5       7         0       6       1         0       6       2         0       6       5         0       6       9         0       6       9         0       7       0         0       7       1         0       7       3         0       7       5         0       7       5         0       7       6         0       7       7         0       7       5         0       7       7         0       7       6         0       7       7         0       7       7         0       9       0         1       0       1         1       0       4         1       0       7         1       0       4         1       0       7         1       1       1         1       1       1         1       1       3	0	5	3
0       5       5         0       5       7         0       6       1         0       6       2         0       6       5         0       6       9         0       6       9         0       7       0         0       7       1         0       7       2         0       7       3         0       7       5         0       7       5         0       7       6         0       7       7         0       9       0         1       0       1         1       0       4         1       0       5         1       0       4         1       0       7         1       0       6         1       0       7         1       0       7         1       0       7         1       0       7         1       0       7         1       0       7         1       0       7	0	5	4
056057061062065069070071072075076075076077090101104105106107108111113113114	0	5	5
0       5       7         0       6       1         0       6       2         0       6       5         0       6       9         0       6       9         0       7       0         0       7       1         0       7       2         0       7       5         0       7       5         0       7       6         0       7       6         0       7       7         0       9       0         1       0       1         1       0       4         1       0       5         1       0       4         1       0       8         1       1       1         1       1       3         1       1       3         1       1       4	0	5	6
061062065069070071072075076077090101101105106105108111113113114	0	5	7
062065066069070071072075075076077090101101105106107108111113113114	0	6	1
065069070071072072075075076077090101104105106107108111113113114	0	6	2
$\begin{array}{c c c c c c c c c } 0 & 6 & 6 \\ 0 & 6 & 9 \\ 0 & 7 & 0 \\ 0 & 7 & 1 \\ 0 & 7 & 1 \\ 0 & 7 & 2 \\ 0 & 7 & 2 \\ 0 & 7 & 2 \\ 0 & 7 & 3 \\ 0 & 7 & 5 \\ 0 & 7 & 5 \\ 0 & 7 & 6 \\ 0 & 7 & 5 \\ 0 & 7 & 6 \\ 0 & 7 & 7 \\ 0 & 9 & 0 \\ 1 & 0 & 7 \\ 1 & 0 & 1 \\ 1 & 0 & 4 \\ 1 & 0 & 5 \\ 1 & 0 & 4 \\ 1 & 0 & 5 \\ 1 & 0 & 6 \\ 1 & 0 & 5 \\ 1 & 0 & 6 \\ 1 & 0 & 7 \\ 1 & 0 & 8 \\ 1 & 1 & 0 \\ 1 & 1 & 1 \\ 1 & 1 & 2 \\ 1 & 1 & 3 \\ 1 & 1 & 4 \\ \end{array}$	0	6	5
$\begin{array}{c cccc} 0 & 6 & 9 \\ 0 & 7 & 0 \\ 0 & 7 & 1 \\ 0 & 7 & 1 \\ 0 & 7 & 2 \\ 0 & 7 & 2 \\ 0 & 7 & 3 \\ 0 & 7 & 5 \\ 0 & 7 & 5 \\ 0 & 7 & 6 \\ 0 & 7 & 7 \\ 0 & 9 & 0 \\ 1 & 0 & 7 \\ 1 & 0 & 9 \\ 1 & 0 & 1 \\ 1 & 0 & 1 \\ 1 & 0 & 4 \\ 1 & 0 & 5 \\ 1 & 0 & 4 \\ 1 & 0 & 5 \\ 1 & 0 & 6 \\ 1 & 0 & 5 \\ 1 & 0 & 6 \\ 1 & 0 & 7 \\ 1 & 0 & 8 \\ 1 & 1 & 0 \\ 1 & 1 & 1 \\ 1 & 1 & 2 \\ 1 & 1 & 3 \\ 1 & 1 & 4 \\ \end{array}$	0	6	6
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$			-
0       7       0         0       7       1         0       7       2         0       7       2         0       7       3         0       7       5         0       7       6         0       7       7         0       9       0         1       0       1         1       0       4         1       0       4         1       0       5         1       0       6         1       0       8         1       1       1         1       1       1         1       1       3         1       1       3         1       1       4	0	6	9
0       7       1         0       7       2         0       7       3         0       7       5         0       7       5         0       7       6         0       7       7         0       9       0         1       0       1         1       0       4         1       0       5         1       0       6         1       0       8         1       1       1         1       1       2         1       1       3         1       1       4	0	7	0
0       7       2         0       7       3         0       7       5         0       7       6         0       7       7         0       9       0         1       0       1         1       0       4         1       0       5         1       0       6         1       0       8         1       1       1         1       1       1         1       1       3         1       1       3         1       1       4	0	7	1
0     7     3       0     7     5       0     7     6       0     7     7       0     9     0       1     0     1       1     0     4       1     0     5       1     0     6       1     0     8       1     1     1       1     1     3       1     1     3       1     1     4	0	7	2
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$			
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0	7	3
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	0 0	7	3 5
$\begin{array}{c ccccc} 0 & 9 & 0 \\ 1 & 0 & 0 \\ 1 & 0 & 1 \\ 1 & 0 & 1 \\ 1 & 0 & 4 \\ 1 & 0 & 5 \\ 1 & 0 & 6 \\ 1 & 0 & 7 \\ 1 & 0 & 8 \\ 1 & 1 & 0 \\ 1 & 1 & 1 \\ 1 & 1 & 2 \\ 1 & 1 & 3 \\ 1 & 1 & 4 \\ \end{array}$	0 0 0	7 7 7	3 5 6
$\begin{array}{c cccccc} 1 & 0 & 0 \\ \hline 1 & 0 & 1 \\ \hline 1 & 0 & 4 \\ \hline 1 & 0 & 5 \\ \hline 1 & 0 & 6 \\ \hline 1 & 0 & 7 \\ \hline 1 & 0 & 8 \\ \hline 1 & 1 & 0 \\ \hline 1 & 1 & 1 \\ \hline 1 & 1 & 2 \\ \hline 1 & 1 & 3 \\ \hline 1 & 1 & 4 \\ \end{array}$	0 0 0	7 7 7 7	3 5 6 7
$\begin{array}{c ccccc} 1 & 0 & 1 \\ \hline 1 & 0 & 4 \\ \hline 1 & 0 & 5 \\ \hline 1 & 0 & 6 \\ \hline 1 & 0 & 7 \\ \hline 1 & 0 & 8 \\ \hline 1 & 1 & 0 \\ \hline 1 & 1 & 1 \\ \hline 1 & 1 & 2 \\ \hline 1 & 1 & 3 \\ \hline 1 & 1 & 4 \\ \end{array}$	0 0 0 0	7 7 7 7 9	3 5 6 7 0
$\begin{array}{c ccccc} 1 & 0 & 4 \\ \hline 1 & 0 & 5 \\ \hline 1 & 0 & 6 \\ \hline 1 & 0 & 7 \\ \hline 1 & 0 & 8 \\ \hline 1 & 1 & 0 \\ \hline 1 & 1 & 1 \\ \hline 1 & 1 & 2 \\ \hline 1 & 1 & 3 \\ \hline 1 & 1 & 4 \\ \end{array}$	0 0 0 0 1	7 7 7 9 0	3 5 6 7 0
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0 0 0 0 1	7 7 7 9 0	3 5 6 7 0 0
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0 0 0 0 1 1	7 7 7 9 0 0	3 5 6 7 0 0 1 4
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0 0 0 1 1 1 1	7 7 7 9 0 0 0 0	3 5 6 7 0 0 1 4 5
1     0     8       1     1     0       1     1     1       1     1     2       1     1     3       1     1     4	0 0 0 1 1 1 1 1	7 7 7 9 0 0 0 0 0	3 5 6 7 0 0 1 4 5 6
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	0 0 0 1 1 1 1 1 1	7 7 7 9 0 0 0 0 0 0 0	3 5 6 7 0 0 1 4 5 6 7
1     1     1       1     1     2       1     1     3       1     1     4	0 0 0 1 1 1 1 1 1 1	7 7 7 9 0 0 0 0 0 0 0 0	3 5 6 7 0 0 1 4 5 6 7 8
1         1         2           1         1         3           1         1         4	0 0 0 1 1 1 1 1 1 1 1 1	7 7 7 9 0 0 0 0 0 0 0 0 1	3 5 6 7 0 0 1 4 5 6 7 8 0
1     1     3       1     1     4	0 0 0 1 1 1 1 1 1 1 1 1 1	7 7 7 9 0 0 0 0 0 0 0 0 1 1	3 5 6 7 0 0 1 4 5 6 7 8 0 1
1 1 4	0 0 0 1 1 1 1 1 1 1 1 1 1 1	7 7 7 9 0 0 0 0 0 0 0 0 1 1 1	3 5 6 7 0 0 1 4 5 6 7 8 0 1 2
	0 0 0 1 1 1 1 1 1 1 1 1 1 1 1	7 7 7 9 0 0 0 0 0 0 0 0 1 1 1 1 1	3 5 6 7 0 0 1 4 5 6 7 8 0 1 2 3

Y axis output pulse number	
Y axis motor feedback position	•
Z axis output pulse number	•
Z axis motor feedback position	•
4 <sup>m</sup> axis output pulse number	•
4th axis motor feedback position	
5th axis output pulse number	•
5th axis motor feedback position	•
MPG 1 counting (Rear cover MPG interface CN31)	
MPG 2 counting (Rear cover MPG interface CN32)	•
Spindle 1 encoder counting (Rear cover CN21)	•
Spindle 2 encoder counting (Rear cover CN22)	
The pulse number from the time that X axis starts detecting PC signal to PC signal is detected	•
The pulse number from the time that Y axis starts detecting PC signal to PC signal is detected	
The pulse number from the time that Z axis starts detecting PC signal to PC signal is detected	•
The pulse number from the time that 4 <sup>th</sup> axis starts detecting PC signal to PC signal is detected	•
The pulse number from the time that 5 <sup>th</sup> axis starts detecting PC signal to PC signal is detected	
The total times of system history underpressure	
The counts that power is low(Power is on)	
When power is low,times of not finishing save data (unit:ms)	
Nvram data accumulation error times	
Spindle encoder 1 detection linear number (Rear cover encoder interface CN21)	
Spindle encoder 2 detection linear number (Rear cover encoder interface CN22)	
The accumulation times of GDT data verification error along X axis	•
The accumulation times of GDT data verification error along Z axis	•
The accumulation times of GDT data verification error along Y axis	•
The accumulation times of GDT data verification error along 4TH axis	•
The accumulation times of GDT data verification error along 5TH axis	
The accumulation times of GDT data verification error of spindle 1	
The accumulation times of GDT data verification error of spindle 3	
The accumulation times of GDT data verification error of spindle 4	
The accumulation times of GDT data verification error of IO unit	
The accumulation times of GDT data verification error of gateway	

#### 5.1.3 Diagnosis Keys

DGN.016 $\sim$ DGN.024 are the diagnosis messages of edit keypad keys; DGN.024 $\sim$ DGN.029 are the diagnosis messages of machine operation panel keys. When pressing a key in the operation panel, the corresponding bit displays "1", and "0" after releasing this key. If it displays reversely, it means there is a fault in the keypad circuit.

0 1 6	VF1	RST	0	Ν	G	7	8	9
key		//		Ν	G	7	8	9
0 1 7	VF2	X	7	U	W	4	5	6
		X	7			-		
кеу					•••	_4	0	•
0 1 8	VF3	H/Y	F/E	R/V	D/L	1	2	3
key		$H_{\gamma}$	F	$R_{_{\!$		1	ນ	ß
		1/4		1//0				
0 1 9	VF4	I/A	J/B	K/C	P/Q	-	0	•
key		IA	JB	K	Pg	- + IJ		· < >
					1	<b>-</b>		
0 2 0	VF5		5		/、#	BLK	EOB	IN
key		M	S,	Τ_	/*		EOB	JAAM, BEBLI
0 2 1	VF6	PGU	PGD	CHG	INS/ALT	DEL	CAN	OUT
key				CHANGE	a an	11	•	B
				CHANK	& AITER	DECETE	DANGEL	
0 2 2	VF7	CRU	RIGHT	POS	RPG	OFT	ALM	SET
key		个			PROGRAM		ALARM	SETTING
0 2 3	VF8	CRD	LEFT	PAR	DGN	GRA	PLC	HELP
key		$\downarrow$	<	PARAMETER	DADADASS	GRAPH	PLC	HELP
			· · · · · · · · · · · · · · · · · · ·					
0 2 4	F1	F2	F3	F4	F5	F6	F7	F8
key								

### 5.2 PLC State

This part of diagnosis is used to detect the signal state of machine $\rightarrow$ PLC(X), PLC $\rightarrow$ machine(Y), CNC $\rightarrow$ PLC (F), PLC $\rightarrow$ CNC (G) and alarm address A states.

### 5.2.1 X Address (Machine→PLC , Defined by Standard PLC Ladders)

05: tool signal T05 RES: pressure check input signal
RES: pressure check input signal
SD:
SF. emergency stop signal
ITW: tailstock control input
ECX: X deceleration signal
IQP: chuck control input
P: external pause
AGT: safety door check signal
0001         T01         M42I         M41I         ST         DECZ         T08/CHOT         T07/IND2
01: tool signal T01
I42I: spindle automatic gear shifting 2-gear in-position signal
I41I: spindle automatic gear shifting 1-gear in-position signal
T: external cycle start
ECZ: Z deceleration signal
08/CHOT: tool signal T08/tool post worktable overheat
07/INDX: tool signal T07/Yantai tool post pregraduation input

T06/SELE: tool signal T06/Yantai tool post strobe signal

X0002			TCP	DEC5	DEC4	DECY	T04	T03	T02
TCP:	too	l post clar	np signal						
DEC5:	$5^{th}$	decelerati	ion signal						
DEC4:	4 <sup>th</sup>	decelerati	ion signal						
DECY:	Υd	leceleratio	on signal						
T04:	too	l signal T	04						
T03:	too	l signal T	03						
T02:	too	l signal T(	)2						

X0003		AEZ	AEX	SKIP	NQPJ	WQPJ	LMIZ	LMIY	LMIX
AEZ:	G3	7 skip sigi	nal		•				
AEX:	G36	6 skip sigi	nal						
SKIP:	G3 <sup>-</sup>	1 skip sigi	nal						
NQPJ:	inne	er chuck d	clamp/out	er chuck	clamp in-	position s	signal		
WQPJ:	inne	er chuck r	elease/o	uter chuc	k clamp ir	n-position	signal		
LMIZ:	Zo	vertravel	input						
LMIY:	Υo	vertravel	input						
LMIX:	Хо	vertravel	input						

X0005	***	***	***	***	***	***	***	SALM
SALM:	spindle 1 ab	normality	alarm inp	ut				
X0006	***	***	×100	×10	×1	ZHAN	YHAN	XHAN
×100:	increment ×	100 (exte	ernal)					
×10:	increment×1	0 (extern	nal)					
<b>x</b> 1:	increment×1	(externa	al)					
ZHAN:	Z selection	(external)	)					
YHAN:	Y selection	(external)	)					
XHAN:	X selection	external	)					
X0008	***	***	***	***	***	***	***	SALM2
SALM2:	the alarm in	nput signa	al of seco	nd spindl	e			
X0009	***	***	***	***	EXESP	***	SP	ST
EXESP:	External eme	rgency st	op input s	signal				
SP: E>	ternal pause							
ST: E>	ternal cycle sta	rt						

### 5.2.2 Y Address (PLC→Machine, Defined by Standard PLC Ladders)

SPZD:       spindle brake         SCLP:       spindle clamped         M05:       spindle stop         M04:       spindle rotation CCW         M03:       spindle rotation CW         M32:       lubricating output         COOL:       cooling output         Y0001       TL-         TL-:       TL-tool post rotation (CW)         TL+:       TL+tool post rotation(CCW)         DOQPS:       chuck release         DOQP k       shuck clamp
SCLP:       spindle clamped         M05:       spindle stop         M04:       spindle rotation CCW         M03:       spindle rotation CW         M32:       lubricating output         COOL:       cooling output         Image: TL-:       TL-         TL-:       TL-         TL-:       TL-tool post rotation (CW)         TL+:       TL+tool post rotation (CCW)         DOQPS:       chuck release         DOQP k       shuck slamp
M05:       spindle stop         M04:       spindle rotation CCW         M03:       spindle rotation CW         M32:       lubricating output         COOL:       cooling output         Y0001       TL-         TL-:       TL-         TL-tool post rotation (CW)         TL+:       TL+tool post rotation(CCW)         DOQPS:       chuck release
M04:       spindle rotation CCW         M03:       spindle rotation CW         M32:       lubricating output         COOL:       cooling output         Y0001       TL-         TL-:       TL-         TL-tool post rotation (CW)         TL+:       TL+tool post rotation(CCW)         DOQPS:       chuck release         DOOP Is       shuck clamp
M03:       spindle rotation CW         M32:       lubricating output         COOL:       cooling output         Y0001       TL-         TL-:       TL+         DOQPS:       chuck release         DOQPI       chuck release
M32: lubricating output COOL: cooling output Y0001 TL- TL+ DOQPS DOQPJ S4/M44 S3/M43 S42/M42 TL-: TL-tool post rotation (CW) TL+: TL+tool post rotation(CCW) DOQPS: chuck release
Y0001       TL-       TL+       DOQPS       DOQPJ       S4/M44       S3/M43       S42/M42         TL-:       TL-tool post rotation (CW)         TL+:       TL+tool post rotation(CCW)         DOQPS:       chuck release         DOOP I:       shuck clamp
Y0001       TL-       TL+       DOQPS       DOQPJ       S4/M44       S3/M43       S42/M42         TL-:       TL-tool post rotation (CW)         TL+:       TL+tool post rotation(CCW)         DOQPS:       chuck release         DOOP Is       shugk clamp
TL-:       TL-tool post rotation (CW)         TL+:       TL+tool post rotation(CCW)         DOQPS:       chuck release         DOOD I:       shuck clamp
TL+:     TL+tool post rotation(CCW)       DOQPS:     chuck release
DOQPS: chuck release
DOQPJ: Chuck clamp
S4/M44: spindle mechanical 4-gear
S3/M43: spindle mechanical 3-gear
S2/M42: spindle mechanical 2-gear

S1/M41: spindle mechanical 1-gear

Y0002	,	***	VP2	DOTWS	DOTWJ	CLPR	CLPG	CLPY	INDXS/TCLP	TZD/TLS
DOTWS:	tail	stock	going b	ackward						

DOTWJ: tailstock going forward

CLPR: three-color lamp-red

CLPG: three-color lamp-green

CLPY: three-color lamp-yellow

INDXS/TCLP: Yantai Tool post worktable pregraduation coil /LIO\_SHING Tool Post locked

TZD/TLS: Yantai Tool post worktable brake /LIO\_SHING Tool Post releasing

Y0003	UO5	UO4	UO3	U	02	UO1	UO0	HPST	***
UO5:	user macro	o output 5		<u> </u>		<u> </u>			
UO4:	user macro	o output 4							
UO3:	user macro	o output 3							
U2:	user macro	o output 2							
U1:	user macro	o output 1							
U0:	user macro	o output 0							
HPST:	hydraulic c	ontrol outpu	ıt						
Y0005	***	***	***	***	***	***	SRV	SFR	
SRV:	spindle rota	ation(CW)	1 1			11			

SFR: spindle rotation(CCW)

Y0008		***	***	***	***	***	***	SRV2	SFR2
SRV2:	seco	nd spindl	e CCW						

SFR2: second spindle CW

### 5.2.3 Machine Panel



GSK980TDi machine panel

11	0	N	G	Pa	7	8	9	DATA	POSITION	PARAMETER
	×	Z	U	W	4	5	6		PROGRAM	DIAGNOSIS
	$H_{\gamma}$	F	$\mathbf{R}_{\!$	L	1	2	З	CHANGE		GRAPH
<b>†</b>	$\neg$		JB	$\kappa_{c}$	-+	0	·< >	/ * #	ALARM	PLC
Ą	<-	M	s,	Τ_	UI DELETE		EOB		SETTING	HELP
	Y22.7	Y22.6	Y22	.5 Y	22.4	Y22.3	Y22.2	Y22.1	Y22	2.0
GEA	VTOOL NO.				UCHWE BRO	MPG MA	NUAL PROG			1
Y	X1 25 Y2	8.0 X1 3.7 Y2	8.1 X1 3.6 Y2	8.2 X1 3.5 Y2	8.3 X 3.4 Y	18.4 X1 23.3 Y2	8.5 X19 3.2 Y18	0.3 X26 0.2 Y26	.3 X24 .3 Y24	.2 .2
SINGLE	SKIP	MACHINE	MST CHO M.S.T. LOCK	DRY	OPTIONAL STOP	MPG INTERRUPT	JTLX1 ℃ F0	JLX10 11 25%	JTLX100 1 50%	JTLX1000 100%
X18.6 Y18.7	X18.7 Y18.6	X19.0 Y18.5	X19.1 Y18.4	X19.2 Y18.3	X20.0 Y21.7	X24.1 Y24.1	X19.4 Y19.7	X19.5 Y19.6	X19.6 Y19.5	X19.7 Y21.5
TS.		-	-	-		the state of the s	-	and the second se		
		4th	Ð	СНИСК	COOLING	LIGHT	S. OW	<b>小%</b> + S. OVERRIDE	WM%+ F. OVERRIDE	CYCLE START
X20.2 Y19.3	X20.3 Y19.4	X21.0 Y21.4	X20.1 Y21.6	СНИСК Х26.6 У26.6	COOLING X21.4 Y23.0	Цієнт X26.0 Y26.0	X21.7 Y19.1	10%+ s. override X22.1 Y20.6	WW %+ F. OVERRIDE X22.3 Y20.4	CYCLE START X23.0 Y20.0
X20.2 Y19.3	X20.3 Y19.4	X21.0 Y21.4	2) X20.1 Y21.6 C/S	СНИСК Х26.6 У26.6	X21.4 Y23.0	X26.0 Y26.0 W26.0	X21.7 Y19.1	10%+ s. 0VERRIDE X22.1 Y20.6	<b>WW.%</b> + F. OVERRIDE X22.3 Y20.4 <b>WW.100%</b> F. OVERRIDE	CYCLE START X23.0 Y20.0
X20.2 Y19.3 Z20.5 Y19.2	X20.3 Y19.4 NAPLD X20.6 Y18.1	X21.0 Y21.4 Z20.7 Y28.2	20.1 Y21.6 C/S X25.7 Y21.3	Сниск Х26.6 У26.6 Тацетоск Х26.5 У26.5	COOLING X21.4 Y23.0 LUBRICATING X21.6 Y20.7	X26.0 Y26.0 V26.0 DHIP DW X24.6 Y24.6	X21.7 Y19.1 Constant S.STOP X21.5 Y18.0	10%+ s 0VERRIDE X22.1 Y20.6 ↓ 06 X25.5 Y21.1	₩₩%+ F. DVERRIDE X22.3 Y20.4 ₩100% F. OVERRIDE X26.7 Y26.7	X23.0 Y20.0
X20.2 Y19.3 X20.5 Y19.2	X20.3 Y19.4 RAPID X20.6 Y18.1	X21.0 Y21.4 Z20.7 Y28.2	5) X20.1 Y21.6 C/S X25.7 Y21.3	СНИСК Х26.6 У26.6 ТАЦБТОСК Х26.5 У26.5	COOLING X21.4 Y23.0 V LUBRICATING X21.6 Y20.7	Х26.0 У26.0 Ю:) СНР СМ Х24.6 У24.6	Х21.7 У19.1 ФО з. sтор Х21.5 У18.0		₩₩%+ F DVERRIDE X22.3 Y20.4 ₩100% F DVERRIDE X26.7 Y26.7 ¥26.7	VICLE START X23.0 Y20.0
X20.2 Y19.3 X20.5 Y19.2 X20.5 Y19.2 X20.4 X20.4 Y28.3	X20.3 Y19.4 X20.6 Y18.1 X20.6 Y18.1 X21.1 Y28.0	X21.0 Y21.4 X20.7 Y28.2 X20.7 Y28.2 X21.2 Y28.1	<ul> <li>x20.1</li> <li>y21.6</li> <li>C/S</li> <li>x25.7</li> <li>y21.3</li> <li>x25.6</li> <li>y28.4</li> </ul>	Сниск Х26.6 Ү26.6 Тацьтоск Х26.5 Ү26.5 НУОКАЦИС Х26.4 Ү26.4	COOLING X21.4 Y23.0 LUBRICATING X21.6 Y20.7 Z21.6 Y20.7	Х26.0 Y26.0 V26.0 Снир Сму X24.6 Y24.6 V24.6 V24.6 X24.7 X24.7	X21.7 Y19.1 V19.1 X21.5 Y18.0 X21.5 Y18.0 X21.3 S. CCW X21.3 Y23.1	₽%+ s. 0VERRIDE          X22.1         Y20.6         0         0         J06         X25.5         Y21.1         1         1         0         S. 0VERRIDE         X22.4         Y20.3	₩₩%- F DVERRIDE X22.3 Y20.4 ₩₩100% F DVERRIDE X26.7 Y26.7 ¥26.7 Y26.7 ₩₩%- E OVERRIDE X22.6 Y20.1	Х23.0 Y20.0

GSK980TDi-V machine panel

### 5.2.4 F Address(CNC $\rightarrow$ PLC)

F0000	]	OP	SA	STL	SPL	***	***	***	RWD
OP:	Auto run	signal							
SA:	Servo rea	ady signa	I						
STL:	Cycle sta	art indicate	or signal						
SPL:	Feed hol	d indicato	or signal						
F0001	]	MA	TCEN	TAP	ENB	DEN	***	RST	AL

- MA: CNC ready signal
- TCEN: Tool-change allowable signal
- TAP: Tapping signal
- ENB: Spindle enable signal
- DEN: Designation end signal
- RST: Reset signal
- AL: Alarm signal

F0002	1	MDRN	CUT	***	SRNMV	THRD	CSS	RPDO	INCH
MDRN:	Dry rur	n detecti	on signal						
CUT:	Cutting	feed sig	gnal						
SRNMV:	Progra	m start	signal						
THRD:	Thread	ing sign	al						
CSS:	Consta	ant surfa	ce speed	l signal					
RPDO:	Rapid f	eed sig	nal						
INCH:	Inch in	put sign	al						
F0003	لز	***	MEDT	MMEM		MMDI	MJ	MH	MINC
MEDT:	Memory	y edit se	lection d	etection s	ignal				

- MMEM: Auto run selection detection signal
- MMDI: MDI selection detection signal
- MJ: JOG selection detection signal
- MH: MPG selection detection signal
- MIR. MIR G Selection detection signal

MINC: Increment feed detection signal

F0004		***	MPST	MREF	MAFL	MSBK	MABSM	MMLK	MBDT1		
MPST:	Prog	ram begii	nning retu	irn detect	tion signa	l					
MREF:	Man	ual refere	ence retur	n detectio	on signal						
MAFL:	MST	lock dete	ection sig	nal							
MSBK:	Sing	Single block detection signal									
MABSM:	JOG	JOG absolute detection signal									
MMLK:	All n	All machine axes lock detection signal									
MBDT1:	Opti	Optional block skip detection signal									

F0007		***	***	***	***	TF	SF	***	MF
TF: T	ool functi	on strobe	signal						

- SF: Spindle speed strobe signal
- MF: MST function strobe signal

F0009	D	00M0	DM01	DM02	DM30	***	***	***	***
DM00:	M decoding	g signa							
DM01:	M decoding	g signa	l						
DM02:	M decoding	g signa	I						
DM30:	M decoding	g signa	I						

	F0010	MB07	MB06	MB05	MB04	MB03	MB02	MB01	MB00
--	-------	------	------	------	------	------	------	------	------

F0011	MB15	MB14	MB13	MB12	MB11	MB10	MB09	MB08
F0012	MB23	MB22	MB21	MB20	MB19	MB18	MB17	MB16
F0013	MB31	MB30	MB29	MB28	MB27	MB26	MB25	MB24

Miscellaneous function codes MB00~MB31

F0022	SB07	SB06	SB05	SB04	SB03	SB02	SB01	SB00
F0023	SB15	SB14	SB13	SB12	SB11	SB10	SB09	SB08
F0024	SB23	SB22	SB21	SB20	SB19	SB18	SB17	SB16
F0025	SB31	SB30	SB29	SB28	SB27	SB26	SB25	SB24

Spindle speed code signal SB00~SB31

F0026	TB07	TB06	TB05	TB04	TB03	TB02	TB01	TB00
F0027	TB15	TB14	TB13	TB12	TB11	TB10	TB09	TB08
F0028	TB23	TB22	TB21	TB20	TB19	TB18	TB17	TB16
F0029	TB31	TB30	TB29	TB28	TB27	TB26	TB25	TB24

Tool function code signal TB00~TB31

F0036	R08O	R07O	R06O	R05O	R04O	R03O	R02O	R010
F0037	***	***	***	***	R120	R110	R100	R090
04011		<b>D</b> 400						

S12 bit code signal R010~R120

F0040	AR7	AR6	AR5	AR4	AR3	AR2	AR1	AR0
F0041	AR15	AR14	AR13	AR12	AR11	AR10	AR9	AR8
Oraliza all a								

Spindle actual speed AR0~AR15

F0044		***	***	***	***	***	***	FSCSL	***	-
	Tho 1ct o	pindlo or	Itling con	trol chiftin	a and sig	inal				

FSCSL: The 1st spindle outline control shifting end signal

F0045		***	RTAPA	PSRA	SARA	TLMA	ORARA	SSTA	ALMA
	oorioo o	aiadla 1 r	iaid toppir						

RTAPA: series spindle 1 rigid tapping signal

PSRA: Series spindle1 position arrival signal

- SARA: Series spindle1 speed arrival signal
- TLMA: Series spindle1torque arrival signal

ORARA: Series spindle1orientation completion signal

- SSTA: Series spindle1zero-speed signal
- ALMA: Series spindle1alarm signal

F0049	***	RTAPB	PSRB	SARB	TLMB	ORARB	SSTB	ALMB

RTAPB: series spindle 2 rigid tapping signal

PSRB: Series spindle2position arrival signal

SARB: Series spindle2 speed arrival signal

TLMB: Series spindle2orque arrival signal

ORARB: Series spindle2orientation completion signal

SSTB: Series spindle2zero-speed signal

ALMB: Series spindle2alarm signal

F0053		***	RTAPC	PSRC	SARC	TLMC	ORARC	SSTC	ALMC
RTAPC:	series s	pindle 3 r	igid tappin	ig signal					

PSRC: Series spindle3 position arrival signal

SARC: Series spindle3 speed arrival signal

TLMC: Series spindle3torque arrival signal

ORARC: Series spindle3orientation completion signal

SSTC: Series spindle3zero-speed signal

ALMC: Series spindle3alarm signal

F0054	UO07	UO06	UO05	UO04	UO03	UO02	UO01	UO00
F0055	UO15	UO14	UO13	UO12	UO11	UO10	UO09	UO08
N 4	 111000	11045						

Macro output signal UO00~UO15

	_								
F0056		U107	U106	U105	U104	U103	U102	U101	U100
F0057		U115	U114	U113	U112	U111	U110	U109	U108
F0058		U123	U122	U121	U120	U119	U118	U117	U116
F0059		U131	U130	U129	U128	U127	U126	U125	U124
Maaraa			404						

Macro output signal U100~131

F0064		***	***	***	***	***	***	TLNW	TLCH
	Now tool	coloction	signal (fo	r tool life	managar	nont)			

TLNW: New tool selection signal (for tool life management) TLCH: Tool change signal(for tool life management)

F0065	***	***	***	***	***	***	RGSPM	RGSPP
RGSPM: Spind	le CCW ro	tation (in	rigid tapp	ing)			•	
RGSPP: Spindl	e CW rota	tion (in rig	jid tapping	g)				
F0076	***	***	***	***	RTAP	***	***	***
RTAP: rigid tap	ping metho	od signal	1	1			1 1	
F0091	***	***	***	***	MMMO	D ***	***	***
MMMOD: Mode	e signal; it	informs s	ystem of t	the manu	al trial cut	t mode;		I
F0094	***	***	***	ZP5	ZP4	ZP3	ZP2	ZP1
ZP5~ZP1: Re	ference po	oint return	end sign	al ZP5~Z	P1		11	
F0096	***	***	***	ZP25	ZP24	ZP23	ZP22	ZP21
ZP25~ZP21: Th	ne 2 <sup>nd</sup> Refe	erence po	int return	end signa	al ZP25~2	ZP21	1 1	
F0098	***	***	***	ZP35	ZP34	ZP33	ZP32	ZP31
ZP35~ZP31: Th	ne 3 <sup>rd</sup> Refe	erence po	int return	end signa	al ZP35~Z	ZP31	1 1	
F0100	***	***	***	ZP45	ZP44	ZP43	ZP42	ZP41
ZP45~ZP41: Th	ne 4 <sup>th</sup> Refe	rence poi	nt return	end signa	al ZP45~Z	ZP41		
F0102	***	***	***	MV5	MV4	MV3	MV2	MV1
	L	1	1	1	1	1	1 1	

MV5~MV1: Axis move signal MV5~MV1

F0106	*** ***	***	MVD5	MVD4	MVD3	MVD2	MVD1	]
MVD5~MVD1	Axis move dire	ection signal	MVD5~M	VD1			4	-
F0120	*** ***	***	ZRF5	ZRF4	ZRF3	ZRF2	ZRF1	]
ZRF5~ZRF1:	Reference point	creation sig	nal ZRF5~	ZRF1				
					_			
F0127	*** ***	***	ABLE5	ABLE4	ABLE3	ABLE2	ABLE1	
ABLE5~ ABLI	E1: axis active sig	nal ABLE5~	ABLE1					
			1		T	1	<u>,</u>	
F0129	*** ***	***	***	***	***	***	KEAXS	L
KEAXSL: PLO	Caxis control statu	us selection s	signal					
F0130	EBSYA *	** ***	EGENA	EDEN	A ***	***	***	
EBSYA: PLC	axis control group	A command	read com	pleted sig	gnal			
EGENA: PLC	axis control group	A axis mov	ement sigr					
EDENA: PLC	axis control group	A auxiliary 1	runction im	iplement	signai			
<b>E0121</b>	*** ***	***	***	***	***			
						EABUE		1
	PLC axis control g	Jroup A buffe	er tull signa	ll Na straka				
EMFA:	PLC axis control g	group A auxii	lary function	on strobe	signai			
E0122		24A EM22						111 0
								VIIIA
FLC axis com	ioi gioup A auxila		oue signa					
F0133	FBSYB *	** ***	FGENE		IB ***	**	* *	**
EBSYB PL	Caxis control grou	ID B commai	nd read co	mpleted	signal			
EGENB: PL	C axis control grou	up B axis mo	ovement si	anal	orginal			
EDENB: PL	C axis control gro	up B auxiliar	v function	impleme	nt signal			
	0			•	0			
F0134	*** ***	***	***	***	***	EABUF	B EMFE	3
EABUFB:	PLC axis control g	roup B buffe	er full signa	al				
EMFB:	PLC axis control	, proup B auxil	liary function	on strobe	signal			
			,		U			
F0135	EM28B EM	24B EM22	B EM21	B EM18	BB EM1	4B EM1	2B EN	M11B
PLC axis cont	rol group A auxilia	ary function c	ode signa	Is EM11E	B~EM28B	·		
	<b>-</b> .		·					
F0136	EBSYC *	** ***	EGENO		IC ***	**	ć* 7	***
EBSYC: PLC	axis control group	C command	d read con	pleted s	ignal	1	I	
EGENC: PLC	axis control group	o C axis mov	ement sig	nal	-			
EDENC: PLC	axis control group	C auxiliary	function in	nplement	signal			
	5 1	,		-	-			
F0137	*** ***	***	***	***	***	EABUF	CEMF	2
EABUFC:	PLC axis control of	aroup C buffe	er full signa	al	1	1	<u> </u>	

EMFC: PLC axis control group C auxiliary function strobe signal

F0138		EM28C	EM24C	EM220	C EM210	C EM18	BC	EM14	CE	M12C	EM1	1C
PLC axi	s control	group A a	uxiliary fu	nction co	ode signal	s EM11C	C~EI	M28C				
F0139		EBSYD	***	***	EGEND	EDEN	ID	***		***	***	
EBSYD	PLC axi	s control g	group D c	ommand	read com	pleted si	igna	d				]
EGEND	: PLC axi	is control	group D a	ixis move	ement sigr	nal						
EDEND	: PLC axi	s control	group D a	uxiliary i	mplement	signal						
F0140		***	***	***	***	***	***		ΕΑΒι	JFD E	MFD	
EABUFI	D: PLO	C axis con	trol group	D buffe	r full signa	I						
EMFD:	PLC	C axis con	trol group	D auxili	ary functio	n strobe	sig	nal				
F0141		EM28D	EM24D	EM220	D EM210	D EM18	8D	EM14	DE	M12D	EM1	1D
PLC axi	s control	group A a	uxiliary fu	nction co	ode signal	s EM11C	)~El	M28D	I			
F0142		EM48A	EM44A	EM42A	EM41A	EM38	BA	EM34A	A E	M32A	EM3	1A
PLC axi	s control	group A a	uxiliary fu	nction co	ode signal	s EM31A	ا⊐~∧	M48A			1	
Fn144		***	***	***	***	***	***	·	FSCS	SL2 ***	·	
FSCSL2	2: The 2 <sup>nd</sup>	spindle o	utline cor	ntrol shift	ing end sig	gnal	I			Į		
		•			0	-						
F0145		EM48B	EM44B	EM42E	B EM41E	EM38	BB	EM34E	B E	M32B	EM3 <sup>-</sup>	1B
PLC axi	s control	group B a	uxiliary fu	Inction co	ode signal	s EM3B	A~E	M48B				]
			-		-							
F0148		EM48C	EM44C	EM420	C EM410	C EM3	BC	EM34	CE	M32C	EM3	81C
PLC axi	s control	group C a	uxiliary fu	unction c	ode signal	s EM310	C~E	M48C	Į			
			-		•							
F0151		EM48D	EM44D	EM42[	D EM41	D EM3	8D	EM34	DE	M32D	EM3	B1D
PLC axi	s control	group D a	uxiliary fu	unction c	ode EM31	D~EM48	3D					]
			-									
F0182		***	***	***	EACNT5	EACN	IT4	EAC	VT3	EACN	[2 E/	ACNT
EACNT	5: PLC a	kis control	5th axis	control si	gnal							
EACNT	4: PLC a	kis control	4th axis	control si	gnal							
EACNT	3: PLC a	kis control	Y axis co	ontrol sigi	nal							
EACNT	2: PLC a	kis control	Z axis co	ontrol sigi	nal							
EACNT	1: PLC a	kis control	X axis co	ontrol sig	nal							
F0198		***	***	***	PRO5	PRO4	PF	RO3   I	PRO	2 PRC	)1	
PRO4:	Program	n zero retu	urn end si	gnal PR	D5			I		1		
PRO4:	Program	n zero retu	urn end si	gnal PR	D4							
PRO3:	Program	n zero retu	urn end si	gnal PR	<b>D</b> 3							
PRO2:	Program	n zero retu	urn end si	gnal PR	D2							
PRO1:	Program	n zero retu	urn end si	gnal PR	D1							

 F0199
 \*\*\*
 \*\*\*
 \*\*\*
 \*\*\*
 MSPHD

MSPHD	: Spine	dle JOG c	letection s	signal						
F0200		***	***	***	SIMSPL	***	***	***	***	
SIMSPL	: Anal	og spindle	e active							
F0201		***	***	DECI	***	***	DCS	***	***	
DECI:	DEC sig	gnal level	selection	in referer	nce returr	ו				
DCS:	If OUT	key may	start prog	ram in MI	DI mode					
F0205		***	***	***	***	***	ZNIK	***	***	
ZNIK:	Axis m	ove key h	old active	e in zero r	eturn					
		-								
F0207		TN7	TN6	TN5	TN4	TN3	TN2	TN1	TN0	
total too	ls numbe	r								]
F0210		***	MST	MSP	***	MESP	***	SINC	SOV	/
MST:	Shield	external	cvcle star	t signal						
MSP:	Shield	d external	feed hold	l signal						
MESP	Shield	d external	emergen	icv stop s	ional					
	Chief		ennergen		ignai					
F0212		***	***	***	COVL	CINP	CDWL	***	***	
COVI	Bit ch	eck being	Lexecuter	4		•				
CINP.	G04 (	code bein	a execute	2 2						
	RS23	32 interfac	e beina r	eceivina						
02112	1.020		o bonig i	oconting						
F0213		***	***	***	***	***	***	CTRD	CTP	11
	RS2	32 interfa	ce heina i	transmitti	na		ļ	01110	0.11	<u> </u>
CTPU:	Spin	dle ioa/lut	oricating s		ing					
011 0.	Opin	ale jog/lai	Sheating a	Sciection						
F0214		***	***	***				7\/41	<u></u> Υ\/Δ	
	<sup>th</sup> avis dir	ection sel	ection		VALU	VALT	VALI	ZVAL		<b>L</b>
	th avis di	rection se								
	diraction									
	direction									
	direction		1 ~							
VALA. A	anection	rselection	1							
F0215		SGR07	SGR06	SGR05	SGR04	4 SGR	03 SGF	R02 SGF	R01	SGR00
F0216		***	***	***	***	SGR	11 SGF	R10 SG	R09	SGR08
Speed o	ommand	signal for	l r gear shif							56100
opecu e		Signal 10	gour orm		CONT					
			1			1		1		

F0240		INP07	INP06	INP05	INP04	INP03	INP02	INP01	INP00
F0241		INP15	INP14	INP13	INP12	INP11	INP10	INP09	INP08
Input sp	eed com	mand of s	pindle INF	200~ INP	15				
F0250		SYS7	SYS6	SYS5	SYS4	SYS3	SYS2	SYS1	SYS0

system type 0:980TDi 1:980TDi-V

5.2.5	G Add	dress (I	PLC→(	CNC)					
G0004		***	***	***	***	FIN	***	***	***
FIN:	MST fu	nction en	d signal						]
			-						
G0005		***	AFL	***	***	***	***	***	***
AFL:	MST lo	ock signal				4	l	II	]
SFIN:	Spindle	S function	on end sig	gnal					
G0006		***	SKIPP	***	OVC	***	ABSM	***	SRN
OVC:	Feedr	ate overri	de cance	l signal					
SRN:	Progra	am restar	t signal						
				-					<u>.</u>
G0007		RLSOT	EXLM	***	***	***	ST	STLK	***
ST:	Cycle	start sign	al						
	1							· · · · · · · · · · · · · · · · · · ·	
G0008		ERS	RRW	SP	ESP	***	***	***	IT
ERS:	External	reset sig	nal						
RRW:	Reset a	nd cursor	return sig	gnal					
SP:	Feed ho	ld signal							
ESP:	Emerge	ncy stop s	signal						
00010		11/07	11/00	11/05	11/04	11/02	11/00	11/04	11/00
G0010			JV06	JV05	JV04	JV03	JV02		JV00
	orrido oig		JV14	JV13	JVIZ	JVII	JV10	1009	JV00
JOG 00	ernue sig	nai JV00-	-1415						
G0012		E\/07	E\/06	E\/05	EV/04	E\/03	E\/02	EV/01	E\/00
Feedrat	e override	signal F	1 000 V00~EV0	1 000	1 004	1 000	1 002	1 001	1 000
reculat	e overnue	s Signal i	v00~i v0	,,					
G0014		***	***	***	***	***	***	RV2	RV1
RV2 <sup>·</sup> F	Rapid fee	drate ove	rride sian	al RV2					
RV1: F	Rapid fee	drate ove	rride sign	al RV1					
G0018		H2D	H2C	H2B	H2A	H1D	H1C	H1B	H1A
H2D: I	MPG 2 fe	ed selecti	on signal	(01015th	ו ר)				
H2C	MPG 2 fe	ed select	ion signa	I (01004t	<i>,</i> h)				
H2B: N	MPG 2 fee	ed selecti	on signal	(0011Y)					
H2A: N	MPG 2 fee	ed selecti	on signal	(0001X.	0010Z)				
H1D: I	MPG 1 fe	ed selecti	on signal	(01015tł	ר)				
H1C	MPG 1 fe	ed select	ion signa	l (01014t	h)				
H1B: N	MPG 1 fee	ed selecti	on signal	(0011Y)					
H1A: N	MPG 1 fee	ed selecti	on signal	(0001X.	0010Z)				
G0019		RT	***	MP2	MP1	***	***	***	***

RT: Manual rapid feed selection signal

MP2: MPG override signal MP2

MP1: MPG override signal MP1

R021

R011

G0027		CON	***	SSTP3	SSTP2	SSTP1	***	SWS2	SWS1
CON:	Cs conte	ouring co	ntrol swite	ch signal	•	•	•		<u> </u>
SSTP3:	3 <sup>rd</sup> spine	dle stop s	ignal (for	multi-spin	ndle functi	on)			
SSTP2:	2nd spir	ndle stop	signal (fo	r multi-spi	indle func	tion)			
SSTP1:	1st spin	dle stop s	ignal (for	multi-spir	ndle funct	ion)			
SWS2:	Multi-sp	indle sele	ction sigr	nal 2					
SWS1:	Multi-sp	indle sele	ction sigr	nal 1					
G0028		***	***	***	***	***	GR2	GR1	***
GR2: Ge	ear selec	tion signa	l				•		
GR1: Ge	ear selec	tion signa	d						
G0029		***	KSSTF	<b>&gt;</b> ***	SAR	GR32	GR31	GR2	2 GR2
		LI		1	1	1		1	1

KSSTP: spindle stop signal

SAR: spindle speed arrival

GR32: 3<sup>rd</sup> spindle gear selection signal 2 (for multi-spindle function)

GR31: 3<sup>rd</sup> spindle gear selection signal 1 (for multi-spindle function)

GR22: 2nd spindle gear selection signal 2 (for multi-spindle function)

GR21: 2nd spindle gear selection signal 1 (for multi-spindle function)

G0030		SOV7	SOV6	SOV5	SOV4	SOV3	SOV2	SOV1	SOV0		
SOV7: 2nd Spindle override signal SOV7											
SOV6: 2	2nd Spind	lle overric	le signal	SOV6							
SOV5: 2	2nd Spind	lle overric	le signal	SOV5							
SOV4: 2	2nd Spind	lle overric	le signal	SOV4							
SOV3: 1	st Spindl	e override	e signal S	SOV3							
SOV2: 1	st Spindl	e override	e signal S	SOV2							
SOV1: 1	st Spindl	e override	e signal S	SOV1							
SOV0: 1	st Spindl	e override	e signal S	SOV0							

G0032	]	R08I	R07I	R06I	R05I	R04I	R03I
R08I:	Spindle m	notor spee	ed code s	signal R08	31		
R07I:	Spindle m	notor spee	ed code s	ignal R07	<b>'</b>		
R06I:	Spindle m	notor spee	ed code s	signal R06	61		
R05I:	Spindle m	notor spee	ed code s	signal R05	51		
R04I:	Spindle m	notor spee	ed code s	ignal R04	H		
R03I:	Spindle m	notor spee	ed code s	signal R03	31		
R02I:	Spindle m	notor spee	ed code s	signal R02	21		
R01I:	Spindle m	notor spee	ed code s	ignal R01	1		

G0033	]	SIND	***	***	***	R12I	R11I	R10I	R09I		
SIND:	Spindle r	Spindle motor speed code selection signal									
R12I:	Spindle m	notor spee	ed code s	ignal R12	21						
R11I:	Spindle m	notor spee	ed code s	ignal R11	I						
R10I:	Spindle m	notor spee	ed code s	ignal R10	)I						

R09I:	Spindle n	lotor spee	eu coue s	ignal Rus	91				
G0039	]	GOQSN	/ WOQ	SM **	* ***	***	***	***	***
GOQSN	M: Toc	l offset w	riting mod	de select	signal				
WOQSI	M: Workp	iece coor	dinate sys	stem offs	et writing	mode sel	ect signa	I	
	7								
G0040		WOSET	PRC	***	***	***	***	***	***
WOSE	T: Workpie	ce coord	inate syst	em offset	t writing s	ignal			
PRC:	Absolute	e coordina	ate postic	on record	signal				
G0043	7	7RN	***	DNC1	***	***	MD4	MD2	MD1
7RN-	Current	mode sel	ection 4	BROT				MDZ	
DNC1	DNC se	lection sid	nal						
MD4:	Current	mode sel	ection 3						
MD2:	Current	mode sel	ection 2						
MD1:	Current	mode sel	ection 1						
G0044	]	HDT	***	***	***	***	***	MLK	BDT
HDT:	J Manual t	ool chang	ge signal	I			I		
MLK:	Machine	lock sigr	al(PLC→	CNC)					
BDT:	Block sk	ip signal (	(PLC→CI	NC)					
			•						
G0046	1	DRN	***	***	***	KEY1	***	SBK	***
DRN:	」 Dry run s	ignal	ļ	ļ		<u> </u>	ļ	I	<u> </u>
KEY1:	Memory	protectio	n sianal						
			n Signai						
SBK:	Single blo	ock signal	(PLC→C	NC)					
SBK:	Single blo	ock signal	(PLC→C	NC)					
SBK: <b>G0047</b>	Single blo	ock signal	(PLC→C	NC) TL32	TL16	TL08	TL04	TL02	TL01
SBK: <b>G0047</b> Tool gro	Single blo ] oup numb	TL128 er select	(PLC→C TL64 signal TL	NC) TL32 01~TL128	TL16	TL08	TL04	TL02	TL01
SBK: <b>G0047</b> Tool gro	Single blo	TL128 er select	(PLC→C TL64 signal TL	CNC) TL32 01~TL128	TL16 8	TL08	TL04	TL02	TL01
SBK: <b>G0047</b> Tool gro <b>G0048</b>	Single blo ] pup numb	TL128 TL128 er select	(PLC→C TL64 signal TL	NC) TL32 01~TL128 TLSKP	TL16 8	TL08	TL04	TL02	TL01
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST:	Single blo ] pup numb ] tool char	TL128 er select TLRST nge reset	(PLC→C TL64 signal TL *** signal	NC) TL32 01~TL128 TLSKP	TL16 8	TL08	TL04	TL02	TL01
SBK: G0047 Tool gro G0048 TLRST: TLSKP:	Single blo pup numb tool char tool skip	TL128 er select TLRST nge reset signal	(PLC→C TL64 signal TL *** signal	NC) TL32 01~TL128 TLSKP	TL16 8	TL08	TL04	TL02	TL01
SBK: G0047 Tool gro G0048 TLRST: TLSKP:	Single blo pup numb tool char tool skip	TL128 er select TLRST nge reset signal	(PLC→C TL64 signal TL *** signal	NC) TL32 01~TL128 TLSKP	TL16 8	TL08	TL04	TL02	TL01
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b>	Single blo pup numb tool char tool skip	TL128 er select TLRST nge reset signal	(PLC→C TL64 signal TL *** signal	NC) TL32 01~TL128 TLSKP	TL16 8 ***	TL08 ***	TL04 ***	TL02 ***	TL01 ***
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b>	Single blo pup numb tool char tool skip	TL128 er select TLRST nge reset signal UI07 UI15	(PLC→C TL64 signal TL *** signal UI06 UI14	NC) TL32 01~TL128 TLSKP UI05 UI13	TL16 8 *** UI04 UI12	TL08 *** UI03 UI11	TL04 *** UI02 UI10	TL02 *** UI01 UI09	TL01 *** UI00 UI08
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U	Single blo pup numb tool char tool skip	TL128 er select TLRST nge reset signal UI07 UI15 cro input	(PLC→C TL64 signal TL4 *** signal <b>UI06</b> <b>UI14</b> signal UI0	NC) TL32 01~TL128 TLSKP UI05 UI05 UI13 00~UI15	TL16 8 *** UI04 UI12	TL08 *** UI03 UI11	TL04 *** UI02 UI10	TL02 *** UI01 UI09	TL01 *** UI00 UI08
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U	Single blo pup numb tool char tool skip	TL128 er select TLRST nge reset signal UI07 UI15 cro input	(PLC→C TL64 signal TL *** signal <b>UI06</b> <b>UI14</b> signal UI0	NC) TL32 01~TL128 TLSKP UI05 UI13 00~UI15	TL16 8 ///////////////////////////////////	TL08 *** UI03 UI11	TL04 *** UI02 UI10	TL02 *** UI01 UI09	TL01 *** UI00 UI08
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0061</b>	Single blo pup numb tool char tool skip	TL128 er select TLRST nge reset signal UI07 UI15 cro input	(PLC→C TL64 signal TL4 signal dl6 UI06 UI14 signal UI0 ***	NC) TL32 01~TL128 TLSKP UI05 UI13 00~UI15 RGTSP	TL16 8 1*** UI04 UI12 2 RGTS	TL08 *** UI03 UI11 SP1 **	TL04 *** UI02 UI10	TL02 *** UI01 UI09	TL01 *** UI00 UI08 ** RGT
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0061</b> RGTAP	Single blo Dup numb tool char tool skip	TL128         TL128         er select         TLRST         nge reset         signal         UI07         UI15         cro input         ****         tapping s	(PLC→C TL64 signal TL *** signal UI06 UI14 signal UI0 ***	NC) TL32 01~TL128 TLSKP UI05 UI13 00~UI15 RGTSP	TL16 8 UI04 UI12 2 RGTS	TL08 *** UI03 UI11 SP1 **	TL04 *** UI02 UI10	TL02 *** UI01 UI09	TL01 *** UI00 UI08
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0061</b> RGTSP	Single blo Dup numb tool char tool skip 115: Ma 115: Ma	TL128         TL128         er select         TLRST         nge reset         signal         UI07         UI15         cro input         ***         tapping s         dle selection	(PLC→C TL64 signal TL signal TL signal UI06 UI14 signal UI0 **** signal	NC) TL32 01~TL128 TLSKP UI05 UI13 00~UI15 RGTSP d tapping	TL16 8 *** UI04 UI12 2 RGTS RGTSP1	TL08 *** UI03 UI11 SP1 **	TL04 *** UI02 UI10	TL02 *** UI01 UI09 *** **	TL01 *** UI00 UI08 ** RGT
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0061</b> RGTAP RGTSP RGTSP	Single blo Dup numb tool char tool skip 115: Ma 2: Rigid 21: Spino 22: Spino	CK signal TL128 er select TLRST nge reset signal UI07 UI15 cro input *** tapping s dle selection	(PLC→C TL64 signal TL signal TL signal UI06 UI14 signal UI0 *** signal ion in rigio ion in rigio	TL32 01~TL128 TLSKP UI05 UI13 00~UI15 RGTSP d tapping d tapping	TL16 8 ///////////////////////////////////	TL08 *** UI03 UI11 SP1 * <sup>1</sup>	TL04 *** UI02 UI10 ** *	TL02 *** UI01 UI09 *** **	TL01 *** UI00 UI08 ** RG1
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0061</b> RGTSP RGTSP RGTSP	Single blo Dup numb tool char tool skip 115: Ma 115: Ma 2: Rigid 21: Spino	TL128         TL128         er select         TLRST         nge reset         signal         UI07         UI15         cro input         ***         tapping s         dle selection	(PLC→C TL64 signal TL signal TL signal UI06 UI14 signal UI0 **** signal ion in rigio	NC) TL32 01~TL128 TLSKP UI05 UI13 00~UI15 RGTSP d tapping d tapping	TL16 8 *** UI04 UI12 2 RGTS RGTSP1 RGTSP2	TL08 *** UI03 UI11 SP1 ***	TL04 *** UI02 UI10 ** ** **	TL02 *** UI01 UI09 *** **	TL01  *** UI00 UI08  ** RGT
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0061</b> RGTAP RGTSP RGTSP <b>G0070</b>	Single blo Dup numb tool char tool skip 115: Ma 115: Ma 2: Rigid 21: Spino 22: Spino	CK signal TL128 er select TLRST nge reset signal UI07 UI15 cro input *** tapping s dle select dle select HLVA	(PLC→C TL64 signal TL signal TL signal UI06 UI14 signal UI0 *** signal ion in rigio ion in rigio BREFA	NC) TL32 01~TL128 TLSKP UI05 UI13 00~UI15 RGTSP d tapping d tapping SFRA	TL16 8 <b>UI04</b> <b>UI04</b> <b>UI12</b> <b>2 RGTS</b> RGTSP1 RGTSP2 RGTSP2	TL08 *** UI03 UI11 SP1 **	TL04 *** UI02 UI10 ** *:	TL02  ***  UI01 UI09  **  A ZSLA	TL01  *** UI00 UI08  ** RGT
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0061</b> RGTSP RGTSP RGTSP <b>G0070</b> HLVA:	Single blo Dup numb tool char tool skip 115: Ma 115: Ma 21: Spino 22: Spino 22: Spino	TL128         TL128         er select         TLRST         nge reset         signal         UI07         UI15         cro input         ***         tapping s         dle selection         HLVA         pindle 1 h	(PLC→C TL64 signal TL signal TL signal UI06 UI14 signal UI0 **** signal ion in rigio ion in rigio ion in rigio	NC) TL32 01~TL128 TLSKP UI05 UI13 00~UI15 RGTSP d tapping d tapping SFRA peed shif	TL16         8         ***         UI04         UI12         2       RGTSP1         RGTSP2         SRVA         ting signa	TL08 *** UI03 UI11 SP1 ** TAPA al	TL04 *** UI02 UI10 *** **	TL02 *** UI01 UI09 *** ** A ZSLA	TL01  *** UI00 UI08  ** RGT
SBK: <b>G0047</b> Tool gro <b>G0048</b> TLRST: TLSKP: <b>G0054</b> <b>G0055</b> UI00~U <b>G0056</b> UI00~U <b>G0061</b> RGTSP RGTSP RGTSP <b>G0070</b> HLVA: BREFA	Single blo Dup numb tool char tool skip 115: Ma 2: Rigid 21: Spino 22: Spino 22: Spino 23: series s	TL128         TL128         er select         TLRST         nge reset         signal         UI07         UI15         cro input         ****         tapping selection         dle selection         HLVA         pindle 1 h         pindle 1 r	(PLC→C TL64 signal TL signal TL signal UI06 UI14 signal UI0 *** signal ion in rigio ion in rigio BREFA nigh/low s nechanica	NC) TL32 01~TL128 TLSKP UI05 UI05 UI13 00~UI15 RGTSP d tapping d tapping SFRA peed shif al locking	TL16 8  v*** UI04 UI12 2 RGTSP1 RGTSP1 RGTSP2 SRVA ting signal	TL08         ***         UI03         UI11         SP1       **         TAPA         al	TL04 *** UI02 UI10 ** ORCM	TL02  *** UI01 UI09  ** *	TL01  *** UI00 UI08  ** RGT

SRVA: series spindle 1 rotation signal CCW(negative)

TAPA: series spindle 1 rigid tapping signal

ORCMA: series spindle 1 orientation start signal

ZSLA: series spindle 1 zero clamping signal

ARSTA: series spindle 1 alarm cleaning signal

G0074		HLVB	BREFB	SFRB	SRVB	TAPB	ORCMB	ZSLB	ARSTB		
HLVB:	series s	pindle 1 h	high/low sp	eed shift	ing signal						
BREFB:	EFB: series spindle 1 mechanical locking signal										
SFRB:	series s	pindle 1 r	otation sig	nal CW(p	ositive)						
SRVBA:	series s	pindle 1 r	otation sig	nal CCW	(negative	e)					
TAPB:	series s	pindle 1 r	igid tappin	g signal							
ORCME	s: seri	ies spindl	e 1 orienta	ation start	signal						
ZSLB:	series s	pindle 1 z	ero clamp	ing signa	l						
ARSTB:	series s	pindle 1 a	alarm cleai	ning signa	al						

G0078		HLVC	BREFC	SFRC	SRVC	TAPC	ORCMC	ZSLC	ARSTC
HLVC:	series s	pindle 1 ł	nigh/low sp	eed shift	ing signal				
BREFC:	series s	pindle 1 r	nechanica	l locking :	signal				
SFRC:	series s	pindle 1 r	otation sig	nal CW (	positive)				
SRVC:	series s	pindle 1 r	otation sig	nal CCW	(negative	e)			
TAPC:	series s	pindle 1 r	igid tappin	g signal					
ORCMC	: seri	ies spindl	e 1 orienta	ation start	signal				
ZSLC:	series s	pindle 1 z	zero clamp	ing signa	l				
ARSTC:	series s	pindle 1 a	alarm clear	ning signa	al				

G0100	]	***	***	***	+J5	+J4	+J3	+J2	+J1
+J1: F	eed axis	and direc	tion selec	tion signa	al +J1				

- +J2: Feed axis and direction selection signal +J2
- +J3: Feed axis and direction selection signal +J3
- +J4: Feed axis and direction selection signal +J4
- +J5: Feed axis and direction selection signal +J5

G0102		***	***	***	-J5	-J4	-J3	-J2	-J1
-J1: Fe	ed axis a	and direct	ion selec	tion signa	ıl -J1				

-J2: Feed axis and direction selection signal -J2

- -J3: Feed axis and direction selection signal -J3
- -J4: Feed axis and direction selection signal -J4
- -J5: Feed axis and direction selection signal –J5

G0114	ŀ	***	***	***	+L5	+L4	+L3	+L2	+L1
+L1:	Axis overt	ravel sign	al +L1						
+L2:	Axis overt	ravel sign	al +L2						
+L3:	Axis overtravel signal +L3								
+L4:	Axis overt	ravel sign	al +L4						
+	_5: Axis c	overtravel	signal +L	.5					

	_		4.4.4		4.4.4						
G011	6		***	***	***	-L5	-L4	-L3	-L2	-	_1
-L1:	Axis	overtr	avel signa	al -L1							
-L2:	Axis	overtr	avel signa	al -L2							
-L3:	Axis	overtr	avel signa	al -L3							
-L4:	Axis	overtr	avel signa	al -L4							
-L5:	Axis	overtr	avel signa	al –L5							
G013	6		***	***	***	EAX5	EAX4	EAX3	EAX	2   E/	X1
EAX5	i: Ax	is 5th	select sig	gnal of PL	_C contro	l					
EAX4	: Ax	is 4th	select sig	gnal of PL	_C control	l					
EAX3	: Ax	is Y s	elect sign	al of PLC	control						
EAX2	: Ax	is Z s	elect sign	al of PLC	control						
EAX1	: Ax	is X s	elect sign	al of PLC	control						
G014	1		***	***	***	***	EABSD	EABS	SC EA	BSB	EABSA
EABS	SD: I	PLC c	ontrol gro	up D is a	bsolute (1	1)/relative	(0) coor	dinate			
EABS	SC: I	PLC c	ontrol gro	up C is a	bsolute (1	1)/relative	(0) coor	dinate			
EABS	SB: F	PLC c	ontrol gro	up B is al	bsolute (1	)/relative	(0) coord	dinate			
EABS	SA: F	PLC c	ontrol gro	up A is al	osolute (1	)/relative	(0) coord	linate			
G014	2		EBUFA	ECLRA	ESTP/	A ESOF	A ESB	KA EN	/IBUFA	***	EFINA
EBUF	A:	Inst	truction re	ading sig	gnal of PL	C control	group A	Į			_!
ECLR	RA:	Re	set signal	of PLC c	control gro	oup A					
ESTP	A:	Axi	s pause s	ignal of F	PLC contr	ol group A	4				
ESOF	A:	Ser	vo off sig	nal of PL	C control	group A					
ESBK	KA:	Sin	gle block	stop sign	al of PLC	control o	roup A				
EMBL	JFA:	Buf	- fer prohib	ition sign	al of PLC	control g	roup A				
EFIN/	A:	Aux	kiliary fund	ction finis	h signal c	of PLC co	ntrol grou	Jp A			
			,		U		0	•			
C014	2		EC74	ECGA	EC5A	EC44			20 6		ECOA

 G0143
 EC7A
 EC6A
 EC5A
 EC4A
 EC3A
 EC2A
 EC1A
 EC0A

 Control instruction signal of PLC control group A
 EC3A
 EC3A

G0144		EIF7A	EIF6A	EIF5A	EIF4A	EIF3A	EIF2A	EIF1A	EIF0A		
G0145		EIF15A	EIF14A	EIF13A	EIF12A	EIF11A	EIF10A	EIF9A	EIF8A		
	Frederic additional of DLO constant maxim A										

Feed speed signal of PLC control group A

G0146	EID7A	EID6A	EID5A	EID4A	EID3A	EID2A	EID1A	EID0A
G0147	EID15A	EID14A	EID13A	EID12A	EID11A	EID10A	EID9A	EID8A
G0148	EID23A	EID22A	EID21A	EID20A	EID19A	EID18A	EID17A	EID16A
G0149	EID31A	EID30A	EID29A	EID28A	EID27A	EID26A	EID25A	EID24A
	 -							

Data signal of PLC control group A

G0150		***	***	***	***	***	***	ROV2E	ROV1E		
ROV2E	Rapid ra	tio signal	of PLC c	ontrol							
ROV1E: Rapid ratio signal of PLC control											
G0151		FV7E	FV6E	FV5E	FV4E	FV3E	FV2E	FV1E	FV0E		

Feed ratio signal of PLC control

G0154		EBUFB	ECLRB	ESTPB	ESOFB	ESBKB	EMBUFB	***	EFINB
EBUFB:	Inst	truction rea	ading signa	al of PLC	control gro	oup B			
ECLRB:	Res	set signal o	of PLC cor	ntrol group	в				
ESTPB:	Axi	s pause si	gnal of PL	C control	group B				
ESOFB:	Ser	vo off sign	al of PLC	control gro	oup B				
ESBKB:	Sin	gle block s	stop signal	of PLC co	ontrol grou	ір В			
EMBUFE	B: Buf	fer prohibi	tion signal	of PLC co	ontrol grou	ір В			
EFINB:	Aux	kiliary func	tion finish	signal of F	PLC contro	ol group B			

G0155		EC7B	EC6B	EC5B	EC4B	EC3B	EC2B	EC1B	EC0B
Control i	nstructio	n signal of	FPLC con	trol aroun	R				

ontrol instruction signal of PLC control group B

G0156	EIF7B	EIF6B	EIF5B	EIF4B	EIF3B	EIF2B	EIF1B	EIF0B
G0157	EIF15B	EIF14B	EIF13B	EIF12B	EIF11B	EIF10B	EIF9B	EIF8B
			6					

Feed speed signal of PLC control group B

G0158	EID7B	EID6B	EID5B	EID4B	EID3B	EID2B	EID1B	EID0B
G0159	EID15B	EID14B	EID13B	EID12B	EID11B	EID10B	EID9B	EID8B
G0160	EID23B	EID22B	EID21B	EID20B	EID19B	EID18B	EID17B	EID16B
G0161	EID31B	EID30B	EID29B	EID28B	EID27B	EID26B	EID25B	EID24B
		-						

Data signal of PLC control group B

G0166	EBUFC	ECLRC	ESTPC	ESOFC	ESBKC	EMBUFC	***	EFINC
EBUFC:	Instruction re	ading signa	al of PLC	control gro	up C			
ECLRC:	Reset signal	of PLC cor	ntrol group	С				
ESTPC:	Axis pause si	gnal of PL	C control	group C				
ESOFC:	Servo off sigr	nal of PLC	control gro	oup C				
ESBKC:	Single block	stop signal	of PLC co	ontrol grou	рС			
EMBUFC:	Buffer prohib	ition signal	of PLC co	ontrol grou	рС			
EFINC:	Auxiliary fund	tion finish	signal of F	PLC contro	l group C			

G0167	[	EC7C	EC6C	EC5C	EC4C	EC3C	EC2C	EC1C	EC0C
Control ins	struction	n signal of	PLC con	С					

G0168		EIF7C	EIF6C	EIF5C	EIF4C	EIF3C	EIF2C	EIF1C	EIF0C
G0169		EIF15C	EIF14C	EIF13C	EIF12C	EIF11C	EIF10C	EIF9C	EIF8C
Food an ordinated of PLC control group C									

Feed speed signal of PLC control group C

G0170		EID7C	EID6C	EID5C	EID4C	EID3C	EID2C	EID1C	EID0C
G0171		EID15C	EID14C	EID13C	EID12C	EID11C	EID10C	EID9C	EID8C
G0172		EID23C	EID22C	EID21C	EID20C	EID19C	EID18C	EID17C	EID16C
G0173		EID31C	EID30C	EID29C	EID28C	EID27C	EID26C	EID25C	EID24C
Data sig	inal of PL	C control	group C						
G0178		EBUFD	ECLRD	ESTPD	ESOFD	ESBKD	EMBUFD	***	EFIND

- EBUFD: Instruction reading signal of PLC control group D
- Reset signal of PLC control group D ECLRD:
- Axis pause signal of PLC control group D ESTPD:
- Servo off signal of PLC control group D ESOFD:

Single block stop signal of PLC control group D ESBKD:

EMBUFD: Buffer prohibition signal of PLC control group D

EFIND: Auxiliary function finish signal of PLC control group D

G0179		EC7D	EC6D	EC5D	EC4D	EC3D	EC2D	EC1D	EC0D
Control i	nstructio	n signal of	f PI C con	trol aroup	D				

ol instruction signal of PLC control group D

G0180		EIF7D	EIF6D	EIF5D	EIF4D	EIF3D	EIF2D	EIF1D	EIF0D
G0181		EIF15D	EIF14D	EIF13D	EIF12D	EIF11D	EIF10D	EIF9D	EIF8D
Food speed signal of DLC control group D									

Feed speed signal of PLC control group D

G0182	EID7D	EID6D	EID5D	EID4D	EID3D	EID2D	EID1D	EID0D
G0183	EID15D	EID14D	EID13D	EID12D	EID11D	EID10D	EID9D	EID8D
G0184	EID23D	EID22D	EID21D	EID20D	EID19D	EID18D	EID17D	EID16D
G0185	EID31D	EID30D	EID29D	EID28D	EID27D	EID26D	EID25D	EID24D

Data signal of PLC control group D

G0200		***	***	***	***	***	***	***	SPD
SPD	Spindle	jog signa	l						

G0201		NT07	NT06	NT05	NT04	NT03	NT02	NT01	NT00
NT00:	Current t	ool No. N	Т00						
NT01:	Current t	ool No. N	T01						
NT02:	Current t	ool No. N	T02						
NT03:	Current t	ool No. N	T03						
NT04:	Current t	ool No. N	T04						
NT05:	Current t	ool No. N	T05						
NT06:	Current t	ool No. N	T06						
NT07:	Current t	Current tool No. NT07							
G0202		NT15	NT14	NT13	NT12	NT11	NT10	NT09	NT08
NT08:	Current tool No. NT08								

NT08:	Current t	Current tool No. NT08									
NT09:	Current t	Current tool No. NT09									
NT10:	Current t	ool No. N	IT10								
NT11:	Current t	ool No. N	IT11								
NT12:	Current t	ool No. N	IT12								
NT13:	Current t	ool No. N	IT13								
NT14:	Current t	ool No. N	IT14								
NT15:	Current t	ool No. N	IT15								
G0203	NT23 NT22 NT21 NT20 NT19 NT18 NT17 NT16										
NT16:	Current tool No. NT16										
NT17:	Current tool No. NT17										

- NT18: Current tool No. NT18NT19: Current tool No. NT19NT20: Current tool No. NT20NT21: Current tool No. NT21NT22: Current tool No. NT22
- NT23: Current tool No. NT23

G0204		NT31	NT30	NT29	NT28	NT27	NT26	NT25	NT24
NT24:	Current t	ool No. N	IT24						
NT25:	Current t	ool No. N	IT25						
NT26:	Current t	ool No. N	IT26						
NT27:	Current t	ool No. N	IT27						
NT28:	Current t	ool No. N	IT28						
NT29:	Current t	ool No. N	IT29						
NT30:	Current t	ool No. N	IT30						
NT31:	Current t	ool No. N	IT31						

## 5.2.6 Address A (Message Display Requiery Signal, Defined by Standard PLC Ladders)

Address	Alarm No.	Content
A0000.0	1000	Tool change too long
A0000.1	1001	Tool post not in-position alarm as tool change ends
A0000.2	1002	Tool change unfinished alarm
A0000.3	1003	Tool post clamping signal not received
40000 /	1004	Recheck clamping signal, and clamping signal inactive as tool
A0000.4	1004	change ends
A0000.5	1005	Tool change execution is mistaken before power off
A0000.6	1006	Pre-indexing proximity switch not arrived
A0000.7	1007	Tool post overheat alarm
A0001.0	1008	M10 and M11 codes disabled for tailstock function inactive
A0001.1	1009	Run-out disabled in spindle running
A0001.3	1011	Spindle start unallowed as tailstock advancing not detected
A0001.4	1012	Cycle unallowed for cycle start disabled
A0001.5	1013	Spindle start unallowed for spindle enable off
A0001.6	1014	Confirm the tools of tool post (8, 10, 12 tools)
A0002.0	1014	Please reset BIT1, BIT0 of parameter 168 for tool post model
A0002.1	1016	Alarm of safe door not closed
A0002.3	1017	Alarm of chuck low pressure
A0002.4	1019	Chuck released unallowed in spindle running
A0002.5	1020	Clamping in-position signal inactive alarm in spindle running
A0002.6	1021	Spindle start unallowed if chuck clamping in-position signal inactive
A0003.0	1022	Spindle start unallowed for chuck releasing
A0003.0	1024	M12/M13 code disabled as chuck inactive
A0003.1	1025	Has not checked the chuck clamped/released start signal
A0003.3	1027	The tool pot is not released

Address	Alarm No.	Content
A0003.4	1028	Has not found the target tool
A0003.5	1029	Has not received tool pot stop and locking start signal
A0002 7	1021	Total tools is more than 4, and the external override cannot be
A0003.7	1031	connected
A0004.1	1032	Illegal M code
A0004.2	1033	Spindle jog disabled in non-analog spindle mode
A0004.3	1035	M63, M64 designation error
A0004.4	1036	Spindle gear change time is too long
A0004.5	1037	Spindle speed/position control switch time is too long
A0004.6	1038	The 2nd spindle speed/position control switch time is too long
A0004.7	1039	Spindle position control does not permit the orientation
A0005.0	1040	Spindle orientation time is too long
A0005.1	10/1	Alarm for the abnormal spindle servo or frequency converter for
	1041	abnormality
A0005.2	1042	Alarm for the abnormal 2nd spindle servo or frequency converter
A0005.3	1043	Forbid clamping the spindle when the spindle rotating or feeding
A0005.4	1044	Spindle is clamped not to rotate or feed
A0007.0	2000	Hydraulic motor is not started
A0007.1	2001	Safety door has been opened
A0007.3	2003	Alarm for the tool pot unclocked
A0007.5	2005	Feedrate override is fixed to 100%,can't be adjusted
A 0 0 0 7 C	2006	The panel override is disabled when the external override is
AUUU7.6	2006	enabled.
A0007 7	2007	The program can not be operated due to the external dwell switch is
AUUU7.7	2007	cut off.
A0008.0	2008	The axis can not be moved due to the manual override is 0.
A0008.3	2011	Machining numbers are reached to the setting one.

### CHAPTER 6 MEMORIZING PITCH ERROR COMPENSATION

#### 6.1 Function Description

There are more or less precision errors in the pitch of machine axes lead screw, and it will definitely affect the parts machining precision. This GSK980TDi CNC system has the memorizing pitch error offset function that it can accurately compensate the pitch error of the lead screw.

### 6.2 Specification

- 1) The set offset amount is concerned with the offset origin, offset intervals etc.;
- Pitch error offset value is get by searching the table about machine coordinates and pitch error compensation origin;
- Points to be compensated: 1200 points for 5 axes, each axis confirms point range by parameter setting;
- 4) Axis compensated: X, Y, Z ,4th,5th axis
- 5) Compensation range: -2550~2550×least input increment;
- 6) Compensation interval: 10000~99999999××least input increment;
- Compensation amount of compensation point N(N=0,1,2,3,...1023) is determined by the mechanical error between point N and point N-1;
- 8) The setting is the same as the CNC parameters input, see II Operation.

### 6.3 Parameter Setting

#### 6.3.1 Pitch Compensation

Bit parameter

0	0	3				PCOMP					
Bit5=1: Pitch error offset active;											

Bit5=0: Pitch error offset inactive;

### 6.3.2 Pitch Error Compensation Number

Set the maximum pitch error compensation number and the minimum pitch error compensation number of each axis through parameters No.096 and No.097 so that the compensation range can be determined. In an offset value list, the number that corresponds to machine zero point is called pitch error compensation origin (reference point). The pitch error compensation origin is set by parameter No. 098. It can be any value within the compensation range according to mechanical requirement.

Data parameter

0	9	6

PECMINn

The maximum pitch error compensation number

#### PECMAXn

The minimum pitch error compensation number

098

PECORGn

0.0001 mm

0.00001 inch

The pitch error compensation number that corresponds to machine zero point

### 6.3.3 Pitch error compensation interval

Metric machine

Inch machine

099		PECINTn				
[Meaning]	Interval between	pitch error co	npensation point			
[Unit]						
	Setting Unit	IS-B	IS-C			

0.001 mm

0.0001 inch

Гг	<b>-</b>		- T
h	≺аr	101	е Г
			<u> </u>

	IS-B	IS-C
Metric machine	1000~999999	10000~9999999
Inch machine	400~999999	4000~9999999

### 6.3.4 Offset Value

Pitch error offset amount of each axis is set according to the following table, and offset amount is input in diameter value without relating to diameter programming or radius programming, and the input value unit is the least input increment.

Offset No.	Offset value	Z	Offset value
000	0	0200	0
001	5	0201	-2
002	-3	0202	4

### 6.4 Notes of Offset Setting

The setting and alteration of pitch offset can only be done at the authority of password level 2.
 After the parameter of pitch offset is set, only the machine zero is returned could the offset be done.

### 6.5 Setting Examples of Offset Parameters

Assume that the pitch error compensation range is 0~255.

① Data parameter No.098 (pitch error origin) =0, Data parameter No.099 (offset interval)=10.000 When the pitch error origin is set to 0:

The offset value for the 1<sup>st</sup> segment is set by the position No.001 in the offset table, the offset value for the 2<sup>nd</sup> segment is set by the position No.002 in the offset table, and the offset value for the Nth segment is set by the position No.000+N in the offset table.

The machine zero is regarded as the reference point of pitch error origin, it begins to compensate

the position No.001 in the offset table from the machine zero. So the pitch error offset can only be done in the positive moving direction of the machine coordinate system.



The position No.000 in the offset table corresponds to the reference point (i.e. pitch error origin 0), the offset point 1 corresponds to a point of positive 10.000 moving from this reference point, and So there is a offset point every 10.000 mm. I. At offset point N, set an offset value which is the compensation amount by moving from (N-1) × (offset interval) to N×(offset interval).

The following table content is resulted from the above:

Machine coordinate	Offset	Offset	Drive unit current code	Drive unit current command
system	parameter No.	value	pulses before compensating	pulses after compensating
Reference point 0	000	000	00000	00000
10.000	001	7	10000	10007
20.000	002	-6	20000	20001
30.000	003	4	30000	30005
	004			

Actually the machine moves from the reference point to the point of +30.000, the pitch error offset is: (+7) + (-6) + (+4) = +5

②Data parameter No.098 (pitch error origin) =60, No.099 (offset interval) =10.000 When the pitch error origin is set to 60:

For the positive moving, the 1<sup>st</sup> segment error offset is set by position No.061 in the offset table, the 2<sup>nd</sup> segment by position No.062. The Nth segment error offset is set by position No.060+N in the offset table.

For the negative moving, the 1<sup>st</sup> segment error offset is set by position No.060 in the offset table, the 2<sup>nd</sup> segment by position No.059. The Nth segment error offset is set by position No.060-N in the offset table.

The machine zero is taken as the reference point of the pitch error origin, when moving from the positive of machine coordinate system, it begins to compensate by the corresponding position No.061 in the offset table; when moving from the negative of the machine coordinate system, it begins to compensate by the position No.060. Therefore the pitch offset can be done when moving in the positive or the negative axis of machine coordinate system.



The position No.060 in the offset table corresponds to the reference point, No.061value in the

compensation table is a compensation amount by executing a positive movement 10.000mm from origin. So there is an offset point every 10.000. No.061value in the compensation table is a compensation amount by executing a negative movement 10.000mm from origin. So there is an offset point every -10.000. No.59 is a compensation amount at -10.000~-20.000mm. Therefore the point N is set by an offset of move from (N-61) × (offset interval) to (N-60) × (offset interval).

The following table content is resulted from the above:

Machine coordinate system	Offset parameter No.	Offset value	Drive unit current code pulses before compensating	Drive unit current code pulses after compensating
-30.000	058	-7	-30000	-29992
-20.000	059	-7	-20000	-19999
-10.000	060	+6	-10000	-10006
Reference point 0			0	0
10.000	061	+4	10000	10004
	062			

Actually as the machine moves from point -30.000 to the point +10.000, the pitch error offset is: (-7)+(-7)+(+6)+(+4)=(-4)

③Data parameter No.098 (pitch error origin) =127, No.099 (offset interval) =10.000

When the pitch error origin is set to 255:

The offset value for the 1<sup>st</sup> segment is set by the position No.255 in the offset table, the offset value for the 2<sup>nd</sup> segment is set by the position No.254 in the offset table, and the offset value for the Nth segment is set by the position No.256-N in the offset table.

The machine zero is regarded as the reference point of pitch error origin, the system compensates the compensate amount set by No.255 in the offset table from the machine zero to the negative direction. So the pitch error compensation can be executed when the machine coordinates are less than 0.



The position No.255 is an offset value from reference point to -10.000mm, No.254 value in the table is the one from -10.000mm to -20.000mm, so there is an offset point every -10.000. Therefore the point N is set by an offset of move from (N-256)×(offset interval) to (N-255)×(offset interval).

Above is the example of the following offset interval error.

Machine	Offset	Offset value	Drive unit current	Drive unit current
coordinate	parameter		code pulses before	code pulses after
system	number		compensating	compensating
Reference point 0			0	0
-10.000	127	2	10000	10002
-20.000	126	0	20000	20002
-30.000	125	-7	30000	29995
-40.000	124	3	40000	39998

Actually the machine moves from the point -40.000 to the reference point, the pitch error offset is: (+3) + (-7) + (0) + (+2) = (-2).

#### 6.5.1 Rotation Axis Pitch Error Compensation

Addition axis is the linear or rotation axis (Type B), the pitch error compensation method is identical with the common linear axis. The pitch error compensation function in which the addition axis is regarded as the rotation axis (Type A); refer to the following explanations:

- Movement value per revoltion: 360°
- Pitch error position interval: 45°
- The compensation position number of reference point: 60

After the above-mentioned parameters are set, the farthest position number along the negative direction of the rotation axis equals to the compensation position number of the reference point;

The farthest compensation number along with the positive direction is as follows:

Compensation position number of reference point + (Movement value per revolution/Compensation position interval) = 60 + 360/45 = 68;

The corresponding relationships between the machine coordinate and compensation position number are shown below:

# IV Appendix

APPENDIX I GSK980TDi, GSK980TDi-V APPEARANCE DIMENSION

### 1.1 GSK980TDi Appearance Dimension



GSK980TDi appearance dimension
## 1.2 GSK980TDi-V Appearance Dimension



User istallation drawing



GSK980TDi-V appearance dimension

## APPENDIX II OUTLINE DIMENSION of ACCESSIONAL PANEL

### 2.1 Outline Dimension of Accessional Panel AP01A

AP01: Accessional Panel of GSK980TDi, can be fixed below the panel and the outline dimension is as follow:



#### 2.2 Outline Dimension of Accessional Panel AP03A

AP01B: Accessional Panel of GSK980TDi-V, can be fixed at the side of panel and the outline dimension is as follows:



## APPENDIX III OUTLINE DIMENSION of I/O Deconcentrator MCT01B



# APPENDIX IV OUTLINE DIMENSION of I/O Deconcentrator MCT06R

For installation, debugging and maintenance of the product, our company has already developed the brand-new I/O deconcentrator MCT06-R with the relay to reduce the faults, such as the product running abnormal and the component damage, etc due to the incorrect connection during installation and connection. MCT06-R deconcentrator is composed of the deconcentrator basic module, the relay extension module and the spindle servo transfer module or some of them and it is configurated eight specifications based on the user requirements.



TYPE		MCT06-R1	MCT06-R2	MCT06-R3	MCT06-R4
OVERALL					
DIMENSION		180*125	255*125	330*125	405*125
(mm*mm)					
Form	The deconcentrator basic module	1 piece	1 piece	1 piece	1 piece
	The relay extension module	Opc (0 relay )	1pc(8 <b>relays</b> )	2pcs (16 <b>relays</b> )	3pcs (24 relays)

## APPENDIX $\,\mathrm{V}\,$ Delivery standard parameter

	Standard parameter	Standard parameter	User parameter
State parameter	(servo 1u-level)	(servo 0.1u-level)	(backup)
001	00000000	00011010	
002	0000010	0000010	
003	00010000	00010000	
004	0100000	0100000	
005	00010010	00010010	
006	0000000	0000000	
*007	1000000	1000000	
008	00011111	00011111	
009	0000000	0000000	
010	00001111	00011111	
011	00000000	0000000	
012	10101011	10101011	
013	00000000	0000000	
014	00011111	00011111	
017	00001000	00001000	
018	00000000	0000000	
020	00000000	0000000	
172	01100000	01100000	
174	00001000	00001000	
*175	0000000	0000000	
180	00000000	0000000	
181	11100000	11100000	
183	0000000	0000000	
184	0000000	0000000	
185	0000000	0000000	
186	0000000	0000000	
187 X	0000010	0000010	
Z	0000010	0000010	
188 X	01000101	01000101	
Z	01000101	01000101	
189 X	00100000	00100000	
Z	00100000	00100000	
190 X	0000000	0000000	
Z	0000000	0000000	
195 S1	0100000	0100000	
S2	0000000	0000000	
\$3	0000000	0000000	
196	0000000	0000000	
202	00000000	00000000	
201	0000001	0000001	
203	00000000	0000000	
250	0000001	0000001	



State	Standard parameter 1	Standard parameter 3	User parameter
parameter	(servo 1u-level)	( servo 0.1u-level )	(backup)
015 X	1	1	
Z	1	1	
016 X	1	1	
Z	1	1	
019	5	5	
021 S1	0	0	
S2	0	0	
022 X	4000	4000	
Z	8000	8000	
*023 X	100	100	
Z	100	100	
024	0	0	
025	0	0	
*026	100	100	
*027	8000	8000	
*028	200	200	
*029	100	100	
*030	200	200	
031	1260	1260	
032 X	200	200	
Z	400	400	
033 X	100	100	
Z	200	200	
034 X	0	0	
Z	0	0	
035	0	0	
036 S1	0	0	
S2	0	0	
S3	0	0	
037 S1	9999	9999	
S2	9999	9999	
S3	9999	9999	
038 S1	9999	9999	
S2	9999	9999	
S3	9999	9999	
039 S1	9999	9999	
S2	9999	9999	
S3	9999	9999	
040 S1	9999	9999	
S2	9999	9999	
S3	9999	9999	
*041	100	100	
042	10	10	
043	99	99	
044	115200	115200	
045 X	99999999	99999999	
Z	99999999	99999999	

State	Standard parameter 1	Standard parameter 3	User parameter
parameter	( servo 1u-level )	( servo 0.1u-level )	( backup )
046 X	-99999999	-99999999	
Z	-99999999	-99999999	
047 X	0	0	
Z	0	0	
048	0	0	
049	0	0	
050	0	0	
051	1	1	
052	0	0	
053	0	0	
054	0	0	
055	1	1	
056	0	0	
057	1	1	
058	0	0	
059	0	0	
060	0	0	
061	0	0	
062	0	0	
063	0	0	
064	0	0	
065	0	0	
066	0	0	
067 S1	100	100	
S2	100	100	
S3	100	100	
068 S1	0	0	
S2	0	0	
\$3	0	0	
069 S1	1	1	
\$2	0	0	
\$3	0	0	
070 S1	1024	1024	
S2	1024	1024	
\$3	1024	1024	
071	32	32	
072	50	50	
073 31	65535	65555	
\$2	65535	65535	
\$3	65535	65535	
074 S1	0	0	
S2	0	0	
S3	0	0	
075 S1	0	0	
S2	0	0	
\$3	0	0	
076 S1	0	0	



State	Standard parameter 1	Standard parameter 3	User parameter
parameter	( servo 1u-level )	( servo 0.1u-level )	( backup )
S2	0	0	
S3	0	0	
077	0	0	
078	0	0	
079	0	0	
080	0	0	
081	0	0	
082	0	0	
083	0	0	
084	4	4	
085	0	0	
086	0	0	
087	0	0	
088	0	0	
089	0	0	
090	0	0	
091	0	0	
092	0	0	
093	0	0	
094	0	0	
095	0	0	
096 X	0	0	
Z	200	200	
097 X	199	199	
Z	399	399	
098 X	100	100	
Z	300	300	
099 X	10000	100000	
Z	10000	100000	
100 X	0	0	
Z	0	0	
101 X	0	0	
Z	0	0	
102 X	0	0	
Z	0	0	
103 X	0	0	
Z	0	0	
104	0	0	
105	0	0	
106	U	0	
107	0	0	
108	0	0	
109	40	40	
110 51		1	
52		1	
53		1	
111-51	I	I	

State	Standard parameter 1	Standard parameter 3	User parameter
parameter	( servo 1u-level )	( servo 0.1u-level )	(backup)
\$2	1	1	· ·
S3	1	1	
112	0	0	
113 X	3800	3800	
Z	7600	7600	
114 X	0	0	
Z	0	0	
115	0	0	
116	0	0	
117	0	0	
118	0	0	
119	3	3	
120 X	0	0	
Z	0	0	
121 X	0	0	
Z	0	0	
122 X	0	0	
Z	0	0	
123 X	0	0	
Z	0	0	
124	0	0	
125	0	0	
126	0	0	
127	0	0	
128	0	0	
129	0	0	
130	0	0	
131	0	0	
132	0	0	
133	0	0	
134	1	1	
135	0	0	
136	0	0	
137	0	0	
138	0	0	
139	0	0	
140	1000	1000	
141	100	100	
142	10000	100000	
143	20000	200000	
144	7500	75000	
145	15000	150000	
146	0	0	
147	0	0	
148	35	35	
149	0	0	
150	0	0	



State	Standard parameter 1	Standard parameter 3	User parameter
parameter	(servo 1u-level)	( servo 0.1u-level )	( backup )
151	0	0	
152	0	0	
153	0	0	
154	10	100	
155	0	0	
156	0	0	
157	0	0	
158	0	0	
159	0	0	
160	0	0	
161	0	0	
162 S1	10	10	
S2	10	10	
S3	10	10	
163 S1	100	100	
S2	100	100	
S3	100	100	
164 S1	14	14	
S2	0	0	
S3	0	0	
165	0	0	
166 S1	10	10	
S2	10	10	
S3	10	10	
167 S1	200	200	
S2	200	200	
S3	200	200	
168 S1	0	0	
S2	0	0	
S3	0	0	
169 S1	0	0	
S2	0	0	
\$3	0	0	
170	20	20	
171	0	0	
170	0	0	
178	0	0	
179	0	0	
182	0	0	
189	0	0	
190	0	0	
191 X	0	0	
Z	0	0	
192	0	0	
193	0	0	
194	0	0	

State	Standard parameter 1	Standard parameter 3	User parameter
parameter	( servo 1u-level )	( servo 0.1u-level )	( backup )
197		0	( 2001/04 /
198	0	0	
199	0	0	
200	0	0	
204	0	0	
205	0	0	
206	0	0	
207	0	0	
208	0	0	
209	0	0	
210	0	0	
211	0	0	
212	0	0	
213	0	0	
214	0	0	
215	0	0	
216	0	0	
217	0	0	
218	0	0	
219 X	1	1	
Z	2	2	
220 S1	1	1	
S2	2	2	
S3	0	0	
221 S1	5	5	
S2	4	4	
S3	3	3	
222	0	0	
223	0	0	
224	2	2	
225 X	88	88	
Z	90	90	
226 X	0	0	
Z	0	0	
227	0	0	
228	0	0	
229	0	0	
230 X	1	1	
Z	3	3	
231	0	0	
232	0	0	
233	0	0	
234	0	0	
235	0	0	
236	4	4	
237	0	0	
238	0	<u> </u>	
239	U	U	



State	Standard parameter 1	Standard parameter 3	User parameter
parameter	( servo 1u-level )	( servo 0.1u-level )	( backup )
240	10	10	
241	1	1	
242	0	0	
243	1	1	
244	0	0	
245	1	1	
246	0	0	
247	0	0	
248	0	0	
249 X	1000	10000	
Z	1000	10000	
251	0	0	
252	0	0	
253	0	0	
254	0	0	

Note: The parameters of its number with "\*" influence the acceleration/deceleration characteristics and the user can properly adjust them according to the system allocation and load characteristics.

## APPENDIX VI ALARM LIST

### 1.CNC alarm

No.	Content	Remark
000	Emergent stop alarm and ESP open circuit	
001	Called programs do not exist or cannot be opened	
003	Characters are less than 2 or more than 11 for one word	
004	Address error (address is A~Z)	
005	Illegal command value	
006	Block numbers are negative or with decimals	
007	Illegal G commands	
008	Execute G96 when the spindle analog voltage control is invalid	
000	Command movement distance when G commands in group 00 and 01 are	
009	not input and there are invalid commands in group 01	
010	There are the same addresses in one block	
011	There are more than 40 words in one block	
012	Command values exceed their valid range or command addresses which	
012	cannot be omitted is omitted	
012	Input S commands except for S00~S99 when the spindle analog voltage	
013	control is invalid	
014	G commands in group 00, 01 and 12 cannot be in the same one block	
015	Execute M commands for spindle automatic gear shifting when the spindle	
015	analog voltage control is invalid	
016	Tool offset numbers exceed their valid range(0~32)	
017	Tool number exceeds the range of No.084 parameter	
018	The data specified by the interpolation command cannot form a correct	
010	curve	
010	The tool group number exceeds the range (1~32) in the tool life	
019	management	
020	Cannot execute T command in C tool nose radius compensation, cancel it	
0021	G71~G78,G90,G92,G94 can only be used in G18 plane	
0022	Forbid to use plane exchange code G17~G19 here	
0023	The programming radius of G05 code is out of allowable range	
024	There is no G11 or G13.1 in the program	
025	There is no tool in the current tool group in the tool life management	
026	The current tool group has not been defined in the tool life management	
027	The tool quantity exceeds 8 in the current tool group in tool life management	
028	The tool life management function is invalid and G10 L3 cannot be used	
000	G17~G19 codes Cann't be executed in C tool compensation or cylindrical	
030	interpolation	
032	Absolute value of R is more than that of U/2 in G90, G92, G92.1	
033	Absolute value of R is more than that of W in G94	
040	There are more than 100 blocks in G70~G73	
041	Ns and Nf are reversed each other in G70~G73	
042	There is no Ns or Nf or they exceed their allowed range in G70~G73	

## **CNCmakers**

No.	Content	Remark
043	There is no Ns or Nf in G70~G73	
044	Call subprograms in G70~G73	
045	Ns does not command G00 or G01 in G70~G73	
046	Initial blocks are employed with the forbidden G commands in G70~G73	
047	Unusable G code is in the block specified by Q in G70,G71,G72,G73	
050	G71~G72 command can't satisfy the condition of single increase or	
030	decrease	
051	Single infeed exceeds its allowed range in G71 or G72	
052	Single tool retraction exceeds its allowed range in G71 or G72	
053	The cycle starting point is in the closed area formed by the starting point and	
000	end point of the finishing path in G71 or G72	
054	Flute quantity is more than 10 in G71 or G72	
055	X/Z value is not specified in the first block or the movement is 0 in G71	
056	X/Z value is not specified in the first block or the movement is 0 in G72	
057	Cycle times is less than 1 or more than 99999 in G73	
060	Single tool retraction R(e) exceeds its allowed range in G74 or G75	
061	The tool retraction is negative at the end of cutting in G74 or G75	
0062	Z value is 0 or not input in G74	
0063	Q is in default or out of range in G74	
0064	X single cutting value(P) exceeds its allowed range in G74	
0065	X value is 0 or not input in G75	
0066	P is in default or out of range in G75	
0067	Z single cutting value(Q) exceeds its allowed range in G75	
0060	Starting point coordinates are abnormal when cycle ends and returns to	
0003	starting point	
0070	The tool starts from the midway in taper screw thread cutting in G76/G78	
0071	Min. cutting value exceeds its allowed range in G76 or G78	
0072	Finishing allowance exceeds its allowed range in G76 or G78	
0073	Tooth height is less than finishing allowance or 0 in G76 or G78	
0074	Cycle times exceeds its allowed range in G76 or G78	
0075	X/Z movement distance in G76 is zero	
0076	There is no specified tooth height P in G76 or G78	
0077	There is no the first cutting depth Q or Q is 0 or Q is not input in G76 or G78	
0078	Tool nose angle is more than or equal to thread angle in G76 or G78	
0079	Cutting value of G78 is out of range(0,1)	
0080	Cutting mode of G78 is out of range(0,1,2,3)	
0082	Have no the measured position arrival signal in parameter specifying area in	
0002	automatic tool offset(G36,G37)	
0000	Specifying an invalid axis or a command is incremental in automatic tool	
0000	offset (G36,G37). Modify the program	
0084	Have the measured position arrival signal in area set by the parameter in	
0004	automatic tool offset(G36,G37)	
	The distance between the starting point and the target is less than the	
0085	setting (142,143) in automatic tool offset(G36,G37), have no set the rapid	
	motion area	

No.	Content	Remark
0086	The parameter (142,144) or (143,145) area setting are wrong in automatic	
0000	tool offset(G36,G37)	
0087	Firstly create or set the coordinate system before executing G36,G37	
0088	Firstly set the correct tool number and the compensation number before	
0000	executingG36,G37	
0089	The tool offset is in protection state, and cannot be written	
0090	When tool offset measure executes the direction input B operation, axis	
	Can't find the thread repair position. An soft key [THD.REPAIR RECORD	
0092	POS] displayed on the ABSOLUTE screen. In JOG, HND or STEP mode,	
	press the key record the thread repair position.	
0000	The thread repair position beyond the thread repair program, please check	
0093	the program and the thread repair position	
0095	Subprogram numbers are not input or are illegal when M98 calls them	
0096	Layers of nested subprograms are more than 4	
0097	Calling programs in M98 is the current one(main program)	
0099	Use M98 or M99 in C tool radius compensation	
0103	Denominator is 0 for division operation in G65	
0104	G65 commands illegal H command	
0105	Macro variable number of G65 is illegal(error)	
0109	P command value isn't variable in G65	
0111	H99 user alarm number in G65 exceeds its range	
0112	Block number of macro command (G65)skip or M99 program return	
0110	exceeds their range	
0113	I here is no block number for block skip or Migg program return	
0114	G65, G66 command format are mistaken	
0115	G codo format of calling macro program is orr	
0110	Number of argument L. L.K. cannot exceed 10	
0110	P value of G30 code is out of range $(2 \sim 4)$	
0120	$G_{22}$ $G_{23}$ command code can not be executed with other GMST command	
0122	simultaneously	
	Stored travel check function has been closed.Can't use G22,G23 command	
0123	code.\nmodify parameter No.172 please.	
0129	Programmed axis name is invalid	
0130	axis address is not normative	
0121	G31/G32/G32.1/G33/G34/G36/G37/G84/G88/auxiliary axis code can't be	
0131	used in C offset type	
0133	Specified axis is a linearity of cylinder or rotary axis	
0134	Cannot specify the cylinder radius again	
0135	The linear or rotary axis setting used to the cylinder interpolation is mistaken	
0136	Only currently use the tool nose direction T0 or T9 to create C tool	
	compensation	
0140	The macro format is specified in error	
0141	DO,END tabs are not 1,2,3 in macro statement	
0142	DO,END formats are specified in error	

# **CNCmakers**

No.	Content Rema					
0143	The brackets are not matched in macro statement or the format is specified					
	in error					
0144	The divisor in macro statement cannot be 0					
0145	The specified anti-tangent ATAN format is mistaken in macro statement					
0146	The anti logarithm of LN in macro statement is 0 or less than 0					
0147	The square root in macro statement cannot be negative					
0148	The tangent TAN result in macro statement is endless					
0149	The operands of anti sine or anti cosine in macro statement exceed the					
	range between -1 and 1					
0150	The macro variable number or the variable value is illegal(error) in macro					
	statement					
0151	The local variable is empty					
0152	The variable #0 is always empty and cannot be operated					
0153	The operand in macro statement is not binary					
0154	P value don't want to be defined while calling macro program of using G					
	code					
0155	Format of program note is mistaken (mismatching)					
0156	G20,G21 command code can not be executed with other command					
	simultaneously					
0157	Metric/Inch system has been changed, and will be effective after restart					
0174	Some parameters cann't be modified for current operation level					
0175	W value or macro variety value of W is out of range while writing parameters					
0176	W value or macro variety value of W is not a valid binary value while writing					
	parameters					
0177	Not specify writing or reading operand under the state of writing or reading					
	parameters					
0178	Not specify a parameter or the parameter don't exist under the state of					
	writing or reading parameters					
0179	Not specify axis NO. when writing or reading axis parameters					
0180	R only specify macro variety under the state of writing or reading parameters					
0181	The axis NO. of setting is out of range while writing or reading parameters					
0182	Specify simultaneously a operand of writing and reading in one program					
	segment under the state of writing or reading parameters					
0183	Operand cann't be a decimal fraction under the state of writing or reading					
	parameter					
0184	Specify two or above parameters in one program segment under the state of					
	writing or reading parameters					
0185	Parameter NO. cann't be a decimal fraction under the state of writing or					
0400	reading parameters					
0190	Not specify screw pitch or out of range in machinning screw or tap					
0191	Head quantity of multi-thread is out of range					
0192	Initial angle of screw (Q value) is out of range					
0193	Nonzero move value of X axis has been commanded in G33					
0194	Y axis can't interpolate with $X/Z$ axis in G33					
0195	R value of G34 is out of range					

No.	Content					
0200	Circle radius is zero or undefined					
0201	The distance of circle start and end point is too small					
0202	Circle start point and center of the circle are the same as one point					
0203	The error of circle radius is out of range of the parameter NO.154					
0204	Not specify middle point in three point circle instruction					
0205	Three points are a line in three point circle instruction					
0206	Helical interpolation is invalid if defined plane hasn't movement					
0208	Long radius or short radius of ellipse is zero or undefined					
0209	P value of parabola is zero or undefined					
0227	Spindle positioning axis isn't allowed to execute the function					
0228	Spindle positioning axis and some code cann't be in the same block					
0229	Unusable code or command in synchro control					
0232	Specify the axis movement command in M29 or G84/G88					
0233	Rigid tapping signal (G61.0) in rigid tapping mode is abnormal					
0234	Specify M29 repetitively or not input M29 before rigid tapping					
0235	The spindle must be oriented, M29 cannot be with G84/G88 in the same					
0200	block when rigid tapping					
0236	Set the axis used to the spindle control to the rotary axis before the rigid					
0200	tapping/rigid thread machining					
0237	Have used unnecessary commands in rigid tapping or rigid screw					
0238	Have not selected the spindle used to the rigid tapping for the multi-spindle					
	function device when rigid tapping					
0239	Cannot switch the spindle used to the tapping when rigid tapping					
0251	Mistake in programming causes an error of C tool nose radius					
	compensation					
0252	Mistake in programming causes an end point of arc machining is not on the					
	arc in the course of C tool nose radius compensation					
0253	Mistake in programming causes there are the same coordinates for two					
	neighboring points not to execute C tool nose radius compensation					
0054	Mistake in programming causes there are the same coordinates between					
0254	center point and starting point of arc not to execute C tool nose radius					
	Compensation					
0255	mistake in programming causes there are the same coordinates between					
0255	center point and end point of arc not to execute C tool nose radius					
	Are redius is less than that of tool pass to source not to execute C tool pass					
0256	radius componention					
	Mistake in programming causes there is not intersection of two area of					
0257	current tool radius in the course of C tool nose radius compensation					
0258	Current tool radius in the course of C tool nose radius compensation					
0250	Specify one arc command as executing C tool nose radius compensation					
0260	Specify one arc command as canceling C tool nose radius compensation					
0200	Mistake in programming causes there is not intersection between straight					
0261	line and arc of current tool radius in the course of C tool nose radius					
5201	compensation					
0261	compensation					

No.	Content			
	Mistake in programming causes there is not intersection between arc and			
0262	straight line of current tool radius in the course of C tool nose radius			
	compensation			
0263	There are too non movement commands in C too radius compensation, the			
0205	buffer overflows			
0270	The circle centre angle of circular screw interpolation is not in the range of			
0270	45°~135°or 135°~225°or 225°~315°or -45°~45.modify the program please			
0276	The end point and angle value using direct input of drawing dimensions are			
0270	not applicable or normal			
0277	The instruction isn't allowed in direct input of drawing dimensions or			
0211	non-motion blocks are too much			
0278	The middle block using direct input of drawing dimensions cann't be the last			
0270	block of a loop			
0279	Angle is not normal or the end point cann't be calculated in direct input of			
0213	drawing dimensions			
0281	The linear chamfer length is too length			
0282	The arc chamfer radius is too big			
0283	The linear chamfer length is too big or the arc data is mistaken			
0284	The arc chamfer radius is too big or the arc data is mistaken			
0285	The linear chamfer length is too big or the arc data is mistaken			
0286	The arc chamfer radius is too big or the arc data is mistaken			
0287	The linear chamfer length is too big or the intersection is not on the arc			
0288	The arc chamfer radius is too big or the intersection is not on the arc			
0289	The chamfer cannot be executed in end position			
0200	Cannot start the polar coordinate and the cylinder interpolation in C tool			
0230	compensation state or G99			
0201	The linear axis or rotary axis of the polar coordinates does not correspond to			
0231	No.189 or the linear axis attribution setting is mistaken			
0202	Execute the length compensation of all axes before starting the polar			
0232	coordinates			
0293	X cannot be negative or 0 in G16/G15			
0294	Have used the command which cannot be used to the polar coordinates and			
0204	the cylinder interpolation			
0295	C tool compensation is not cancelled in the polar coordinates and the			
0200	cylinder interpolation			
0296	Finish machining counts of cylindrical interpolation loop are over 9999			
0297	Cann't cut the workpiece in cylindrical interpolation loop because X			
0201	orientation and cutting direction are not same			
6000	CNC emergent stop is failure(restart the CNC)			
6001	No program zero is defined			
6003	Feed speed is too high			
6004	Spindle stopped accidentally, please stop feeding and check the spindle			
6005	Not define the highest speed of some gear, please check the parameter			
	No.37~No.40			
6010	10 Spindle doesn't rotate, or speed is too slow in thread cutting			

No.	Content	Remark			
6011	feed speed exceeds limit speed in cutting(Parameter No.027)				
6012	Spindle speed fluctuation has exceeded the alarm valve in thread cutting				
6013	The screw pitch occurs 0				
6014	Spindle encoder pulse is out of 100~10000				
6020	reference point hadn't found, Don't go back 2nd or 3rd or 4th reference point				
6050	PLCAxis is working,Don't change Ctrlmode				
6051	CNCAxis is working, Don't change Ctrlmode				
6052	PLCAxis is working,CNC can't Ctrl this axis				
6053	The movement distance of PLC axis is out of range				
6054	In Ref mode A, the move is fail				
6300	Stored stroke limit 1 has been exceeded				
6301	Stored stroke limit 2 has been exceeded				
6302	Stored stroke limit 3 has been exceeded				
6304	Reference point is in the limit area of stored stroke limit 1, Please modify parameter No.045, No.046				
6305	Reference point is in the limit area of stored stroke limit 2.Please modify parameter No.100, No.101				
	Reference point is in the limit area of stored stroke limit 3.Please modify				
6306	parameter No.102. No.103				
6311	overtravel in setting positive location of axis X				
6312	overtravel in setting positive location of axis Z				
6313	overtravel in setting positive location of axis Y				
6314	overtravel in setting positive location of axis 4th				
6315	overtravel in setting positive location of axis 5th				
6316	overtravel in setting positive location of axis 6th				
6321	overtravel in setting negative location of axis X				
6322	overtravel in setting negative location of axis Z				
6323	overtravel in setting negative location of axis Y				
6324	overtravel in setting negative location of axis 4th				
6325	overtravel in setting negative location of axis 5th				
6326	overtravel in setting negative location of axis 6th				
6331	The X axis positive location of stored stroke limit 2 has been exceeded				
6332	The Z axis positive location of stored stroke limit 2 has been exceeded				
6333	The Y axis positive location of stored stroke limit 2 has been exceeded				
6334	The 4th axis positive location of stored stroke limit 2 has been exceeded				
6335	The 5th axis positive location of stored stroke limit 2 has been exceeded				
6336	The 6th axis positive location of stored stroke limit 2 has been exceeded				
6341	The X axis negative location of stored stroke limit 2 has been exceeded				
6342	The Z axis negative location of stored stroke limit 2 has been exceeded				
6343	The Yaxis negative location of stored stroke limit 2 has been exceeded				
6344	The 4th axis negative location of stored stroke limit 2 has been exceeded				
6345	The 5th axis negative location of stored stroke limit 2 has been exceeded				
6346	The 6th axis negative location of stored stroke limit 2 has been exceeded				
6351	The X axis positive location of stored stroke limit 3 has been exceeded				
6352	The Z axis positive location of stored stroke limit 3 has been exceeded				

No.	Content	Remark		
6353	The Y axis positive location of stored stroke limit 3 has been exceeded			
6354	The 4th axis positive location of stored stroke limit 3 has been exceeded			
6355	The 5th axis positive location of stored stroke limit 3 has been exceeded			
6356	The 6th axis positive location of stored stroke limit 3 has been exceeded			
6361	The X axis negative location of stored stroke limit 3 has been exceeded			
6362	The Z axis negative location of stored stroke limit 3 has been exceeded			
6363	The Y axis negative location of stored stroke limit 3 has been exceeded			
6364	The 4th axis negative location of stored stroke limit 3 has been exceeded			
6365	The 5th axis negative location of stored stroke limit 3 has been exceeded			
6366	The 6th axis negative location of stored stroke limit 3 has been exceeded			
6411	axis X+ overtravel			
6412	axis Z+ overtravel			
6413	axis Y+ overtravel			
6414	axis 4th+ overtravel			
6415	axis 5th+ overtravel			
6416	axis 6th+ overtravel			
6421	axis X- overtravel			
6422	axis Z- overtravel			
6423	axis Y- overtravel			
6424	axis 4th- overtravel			
6425	axis 5th- overtravel			
6426	axis 6th- overtravel			
6431	The axis X driver is not prepared			
6432	The axis Z driver is not prepared			
6433	The axis Y driver is not prepared			
6434	The axis 4th driver is not prepared			
6435	The axis 5th driver is not prepared			
6436	The axis 6th driver is not prepared			
6441	Spindle servo 1 is not ready			
6442	Spindle servo 2 is not ready			
6443	Spindle servo 3 is not ready			
6500	Slave device number conflict in GSKLINK communication			
6600	The bus connection is OFF			
6601	Enumberation overtime			
6602	The bus connection creating communication fails			
6603	The bus connection delaying causes the test device to fail			
6604	The bus communication's parameterr allocation fails			
6605	The bus communication allocation overtime			
6606	The bus main station's communication returns to CP0 stage			
6607	The slave station number set by the system is inconsistent with the actual			
6600	The slave device's axis name (logic address) is not matched with the			
8099	system's valid axis			
6610	MDT data loss			
6611	MST data loss			
6612	MDT data check error			

No.	Content					
6613	GDT data check error					
6620	IDN16, 24 allocation fails					
6621	IDN32,35 allocation fails					
6622	IDN5030,5031,5033 allocation fails					
6630	I/O unit allocation fails					
6702	Setup machine zero point again please. Because the parameter file of zero point failed to save as using absolute encoder motor					
6703	Setup machine zero point again please. Because the parameter file of zero point failed to read as using absolute encoder motor.					
6711	The error of actual position and memory position oversteps the range permitted as axis X equipped absolute encoder. Return machine zero point manually and set zero point again.					
6712	The error of actual position and memory position oversteps the range permitted as axis Z equipped absolute encoder. Return machine zero point manually and set zero point again					
6713	The error of actual position and memory position oversteps the range permitted as axis Y equipped absolute encoder. Return machine zero point manually and set zero point again					
6714	The error of actual position and memory position oversteps the range permitted as axis 4TH equipped absolute encoder. Return machine zero point manually and set zero point again.					
6715	The error of actual position and memory position oversteps the range permitted as axis 5TH equipped absolute encoder. Return machine zero point manually and set zero point again.					
6716	The error of actual position and memory position oversteps the range permitted as axis 6TH equipped absolute encoder. Return machine zero point manually and set zero point again.					
6721	Initialization of machine coordinates makes a mistake while starting as axis X equipped absolute encoder. Reset machine zero point again.					
6722	Initialization of machine coordinates makes a mistake while starting as axis Z equipped absolute encoder. Reset machine zero point again.					
6723	Initialization of machine coordinates makes a mistake while starting as axis Y equipped absolute encoder. Reset machine zero point again.					
6724	Initialization of machine coordinates makes a mistake while starting as axis 4TH equipped absolute encoder. Reset machine zero point again					
6725	5 Initialization of machine coordinates makes a mistake while starting as axis 5 5TH equipped absolute encoder. Reset machine zero point again.					
6726	Initialization of machine coordinates makes a mistake while starting as axis 6TH equipped absolute encoder. Reset machine zero point again.					
6741	When X axis is allocated with an absolute encoder without a reference point, a reference point is set after the machine is debugged normally					
6742	When Z axis is allocated with an absolute encoder without a reference point, a reference point is set after the machine is debugged normally					
6743	When Y axis is allocated with an absolute encoder without a reference point, a reference point is set after the machine is debugged normally					

No.	Content	Remark
6744	When 4th axis is allocated with an absolute encoder without a reference	
	point, a reference point is set after the machine is debugged normally	
6745	When 5th axis is allocated with an absolute encoder without a reference	
	point, a reference point is set after the machine is debugged normally	
6746	When 6th axis is allocated with an absolute encoder without a reference	
	point, a reference point is set after the machine is debugged normally	
	Gear ratio of CNC or servo ,the direction of axis moving and the machine	
6751	zero points are not as different as data established successfully while axis X	
	equipped absolute encoder. Check up parameters and renew to set	
	machine zero points	
	Gear ratio of CNC or servo , the direction of axis moving and the machine	
6752	zero points are not as different as data established successfully while axis $Z$	
	equipped absolute encoder. Check up parameters and renew to set	
	machine zero points.	
	Gear ratio of CNC or servo, the direction of axis moving and the machine	
6753	zero points are not as different as data established successfully while axis y	
	equipped absolute encoder. Check up parameters and renew to set	
	machine zero points.	
	Geal faile of CIVC of serve, the direction of axis moving and the machine	
6754	ATH equipped absolute encoder. Check up parameters and renew to set	
	machine zero points	
	Gear ratio of CNC or servo, the direction of axis moving and the machine	
	zero points are not as different as data established successfully while axis	
6755	5TH equipped absolute encoder. Check up parameters and renew to set	
	machine zero points.	
	Gear ratio of CNC or servo ,the direction of axis moving and the machine	
0750	zero points are not as different as data established successfully while axis	
6756	6TH equipped absolute encoder. Check up parameters and renew to set	
	machine zero points.	
6761	The batteries of absolute encoder are too low as axis X equipped absolute	
0/01	encoder. Renew batteries and set machine zero point again.	
6762	The batteries of absolute encoder are too low as axis Z equipped absolute	
0702	encoder. Renew batteries and set machine zero point again.	
6763	The batteries of absolute encoder are too low as axis Y equipped absolute	
0,00	encoder. Renew batteries and set machine zero point again.	
6764	The batteries of absolute encoder are too low as axis 4th equipped absolute	
	encoder. Renew batteries and set machine zero point again.	
6765	The batteries of absolute encoder are too low as axis 5th equipped absolute	
	encoder. Renew batteries and set machine zero point again.	
6766	I ne batteries of absolute encoder are too low as axis 6th equipped absolute	
	encoder. Renew batteries and set machine zero point again.	
6771	Machine zero point Can't be returned because no zero point position is	
	established as axis x of equipping absolute encoder	
6772	iviachine zero point Can't be returned because no zero point position is	
	established as axis $\angle$ of equipping absolute encoder	

No.	Content	Remark
6773	Machine zero point Can't be returned because no zero point position is	
	established as axis Y of equipping absolute encoder	
6774	Machine zero point Can't be returned because no zero point position is	
	established as axis 4TH of equipping absolute encoder	
6775	Machine zero point Can't be returned because no zero point position is	
0110	established as axis 5TH of equipping absolute encoder	
6776	Machine zero point Can't be returned because no zero point position is	
0110	established as axis 6TH of equipping absolute encoder	
6781	The position of movining is being out of range as axis X of equipping	
	absolute encoder	
6782	The position of movining is being out of range as axis Z of equipping	
	absolute encoder	
6783	The position of movining is being out of range as axis Y of equipping	
	absolute encoder	
6784	The position of movining is being out of range as axis 41H of equipping	
	absolute encoder	
6785	The position of movining is being out of range as axis 51H of equipping	
	absolute encoder	
6786	the position of movining is being out of range as axis 61H of equipping	
	The name of axis isn't in the usable range or exists same name with	
7001	others set parameter #225	
	increment system of additional axis(Y4th 5th) should not less than current	
7002	increment system(IS-B.IS-C) setting again	
7003	basic axis X/Y/Z can only set one set parameter #230	
7008	parameters of electric-gear set wrong	
	data errors ! restart and return reference please! adjust tool offsets, check all	
7009	parameters.	
	can't set two or more CS axes effectively if muilt-spindles function are not	
7010	effect or if no using second CS axis	
	Can't use CS spindle because the spindle don't bind a valid feed axis.\n	
7011	Please check the parameter No.221	
7012	Set rotary axis function firstly before using CS axis or rigid tapping.	
7013	Can't use axis CS because it isn't a serial spindle.	
7014	Fail to switch CS mode	
7015	don't switch spindle working mode while using Cs axis	
7016	Set rotary axis function firstly before using CS axis or rigid tapping	
7017	Can't use axis CS because it isn't a serial spindle.	
7020	Spindle No. definition error or repeated\n please set parameter No.220	
7021	The feed axis which binds to spindle is set by error or repeated.\n Please	
1021	check the parameter No.221	
7022	The feed axis which binds to spindle is invalid or CS axis at first. Then the	
1022	function of servo motor spindle can be used.	

No.	Content	Remark				
7023	There isn't a feed axis which binds to spindle. Can't use spindle function of					
	servo motor. Please check parameter No.221					
7024	Spindle positioning axis can't move in manual					
7030	Synchronous control master axis and slave axis cannot return to reference					
	Synchronous axis no incorrect duplicated or axis is invalid \nModify					
7031	parameter No.197~No.199 please.					
	Function is invalid due to detecting signal add settting incorrect.\nmodify					
7035	parameter No.136~No.139 please					
	The coordinates switched is out of range when G54~G59 coordinates					
7037	system switchs.Return machine zero point and set tool offset again please.					
	Nvram data error(CurMachCoord,CurAbsCoord,CurRelCoord)\n Restart					
7100	machine and set zero point and set tool offset again please.					
	Nvram data error(MlkAbsCoord,MlkRelCoord,PoffMlkState)\n Restart					
7101	machine and return zero point and set tool offset again please.					
7400	Nvram data error(LocalCoordOFT)\n Restart machine and return zero point					
7102	and set tool offset again please.					
7400	Nvram data error(MoveDirlsPlus)\n Restart machine and return zero point					
7103	and set tool offset again please.					
7104	Nvram data error(OffsUnmoved)\n Restart machine and return zero point					
7104	and set tool offset again please.					
7105	Nvram data error(Last_Toffs)\n Restart machine and return zero point and					
7105	set tool offset again please.					
7106	Nvram data error(ToffsUnmoved)\n Restart machine and return zero point					
7100	and set tool offset again please.					
7107	Nvram data error(OffsRcd)\n Restart machine and return zero point and set					
1101	tool offset again please.					
7108	Nvram data error(OffsRcdts)\n Restart machine and return zero point and					
7100	set tool offset again please.					
7109	Nvram data error(LOffsDiff)\n Restart machine and return zero point and set					
1100	tool offset again please.					
7110	Nvram data error(CompPos)\n Restart machine and return zero point and					
	set tool offset again please.					
7111	Nvram data error(CurCoordSys)\n Restart machine and return zero point					
	and set tool offset again please.					
	Nvram data error(CNC_CurrentToolNo, CNC_CurrentTComp,					
7112	CurrentRoffsmode)\n Restart machine and return zero point and set tool					
	offset again please.					
7113	Nvram data error(IottLock)\n Restart machine and return zero point and set					
	tool offset again please.					
7114	INVram data error(PubliviacroBut_S)\n Restart machine and return zero point					
	and set tool offset again please.					
7115	INVITAIN data error(APCKerPos)\n Restart machine and set zero point and set					
	tool oliset again please.					
7116	INVIAIL data error(ReiCuriviachCoord)\n Restart machine and set zero point					
_	and set tool offset again please.					

No.	Content	Remark			
7117	Nvram data error(BLashSum)\n Restart machine and set zero point and set				
	tool offset again please.				
7118	Nvram data error(PitchSum)\n Restart machine and set zero point and set				
	tool offset again please.				
7100	Nvram data error(TSafetyPos)\n Restart machine and set safe position of				
1120	switching tool please.				
7801	Parameter switch has been opened				
7803	Fail to open or delete the part program				
7904	Set position number of screw compensation error.\nmodify parameter No.96				
7004	~ 98 please.				
7805	USB disk connectted again. please reload the program if the file has been				
7805	modified!				
7806	turn on power again when parameter is modified				
7807	Success to renew the working ladder which has been stopped.rerun it or				
1001	power on again please.				
7808	CNC is failed to communicate with keyboard				
7810	Fail to open PLC file				
7811	The software version of ladder_chart is not suited				
7812	The first grade program of ladder_chart is too long				
7815	The voltage is low or unsteady.				
7816	NVRAM data verifies error!				
7817	The time is too short to save NVRAM data for last time when lost power.				
7830	Machine diagnosis configuration file is modified, it is better to restart again.				
7900	Loaded system allocation file is mistaken. Confirm whether cnc.cfg. exists				
7901	Loaded system allocation file is mistaken. Confirm whether param.cfg.				
7902	exists 7002 Leaded parameter value file is misteken				
1302	Tool offset errorlRefresh tool offset please. Clear alarm for pressing keys				
7903	[CAN] [RESET] simultaneously				
7904	Loaded pitch compensation file is mistaken				
7905	Fail to load file COORD.CRD				
7906	Fail to start PLC ladder\nCheck ladder!				
7908	Fail to load toollife file!				
	Limited-time stop time is over and the system cannot run normally. Please				
7909	contact with salesmen				
	CNC level degrade to lowest beause the time of stopping has been				
7910	arrived, contact your supplier please.				
7044	CNC is going to stop work in several days.\nContact with supplier in				
7911	advance please.				
7040	The password of stopping operation is default.Suggest to change the				
7912	password please.				
7998	System software error! please contact with GSK CNC equipment co., ltd.!				
7999	There is an unknown alarm. Please contact with developers.				

#### 2.PLC alarm (standard PLC ladder definition)

Address	Alarm No.	Content
A0000.0	1000	Tool change time is too long
A0000.1	1001	Alarm for the tool is not in-position when tool change ends
A0000.2	1002	Alarm for the tool change is not completed
A0000.3	1003	Alarm for the system has not received the lock signal
10000 1	1004	The system repetitively checks the lock signal and the lock signal
A0000.4	1004	is invalid when tool change is done
A0000.5	1005	Tool change makes mistakes before the system is turned off
A0000.6	1006	Pre-indexing proximity switch does not reach
A0000.7	1007	Alarm for tool post overheat
A0001.0	1008	Tailstock function is invalid, and M10 and M11 cannot be executed
A0001.1	1009	The thread run-out cannot be executed when the spindle rotating
A0001.3	1011	Have not checked the tailstock forward and cannot start the spindle
A0001.4	1012	Tool change mode A and B can have up to 8 tools
A0001.5	1013	Tool use life ends
A0001.6	1014	Confirm tool number of tool post (8, 10, 12)
A0001.7	1015	Confirm tool number of tool post (6, 8, 10, 12)
A0002.0	1016	Alarm for protection door not closed
A0002.1	1017	Alarm for pressure low
A0002.3	1019	Can't release chuck when spindle rotating
A0002.4	1020	Alarm for disabled clamping in-position signal when spindle rotating
A0002.5	1021	Can't start spindle when disabled clamping in-position signal
A0002.6	1022	Can't start spindle when chuck is released
A0003.0	1024	Can't execute M12 or M13 with disabled chuck function
A0003.1	1025	Have not checked chuck clamping/releasing in-position signal
A0003.3	1027	Tool pot is not released or lock signal is not cancelled
A0003.4	1028	Has not found the target tool number
A0003.5	1029	Has not received tool pot stop and locking start signal
A0004.0	1032	Illegal M code
A0004.1	1033	The current spindle is not analog, and Jog function cannot be executed
A0004.2	1034	M03,M04 specification are mistaken
A0004.3	1035	M63,M64 specification are mistaken
A0004.4	1036	Spindle gear shift time is too long
A0004.5	1037	Spindle speed/position control switch time is too long
A0004.6	1038	The 2nd spindle speed/position control switch time is too long
A0004.7	1039	Spindle position control does not permit orientation
A0005.0	1040	Spindle orientation time is too long
A0005 1	10/1	Alarm for the abnormal spindle servo or frequency converter
A0003.1	1041	for abnormality
A0005.2	1042	Alarm for the abnormal 2nd spindle servo or frequency converter
A0005.3	1043	Forbid clamping the spindle when the spindle rotating or feeding
A0005.4	1044	Spindle is clamped not to rotate or feed
A0007.0	2000	Hydraulic motor is not started
A0007.1	2001	Safety door has been opened
A0007.3	2003	Alarm for the tool pot unclocked
A0007.5	2005	Regulation is invalid when feedrate override is fixed to 100%
A0007.6	2006	Override on the panel is disabled when external override is enabled
A0007.7	2007	Program does not run when external pause switch is OFF
A0008.0	2008	Axis does not move when manual override is 0
A0008.1	2009	Disabled feed enabling knob input, fail to operate the program
A0008.2	2010	Disabled spindle enabling knob input, fail to rotate the spindle
A0008 3	2011	Workpiece number has been reached to the setting numbers
10000.0	2011	Spindle is on the position control, which can not be rotated the animale
AUUU8.4	2012	

**Cmakers** Limite

Email: info@CNCmakers.com